

CCD-TR42/TR70/TR72/TR80/TR82/ TR400/TR430/TR550/TR750

RMT-708

SERVICE MANUAL



Photo : CCD-TR42

US Model
CCD-TR70/TR72/TR80/TR82/TR400

Canadian Model
CCD-TR42/TR70/TR80/TR82/TR400

E Model
CCD-TR430/TR550/TR750

Tourist Model
CCD-TR550/TR750

Handycam

A MECHANISM

We will inform you of the electrical adjustment of the color view finder in the future.

In this service manual, board names will be different for each model and indicated as follows.

	TR42/TR70/TR82/TR550	TR72/TR80/TR400/TR430/TR750
VC BOARD	VC-145 BOARD	VC-138 BOARD
VS BOARD	VS-112 BOARD	VS-104 BOARD
DD BOARD	DD-66 BOARD	DD-60 BOARD

**For MECHANISM ADJUSTMENTS, refer to the
"8 mm Video MECHANICAL ADJUSTMENT
MANUAL IV" (9-973-199-11).**

SPECIFICATIONS

System

Video recording system: Two rotary heads, Helical scanning, FM system

Audio recording system: Rotary heads, FM system

Video signal: NTSC color, EIA standards

Usable cassette: 8 mm video format cassette (standard 8 mm)

Tape speed: <SP mode> Approx. 19/32 inches (1.43 cm)/second, <LP mode> Approx. 5/16 inches (0.72 cm)/second (playback only)

Recording time: SP mode 2 hours (P6-120)

Playback time: <SP mode> 2 hours (P6-120), <LP mode> 4 hours (P6-120)

Fastforward/rewind time: Approx. 6 min. 30 sec. (P6-120)

Image device: CCD (Charge Coupled Device)

Viewfinder: See the table on the next page.

Lens: See the table on the next page.

Color temperature: Auto

Minimum illumination: See the table on the next page.

Illumination range: See the table on the next page.

Recommended illumination: More than 100 lx

Output connector

Video output: Phono jack, 1 Vp-p, 75 Ω, unbalanced, sync negative

Audio output: See the table on the next page.

RFU DC OUT: Special minijack, DC 5 V

Headphones/Earphone jack: See the table on the next page.

LANC jack: Stereo mini-minijack (ø 2.5 mm)

MIC jack: See the table on the next page.

General

Power requirements: On battery mounting surface 6.0 V (battery pack), 7.5 V (AC power adaptor)

Average power consumption: See the table on the next page.

Installation: Vertically, Horizontally

Operating temperature: 32°F to 104°F (0°C to 40°C)

Storage temperature: -4°F to +140°F (-20°C to +60°C)

Dimensions: See the table on the next page.

Mass: See the table on the next page.

Microphone: See the table on the next page.

— Continued on next page —

8 VIDEO CAMERA RECORDER
CCD-TR42/TR70/TR72/TR80/TR82/TR430/TR550

Hi 8 VIDEO CAMERA RECORDER
CCD-TR400/TR750

SONY®



CCD-TR42/TR70/TR72/TR80/TR82/ TR400/TR430/TR550/TR750

RMT-708

SERVICE MANUAL



Photo: CCD-TR42

US Model
CCD-TR42/TR70/TR72/TR80/TR82

Canadian Model
CCD-TR42/TR70/TR72/TR80/TR82

E Model
CCD-TR42/TR70/TR72/TR80/TR82

Tourist Model
CCD-TR42/TR70/TR82

Handycam

A 58000000

We will illustrate in the diagram elements of the video video information items.

In the service manual, each issue will be different for each model and information items.

	TR42/TR70/TR72/TR80	TR400/TR430/TR550/TR750
VO BOARD	VO-118 BOARD	VO-118 BOARD
VE BOARD	VE-111 BOARD	VE-118 BOARD
SB BOARD	SB-88 BOARD	SB-88 BOARD

For MECHANICAL ADJUSTMENTS, refer to the
"9. MECHANICAL ADJUSTMENT
MANUAL" (P. 11) (P. 11-11).

OPERATIONS

System

Video recording system: Two
track/track, Video recording,
Still system

Audio recording system: Stereo
track, 1/2 track

Video signal: 4:3/3:4 ratio, 60K,
4:3/3:4 ratio

Audio system: Stereo, stereo
track, stereo track/track

Engineered: off-camera system,
on-camera system, 1/2 track/track

CCD system: 1/2 track/track,
1/2 track/track, 1/2 track/track

Recording time: 1/2 track/track,
1/2 track/track

Playback: 1/2 track/track, 1/2 track/track,
1/2 track/track

Playback: 1/2 track/track, 1/2 track/track,
1/2 track/track

Playback: 1/2 track/track, 1/2 track/track,
1/2 track/track

Playback: 1/2 track/track, 1/2 track/track,
1/2 track/track

Viewfinder: by the video camera

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

Color: 1/2 track/track, 1/2 track/track

General

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Power: 1/2 track/track, 1/2 track/track

Continued on next page

8 VIDEO CAMERA RECORDER
CCD-TR42/TR70/TR72/TR80/TR82

Hi 8 VIDEO CAMERA RECORDER
CCD-TR42/TR70/TR82

SONY



Model	CCD-TR42	CCD-TR70	CCD-TR72	CCD-TR80	CCD-TR82	Notes
Viewfinder	B/W	Color	B/W	Color	B/W	Electronic viewfinder
Lens	12 x	10 x	12 x			Combined power zoom lens, Filter diameter 1 1/2 inches (37 mm), TTL autofocus system inner focus wide macro system
Focal distance f =	7/32 – 2 5/8 in (5.4 – 64.8 mm)	7/32 – 2 1/4 in (5.4 – 54 mm)	7/32 – 2 5/8 in (5.4 – 64.8 mm)			—
	—				9/32 – 3 1/8 in (6.5 – 78 mm)	at Steady Shot
	1 9/16 – 18 1/2 in (39 – 468 mm)	1 9/16 – 15 3/8 in (39 – 390 mm)	1 9/16 – 18 1/2 in (39 – 468 mm)		1 7/8 – 22 1/4 in (47 – 564 mm)	When converted into a 35-mm still camera
Minimum illuminations	2 lx				5 lx	F 1.8
Illumination range	2 – 100,000 lx				5 – 100,000 lx	—
Audio output	Monaural		2: stereo L and R		Monaural	Phono jack 7.5 dBs, (at output impedance 47 kΩ) impedance less than 2.2 kΩ
Headphones/ Earphone jack	Minijack		Stereo minijack		Minijack	—
MIC jack	Minijack		Stereo minijack		Minijack	–66 dBs low impedance with 2.5 to 3 V DC, output impedance 6.8 kΩ (ø 3.5 mm)
Average power consumption	4.9 W	5.2 W	5.0 W	5.3 W	5.4 W	Camera recording, including the viewfinder
Dimensions	4 1/2 x 4 3/8 x 8 1/4 inches (114 x 110 x 207 mm)		4 1/2 x 4 3/8 x 8 1/4 inches (114 x 110 x 208 mm)		4 1/2 x 4 3/8 x 8 1/4 inches (114 x 110 x 207 mm)	w/h/d
Mass	1 lb 15 oz (890 g)	1 lb 15 oz (880 g)	1 lb 15 oz (890 g)	1 lb 15 oz (880 g)	1 lb 15 oz (900 g)	Excluding the battery pack, lithium battery, cassette, and shoulder strap
Mass	2 lb 7 oz (1,110 g)				2 lb 8 oz (1,120 g)	Including the battery pack NP-55, lithium battery CR2025, cassette P6-120, and shoulder strap
Microphone	Monaural		Stereo		Monaural	Electret condenser microphone

— Continued on next page —

AC power adaptor

Power requirements: 110 – 240 V AC*, 50/60 Hz

Power consumption: See the table below.

Output voltage: See the table below.

Application: Sony battery packs NP-55, NP-55H, NP-60D, NP-66H, NP-77H, NP-80/80D

Operating temperature: 32°F to 104°F (0°C to 40°C)

Storage temperature: –4°F to +140°F (–20°C to +60°C)

Dimensions: Approx. 4 1/8 x 1 15/16 x 2 1/2 inches (103 x 49 x 63 mm) including projecting parts and controls

Mass: See the table below.

* Canadian Standard Association (CSA) certifies 120 V AC only.

Model	AC-V25	AC-V25A	AC-V25B	Notes
Power consumption	15 W	17 W	17 W	—
Output voltage	7.5 V, 1.2 A	7.5 V, 1.5 A	7.5 V, 1.5 A	DC OUT in operating mode
Mass	10 oz (290 g)	11 oz (320 g)	10 oz (290 g)	—

Design and specifications are subject to change without notice.

Note :



We will inform you of the specification of the CCD-TR400/TR430/TR550/TR750 in the future.

SAFETY CHECK-OUT


After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the B+ voltage to see it is at the values specified.
6. Flexible Circuit board Repairing
 - Keep the temperature of the soldering iron around 270°C during repairing.
 - Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
 - Be careful not to apply force on the conductor when soldering or unsoldering.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK  OR DOTTED LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE  SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

[illegible]

1000

Table 1

1000

1000

Abstract

1000

1000

100

Abstract

Table 1

Abstract

Table 1

100

1000

1. The first step is to identify the problem or question that needs to be answered. This involves understanding the context and the specific requirements of the task.

[illegible]

1000

Table 1

11. *Journal of the American Medical Association*, 283: 2623-2628, 2000.

Material	2017/2018	2018/2019	2019/2020	Notes
Source: <i>www.mca.gov</i>	2018	2019	2020	---
Company ratings	7.0 (A) & 7.0 (A)	7.0 (A) & 7.0 (A)	7.0 (A) & 7.0 (A)	7.0 (A) & expanding assets
Notes	7.0 (A) (2017 g)	7.0 (A) (2017 g)	7.0 (A) (2017 g)	---

1. *Journal of the American Medical Association*, 2000; 283: 2689-2695.
 2. *Journal of the American Medical Association*, 2000; 283: 2696-2703.

1000

1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 2679, 26

WATER CHOCOLATE

After mapping the original words problem, perform the following table above before submitting the bid to the customer.

- Check the area of your roof that is scheduled to be replaced to verify structural soundness. Check the entire roof surface for other splines and bridges.
- Check the installed shingles to ensure they adhere to the "blanket" to ensure high coverage values.
- Look for unscheduled replacement parts, particularly accessories, that were installed during a previous repair. After three (3) in the customer and document their replacement.
- Look for parts that, through shimming, show obvious signs of installation. After three (3) in the customer and document their replacement.
- Check for 84 ratings to see if it is a sh-value specified.
- Provide Critical Point Training:
 - Keep the temperature of the shimming less than 100°F during shimming.
 - Use the wet mode the shimming tool on the same members of the same board (within 3' area).
 - Reinstall shingles to apply force to the structure when shimming is complete.

WILEY-BLANKENHORN

COMPONENTS IDENTIFIED BY NAME A OR OTHER
LINE WITH NAME A ON THE IDENTIFICATION DIAGRAM
AND IN THE PARTS LIST ARE CRITICAL TO SAFE
OPERATION. REPLACE THESE COMPONENTS WITH
ONLY PARTS WHOSE PART NUMBER APPEAR AS
SHOWN IN THE MANUAL, OR IN SUPPLEMENTARY PART
NUMBER LIST.

© 2000 Blackwell Science Ltd *Journal of Internal Medicine* 247: 105–112

[illegible]





【Zoom lens】

This unit employs two types of lens.

Note that the lenses are interchangeable, however their components are not.

Differentiating the lens

 : difference point

TYPE I (LSV-140A)	TYPE II (VCL-5412WA)
From the front of the lens 	From the front of the lens 
From the right side of the lens (as seen from the front) 	From the right side of the lens (as seen from the front) 

[Zoom lens]

This unit employs two types of lens.

Note that the lenses are interchangeable, however their components are not.

Differentiating the lens

DIFF : difference point





TYPE 1 (JBL-0000)	TYPE 2 (JBL-0000)
<p>From the front of the lens</p> 	<p>From the front of the lens</p> 
<p>From the right side of the lens (as seen from the front)</p> 	<p>From the right side of the lens (as seen from the front)</p> 

TABLE OF CONTENTS

Section	Title	Page	Section	Title	Page
SERVICE NOTE			3. BLOCK DIAGRAMS		
Semiconductor for Correction List Display	8		3-1. Overall Block Diagram	3-1	
Parts Location Diagram Related to Power Supply	8		3-2. Camera Block Diagram	3-5	
Semiconductor Location	8		3-3. Video (1) Block Diagram	3-9	
Head Cleaning	8		3-4. Video (2) Block Diagram	3-14	
1. GENERAL			3-5. Servo Block Diagram	3-17	
Checking Your Model Number	1-1		3-6. System Control Block Diagram	3-20	
Checking Supplied Accessories	1-1		3-7. Audio (STEREO) Block Diagram (TR72/TR80/TR400/TR430/TR750)	3-23	
Charging and Installing the Battery Pack	1-2		3-8. Audio (MONO) Block Diagram (TR42/TR70/TR82/TR550)	3-25	
Inserting a Cassette	1-3		3-9. W/B EVF Block Diagram (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	3-27	
Adjusting the Viewfinder Lens	1-4		3-10. Color EVF Block Diagram (TR70/TR80)	3-28	
Camera Recording	1-4		3-11. Power Block Diagram	3-30	
Hints for Better Shooting	1-6		4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS		
Checking the Recorded Picture	1-6		4-1. Frame Schematic Diagram	4-1	
Connections for Playback	1-7		4-2. Printed Wiring Boards and Schematic Diagrams	4-4	
Playing Back a Tape	1-7		• FP-89 Board	4-5	
Using Alternate Power Sources	1-8		• FP-49 Board (TR82/TR400/TR550/TR750)	4-7	
Recording with the Date or Time	1-9		• VC (Camera, Lens Drive, Steady Shot Control) Board	4-9	
Shooting with Backlighting	1-9		• VC (Camera) Board	4-11	
Using the PROGRAM AE Function	1-10		• VC (Lens Drive) Board	4-17	
Fade-in and Fade-out	1-10		• VC (Steady Shot Control) Board (TR82/TR400/TR550/TR750)	4-19	
Releasing the Steady Shot Function	1-11		• VS (REC/PB Head Amplifier, Y/C Process, Hi8 I/O, Electric Volume, Servo/System Control, Signal I/O)	4-21	
Changing the Mode Settings	1-11		• VS (REC/PB Head Amplifier) Board	4-25	
Editing onto Another Tape	1-13		• VS (Y/C Process) Board	4-28	
Changing the Lithium Battery in the Camcorder	1-14		• VS (Hi8 I/O, Electric Volume) Board	4-31	
Resetting the Date and Time	1-14		• VS (Servo/System Control) Board	4-34	
Playback Modes	1-15		• VS (Signal I/O) Board	4-37	
Tips for Using the Battery Pack	1-15		• HE-14 Board	4-41	
Maintenance Information and Precautions	1-17		• ZB-2 Board	4-45	
Identifying the Parts	1-18		• SL-38 Board	4-47	
Warning Indicators	1-21		• AU-169 Board (TR42/TR70/TR82/TR550)	4-51	
2. DISASSEMBLY			• MA-199 Board (TR42/TR70/TR82/TR550)	4-55	
2-1. Removal of F Panel Block	2-1		• AU-165 Board (TR72/TR80/TR400/TR430/TR750) ..	4-59	
2-2. Removal of Cassette Lid Assembly	2-1		• MA-179 Board (TR72/TR80/TR400/TR430/TR750) ..	4-64	
2-3. Removal of Cabinet (L) Assembly	2-2		• VF-65 Board (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	4-67	
2-4. Removal of Cabinet (R) Assembly	2-2		• VF-66, VF-67, LB-35 Boards (TR70/TR80)	4-70	
2-5. Removal of EVF Assembly (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	2-3		• DD Board	4-77	
2-5. Removal of EVF Assembly (TR70/TR80)	2-3		4-3. Semiconductors	4-81	
2-6. Removal of Control Switch Block (CK)	2-4		5. REPAIR PARTS LIST		
2-7. Removal of DD-60 Board (TR72/TR80/TR400/TR430/TR750) Removal of DD-66 Board (TR42/TR70/TR82/TR550) ..	2-4		5-1. Exploded Views	5-1	
2-8. Removal of Terminal Board and AU-165 Board (TR72/TR80/TR400/TR430/TR750), AU-169 Board (TR42/TR70/TR82/TR550)	2-5		5-1-1. F Panel Block Assembly	5-1	
2-9. Removal of Zoom Lens Block and VC-138 Board (TR72/TR80/TR400/TR430/TR750), VC-145 Board (TR42/TR70/TR82/TR550)	2-5		5-1-2. Cabinet (L) Block Assembly	5-2	
2-10. Removal of VS-104 Board (TR72/TR80/TR400/TR430/TR750) Removal of VS-112 Board (TR42/TR70/TR82/TR550)	2-6		5-1-3. Cabinet (R) Block Assembly	5-3	
2-11. Removal of SL-38 Board	2-6		5-1-4. EVF Block Assembly	5-4	
2-12. Remove of Control Switch Block (FK)	2-6		5-1-5. Main Boards Assembly	5-5	
2-13. Internal Views	2-7		5-1-6. CCD Block Assembly	5-6	
2-14. Circuit Boards Location	2-8		5-1-7. Zoom Lens Assemblies (LSV-140A) (VCL-5412WA)	5-7	
			5-1-8. Cassette Compartment Assembly	5-8	
			5-1-9. LS Chassis Assembly	5-9	
			5-1-10. Mechanism Chassis Assembly (1)	5-10	
			5-1-11. Mechanism Chassis Assembly (2)	5-11	
			5-2. Electrical Parts List	5-12	
			HARDWARE LIST	5-41	

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
6.	INTERFACES • IC PIN		1-3.	Electronic Viewfinder System Adjustments (CCD-TR42/TR72/TR82/TR400/TR430/ TR550/TR750)	7-21
6-1.	Camera Control Micro Processor Pin Function (VC Board IC602: SC424608 MC68HC11MA8FU)	6-1	1-3-1.	Horizontal Slant Adjustment	7-21
6-2.	Steady Shot Control Micro Processor Pin Function (VC Board IC777: CXP87132-010R) (CCD-TR82/TR400/TR550/TR750)	6-2	1-3-2.	Centering Adjustment	7-21
6-3.	Camera Core Pin Function (VC Board IC609: CXD2150R) (TR42/TR70/TR72/TR80/TR82/TR430) (VC Board IC609: CXD2150AR) (TR400/TR550/TR750)	6-3	1-3-3.	Focus Adjustment	7-22
6-4.	Mechanism Control Micro Processor Pin Function (VS Board IC505: CXP87132-009R)	6-5	1-3-4.	Aberration Adjustment	7-23
6-5.	Mode Control Micro Processor Pin Functions (VS Board IC503: MB89098PFV-G-107-BND)	6-6	1-3-5.	Horizontal Amplitude Adjustment (VF-65 board)	7-23
6-6.	Interface	6-8	1-3-6.	Vertical Amplitude Adjustment (VF-65 board)	7-24
6-6-1.	System Control – Video/Audio Block Interface (VS Board)	6-8	1-3-7.	Brightness Adjustments (VF-65 board)	7-24
6-6-2.	System Control – Servo Block Interface	6-8	1-3-8.	Horizontal Amplitude, Vertical Amplitude, Focus Check	7-24
7.	ADJUSTMENTS		1-4.	Color Electronic Viewfinder System Adjustments (CCD-TR70/TR80)	7-24
7-1.	CAMERA SECTION ADJUSTMENTS	7-1	1.	Current Consumption Adjustment (VF-66 board)	7-25
1-1.	Preparations before Adjustment (Camera Section)	7-1	2.	Power Supply Voltage Check (VF-67 board)	7-25
1-1-1.	List of Service Tools	7-1	3.	EVR Initial Data Input	7-25
1-1-2.	Preparations	7-2	4.	VCO Adjustment (VF-67 board)	7-26
1-1-3.	Precautions	7-4	5.	Bright Adjustment (VF-67 board)	7-26
1.	Switch settings	7-4	6.	Contrast Adjustment (VF-67 board)	7-27
2.	Adjusting Procedure	7-4	7.	SUB BRIGHT R Preset Adjustment (1) (VF-67 board)	7-27
3.	Subject	7-4	8.	SUB BRIGHT B Preset Adjustment (2) (VF-67 board)	7-28
1-1-4.	Adjusting Remote Commander	7-5	9.	White Balance Adjustment	7-28
1.	Using the adjusting remote commander	7-5	1-5.	Arrangement Diagram for Adjustment Parts	7-30
2.	Precautions upon using the adjusting remote commander	7-5	7-2.	MECHANICAL SECTION ADJUSTMENTS	7-35
1-1-5.	Page F Address List	7-6	2-1.	Operating without a Cassette	7-35
1-1-6.	Data Processing	7-9	2-2.	Tape Path Adjustment	7-36
1-2.	Camera System Adjustment	7-10	7-3.	VIDEO SECTION ADJUSTMENTS	7-37
1.	Power Supply Voltage Check (DD board)	7-10	3-1.	Preparations Before Adjustment	7-37
2.	Page F Data Initialization	7-10	3-1-1.	Equipments to be Used	7-37
3.	Page F Data Modification 1	7-11	3-1-2.	Adjusting Precautions	7-37
4.	Page F Data Modification 2 (CCD-TR82/TR550)	7-12	3-1-3.	Connecting the Equipments	7-38
5.	Page E Data Write (CCD-TR42/TR70/TR72/TR80/TR430)	7-12	3-1-4.	How to Set the REC Mode in the Model with out REC switch	7-39
6.	28 MHz Original Oscillation Adjustment (VC board)	7-12	3-1-5.	Checking the Input Signals	7-40
7.	V SUB Adjustment	7-12	1.	CAMERA input	7-40
8.	VRG Adjustment	7-13	2.	VIDEO input	7-40
9.	Flange Back Adjustment	7-13	3-1-6.	Alignment Tape	7-41
10.	Flange Back Check	7-14	3-1-7.	Input/Output Level and Impedance	7-42
11.	HALL Adjustment	7-14	3-1-8.	Service Mode	7-43
12.	SYNC Level Check (VC board)	7-15	1.	Setting the service mode	7-43
13.	BURST Level Check (VC board)	7-15	2.	Page D write protect	7-45
14.	Picture Frame Setting	7-16	3.	Test mode setting	7-45
15.	Color Reproduction Adjustment	7-17	4.	Emergency code	7-45
16.	IRIS IN/OUT Adjustment (VC board)	7-18	5.	Emergency mode	7-46
17.	MAX GAIN Adjustment (VC board)	7-19	6.	Bit value discrimination	7-46
18.	Auto White Balance Standard Data Input	7-19	7.	Battery voltage check	7-47
19.	Auto White Balance Adjustment	7-20	8.	Mechanism controller input/output check	7-48
20.	White Balance Check	7-20	9.	Mode switch and CC DOWN switch check	7-49
21.	VIDEO OUT Level Check	7-21	10.	Tape top/end sensor check	7-50
			11.	Version of mechanical control microprocessor	7-50
			12.	Page D address list for standard 8 mm model (CCD-TR42/TR70/TR72/TR80/TR82/ TR430/TR550)	7-51
			13.	Page D address list for Hi8 model (CCD-TR400/TR750)	7-56
			3-2.	Power System Adjustments	7-61
			1.	Oscillator Frequency Check (DD board)	7-61
			2.	Power Voltage Check (DD board)	7-61

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
3-3.	System Control System Adjustments	7-61	3-7.	Monaural Audio System Adjustment (CCD-TR42/TR70/TR82/TR550)	7-87
1.	Page D Initial Value Input	7-61	1.	E-E Output Level Check (AU-169 board)	7-88
2.	Battery End Adjustment	7-62	2.	Deviation Adjustment	7-88
3.	Battery Down Check	7-63	3.	Overall Level Characteristic, Distortion Check	7-88
3-4.	Servo System Adjustments	7-63	4.	Overall Noise Level Check	7-88
1.	Switching Position Adjustment (VS board)	7-63	3-8.	Stereo Audio System Adjustment (CCD-TR72/TR80/TR400/TR430/TR750)	7-89
3-5.	Standard 8 mm Video System Adjustments (CCD-TR42/TR70/TR72/TR80/TR82/TR430/TR550)	7-64	1.	E-E Output Level Check (AU-165 board)	7-89
1.	Playback Frequency Characteristic Adjustment (VS board)	7-64	2.	Matrix L-R Adjustment (AU-165 board)	7-89
2.	Flying Erase Check (VS board)	7-65	3.	REC Matrix L+R Check (AU-165 board)	7-90
3.	VXO Oscillation Frequency Check (VS board)	7-65	4.	1.5 MHz Deviation Adjustment	7-90
4.	SYNC AGC Level Adjustment (VS board)	7-65	5.	1.7 MHz Deviation Adjustment	7-90
5.	Comb Filter Adjustment (VS board)	7-66	6.	Overall Level Characteristics, Distortion Check	7-91
6.	Emphasis Input Level Adjustment (VS board)	7-67	7.	Separation Check	7-91
7.	WHITE CLIP check (VS board)	7-67	8.	Overall Noise Level Check	7-91
8.	DARK CLIP check (VS board)	7-68	3-9.	Arrangement Diagram for Adjustment Parts	7-92
9.	DE EMPH Level Adjustment (VS board)	7-68			
10.	PB Y OUT Level Adjustment	7-69			
11.	Y FM Carrier Frequency Adjustment (VS board)	7-69			
12.	Y FM Deviation Adjustment (VS board)	7-70			
13.	Chroma Emphasis Adjustment 1 (VS board)	7-70			
14.	Chroma Emphasis Adjustment 2 (VS board)	7-71			
15.	Comb Filter Fine Adjustment (VS board)	7-71			
16.	REC Y Level Adjustment (VS board)	7-72			
17.	REC L Adjustment (VS board)	7-72			
18.	REC CHROMA Level Adjustment (VS board)	7-73			
19.	REC ATF Level Check (VS board)	7-74			
3-6.	Hi8 Video System Adjustments (CCD-TR400/TR750) ...	7-74			
1.	Playback Frequency Characteristic Adjustment (VS board)	7-75			
2.	Flying Erase Check (VS board)	7-76			
3.	VXO Oscillation Frequency Check (VS board)	7-76			
4.	SYNC AGC Level Adjustment (VS board)	7-76			
5.	Comb Filter Adjustment (VS board)	7-77			
6.	Emphasis Input Level Adjustment (VS board)	7-78			
7.	WHITE CLIP check (VS board)	7-78			
8.	DARK CLIP check (VS board)	7-79			
9.	DE EMPH Level Adjustment (VS board)	7-79			
10.	PB Y OUT Level Adjustment (VS board)	7-80			
11.	Normal Mode Y FM Carrier Frequency Adjustment (VS board)	7-80			
12.	Normal Mode Y FM Deviation Adjustment (VS board)	7-81			
13.	Hi8 Mode Y FM Carrier Frequency Adjustment (VS board)	7-81			
14.	Hi8 Mode Y FM Deviation Adjustment (VS board)	7-82			
15.	Chroma Emphasis Adjustment 1 (VS board)	7-82			
16.	Chroma Emphasis Adjustment 2 (VS board)	7-83			
17.	Comb Filter Fine Adjustment (VS board)	7-83			
18.	REC Y Level Adjustment (VS board)	7-84			
19.	REC L Adjustment (VS board)	7-85			
20.	REC CHROMA Level Adjustment (VS board)	7-86			
21.	REC ATF Level Check (VS board)	7-87			

There is the color reproduction standard frame at the back of the book.

Section	Title	Page
0-0	System Level System Adjustments	0-00
1	Page 0-0000 Table Input	0-00
2	Battery Grid Adjustment	0-00
3	Battery Screen Check	0-00
0-0-0	Base System Adjustments	0-00
1	Antenna Position Adjustment (VR board)	0-00
0-0-0	Standard 8 pin View System Adjustments	0-00
000-0000-0000-0000-0000-0000-0000-0000		0-00
1	Playback Frequency Characteristics Adjustment	0-00
2	Play Screen Check (VR board)	0-00
3	ISO Oscillator Frequency Check (VR board)	0-00
4	VIDEO AGC Level Adjustment (VR board)	0-00
5	Color Filter Adjustment (VR board)	0-00
6	Replay Input Level Adjustment (VR board)	0-00
7	WHITE CLIP Check (VR board)	0-00
8	DATA CLIP Check (VR board)	0-00
9	ISO GATE Level Adjustment (VR board)	0-00
10	ISO T-OUT Level Adjustment	0-00
11	1 VR Center Frequency Adjustment (VR board)	0-00
12	1 VR Oscillator Adjustment (VR board)	0-00
13	Screen Frequency Adjustment 1 (VR board)	0-00
14	Screen Frequency Adjustment 2 (VR board)	0-00
15	Color Filter Pin Adjustment (VR board)	0-00
16	NRG T Level Adjustment (VR board)	0-00
17	NRG L Adjustment (VR board)	0-00
18	NRG CHROMA Level Adjustment (VR board)	0-00
19	NRG A/B Level Check (VR board)	0-00
0-0-0	VR Video System Adjustments (000-0000-0000)	0-00
1	Playback Frequency Characteristics Adjustment	0-00
2	Play Screen Check (VR board)	0-00
3	VIDEO Oscillator Frequency Check (VR board)	0-00
4	VIDEO AGC Level Adjustment (VR board)	0-00
5	Color Filter Adjustment (VR board)	0-00
6	Replay Input Level Adjustment (VR board)	0-00
7	WHITE CLIP Check (VR board)	0-00
8	DATA CLIP Check (VR board)	0-00
9	ISO GATE Level Adjustment (VR board)	0-00
10	ISO T-OUT Level Adjustment (VR board)	0-00
11	Screen Mode 1 VR Center Frequency Adjustment	0-00
12	Screen Mode 1 VR Oscillator Adjustment	0-00
13	Screen Mode 1 VR Center Frequency Adjustment	0-00
14	Screen Mode 1 VR Oscillator Adjustment	0-00
15	Screen Frequency Adjustment 1 (VR board)	0-00
16	Screen Frequency Adjustment 2 (VR board)	0-00
17	Color Filter Pin Adjustment (VR board)	0-00
18	NRG T Level Adjustment (VR board)	0-00
19	NRG L Adjustment (VR board)	0-00
20	NRG CHROMA Level Adjustment (VR board)	0-00
21	NRG A/B Level Check (VR board)	0-00

Section	Title	Page
0-0	Standard Audio System Adjustment	0-00
000-0000-0000-0000-0000-0000		0-00
1	ISO Output Level Check (A/B VR board)	0-00
2	Oscillator Adjustment	0-00
3	Screen Level Characteristics (Speaker Check)	0-00
4	Screen Mode Level Check	0-00
0-0-0	Base Audio System Adjustment	0-00
000-0000-0000-0000-0000-0000		0-00
1	ISO Output Level Check (A/B VR board)	0-00
2	Screen L/R Adjustment (A/B VR board)	0-00
3	NRG Audio L/R Check (A/B VR board)	0-00
4	1st Filter Oscillator Adjustment	0-00
5	1st Filter Oscillator Adjustment	0-00
6	Screen Level Characteristics (Speaker Check)	0-00
7	Speaker Check	0-00
8	Screen Mode Level Check	0-00
0-0-0	Speaker Stage for Adjustment Pads	0-00

There is the same reproduction standard table at the back of the book.

SERVICE NOTE

[SEMICONDUCTOR FOR CORRECTION LIST DISPLAY]

Part code and part name of the semiconductor for correction of the print board is described in the space of each print figure. Use this list when ordering parts.


[PARTS LOCATION DIAGRAM RELATED TO POWER SUPPLY]

The parts location diagram for the power supply which are often checked and replaced when repairing the fuse and IC link and so on. (See page 4-24, 4-35, 4-36 and 4-78.)

This diagram is useful for repair.

[SEMICONDUCTOR LOCATION]

In this service manual, the mounted locations of the semiconductors (IC, transistor, diodes) are indicated in red in schematic diagrams. This enables to find the location on the board easily when servicing.



[HEAD CLEANING]

After an extended period of use the video image may become indistinct or may not appear at all during playback of a tape. The cause of this usually are dirty video heads. For remedy, cleaning of the heads is required.

Check for Head Clogs During Recording

- ① Use a blank tape, record a short section, then press the stop button to stop.
- ② Set to recording mode again.
- ③ If the [X] mark is flashing in the viewfinder at this time, head clogs are occurred.

Check During Playback of a Tape

- ① Play back a pre-recorded tape and display the image on a TV screen.
- ② If there is no sound and the image is unstable, no image appears on the screen, or tape transport is unstable, head clogs are occurred.

Remedy

[Cleaning method using a cleaning tape]

- Use the Cleaning Tape. (Please follow the instructions attached to the cleaning tape.)


SECTION 1 GENERAL

This section is extracted from CCD-TR42/TR70/TR72/TR80/TR82 instruction manual.

5

Checking Supplied Accessories

Check that the following accessories are supplied with your camcorder.



- 1 Wireless remote commander (1) (p.17, 48)
- 2 NP-55 Battery pack (1) (p.6, 33)
- 3 AC-V25/V25A/V25B AC power adaptor (1) (p.6, 19)
- 4 RFU-90UC/95UC RFU adaptor (1) (p.16)
- 5 Shoulder strap (1) (p.46)
- 6 CR2025 Lithium Battery (1) (p.30)
Already installed in the camcorder.
- 7 Size AA (R16) Battery for Remote Commander (2) (p.48)
- 8 A/V connecting cable (1) (p.16)
For CCD-TR72/TR80 only

Before You Begin Checking Your Model Number

The instructions in this manual are for five models listed below. Before you start reading and operating, check your model number by looking at the bottom of your camcorder. The CCD-TR42 is the model used for illustration purposes. Otherwise, the model name is indicated in the illustrations. Any differences in operation are clearly indicated in the text, for example, "CCD-TR82". As you read through this manual, buttons and settings on the camcorder are shown in capital letters, e.g. Set the POWER switch to CAMERA.

Types of Differences

Model Number	Audio		Viewfinder		Steady Shot	Zoom (X)
	Monaural	Stereo	B/W	Color		
CCD-TR42	○		○			12
CCD-TR70	○			○		10
CCD-TR72		○	○			12
CCD-TR80		○		○		12
CCD-TR82	○		○		○	12

Note on TV Color Systems

TV color systems differ from country to country. To view your recordings on a TV, you need an NTSC system based TV. When you want to use a PAL-M system based TV, you will need a NTSC/PAL-M transcoder (as this is an NTSC system based camcorder). Please check the list on page 39 to see the TV color system of your country.

Note on the Supplied RFU adaptor

You can use the supplied RFU adaptor only in the country where you bought this camcorder. Since each country has its own electricity and TV color system, you may not be able to use the RFU adaptor when you use the camcorder abroad.

Precaution on Copyright

Television programs, films, video tapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the provision of the copyright laws.

Precautions on Camcorder Care

- Do not let sand get into the camcorder. When you use the camcorder on a sandy beach or dusty place, protect it from the sand or dust. Sand or dust may cause the unit to malfunction and sometimes the malfunction cannot be repaired. [a]
- Do not let the camcorder get wet. Keep the camcorder from rain or sea water. It may cause a malfunction and sometimes the malfunction cannot be repaired. [b]
- Never leave the camcorder under temperatures above 140°F (60°C), such as in a car parked in the sun or under direct sunlight. [c]



4

SECTION 1 GENERAL

This section is extracted from **ISO 17025:2017**.
The copyright owner has authorized the reproduction of this section.



Abstract

100

1. The first step is to identify the key components of the system. This includes understanding the hardware, software, and data involved.

100

THE

[illegible]

100

1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 26

100

to any one of the other 100,000 people in the world. It is a unique, irreplaceable, and unrepeatable experience. It is a chance to see the world from a different perspective, to learn from the experiences of others, and to grow as a person. It is a chance to make a difference in the world, to help those in need, and to create a better future for all.



Abstract—The purpose of this study was to determine the effect of a 10-week training program on the heart rate (HR) and energy expenditure (EE) of sedentary, middle-aged women. The subjects were 15 women, 40 to 50 years of age, who were sedentary and had no cardiovascular or other medical problems. The subjects were randomly assigned to a 10-week training program or a control group. The training program consisted of three sessions per week of aerobic exercise at 60% of the maximum HR. The control group was instructed to maintain their current level of activity. The HR and EE were measured at rest and during a 30-minute period of moderate exercise at the end of the 10-week period. The results showed that the training program had a significant effect on the HR and EE of the subjects. The HR at rest decreased significantly from 72 to 68 beats per minute, and the EE at rest decreased significantly from 1,200 to 1,100 kcal per day. The HR and EE during exercise also decreased significantly. The results suggest that a 10-week training program can have a beneficial effect on the HR and EE of sedentary, middle-aged women.

100

1. 凡在本行開辦之各項業務，均應遵守本行所訂之各項規章，並應遵守國家及地方有關之法律法規。



Getting Started

Charging and Installing the Battery Pack


Before using your camcorder, you first need to charge and install the battery pack. To charge the battery pack, use the supplied AC-V25/V25A/V25B AC power adaptor.

Charging the Battery Pack

Charge the battery pack on a flat place without vibration.

(1) Connect the AC power adaptor to a wall outlet. (2) Align the right side of the battery pack with the line on the AC power adaptor, then slide the battery pack in the direction of the arrow. (3) Set the selector to CHARGE. The POWER lamp (green) and the CHARGE lamp (orange) light up. Charging begins.

When charging is completed, the CHARGE lamp goes out. Set the selector to the center position and unplug the unit from the wall outlet. Then remove the battery pack and install it on the camcorder. To stop charging, set the selector to the center position.



Charging Time

Battery pack	NP-55 (supplied)	NP-80 NP-80D	NP-77H	NP-66H	NP-60D	NP-55H
Charging time*	70	180	160	120	90	80

* Approximate minutes to charge an empty pack using the AC-V25/V25A/V25B (Lower temperatures require a longer charging time.)

Battery Life

CCD-TR42/TR72

Battery Pack	NP-55	NP-80/80D	NP-77H	NP-66H	NP-60D	NP-55H
Typical recording time**	35	95	85	65	45	40
Continuous recording time***	65	180	160	120	85	75

CCD-TR70/TR80

Battery pack	NP-55	NP-80/80D	NP-77H	NP-66H	NP-60D	NP-55H
Typical recording time**	30	90	80	60	40	35
Continuous recording time***	60	170	150	110	80	70

Charging and Installing the Battery Pack

CCD-TR82

Battery pack	NP-55	NP-80/80D	NP-77H	NP-66H	NP-60D	NP-55H
Typical recording time**	30	85	75	55	40	35
Continuous recording time***	55	165	145	105	75	65

** Approximate minutes when recording while you repeat recording start/stop, zooming and turning the power on/off. The actual battery life may be shorter.

*** Approximate continuous recording time indoors.

Important!


Use the battery completely before re-charging!

Before you recharge the battery, make sure the battery has been used up (discharged) completely. Repeated charging while some capacity remains causes a lowering of battery capacity. However, the original battery capacity can be recovered if you use the battery completely and charge it fully again.

To use up the battery, remove the cassette and slide the POWER switch to CAMERA with the battery attached, and leave the camcorder until the \square indicator and the red lamp flash rapidly in the viewfinder.

Removing the Battery Pack

Slide the battery pack in the direction of the arrow.



Notes on charging the battery pack

- The POWER lamp will remain lit for a while even if the battery pack is removed and the power cord is unplugged after charging the battery pack. This is normal.
- If the POWER lamp does not light, set the selector to the center position and disconnect the power cord. After about one minute, reconnect the power cord and set the selector to CHARGE again.
- You cannot operate the camcorder using the AC power adaptor while charging the battery pack.

Assembly Overview

Charging and Installing the Battery Pack

After using your scanner, you should charge and install the battery pack. To charge the battery pack, use the **CHARGE** and **INSTALL** buttons on the scanner.

Charging the Battery Pack

Charge the battery pack in a location that is safe and dry. Do not use the scanner while the battery pack is charging. The battery pack will be fully charged when the **CHARGE** button on the scanner is lit. The **CHARGE** button will be lit when the battery pack is fully charged. The **CHARGE** button will be lit when the battery pack is fully charged. The **CHARGE** button will be lit when the battery pack is fully charged.

After charging the battery pack, you can install it in the scanner. To install the battery pack, use the **INSTALL** button on the scanner. The **INSTALL** button will be lit when the battery pack is fully installed. The **INSTALL** button will be lit when the battery pack is fully installed.



Charging Time

Battery Pack	CHARGE	INSTALL	CHARGE	INSTALL
CHARGE	1	1	1	1

The battery pack will be fully charged when the **CHARGE** button on the scanner is lit. The **CHARGE** button will be lit when the battery pack is fully charged.

Installing the Battery Pack

CHARGE

Battery Pack	CHARGE	INSTALL	CHARGE	INSTALL
CHARGE	1	1	1	1

INSTALL

Battery Pack	CHARGE	INSTALL	CHARGE	INSTALL
CHARGE	1	1	1	1

CHARGE

Battery Pack	CHARGE	INSTALL	CHARGE	INSTALL
CHARGE	1	1	1	1

The battery pack will be fully charged when the **CHARGE** button on the scanner is lit. The **CHARGE** button will be lit when the battery pack is fully charged.

INSTALL

CHARGE

The battery pack will be fully charged when the **CHARGE** button on the scanner is lit. The **CHARGE** button will be lit when the battery pack is fully charged.

INSTALL

The battery pack will be fully installed when the **INSTALL** button on the scanner is lit. The **INSTALL** button will be lit when the battery pack is fully installed.




The battery pack will be fully installed when the **INSTALL** button on the scanner is lit. The **INSTALL** button will be lit when the battery pack is fully installed.

Charging and Installing the Battery Pack


Installing the Battery Pack

(1) Lift up the viewfinder. (2) Align the right side of the battery pack with the white line on the camcorder, and slide the battery pack to the right.



Removing the Battery Pack


(1) Lift up the viewfinder. (2) While pressing BATT, slide the battery pack to the left.



Inserting a Cassette

Make sure that a power source is installed.


(1) While sliding the lid lock, lift up the lid. Then open it. (2) Press EJECT. The cassette compartment automatically lifts up and opens. (3) Insert a cassette (not supplied) with the window facing out. (4) Press the PUSH mark on the cassette compartment to close it. The cassette compartment automatically goes down. (5) Close the lid until it locks.



To Eject the Cassette
Press EJECT.

To Prevent Accidental Erasure


Slide the tab on the cassette to expose the red mark. If you try to record with the red mark exposed, the and indicators flash in the viewfinder, and you cannot record on the tape. To re-record on this tape, slide the tab back out to cover the red mark.



Always use and install only the batteries with


Inserting the Battery Pack

1. Pull the battery pack off the top of the sprayer. The battery pack will come off the top of the sprayer.



Inserting the Battery Pack

2. Insert the battery pack into the battery pack slot.



Inserting a Charger

1. Insert the charger into the battery pack slot. The charger will come off the top of the sprayer. The charger will come off the top of the sprayer.



Inserting the Battery

Inserting the Battery


1. Insert the battery into the battery pack slot. The battery will come off the top of the sprayer. The battery will come off the top of the sprayer.




Adjusting the Viewfinder Lens

Before you use the camcorder for the first time or after someone else has used it, focus the viewfinder lens. Make sure that the power source is connected to the camcorder.

(1) While pressing the small green button on the POWER switch, slide it to CAMERA. (2) Turn STANDBY up. (3) Turn the viewfinder lens adjustment ring so that the indicators in the viewfinder come into sharp focus.



Adjusting the Viewfinder Lens/Camera Recording



Note on beep sound


As indicated with ♪ in the illustrations, a beep sounds when you turn the power on or when you start recording and two beeps sound when you stop recording, confirming the operation. Several beeps also sound as a warning of any unusual condition of the camcorder (p.51). Note that the beep sound is not recorded on the tape. If you do not want to hear the beep sound, select "OFF" in the menu system (p.25).

To Stop Recording Momentarily [a]

Press START/STOP again. The "STBY" indicator appears in the viewfinder (Standby mode).

To Finish Recording [b]

Press START/STOP. Turn STANDBY down, and set the POWER switch to OFF. Then, eject the cassette (p.9).



Adjusting the Stress-Function Keys

Adjusting the stress-function keys for these cameras is usually a simple matter. The right-most stress-function key is usually the only one that is adjustable. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera.



Adjusting the Stress-Function Keys

Adjusting the Stress-Function Keys

Adjusting the stress-function keys for these cameras is usually a simple matter. The right-most stress-function key is usually the only one that is adjustable. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera.



Adjusting the Stress-Function Keys

Adjusting the stress-function keys for these cameras is usually a simple matter. The right-most stress-function key is usually the only one that is adjustable. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera.


Adjusting the Stress-Function Keys

Adjusting the stress-function keys for these cameras is usually a simple matter. The right-most stress-function key is usually the only one that is adjustable. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera.

Adjusting the Stress-Function Keys

Adjusting the stress-function keys for these cameras is usually a simple matter. The right-most stress-function key is usually the only one that is adjustable. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera. The stress-function key is located on the right side of the camera.

Adjusting the Stress-Function Keys



Camera Recording

Note on Standby mode

If you leave the camcorder for 5 minutes or more with a cassette inserted in Standby mode, the camcorder goes off automatically. This prevents wearing down the battery and wearing out the tape. To resume Standby mode, turn **STANDBY** down once and turn it up again. To start recording, press **START/STOP**.

Note on recording

When you record from the beginning of the tape, run the tape for about 15 seconds before actual recording. This prevents the camcorder from missing any start-up scenes when you play back the tape. You can record tapes in **SP** (standard play) mode only.

Note on the tape counter

The tape counter indicates the recording or playback time. Use it as a guide. There will be a time lag of several seconds from the actual time. To set the counter to zero, press **COUNTER RESET** located below the viewfinder. You can know the approximate remaining tape by the remaining tape indicator (p.50).

Note on the AUTO DATE feature

The clock is set to the East Coast Standard Time at the factory. You can reset the clock (p.31). You can change the **AUTO DATE** setting by selecting **ON** or **OFF** in the menu system (p.25).

- The **AUTO DATE** feature works once a day. However, the date may automatically appear more than once a day when:
 - you reset the date and time.
 - you eject and insert the tape again.
 - you stop recording within 10 seconds.
- Once the **AUTO DATE** feature turns off the date display 10 seconds after the start of recording, the date and time are displayed as follows:
 - if the date display setting has been made, the date is displayed.
 - if the time display setting has been made, the time is displayed.
 - if neither display setting has been made, nothing is displayed.

When moving from indoors to outdoors (or vice versa)


Turn **STANDBY** up and point the camcorder at a white object for about 15 seconds so that the white balance is properly adjusted.

Using the Zoom Feature

Zooming is a recording technique that lets you change the size of the subject in the scene. For more professional-looking recordings, use the zoom sparingly.

T side: for telephoto (subject appears closer)

W side: for wide-angle (subject appears farther away)



Zooming Speed

Press the power zoom button firmly for a high-speed zoom. Press it softly for a relatively slow zoom.

When you shoot a subject using a telephoto zoom

If you cannot get a sharp focus while in extreme telephoto zoom, press the W side of the power zoom button until the focus is sharp.

You can shoot a subject that is at least 3.3 feet (about 1 m) away from the lens surface in the telephoto position, or 1/2 inches (about 1 cm) in the wide-angle position.

[illegible]

1. The first step in the process is to identify the problem or issue that needs to be addressed. This involves gathering information and understanding the context of the problem.


1. **Introduction**

1990年12月

...the ...

Hints for Better Shooting

For hand-held shots, you'll get better results holding the camcorder according to the following suggestions:



- Hold the camcorder firmly and secure it with the grip strap so that you can easily manipulate the controls with your thumb. [a]
- Place your right elbow against your side.
- Place your left hand under the camcorder to support it.
- Place your eye firmly against the viewfinder eyecup.
- Use the viewfinder frame as a guide to determine the horizontal plane.
- You can also record in a low position to get an interesting recording angle. Turn the viewfinder up for recording from a low position. [b]

Place the camcorder on a flat surface or use a tripod.

Try placing the camcorder on a table top or any other flat surface of suitable height. If you have a tripod for a still camera, you can also use it with the camcorder (p.46). Make sure the tripod screw is shorter than 9/32 in (6.5mm).

To Use the Viewfinder as a Sports Finder [c]


With the sports finder, you can monitor the picture while your eye is at a distance from the eyecup. The sports finder is convenient when moving around to shoot scenes. While sliding the viewfinder release knob to the left, flip open the viewfinder.

Note on the color viewfinder (for CCD-TR70/TR80)

You may find it difficult to use the color viewfinder as the sports finder for recording in light location.

Cautions on the viewfinder

- Do not pick up the camcorder by the viewfinder. [d]
- Do not place the camcorder so as to point the viewfinder toward the sun. The inside of the viewfinder may be deformed. Be careful in placing the camcorder under sunlight or at the window. [e]




Checking the Recorded Picture

Using EDITSEARCH, you can review the last recorded scene or check the recorded picture in the viewfinder.

- (1) While pressing the small green button on the POWER switch, slide it to CAMERA.
- (2) Turn STANDBY up. (3) Press EDITSEARCH. Press the - (RECALL) side momentarily, the last few seconds of the recorded portion plays back (Rec Review).

Keep pressing EDITSEARCH to play back the last recorded portion (Edit Search).

+ side: to view the forward playback picture
- side: to view the reverse playback picture



Hints for Better Shooting/Checking the Recorded Picture

To Stop Playback

Release EDITSEARCH.

To Begin Re-recording

Press START/STOP. Re-recording begins from the point you released EDITSEARCH. Provided you do not eject the tape, the transition between the last scene you recorded and the next scene you record will be smooth.

Monitoring the Sound While Viewing the Playback Picture in the Viewfinder

Connect earphone/headphones (not supplied) to the @/⏮ jack. Play back the tape in PLAYER mode (p.17).

Harmful for Better Absorption

When you eat or drink, you are not only getting nutrients, you are also getting water.



When you eat or drink, you are not only getting nutrients, you are also getting water. This is why it is important to eat and drink slowly and thoroughly. This allows the water to mix with the food and the nutrients to be absorbed more easily. If you eat or drink too quickly, the food and liquid will not mix properly and the nutrients will not be absorbed as well. This is why it is important to eat and drink slowly and thoroughly.


When you eat or drink, you are not only getting nutrients, you are also getting water. This is why it is important to eat and drink slowly and thoroughly. This allows the water to mix with the food and the nutrients to be absorbed more easily. If you eat or drink too quickly, the food and liquid will not mix properly and the nutrients will not be absorbed as well. This is why it is important to eat and drink slowly and thoroughly.

When you eat or drink, you are not only getting nutrients, you are also getting water. This is why it is important to eat and drink slowly and thoroughly. This allows the water to mix with the food and the nutrients to be absorbed more easily. If you eat or drink too quickly, the food and liquid will not mix properly and the nutrients will not be absorbed as well. This is why it is important to eat and drink slowly and thoroughly.



Checking the Recorded Factors

When you eat or drink, you are not only getting nutrients, you are also getting water. This is why it is important to eat and drink slowly and thoroughly. This allows the water to mix with the food and the nutrients to be absorbed more easily. If you eat or drink too quickly, the food and liquid will not mix properly and the nutrients will not be absorbed as well. This is why it is important to eat and drink slowly and thoroughly.



When you eat or drink, you are not only getting nutrients, you are also getting water.

This is why it is important to eat and drink slowly and thoroughly.

This allows the water to mix with the food and the nutrients to be absorbed more easily.

If you eat or drink too quickly, the food and liquid will not mix properly and the nutrients will not be absorbed as well.

This is why it is important to eat and drink slowly and thoroughly.

This allows the water to mix with the food and the nutrients to be absorbed more easily.

If you eat or drink too quickly, the food and liquid will not mix properly and the nutrients will not be absorbed as well.


This is why it is important to eat and drink slowly and thoroughly.

Connections for Playback

You can use this camcorder as a VCR by connecting it to your TV for playback. There are some ways to connect your camcorder as shown below. It is recommended to use the house current as the power source (p.19).

Connecting to a TV without Video/Audio Input Jacks

Connect the camcorder to the TV using the supplied RFU adaptor. Set the channel selector on the RFU adaptor and your TV channel to VHF channel CH3 or CH4, whichever is not active in your area. With this connection, the sound is monaural.




➡ : Signal flow

Connecting to a TV with Video/Audio Input Jacks or VCR

For Stereo Models (CCD-TR72/TR80)

Connect the camcorder to your TV by using the supplied connecting cable. Set the TV/VCR selector to VCR on the TV. When connecting the camcorder to VCR, set the input selector on the VCR to LINE.




➡ : Signal flow

If your TV or VCR is monaural type, connect only the white plug for audio on both the camcorder and the TV or the VCR. With this connection, the sound is monaural.

For Monaural Models (CCD-TR42/TR70/TR82)

Connect the camcorder to your TV by using a monaural A/V connecting cable (not supplied). Set the TV/VCR selector to VCR on the TV. When connecting the camcorder to VCR, set the input selector on the VCR to LINE.




➡ : Signal flow

Playing Back a Tape

You can monitor the playback picture in the viewfinder. You can also monitor on the TV screen, after connecting the camcorder to the TV/VCR (p.16). You can control playback using the supplied Remote Commander (p.49).

(1) While pressing the small green button on the POWER switch, slide it to PLAYER. (2) Insert the recorded tape with the window facing out. (3) Press \blacktriangleright . Playback starts.



Connect your New PlayStation

Use the new PlayStation as a video game console, or as a TV set. It's the perfect choice for anyone who wants to play video games on a television. It's also a great choice for anyone who wants to play video games on a computer.

Connecting to a TV with Video Game Console Input

Connect the console to a TV with the Video Game Console Input. The console will be connected to the TV's video input. The console will be connected to the TV's audio input. The console will be connected to the TV's power input.



Connecting to a TV with Video Game Console Input

Connect the console to a TV with the Video Game Console Input. The console will be connected to the TV's video input. The console will be connected to the TV's audio input. The console will be connected to the TV's power input.



Using the PlayStation as a video game console, or as a TV set. It's the perfect choice for anyone who wants to play video games on a television. It's also a great choice for anyone who wants to play video games on a computer.



Playing Games on a TV

Use the PlayStation as a video game console, or as a TV set. It's the perfect choice for anyone who wants to play video games on a television. It's also a great choice for anyone who wants to play video games on a computer.



Playing Back a Tape

To stop playback, press **□**.
 To rewind the tape, press **◀◀**.
 To advance the tape rapidly, press **▶▶**.

Various Playback Modes

To view a still picture (playback pause)
 Press **⏸** during playback. To resume playback, press **⏸** or **▶**.

To locate a scene (Picture Search)
 Keep pressing **◀◀** or **▶▶** during playback. To resume normal playback, release the button.

To monitor the high-speed picture during fastforward or rewind (Skip Scan)
 Keep pressing **◀◀** while rewinding or **▶▶** while advancing the tape. To resume normal playback, press **▶**.

To view the picture in a sequence of stop-motion images
 Press **EDITSEARCH** in playback pause mode. If you keep pressing **EDITSEARCH**, you can view the picture playback in the forward (+) or reverse (-) direction.

To view the picture at 1/5 speed (Slow Playback) (only with the Remote Commander)
 Press **⏮** on the Remote Commander during playback. To resume normal playback, press **▶**. If slow playback lasts for about 1 minute, it shifts to normal speed automatically.

Note on playback

- Streaks appear and the sound is muted in the various playback modes.
- When still picture mode lasts for 5 minutes or more, the camcorder automatically enters stop mode.

To display the viewfinder screen indicators on the TV

Press **DISPLAY** on the Remote Commander.
 To erase the indicators, press **DISPLAY** again.

To select the monitor sound - For stereo models (CCD-TR72/TR80)
 Change the "HiFi SOUND" mode setting in the menu system (p.25)

Advanced Operations

Using Alternate Power Sources


You can choose any of the following power sources for your camcorder: battery pack (P.6), house current, and 12/24 V car battery. Choose the appropriate power source depending on where you want to use your camcorder.

Place	Power source	Accessory to be used
Indoors	House current	AC power adaptor AC-V25/V25A/V25B (supplied), AC-S10, AC-V35
Outdoor	Battery pack	Battery pack NP-55 (supplied), NP-80, NP-80D, NP-77H, NP-66H, NP-60D, NP-55H
In the car	12 V or 24 V car battery	DC pack DCP-77

Using House Current

To use the supplied AC-V25/A25A/V25B AC power adaptor:

(1) Lift up the viewfinder. (2) Connect the AC power cord to a wall outlet. Connect the bottom of the AC power adaptor to the battery mounting surface of the camcorder. (3) Set the selector to VTR (DC OUT).



Notes on the POWER lamp

- The POWER lamp will remain lit for a while even if the unit is unplugged after use. This is normal.
- If the POWER lamp does not light, set the selector to the center position and disconnect the power cord. After about one minute, reconnect the power cord and set the selector to VTR (DC OUT) again.

To remove the adaptor

The adaptor is removed in the same way as the battery pack. (p.8)

Using Alternate Power Sources

Using a Car Battery

Use the DCP-77 DC pack (not supplied). Connect the cord of the DC pack to the cigarette lighter socket of a car (12 V or 24 V). Connect the DC pack to the battery mounting surface of the camcorder.

To remove the DC pack


The DC pack is removed in the same way as the battery pack. (p.8)

Options for Charging the Battery Pack

- AC-S10 AC power adaptor:
You can charge a battery pack whether it is used up or not with this adaptor because it has a discharging function.
- BC-S10 portable battery charger (ideal for travel):
You can charge a battery pack on 100 — 240 V AC current.

Recording with the Date or Time


Before you start recording, press DATE or TIME. You can record the date or time displayed in the viewfinder with the picture. You cannot record the date and time at the same time. Except for the date or time indicator, no indicator in the viewfinder is recorded. The clock is set to the East Coast Standard Time at the factory.




To Stop Recording with the Date or Time
Press DATE or TIME again. Recording continues.

Shooting with Backlighting


When you shoot a subject with the light source behind the subject or a subject with a light background, use the BACK LIGHT.

Press BACK LIGHT. The  indicator appears inside the viewfinder.



- [a] Subject is too dark because of backlight.
- [b] Subject becomes bright with backlight compensation.

After shooting

Press BACK LIGHT again to let the  indicator go out under normal lighting condition. Otherwise, the picture will be too bright under normal lighting condition.

This function is also effective under following conditions:

- On the snow e.g. at the ski resort
- At the beach under strong sunshine
- A subject with a light source nearby or a mirror reflecting light
- A white subject against a white background. Especially when you shoot a person wearing shiny clothes made of silk or synthetic fiber, his or her face tends to become dark if you do not use this function.

Quarry and Wildlife Habitat Scenarios

Quarry and Wildlife Habitat Scenarios

Scenario 1: Quarry and Wildlife Habitat Scenarios

Scenario 2: Quarry and Wildlife Habitat Scenarios

Scenario 3: Quarry and Wildlife Habitat Scenarios

Scenario 4: Quarry and Wildlife Habitat Scenarios

Recording with the Culture on Form

Recording with the Culture on Form



Recording with the Culture on Form

Recording with the North Lighting

Recording with the North Lighting

Recording with the North Lighting



Recording with the North Lighting

Recording with the North Lighting

Recording with the North Lighting


Recording with the North Lighting

Recording with the North Lighting


Recording with the North Lighting

SECTION 2 DISASSEMBLY

2-1. REMOVAL OF F PANEL BLOCK




2-2. REMOVAL OF CASSETTE LID ASSEMBLY




SECTION 3 DISASSEMBLY

3-1. REMOVAL OF F-PANEL BLOCK




3-2. REMOVAL OF CASSETTE LID ASSEMBLY




2-3. REMOVAL OF CABINET (L) ASSEMBLY


Note: When incorporating the cabinet (L) block assembly, be sure to remove the lithium battery first or the cabinet (L) will not fit properly.




2-4. REMOVAL OF CABINET (R) ASSEMBLY




2-5. REMOVAL OF EVF ASSEMBLY (TR42/TR72/TR82/TR400/TR430/TR550/TR750)




2-5. REMOVAL OF EVF ASSEMBLY (TR70/TR80)




2-6. REMOVAL OF CONTROL SWITCH BLOCK (CK)




2-7. REMOVAL OF DD-60 BOARD (TR72/TR80/TR400/TR430/TR750) REMOVAL OF DD-66 BOARD (TR42/TR70/TR82/TR550)




**2-8. REMOVAL OF TERMINAL BOARD AND
AU-165 BOARD (TR72/TR80/TR400/TR430/TR750),
AU-169 BOARD (TR42/TR70/TR82/TR550)**




**2-9. REMOVAL OF ZOOM LENS BLOCK AND
VC-138 BOARD (TR72/TR80/TR400/TR430/TR750),
VC-145 BOARD (TR42/TR70/TR82/TR550)**




**3-4. REMOVAL OF TERMINAL BOARD AND
AD-100 BOARD (T702/T703/T704/T705/T706,
AD-100 BOARD (T7042/T7052/T7062/T7082))**




**3-4. REMOVAL OF DOOR LATCH BLOCK AND
VC-100 BOARD (T702/T703/T704/T705/T706,
VC-100 BOARD (T7042/T7052/T7062/T7082))**




**2-10. REMOVAL OF VS-104 BOARD (TR72/TR80/TR400/TR430/TR750)
REMOVAL OF VS-112 BOARD (TR42/TR70/TR82/TR550)**



2-11. REMOVAL OF SL-38 BOARD




2-12. REMOVE OF CONTROL SWITCH BLOCK (FK)



2-13. INTERNAL VIEWS

— Left side —




M901 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)

Drum assembly	DGH-78A-R	A-7048-564-A
Upper drum assembly	DGR-78-R	A-7049-501-A

M901 (TR400/TR750)

Drum assembly	DGH-92A-R	A-7048-633-A
Upper drum assembly	DGR-92-R	A-7049-567-A

— Right side —



WU **WU** **WU**




1000

Overall sensitivity	77.0%-78.0%	1.75-2.00
System (device) sensitivity	77.0%-78.0%	1.75-2.00

Table 1


Overall mean \pm SD	2000-2001 (n=1)	2002-2003 (n=1)
Overall mean \pm SD	2000-2001 (n=1)	2002-2003 (n=1)



4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS








THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.

(In addition to this, the necessary note is printed in each block.)

- For printed wiring boards.
-  : Pattern from the side which enables seeing.
(The other layers' patterns are not indicated.)
- Circled numbers refer to waveforms.
- (B) or (F), etc. of capacitors indicate the temperature characteristics.
- \bigcirc : Through hole.

Caution:

Pattern face side: Parts on the pattern face side seen from the pattern face are indicated.
(Conductor Side)
Parts face side: Parts on the parts face side seen from the parts face are indicated.
(Component side)

- For schematic diagrams.
- Caution when replacing chip parts.
New parts must be attached after removal of chip.
Be careful not to heat the minuts side of tantalum capacitor, because it is damaged by the heat.
- All resistors are in ohms, 1/4W unless otherwise noted.
Chip resistor are 1/10W unless otherwise noted.
k Ω : 1000 Ω , M Ω : 1000k Ω .
- All capacitors are in μ F unless otherwise noted. pF: μ μ F.
50V or less are not indicated except for electrolytics and tantalums.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
-  : nonflammable resistor.
-  : fusible resistor.
-  : panel designation.
- Δ : internal component.
-  : adjustment for repair.
-  : B+ Line.
-  : B- Line.
-  : IN/OUT direction of (+, -) B LINE.
- Circled numbers refer to waveforms.

Note:

The components identified by mark Δ or dotted line with mark Δ are critical for safty. Replace only with part number specified.

Note:


Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

Measuring conditions voltage value and waveform. (CAMERA block)

- The object is color bar chart of pattern box.
- Voltages are dc between ground and measurement points.
Readings are taken with a digital multimeter (DC 10M Ω).
- Voltage variations may be noted due to normal production tolerances.

1. Connection Pattern box



2. Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.




Fig. a (Video output terminal output waveform)




Fig. b (Picture on monitor TV)



(VIDEO, SERVO/SYSTEM CONTROL, AUDIO, LCD CONTROL)

- Voltages are dc between ground and measurement points.
- Readings are taken with a color-bar signal input.
- Readings are taken with a digital multimeter (DC10M Ω).
- Voltage variations may be noted due to normal production tolerances.


FP-89 (CCD IMAGER) PRINTED WIRING BOARD

— Ref. No. FP-89 BOARD: 3000 series —

FP-89 BOARD



FP-89 BOARD



FP-89 (CCD IMAGER) SCHEMATIC DIAGRAM

— Ref. No. FP-89 BOARD: 3000 series —

A

B


C

D


E

FP-89 BOARD

no mark : CAMERA REC mode



FP-89 BOARD




• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC			➡➡➡
PB			

Note on the CCD Imager replacement

- Some of this units require the correction data by the CCD imager (IC691 on FP-89 board), some do not. The correction data is input in F page and addresses 1D to 2C of the camera micro processor (IC602 on VC board), and also written on the CCD data label put on the shield case (upper) of the DD board. The correction data is not required for the CCD imager supplied for repair. Therefore, when replacing the CCD imager to which the CCD data label is put, remove the CCD data label and input 00 to F page and addresses 1D to 2C of the camera micro processor. Refer to the camera adjustment for input method.
- The CCD imager is not mounted for the already mounted FP-89 board supplied as the repair parts. When replacing the FP-89 board, remove the CCD imager from the old board and install on the new board.
- Perform all adjustments of the camera block when the CCD imager has been replaced.
- Handle the CCD imager with attention such as MOS IC as it may be broken by static electricity in the structure. Also, prevent the receiving light section from dust attached and strong light.



FP-88 BOARD



• SIGNAL PATH

	VIDEO SIGNAL		
	ORIGINAL	Y	CHROMA
FP-88			
FP-88			


Notes on the CCD Imager replacement:

- Page 4 of this note applies the mounting site for the CCD Imager (CCD) on FP-88 board, as shown in the diagram. The mounting site is located in 7 pins and addresses 10 to 10 of the camera image processor (CIP) on FP-88 board, and also between the CCD data label pin on the shield case (pin) of the (CCD) board. The mounting site is not applied for the CCD Imager supplied for repair. Therefore, when replacing the CCD Imager to which the CCD data label is put, connect the CCD data label and input 10 to 7 pins and addresses 10 to 10 of the camera image processor (CIP) to the camera adjustment through method.
- The CCD Imager is not removed for the already installed FP-88 board supplied in the repair parts. When replacing the FP-88 board, remove the CCD Imager from the old board and install on the new board.
- Perform all adjustments of the camera block when the CCD Imager has been replaced.
- Handle the CCD Imager with attention such as (1) to (5) as is required before by static electricity in the device. After, perform the mounting. Light section from data created and along light.

FP-49 (STEADY SHOT SENSOR) PRINTED WIRING BOARD (TR82/TR400/TR550/TR750)

— Ref. No. FP-49 BOARD: 3000 series —


FP-49 BOARD



09

1-651-890-

FP-49 BOARD




FP-49 (STEADY SHOT SENSOR) SCHEMATIC DIAGRAM (TR82/TR400/TR550/TR750)

— Ref. No. FP-49 BOARD: 3000 series —

FP-49 BOARD

(CCD-TR82/TR400/TR550/TR750)




FP-45 (STEADY SHOT SENSOR) SCHEMATIC DIAGRAM (TR42/TR400/TR430/TR750)

1 2 3 4 5 6 7

— Ref. To FP-45 BOARD —

FP-45 BOARD
CCD-TR42/TR400/TR430/TR750



SECTION 5 REPAIR PARTS LIST

5-1. EXPLODED VIEWS

NOTES


- 1. JMS, if some standard parts, as they may have some difference from the original one.
- 2. The standard parts with no reference number in the exploded view are not supplied.

- 3. Some marked "A" or "B" are not marked, show they are optional required for certain version, these parts should be investigated when ordering these items.
- 4. Markings (round) in parentheses for the whole parts list.

The components identified by mark A or B added this with mark A or B listed for option. Replace only with part number specified.

The components identified by the reference A and B indicate part is standard. To be consistent you can use other parts number specified.

5-1-1. FRONT BLOCK ASSEMBLY




TR42/TR70/TR72/TR80/TR82

TR400/TR430/TR550/TR750


Ref. No.	Part No.	Description	Unit	Ref. No.	Part No.	Description	Unit
1	1-100-001-00	FRONT PANEL	1	1	1-100-001-00	FRONT PANEL	1
2	1-100-001-01	FRONT PANEL (A)	1	2	1-100-001-01	FRONT PANEL (A)	1
3	1-100-001-02	FRONT PANEL (B)	1	3	1-100-001-02	FRONT PANEL (B)	1
4	1-100-001-03	FRONT PANEL (C)	1	4	1-100-001-03	FRONT PANEL (C)	1
5	1-100-001-04	FRONT PANEL (D)	1	5	1-100-001-04	FRONT PANEL (D)	1
6	1-100-001-05	FRONT PANEL (E)	1	6	1-100-001-05	FRONT PANEL (E)	1
7	1-100-001-06	FRONT PANEL (F)	1	7	1-100-001-06	FRONT PANEL (F)	1
8	1-100-001-07	FRONT PANEL (G)	1	8	1-100-001-07	FRONT PANEL (G)	1
9	1-100-001-08	FRONT PANEL (H)	1	9	1-100-001-08	FRONT PANEL (H)	1
10	1-100-001-09	FRONT PANEL (I)	1	10	1-100-001-09	FRONT PANEL (I)	1
11	1-100-001-10	FRONT PANEL (J)	1	11	1-100-001-10	FRONT PANEL (J)	1
12	1-100-001-11	FRONT PANEL (K)	1	12	1-100-001-11	FRONT PANEL (K)	1
13	1-100-001-12	FRONT PANEL (L)	1	13	1-100-001-12	FRONT PANEL (L)	1
14	1-100-001-13	FRONT PANEL (M)	1	14	1-100-001-13	FRONT PANEL (M)	1
15	1-100-001-14	FRONT PANEL (N)	1	15	1-100-001-14	FRONT PANEL (N)	1
16	1-100-001-15	FRONT PANEL (O)	1	16	1-100-001-15	FRONT PANEL (O)	1
17	1-100-001-16	FRONT PANEL (P)	1	17	1-100-001-16	FRONT PANEL (P)	1

5-1-2. CABINET (L) BLOCK ASSEMBLY




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	X-3943-923-1	CABINET (L) ASSY (TR72/TR80/TR430)		55	3-578-221-00	SPRING, COMPRESSION	
51	X-3943-924-1	CABINET (L) ASSY (TR42/TR70/TR82/TR550)		56	3-942-985-01	KNOB, STAND-BY	
51	X-3944-037-1	CABINET (L) ASSY (TR400/TR750)		57	3-736-364-01	SPRING	
52	3-736-807-01	BELT, GRIP		58	3-942-953-01	HOLDER, STAND-BY KNOB	
53	3-958-606-01	COVER, JACK		59	3-942-895-01	STOPPER, BELT	
54	3-958-608-01	LID, LITHIUM POWER					

8-1-2. CANNON (C) BLOCK ASSEMBLY




Ref. No.	Part No.	Description	Mount	Ref. No.	Part No.	Description	Mount
1	1-10-100-01	Block, Cannon		1	1-10-100-01	Block, Cannon	
2	1-10-100-02	Pin, 1/8" Dia. x 1/2" Long		2	1-10-100-02	Pin, 1/8" Dia. x 1/2" Long	
3	1-10-100-03	Pin, 1/8" Dia. x 1/2" Long		3	1-10-100-03	Pin, 1/8" Dia. x 1/2" Long	
4	1-10-100-04	Pin, 1/8" Dia. x 1/2" Long		4	1-10-100-04	Pin, 1/8" Dia. x 1/2" Long	
5	1-10-100-05	Pin, 1/8" Dia. x 1/2" Long		5	1-10-100-05	Pin, 1/8" Dia. x 1/2" Long	
6	1-10-100-06	Pin, 1/8" Dia. x 1/2" Long		6	1-10-100-06	Pin, 1/8" Dia. x 1/2" Long	
7	1-10-100-07	Pin, 1/8" Dia. x 1/2" Long		7	1-10-100-07	Pin, 1/8" Dia. x 1/2" Long	
8	1-10-100-08	Pin, 1/8" Dia. x 1/2" Long		8	1-10-100-08	Pin, 1/8" Dia. x 1/2" Long	
9	1-10-100-09	Pin, 1/8" Dia. x 1/2" Long		9	1-10-100-09	Pin, 1/8" Dia. x 1/2" Long	
10	1-10-100-10	Pin, 1/8" Dia. x 1/2" Long		10	1-10-100-10	Pin, 1/8" Dia. x 1/2" Long	
11	1-10-100-11	Pin, 1/8" Dia. x 1/2" Long		11	1-10-100-11	Pin, 1/8" Dia. x 1/2" Long	

5-1-3. CABINET (R) BLOCK ASSEMBLY




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	X-3943-921-1	CABINET (R) ASSY (TR82)		111	1-467-676-11	SWITCH BLOCK, CONTROL (CK)	
101	X-3943-926-1	CABINET (R) ASSY (TR72/TR80/TR430)				(TR42/TR82/TR550)	
101	X-3944-036-1	CABINET (R) ASSY (TR70)		111	1-467-676-21	SWITCH BLOCK, CONTROL (CK)	
101	X-3944-090-1	CABINET (R) ASSY (TR42)				(TR70/TR72/TR80/TR430)	
101	X-3944-110-1	CABINET (R) ASSY (TR550)		111	1-467-676-41	SWITCH BLOCK, CONTROL (CK) (TR400/TR750)	
				112	3-948-339-01	SCREW (BTP) (2X5), HEAD	
101	X-3944-111-1	CABINET (R) ASSY (H) (TR400)		* 113	3-958-586-01	LABEL, MODEL NUMBER (72) (TR72)	
101	X-3944-113-1	CABINET (R) ASSY (H) (TR750)		* 113	3-958-638-01	LABEL, MODEL NUMBER (82) (TR82)	
102	3-718-233-01	NUT, PLATE		* 113	3-958-973-01	LABEL, MODEL NUMBER (80) (TR80)	
103	3-719-381-01	SCREW (M2X4)		* 113	3-958-974-01	LABEL, MODEL NUMBER (70) (TR70)	
104	3-719-601-01	SCREW (B2X5), TAPPING		* 113	3-959-117-01	LABEL, MODEL NUMBER (42) (TR42)	
105	3-949-008-01	SHEET, FOOT		* 113	3-959-123-01	LABEL, MODEL NUMBER (550) (TR550)	
106	3-958-618-01	BUTTON, BATTERY RELEASE		* 113	3-959-124-01	LABEL, MODEL NUMBER (430) (TR430)	
107	3-958-620-01	CLAW, BATTERY LOCK		* 113	3-959-126-01	LABEL, MODEL NUMBER (400) (TR400)	
108	3-426-508-00	SPRING, COMPRESSION		* 113	3-959-129-01	LABEL, MODEL NUMBER (750) (TR750)	
109	3-958-650-01	RETAINER, BATTERY RELEASE		* 114	3-959-615-01	CUSHION (CK)	
110	1-810-535-11	DISPLAY PANEL, LIQUID CRYSTAL	(TR400/TR750)				

9-1-2. CABINET (2) BLOCK ASSEMBLY




Ref. No.	Part No.	Description	Notes	Ref. No.	Part No.	Description	Notes
1	1-00-00-01	1-00-00-01		10	1-00-00-01	1-00-00-01	
2	1-00-00-02	1-00-00-02		11	1-00-00-02	1-00-00-02	
3	1-00-00-03	1-00-00-03		12	1-00-00-03	1-00-00-03	
4	1-00-00-04	1-00-00-04		13	1-00-00-04	1-00-00-04	
5	1-00-00-05	1-00-00-05		14	1-00-00-05	1-00-00-05	
6	1-00-00-06	1-00-00-06		15	1-00-00-06	1-00-00-06	
7	1-00-00-07	1-00-00-07		16	1-00-00-07	1-00-00-07	
8	1-00-00-08	1-00-00-08					
9	1-00-00-09	1-00-00-09					
10	1-00-00-10	1-00-00-10					
11	1-00-00-11	1-00-00-11					
12	1-00-00-12	1-00-00-12					
13	1-00-00-13	1-00-00-13					
14	1-00-00-14	1-00-00-14					
15	1-00-00-15	1-00-00-15					
16	1-00-00-16	1-00-00-16					
17	1-00-00-17	1-00-00-17					
18	1-00-00-18	1-00-00-18					
19	1-00-00-19	1-00-00-19					
20	1-00-00-20	1-00-00-20					
21	1-00-00-21	1-00-00-21					
22	1-00-00-22	1-00-00-22					
23	1-00-00-23	1-00-00-23					
24	1-00-00-24	1-00-00-24					
25	1-00-00-25	1-00-00-25					
26	1-00-00-26	1-00-00-26					
27	1-00-00-27	1-00-00-27					
28	1-00-00-28	1-00-00-28					
29	1-00-00-29	1-00-00-29					
30	1-00-00-30	1-00-00-30					
31	1-00-00-31	1-00-00-31					
32	1-00-00-32	1-00-00-32					
33	1-00-00-33	1-00-00-33					
34	1-00-00-34	1-00-00-34					
35	1-00-00-35	1-00-00-35					
36	1-00-00-36	1-00-00-36					
37	1-00-00-37	1-00-00-37					
38	1-00-00-38	1-00-00-38					
39	1-00-00-39	1-00-00-39					
40	1-00-00-40	1-00-00-40					
41	1-00-00-41	1-00-00-41					
42	1-00-00-42	1-00-00-42					
43	1-00-00-43	1-00-00-43					
44	1-00-00-44	1-00-00-44					
45	1-00-00-45	1-00-00-45					
46	1-00-00-46	1-00-00-46					
47	1-00-00-47	1-00-00-47					
48	1-00-00-48	1-00-00-48					
49	1-00-00-49	1-00-00-49					
50	1-00-00-50	1-00-00-50					
51	1-00-00-51	1-00-00-51					
52	1-00-00-52	1-00-00-52					
53	1-00-00-53	1-00-00-53					
54	1-00-00-54	1-00-00-54					
55	1-00-00-55	1-00-00-55					
56	1-00-00-56	1-00-00-56					
57	1-00-00-57	1-00-00-57					
58	1-00-00-58	1-00-00-58					
59	1-00-00-59	1-00-00-59					
60	1-00-00-60	1-00-00-60					
61	1-00-00-61	1-00-00-61					
62	1-00-00-62	1-00-00-62					
63	1-00-00-63	1-00-00-63					
64	1-00-00-64	1-00-00-64					
65	1-00-00-65	1-00-00-65					
66	1-00-00-66	1-00-00-66					
67	1-00-00-67	1-00-00-67					
68	1-00-00-68	1-00-00-68					
69	1-00-00-69	1-00-00-69					
70	1-00-00-70	1-00-00-70					
71	1-00-00-71	1-00-00-71					
72	1-00-00-72	1-00-00-72					
73	1-00-00-73	1-00-00-73					
74	1-00-00-74	1-00-00-74					
75	1-00-00-75	1-00-00-75					
76	1-00-00-76	1-00-00-76					
77	1-00-00-77	1-00-00-77					
78	1-00-00-78	1-00-00-78					
79	1-00-00-79	1-00-00-79					
80	1-00-00-80	1-00-00-80					
81	1-00-00-81	1-00-00-81					
82	1-00-00-82	1-00-00-82					
83	1-00-00-83	1-00-00-83					
84	1-00-00-84	1-00-00-84					
85	1-00-00-85	1-00-00-85					
86	1-00-00-86	1-00-00-86					
87	1-00-00-87	1-00-00-87					
88	1-00-00-88	1-00-00-88					
89	1-00-00-89	1-00-00-89					
90	1-00-00-90	1-00-00-90					
91	1-00-00-91	1-00-00-91					
92	1-00-00-92	1-00-00-92					
93	1-00-00-93	1-00-00-93					
94	1-00-00-94	1-00-00-94					
95	1-00-00-95	1-00-00-95					
96	1-00-00-96	1-00-00-96					
97	1-00-00-97	1-00-00-97					
98	1-00-00-98	1-00-00-98					
99	1-00-00-99	1-00-00-99					
100	1-00-00-100	1-00-00-100					

5-1-4. EVF BLOCK ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	X-3943-930-1	CABINET (L) ASSY, EVF (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		* 164	A-7063-957-A	VF-65 BOARD, COMPLETE (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
151	X-3944-004-1	CABINET (L) ASSY, EVF (TR70/TR80)		* 165	A-7066-011-A	VF-67 BOARD, COMPLETE (TR70/TR80)	
152	3-713-791-51	SCREW (M1.7X3.5), TAPPING, P2		* 166	A-7066-010-A	VF-66 BOARD, COMPLETE (TR70/TR80)	
153	3-948-339-01	SCREW (BTP) (2X5), HEAD		167	1-651-903-11	FP-92 FLEXIBLE BOARD (TR70/TR80)	
154	3-958-627-01	LENS (1), VF		168	1-651-893-11	FP-85 FLEXIBLE BOARD (TR70/TR80)	
155	A-7082-596-A	HOLDER (1) BLOCK ASSY, FINDER (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		169	3-958-969-01	CHIP (LCD), TALLY (TR70/TR80)	
155	A-7082-625-A	HOLDER (1) BLOCK ASSY, FINDER (TR70/TR80)		* 170	A-7056-012-A	LB-35 BOARD, COMPLETE (TR70/TR80)	
156	3-958-217-01	SCREW (M2)		171	1-517-325-11	LAMP, FLUORESCENT (0.55 INCH) (TR70/TR80)	
157	3-958-629-01	SPRING, LEAF		172	3-958-962-01	COVER, BL (TR70/TR80)	
158	3-958-628-01	HOLDER (1), LENS		* 173	3-958-963-01	CUSHION (1) (TR70/TR80)	
159	A-7082-595-A	HOLDER (2) BLOCK ASSY, FINDER		* 174	3-958-964-01	CUSHION (2) (TR70/TR80)	
160	3-958-597-01	EYE CUP		175	3-958-965-01	PLATE, CONDENCE, BL (TR70/TR80)	
161	3-958-592-01	CABINET (R), EVF (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		176	3-958-966-01	ILLUMINATOR, BL (TR70/TR80)	
161	3-958-592-11	CABINET (R), EVF (TR70/TR80)		* 177	3-958-967-01	CUSHION (3) (TR70/TR80)	
Δ 162	1-452-673-11	CRT ASSY (M01KXX90WB) (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		178	3-958-968-01	HOLDER (TR70/TR80)	
163	1-651-894-11	FP-86 FLEXIBLE BOARD (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		180	3-958-975-01	COVER, LCD (TR70/TR80)	
				181	8-753-015-00	LCX005AK-1 (TR70/TR80)	
				W901	1-540-019-21	SOCKET ASSY, CRT (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	

2-1-4. RVP BLOCK ASSEMBLY




The components identified by this symbol are standard items and are not shown in this diagram. The components identified by this symbol are not shown in this diagram. The components identified by this symbol are not shown in this diagram.

Ref. No.	Ref. No.	Description	Ref. No.
100	1-100-100-1	COVER, TOP, RVP, RVP	
101	1-100-100-2	COVER, TOP, RVP, RVP	
102	1-100-100-3	COVER, TOP, RVP, RVP	
103	1-100-100-4	COVER, TOP, RVP, RVP	
104	1-100-100-5	COVER, TOP, RVP, RVP	
105	1-100-100-6	COVER, TOP, RVP, RVP	
106	1-100-100-7	COVER, TOP, RVP, RVP	
107	1-100-100-8	COVER, TOP, RVP, RVP	
108	1-100-100-9	COVER, TOP, RVP, RVP	
109	1-100-100-10	COVER, TOP, RVP, RVP	
110	1-100-100-11	COVER, TOP, RVP, RVP	
111	1-100-100-12	COVER, TOP, RVP, RVP	
112	1-100-100-13	COVER, TOP, RVP, RVP	
113	1-100-100-14	COVER, TOP, RVP, RVP	
114	1-100-100-15	COVER, TOP, RVP, RVP	
115	1-100-100-16	COVER, TOP, RVP, RVP	
116	1-100-100-17	COVER, TOP, RVP, RVP	
117	1-100-100-18	COVER, TOP, RVP, RVP	
118	1-100-100-19	COVER, TOP, RVP, RVP	
119	1-100-100-20	COVER, TOP, RVP, RVP	
120	1-100-100-21	COVER, TOP, RVP, RVP	
121	1-100-100-22	COVER, TOP, RVP, RVP	
122	1-100-100-23	COVER, TOP, RVP, RVP	
123	1-100-100-24	COVER, TOP, RVP, RVP	
124	1-100-100-25	COVER, TOP, RVP, RVP	
125	1-100-100-26	COVER, TOP, RVP, RVP	
126	1-100-100-27	COVER, TOP, RVP, RVP	
127	1-100-100-28	COVER, TOP, RVP, RVP	
128	1-100-100-29	COVER, TOP, RVP, RVP	
129	1-100-100-30	COVER, TOP, RVP, RVP	
130	1-100-100-31	COVER, TOP, RVP, RVP	
131	1-100-100-32	COVER, TOP, RVP, RVP	
132	1-100-100-33	COVER, TOP, RVP, RVP	
133	1-100-100-34	COVER, TOP, RVP, RVP	
134	1-100-100-35	COVER, TOP, RVP, RVP	
135	1-100-100-36	COVER, TOP, RVP, RVP	
136	1-100-100-37	COVER, TOP, RVP, RVP	
137	1-100-100-38	COVER, TOP, RVP, RVP	
138	1-100-100-39	COVER, TOP, RVP, RVP	
139	1-100-100-40	COVER, TOP, RVP, RVP	
140	1-100-100-41	COVER, TOP, RVP, RVP	
141	1-100-100-42	COVER, TOP, RVP, RVP	
142	1-100-100-43	COVER, TOP, RVP, RVP	
143	1-100-100-44	COVER, TOP, RVP, RVP	
144	1-100-100-45	COVER, TOP, RVP, RVP	
145	1-100-100-46	COVER, TOP, RVP, RVP	
146	1-100-100-47	COVER, TOP, RVP, RVP	
147	1-100-100-48	COVER, TOP, RVP, RVP	
148	1-100-100-49	COVER, TOP, RVP, RVP	
149	1-100-100-50	COVER, TOP, RVP, RVP	
150	1-100-100-51	COVER, TOP, RVP, RVP	
151	1-100-100-52	COVER, TOP, RVP, RVP	
152	1-100-100-53	COVER, TOP, RVP, RVP	
153	1-100-100-54	COVER, TOP, RVP, RVP	
154	1-100-100-55	COVER, TOP, RVP, RVP	
155	1-100-100-56	COVER, TOP, RVP, RVP	
156	1-100-100-57	COVER, TOP, RVP, RVP	
157	1-100-100-58	COVER, TOP, RVP, RVP	
158	1-100-100-59	COVER, TOP, RVP, RVP	
159	1-100-100-60	COVER, TOP, RVP, RVP	
160	1-100-100-61	COVER, TOP, RVP, RVP	
161	1-100-100-62	COVER, TOP, RVP, RVP	
162	1-100-100-63	COVER, TOP, RVP, RVP	
163	1-100-100-64	COVER, TOP, RVP, RVP	
164	1-100-100-65	COVER, TOP, RVP, RVP	
165	1-100-100-66	COVER, TOP, RVP, RVP	
166	1-100-100-67	COVER, TOP, RVP, RVP	
167	1-100-100-68	COVER, TOP, RVP, RVP	
168	1-100-100-69	COVER, TOP, RVP, RVP	
169	1-100-100-70	COVER, TOP, RVP, RVP	
170	1-100-100-71	COVER, TOP, RVP, RVP	
171	1-100-100-72	COVER, TOP, RVP, RVP	
172	1-100-100-73	COVER, TOP, RVP, RVP	
173	1-100-100-74	COVER, TOP, RVP, RVP	
174	1-100-100-75	COVER, TOP, RVP, RVP	
175	1-100-100-76	COVER, TOP, RVP, RVP	
176	1-100-100-77	COVER, TOP, RVP, RVP	
177	1-100-100-78	COVER, TOP, RVP, RVP	
178	1-100-100-79	COVER, TOP, RVP, RVP	
179	1-100-100-80	COVER, TOP, RVP, RVP	
180	1-100-100-81	COVER, TOP, RVP, RVP	
181	1-100-100-82	COVER, TOP, RVP, RVP	
182	1-100-100-83	COVER, TOP, RVP, RVP	
183	1-100-100-84	COVER, TOP, RVP, RVP	
184	1-100-100-85	COVER, TOP, RVP, RVP	
185	1-100-100-86	COVER, TOP, RVP, RVP	
186	1-100-100-87	COVER, TOP, RVP, RVP	
187	1-100-100-88	COVER, TOP, RVP, RVP	


Ref. No.	Ref. No.	Description	Ref. No.
150	1-100-100-1	COVER, TOP, RVP, RVP	
151	1-100-100-2	COVER, TOP, RVP, RVP	
152	1-100-100-3	COVER, TOP, RVP, RVP	
153	1-100-100-4	COVER, TOP, RVP, RVP	
154	1-100-100-5	COVER, TOP, RVP, RVP	
155	1-100-100-6	COVER, TOP, RVP, RVP	
156	1-100-100-7	COVER, TOP, RVP, RVP	
157	1-100-100-8	COVER, TOP, RVP, RVP	
158	1-100-100-9	COVER, TOP, RVP, RVP	
159	1-100-100-10	COVER, TOP, RVP, RVP	
160	1-100-100-11	COVER, TOP, RVP, RVP	
161	1-100-100-12	COVER, TOP, RVP, RVP	
162	1-100-100-13	COVER, TOP, RVP, RVP	
163	1-100-100-14	COVER, TOP, RVP, RVP	
164	1-100-100-15	COVER, TOP, RVP, RVP	
165	1-100-100-16	COVER, TOP, RVP, RVP	
166	1-100-100-17	COVER, TOP, RVP, RVP	
167	1-100-100-18	COVER, TOP, RVP, RVP	
168	1-100-100-19	COVER, TOP, RVP, RVP	
169	1-100-100-20	COVER, TOP, RVP, RVP	
170	1-100-100-21	COVER, TOP, RVP, RVP	
171	1-100-100-22	COVER, TOP, RVP, RVP	
172	1-100-100-23	COVER, TOP, RVP, RVP	
173	1-100-100-24	COVER, TOP, RVP, RVP	
174	1-100-100-25	COVER, TOP, RVP, RVP	
175	1-100-100-26	COVER, TOP, RVP, RVP	
176	1-100-100-27	COVER, TOP, RVP, RVP	
177	1-100-100-28	COVER, TOP, RVP, RVP	
178	1-100-100-29	COVER, TOP, RVP, RVP	
179	1-100-100-30	COVER, TOP, RVP, RVP	
180	1-100-100-31	COVER, TOP, RVP, RVP	
181	1-100-100-32	COVER, TOP, RVP, RVP	
182	1-100-100-33	COVER, TOP, RVP, RVP	
183	1-100-100-34	COVER, TOP, RVP, RVP	
184	1-100-100-35	COVER, TOP, RVP, RVP	
185	1-100-100-36	COVER, TOP, RVP, RVP	
186	1-100-100-37	COVER, TOP, RVP, RVP	
187	1-100-100-38	COVER, TOP, RVP, RVP	

5-1-5. MAIN BOARDS ASSEMBLY




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
201	1-467-649-12	SWITCH BLOCK, CONTROL (FK) (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		* 209	A-7072-000-A	SL-38 BOARD, COMPLETE	
201	1-467-649-31	SWITCH BLOCK, CONTROL (FK) (TR400/TR750)		* 210	3-958-667-01	FRAME (B)	
202	3-713-786-21	SCREW (M2X3)		* 211	3-958-928-01	PLATE, SHIELD, RP	
* 203	3-958-925-01	CASE (MAIN), SHIELD, DD		212	1-651-891-11	FP-52 FLEXIBLE BOARD (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
* 204	A-7063-954-A	DD-66 BOARD, COMPLETE (TR42/TR82/TR550)		212	1-651-892-11	FP-53 FLEXIBLE BOARD (TR400/TR750)	
* 204	A-7063-960-A	DD-60 BOARD, COMPLETE (TR72/TR400/TR430/TR750)		* 213	3-958-345-01	FRAME (U)	
* 204	A-7066-006-A	DD-66 BOARD, COMPLETE (TR70)		* 214	X-3943-976-1	SHIELD (MAIN) ASSY, RP	
* 204	A-7066-009-A	DD-60 BOARD, COMPLETE (TR80)		* 215	3-958-924-01	CASE (LID), SHIELD, RP	
* 205	A-7063-953-A	VS-112 BOARD, COMPLETE (TR82)		* 216	A-7063-955-A	VC-145 BOARD, COMPLETE (TR82)	
* 205	A-7063-959-A	VS-104 BOARD, COMPLETE (TR72)		* 216	A-7063-961-A	VC-138 BOARD, COMPLETE (TR72/TR430)	
* 205	A-7066-008-A	VS-104 BOARD, COMPLETE (TR80)		* 216	A-7066-007-A	VC-145 BOARD, COMPLETE (TR70)	
* 205	A-7066-019-A	VS-112 BOARD, COMPLETE (TR70)		* 216	A-7066-018-A	VC-138 BOARD, COMPLETE (TR80)	
* 205	A-7066-047-A	VS-112 (LL) BOARD, COMPLETE (TR42)		* 216	A-7066-080-A	VC-138 BOARD, COMPLETE (TR400/TR750)	
* 205	A-7066-079-A	VS-104 (H) BOARD, COMPLETE (TR400)		* 216	A-7066-084-A	VC-145 BOARD, COMPLETE (TR42)	
* 205	A-7066-085-A	VS-112 BOARD, COMPLETE (TR550)		* 216	A-7066-088-A	VC-145 BOARD, COMPLETE (TR550)	
* 205	A-7066-086-A	VS-104 BOARD, COMPLETE (TR430)		217	A-7066-078-A	HE-14 BOARD, COMPLETE (TR400/TR750)	
* 205	A-7066-134-A	VS-104 (H) BOARD, COMPLETE (TR750)		220	X-3944-169-1	SHIELD (LID) ASSY, DD	
* 206	A-7072-002-A	ZB-2 BOARD, COMPLETE		W500	1-651-889-11	FP-48 (SL) FLEXIBLE BOARD	
207	3-958-341-01	COVER, LS		W501	1-642-186-11	FP-437 FLEXIBLE BOARD	
208	1-691-471-11	CONNECTOR, TRANSLATION 11P					

5-1-8 MAIN SCAPER ASSEMBLY



Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
1	1-401-440-12	SCAPER HEAD, CARTRIDGE	1	1	1-401-440-12	SCAPER HEAD, CARTRIDGE	1
2	1-401-440-13	SCAPER HEAD, CARTRIDGE	1	2	1-401-440-13	SCAPER HEAD, CARTRIDGE	1
3	1-401-440-14	SCAPER HEAD, CARTRIDGE	1	3	1-401-440-14	SCAPER HEAD, CARTRIDGE	1
4	1-401-440-15	SCAPER HEAD, CARTRIDGE	1	4	1-401-440-15	SCAPER HEAD, CARTRIDGE	1
5	1-401-440-16	SCAPER HEAD, CARTRIDGE	1	5	1-401-440-16	SCAPER HEAD, CARTRIDGE	1
6	1-401-440-17	SCAPER HEAD, CARTRIDGE	1	6	1-401-440-17	SCAPER HEAD, CARTRIDGE	1
7	1-401-440-18	SCAPER HEAD, CARTRIDGE	1	7	1-401-440-18	SCAPER HEAD, CARTRIDGE	1
8	1-401-440-19	SCAPER HEAD, CARTRIDGE	1	8	1-401-440-19	SCAPER HEAD, CARTRIDGE	1
9	1-401-440-20	SCAPER HEAD, CARTRIDGE	1	9	1-401-440-20	SCAPER HEAD, CARTRIDGE	1
10	1-401-440-21	SCAPER HEAD, CARTRIDGE	1	10	1-401-440-21	SCAPER HEAD, CARTRIDGE	1
11	1-401-440-22	SCAPER HEAD, CARTRIDGE	1	11	1-401-440-22	SCAPER HEAD, CARTRIDGE	1
12	1-401-440-23	SCAPER HEAD, CARTRIDGE	1	12	1-401-440-23	SCAPER HEAD, CARTRIDGE	1
13	1-401-440-24	SCAPER HEAD, CARTRIDGE	1	13	1-401-440-24	SCAPER HEAD, CARTRIDGE	1
14	1-401-440-25	SCAPER HEAD, CARTRIDGE	1	14	1-401-440-25	SCAPER HEAD, CARTRIDGE	1
15	1-401-440-26	SCAPER HEAD, CARTRIDGE	1	15	1-401-440-26	SCAPER HEAD, CARTRIDGE	1
16	1-401-440-27	SCAPER HEAD, CARTRIDGE	1	16	1-401-440-27	SCAPER HEAD, CARTRIDGE	1
17	1-401-440-28	SCAPER HEAD, CARTRIDGE	1	17	1-401-440-28	SCAPER HEAD, CARTRIDGE	1
18	1-401-440-29	SCAPER HEAD, CARTRIDGE	1	18	1-401-440-29	SCAPER HEAD, CARTRIDGE	1
19	1-401-440-30	SCAPER HEAD, CARTRIDGE	1	19	1-401-440-30	SCAPER HEAD, CARTRIDGE	1
20	1-401-440-31	SCAPER HEAD, CARTRIDGE	1	20	1-401-440-31	SCAPER HEAD, CARTRIDGE	1
21	1-401-440-32	SCAPER HEAD, CARTRIDGE	1	21	1-401-440-32	SCAPER HEAD, CARTRIDGE	1
22	1-401-440-33	SCAPER HEAD, CARTRIDGE	1	22	1-401-440-33	SCAPER HEAD, CARTRIDGE	1
23	1-401-440-34	SCAPER HEAD, CARTRIDGE	1	23	1-401-440-34	SCAPER HEAD, CARTRIDGE	1
24	1-401-440-35	SCAPER HEAD, CARTRIDGE	1	24	1-401-440-35	SCAPER HEAD, CARTRIDGE	1
25	1-401-440-36	SCAPER HEAD, CARTRIDGE	1	25	1-401-440-36	SCAPER HEAD, CARTRIDGE	1
26	1-401-440-37	SCAPER HEAD, CARTRIDGE	1	26	1-401-440-37	SCAPER HEAD, CARTRIDGE	1
27	1-401-440-38	SCAPER HEAD, CARTRIDGE	1	27	1-401-440-38	SCAPER HEAD, CARTRIDGE	1


5-1-6. CCD BLOCK ASSEMBLY



Be sure to read "Note on the CCD Imager replacement" on page 4-6 when changing the CCD imager.


Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251	3-719-381-01	SCREW (M2X4)		264	1-547-529-21	FILTER BLOCK, OPTICAL (TR82/TR400/TR550/TR750)	
252	3-947-268-01	SCREW (B TIGHT) (2), TAPPING		264	1-547-558-21	FILTER BLOCK, OPTICAL (TR42/TR70/TR72/TR80/TR430)	
* 253	3-958-587-01	FRAME (PJ)		265	3-946-857-01	RUBBER (S), SEAL	
254	3-958-310-11	HOLDER, TRIPOD		* 266	A-7072-004-A	FP-89 (CD) BOARD, COMPLETE (TR82/TR400/TR550/TR750)	
255	3-958-286-01	SHEET METAL, TRIPOD		* 266	A-7072-005-A	FP-89 (CD) BOARD, COMPLETE (TR42/TR70/TR72/TR80/TR430)	
256	3-713-786-21	SCREW (M2X3)		* 267	3-959-368-01	CUSHION, CABINET (R) (TR400/TR430/TR550/TR750)	
257	1-651-890-11	FP-49 FLEXIBLE BOARD (TR82/TR400/TR550/TR750)		J201	1-537-731-11	TERMINAL BOARD (TR42/TR70/TR82/TR550)	
* 258	3-958-666-01	FRAME (L)		J201	1-537-731-21	TERMINAL BOARD (TR72/TR80/TR430)	
259	3-948-339-01	SCREW (BTP) (2X5), HEAD		J201	1-537-731-31	TERMINAL BOARD (TR400/TR750)	
260	1-765-361-11	CABLE, FLAT (FFC-115) (TR72/TR80/TR400/TR430/TR750)		IC691	A-7030-368-A	CCD BLOCK ASSY (AUTO) (054 SERVICE) (CCD IMAGER) (TR42/TR70/TR72/TR80/TR430)	
260	1-765-362-11	CABLE, FLAT (FFC-134) (TR42/TR70/TR82/TR550)		IC691	A-7030-373-A	CCD BLOCK ASSY (AUTO) (059V SERVICE) (CCD IMAGER) (TR82/TR400/TR550/TR750)	
* 261	A-7063-952-A	AU-169 BOARD, COMPLETE (TR42/TR70/TR82/TR550)		SE691	1-810-024-31	SENSOR, ANGULAR VELOCITY (PITCH) (TR82/TR400/TR550/TR750)	
* 261	A-7063-958-A	AU-165 BOARD, COMPLETE (TR72/TR80/TR400/TR430/TR750)		SE692	1-810-024-41	SENSOR, ANGULAR VELOCITY (YAW) (TR82/TR400/TR550/TR750)	
262	1-547-716-11	LENS, ZOOM (VCL-5412WA) (TYPE II)					
262	8-848-704-01	DEVICE, LENS LSV-140A (TYPE I)					
263	3-946-856-01	ADAPTOR (H), CCD FITTING					

5-1-7. ZOOM LENS ASSEMBLIES (LSV-140A) (VCL-5412WA)





TYPE I

Ref. No.	Part No.	Description
301	8-848-704-01	DEVICE, LENS (LSV-140A) (TYPE I)
302	A-4910-598-A	DEVICE ASSY, LSV-140A (RP)
303	A-4915-338-A	FLEXIBLE, MOUNT
304	3-713-791-41	SCREW (M1.7X5), TAPPING, P2
M905	1-698-364-01	MOTOR ASSY, FOCUS
M906	1-698-363-01	MOTOR ASSY, ZOOM



TYPE II

Ref. No.	Part No.	Description	Remark
351	1-547-716-11	LENS, ZOOM (VCL-5412WA) (TYPE II)	
352	3-708-891-01	DEVICE ASSY	
353	3-708-890-01	FLEXIBLE BOARD, MAIN	
354	3-708-302-01	SCREW (BT3 P1.7X4C)	
355	3-708-886-01	COVER, IG	
M907	3-708-888-01	METER, IG	
M908	3-708-889-01	MOTOR ASSY, FOCUS	
M909	3-708-887-01	MOTOR ASSY, ZOOM	




TYPE 1

Part No.	Part No.	Description	Amount
100	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
200	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
300	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
400	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
500	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1

TYPE 2


Part No.	Part No.	Description	Amount
100	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
200	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
300	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
400	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1
500	1-000-000-01	MOTOR, 1000 RPM (2000 RPM)	1

5-1-8. CASSETTE COMPARTMENT ASSEMBLY



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
701	A-7040-312-K	CASSETTE COMPARTMENT BLOCK ASSY		707	A-7040-309-A	PROTECT (BASE) BLOCK ASSY	
702	3-945-773-01	BAR, TORSION		708	3-945-760-01	SPRING, TENSION	
703	3-945-771-01	SPRING, TORSION		709	3-321-393-01	WASHER, STOPPER	
704	X-3941-287-2	DAMPER ASSY		710	X-3166-813-1	ROLLER ASSY, HC	
705	3-315-384-31	WASHER, STOPPER		711	X-3941-280-1	RETAINER ASSY, GOOSENECK	
706	3-947-503-01	SCREW (M1.4X2.5)		712	3-945-733-01	COVER, CAPSTAN	


8-1-6 CIGARETTE COMPARTMENT ASSEMBLY



Ref. No.	Part No.	Description	Mount
700	1-100-100-0	CIGARETTE COMPARTMENT ASSEMBLY	
701	1-100-100-1	LID	
702	1-100-100-2	HINGE	
703	1-100-100-3	LATCH	
704	1-100-100-4	MAIN BODY	
705	1-100-100-5	HINGE	
706	1-100-100-6	LATCH	
707	1-100-100-7	BOTTOM SECTION	
708	1-100-100-8	CIGARETTE HOLDER	
709	1-100-100-9	ASHTRAY	

Ref. No.	Part No.	Description	Mount
710	1-100-100-10	SMOKE DETECTOR	
711	1-100-100-11	SMOKE DETECTOR	
712	1-100-100-12	SMOKE DETECTOR	
713	1-100-100-13	SMOKE DETECTOR	
714	1-100-100-14	SMOKE DETECTOR	
715	1-100-100-15	SMOKE DETECTOR	
716	1-100-100-16	SMOKE DETECTOR	
717	1-100-100-17	SMOKE DETECTOR	
718	1-100-100-18	SMOKE DETECTOR	
719	1-100-100-19	SMOKE DETECTOR	

5-1-9. LS CHASSIS ASSEMBLY



Note on FP-443

The FP-443 part, a component of the No. 776 LS chassis assembly, is attached by hot-pressing, and it requires high mounting precision. Therefore, it will not be supplied as a separate part.

Ref.No. Part No. Description

751	X-3941-274-1	TABLE ASSY, REEL, T
752	3-331-007-21	WASHER
753	X-3941-271-5	ARM ASSY, PINCH
754	3-945-743-01	SPRING, TORSION
755	3-945-783-01	SPRING, TENSION
756	A-7040-307-A	GUIDE (BASE) (T) BLOCK ASSY
757	X-3941-424-1	ROLLER ASSY, TG6
758	3-947-504-01	SCREW (M1.2X2)
759	X-3941-267-1	ARM (T) ASSY, GUIDE
760	3-669-465-00	WASHER (1.5), STOPPER
761	X-3941-273-1	SOFT ASSY, T
762	3-945-753-01	ARM, T SOFT
763	3-726-829-01	WASHER, STOPPER
764	X-3941-279-5	GEAR ASSY, GOOSENECK
765	3-947-644-01	RETAINER, TG5 (BASE)
766	A-7040-321-A	CLAW BLOCK ASSY, T HARD
767	X-3943-676-1	TABLE ASSY, S REEL


Remark

Ref.No. Part No. Description

768	3-945-756-01	SCREW (M1.4X3)
769	X-3941-277-1	STRING BLOCK ASSY
770	3-945-801-01	BRAKE, S SOFT
771	3-954-327-01	SPRING, TENSION
772	X-3941-276-1	TG1 ASSY
773	3-945-752-01	SPRING, TORSION
774	3-945-799-01	BRAKE, S HARD
775	3-947-503-01	SCREW (M1.4X2.5)
776	X-3943-307-1	CHASSIS ASSY, LS
777	3-945-784-01	PLATE, CAM, LS
778	A-7040-306-A	GUIDE (BASE) (S) BLOCK ASSY
779	X-3941-269-1	ROLLER ASSY, TG3
780	X-3941-266-1	ARM (S) ASSY, GUIDE
781	3-945-837-01	SLIDER, GL
782	3-949-881-01	SLEEVE
S002	1-572-987-11	SWITCH, PUSH (3 KEY)

(REC PROOF, ME/MP, MP/MP-HG)

8-15. LA CHASSIS ASSEMBLY



Note on PP-445

The PP-445 part, a component of the for 750 LA chassis assembly, is electrically insulating and provides high mounting position. Therefore, it will not be supplied as a separate part.

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description	Ref. No.
751	1-100-100-01	SCREW, 1/4" DIA., 1/2" L.	761	1-100-100-01	SCREW, 1/4" DIA., 1/2" L.	761
752	1-100-100-02	SCREW, 1/4" DIA., 1/2" L.	762	1-100-100-02	SCREW, 1/4" DIA., 1/2" L.	762
753	1-100-100-03	SCREW, 1/4" DIA., 1/2" L.	763	1-100-100-03	SCREW, 1/4" DIA., 1/2" L.	763
754	1-100-100-04	SCREW, 1/4" DIA., 1/2" L.	764	1-100-100-04	SCREW, 1/4" DIA., 1/2" L.	764
755	1-100-100-05	SCREW, 1/4" DIA., 1/2" L.	765	1-100-100-05	SCREW, 1/4" DIA., 1/2" L.	765
756	1-100-100-06	SCREW, 1/4" DIA., 1/2" L.	766	1-100-100-06	SCREW, 1/4" DIA., 1/2" L.	766
757	1-100-100-07	SCREW, 1/4" DIA., 1/2" L.	767	1-100-100-07	SCREW, 1/4" DIA., 1/2" L.	767
758	1-100-100-08	SCREW, 1/4" DIA., 1/2" L.	768	1-100-100-08	SCREW, 1/4" DIA., 1/2" L.	768
759	1-100-100-09	SCREW, 1/4" DIA., 1/2" L.	769	1-100-100-09	SCREW, 1/4" DIA., 1/2" L.	769
760	1-100-100-10	SCREW, 1/4" DIA., 1/2" L.	770	1-100-100-10	SCREW, 1/4" DIA., 1/2" L.	770
761	1-100-100-11	SCREW, 1/4" DIA., 1/2" L.	771	1-100-100-11	SCREW, 1/4" DIA., 1/2" L.	771
762	1-100-100-12	SCREW, 1/4" DIA., 1/2" L.	772	1-100-100-12	SCREW, 1/4" DIA., 1/2" L.	772
763	1-100-100-13	SCREW, 1/4" DIA., 1/2" L.	773	1-100-100-13	SCREW, 1/4" DIA., 1/2" L.	773
764	1-100-100-14	SCREW, 1/4" DIA., 1/2" L.	774	1-100-100-14	SCREW, 1/4" DIA., 1/2" L.	774
765	1-100-100-15	SCREW, 1/4" DIA., 1/2" L.				
766	1-100-100-16	SCREW, 1/4" DIA., 1/2" L.				
767	1-100-100-17	SCREW, 1/4" DIA., 1/2" L.				
768	1-100-100-18	SCREW, 1/4" DIA., 1/2" L.				
769	1-100-100-19	SCREW, 1/4" DIA., 1/2" L.				
770	1-100-100-20	SCREW, 1/4" DIA., 1/2" L.				
771	1-100-100-21	SCREW, 1/4" DIA., 1/2" L.				
772	1-100-100-22	SCREW, 1/4" DIA., 1/2" L.				
773	1-100-100-23	SCREW, 1/4" DIA., 1/2" L.				
774	1-100-100-24	SCREW, 1/4" DIA., 1/2" L.				

SECTION 6

INTERFACES • IC PIN

6-1. CAMERA CONTROL MICRO PROCESSOR PIN FUNCTION (VC BOARD IC602: SC424608 MC68HC11MA8FU)

Pin No.	Signal Name	I/O	Function
1	VTR SI	I	Serial data input from mode control microprocessor (VS board IC503).
2	VTR SCK	I	Serial data transfer clock from/to mode control microprocessor.
3	CAM CS	I	Chip select signal from mode control microprocessor.
4			Not used.
5			
6			
7			
8			
9	PBV	I	V sync signal from servo/mechanism control microprocessor (VS board IC505).
10			Not used (connected to +3.6V).
11			
12	VDD		+3.6V power supply.
13	VSS		GND
14	CS TG	O	Chip select signal to timing generator (IC702).
15			Not used (connected to +3.6V).
16	START	O	Operation signal of IC705. Normally "L". "H" during operation.
17	WEN	I	Write enable signal from timing generator (IC702). Normally "H".
18			Not used.
19	CS VST	O	Chip select signal to steady shot control microprocessor (IC777).
20	CS CORE	O	Chip select signal to camera core (IC609).
21	EEPROM BUSY	I	BUSY signal from EEPROM (IC601). Normally "H". "L" during data read/write.
22			Not used.
23	IRIS PWM	O	Iris control signal.
24			Not used.
25			
26	TESTX	O	Test signal of IC705. "H": Camera mode, "L": Test/VTR mode.
27	LENS RST LED	O	Lens reset sensor LED ON/OFF. "H": ON, "L": OFF.
28	FC RST	I	Lens focus reset sensor signal input.
29	ZM RST	I	Lens zoom reset sensor signal input.
30	XIRQ		Connected to +3.6V.
31	VDD		+3.6V power supply.
32	VSS		GND
33			Not used.
34			
35			
36	CAM SCK	O	Serial data transfer clock.
37	CAM SO	O	Serial data output.
38	CAM SI	I	Serial data input.
39			Not used.
40			

Pin No.	Signal Name	I/O	Function
41	VDD		+3.6V power supply.
42	GENERAL A/D	I	Camera core (IC609) discrimination signal input.
43	LENS TYPE	I	Lens type discrimination signal input.
44	ZOOM SW	I	Zoom key signal input. When not pressed: 1.8V, TELE 1: 2.7V, TELE 2: 3.6V, WIDE 1: 0.9V, WIDE 2: 0V.
45	MAN FOCUS (2)	I	Manual focus dial signal (2) input. 0V to 3.4V depending on the dial turning.
46	MAN FOCUS (1)	I	Manual focus dial signal (1) input. 0V to 3.4V depending on the dial turning.
47			Not used. Connected to GND.
48			
49	HALL A/D	I	Hall voltage. Approx. 1V (iris opened) to approx. 3.5V (iris closed).
50	VRL	I	Connected to GND.
51	VRH	I	Connected to +3.6V.
52	VSS		GND
53	CS EEPROM	O	Chip select signal to EEPROM (IC601).
54	CS CAM OPD	O	Chip select signal to OPD (IC611).
55	D/A STB	O	Strobe signal to camera EVR (IC603).
56	EEPROM RESET	O	EEPROM (IC601) write disable signal. Normally "H".
57	CS AF OPD	O	Chip select signal to AF OPD (IC611).
58	CS PDR	O	Chip select signal to pre-driver (IC753).
59	CAM ON	O	A/D converter (IC704) ON/OFF signal. Normally "H".
60	NTSC	O	"L": NTSC, "H": PAL.
61	IRQ	I	Connected to +3.6V.
62			Not used.
63			
64	PDR RST	O	Reset signal to zoom/focus pre-driver (IC753). "H": Camera mode, "L": VTR mode.
65	NRML/VST	O	"H": Steady shot operation, "L": Normal operation.
66	VST/CORE RST	O	Reset signal to steady shot control microprocessor (IC777) and camera core (IC609). Normally "H". "L": Reset.
67	OPD RST	O	Reset signal to IC611 and IC705. "H": Camera mode, "L": VTR mode.
68			Not used. Connected to GND.
69			
70	VSS		GND
71	VDD		+3.6V power supply.
72			Not used.
73	EXTAL	I	24 MHz clock oscillation circuit.
74	XTAL	O	
75	RESET	I	Reset signal from mode control microprocessor (VS board IC503). Normally "H". "L": Reset.
76	MODB		Connected to +3.6V.
77	MODA		Connected to GND.
78	RXD		Not used.
79	TXD		
80	VTR SO	O	Serial data output to mode control microprocessor (VS board IC503).

SECTION 8
INTERFACES - IC PIN

8-1. CAMERA CONTROL, MICRO PROCESSOR PIN FUNCTION
(IC BOARD CODE: BOARD# 8084C111A000)

Pin #	Signal Name	Signal Description
1	VCC	Supply Voltage
2	GND	Ground
3	DATA	Data Bus
4	DATA	Data Bus
5	DATA	Data Bus
6	DATA	Data Bus
7	DATA	Data Bus
8	DATA	Data Bus
9	DATA	Data Bus
10	DATA	Data Bus
11	DATA	Data Bus
12	DATA	Data Bus
13	DATA	Data Bus
14	DATA	Data Bus
15	DATA	Data Bus
16	DATA	Data Bus
17	DATA	Data Bus
18	DATA	Data Bus
19	DATA	Data Bus
20	DATA	Data Bus
21	DATA	Data Bus
22	DATA	Data Bus
23	DATA	Data Bus
24	DATA	Data Bus
25	DATA	Data Bus
26	DATA	Data Bus
27	DATA	Data Bus
28	DATA	Data Bus
29	DATA	Data Bus
30	DATA	Data Bus
31	DATA	Data Bus
32	DATA	Data Bus
33	DATA	Data Bus
34	DATA	Data Bus
35	DATA	Data Bus
36	DATA	Data Bus
37	DATA	Data Bus
38	DATA	Data Bus
39	DATA	Data Bus
40	DATA	Data Bus
41	DATA	Data Bus
42	DATA	Data Bus
43	DATA	Data Bus
44	DATA	Data Bus
45	DATA	Data Bus
46	DATA	Data Bus
47	DATA	Data Bus
48	DATA	Data Bus
49	DATA	Data Bus
50	DATA	Data Bus
51	DATA	Data Bus
52	DATA	Data Bus
53	DATA	Data Bus
54	DATA	Data Bus
55	DATA	Data Bus
56	DATA	Data Bus
57	DATA	Data Bus
58	DATA	Data Bus
59	DATA	Data Bus
60	DATA	Data Bus
61	DATA	Data Bus
62	DATA	Data Bus
63	DATA	Data Bus
64	DATA	Data Bus
65	DATA	Data Bus
66	DATA	Data Bus
67	DATA	Data Bus
68	DATA	Data Bus
69	DATA	Data Bus
70	DATA	Data Bus
71	DATA	Data Bus
72	DATA	Data Bus
73	DATA	Data Bus
74	DATA	Data Bus
75	DATA	Data Bus
76	DATA	Data Bus
77	DATA	Data Bus
78	DATA	Data Bus
79	DATA	Data Bus
80	DATA	Data Bus
81	DATA	Data Bus
82	DATA	Data Bus
83	DATA	Data Bus
84	DATA	Data Bus
85	DATA	Data Bus
86	DATA	Data Bus
87	DATA	Data Bus
88	DATA	Data Bus
89	DATA	Data Bus
90	DATA	Data Bus
91	DATA	Data Bus
92	DATA	Data Bus
93	DATA	Data Bus
94	DATA	Data Bus
95	DATA	Data Bus
96	DATA	Data Bus
97	DATA	Data Bus
98	DATA	Data Bus
99	DATA	Data Bus
100	DATA	Data Bus

Pin #	Signal Name	Signal Description
1	VCC	Supply Voltage
2	GND	Ground
3	DATA	Data Bus
4	DATA	Data Bus
5	DATA	Data Bus
6	DATA	Data Bus
7	DATA	Data Bus
8	DATA	Data Bus
9	DATA	Data Bus
10	DATA	Data Bus
11	DATA	Data Bus
12	DATA	Data Bus
13	DATA	Data Bus
14	DATA	Data Bus
15	DATA	Data Bus
16	DATA	Data Bus
17	DATA	Data Bus
18	DATA	Data Bus
19	DATA	Data Bus
20	DATA	Data Bus
21	DATA	Data Bus
22	DATA	Data Bus
23	DATA	Data Bus
24	DATA	Data Bus
25	DATA	Data Bus
26	DATA	Data Bus
27	DATA	Data Bus
28	DATA	Data Bus
29	DATA	Data Bus
30	DATA	Data Bus
31	DATA	Data Bus
32	DATA	Data Bus
33	DATA	Data Bus
34	DATA	Data Bus
35	DATA	Data Bus
36	DATA	Data Bus
37	DATA	Data Bus
38	DATA	Data Bus
39	DATA	Data Bus
40	DATA	Data Bus
41	DATA	Data Bus
42	DATA	Data Bus
43	DATA	Data Bus
44	DATA	Data Bus
45	DATA	Data Bus
46	DATA	Data Bus
47	DATA	Data Bus
48	DATA	Data Bus
49	DATA	Data Bus
50	DATA	Data Bus
51	DATA	Data Bus
52	DATA	Data Bus
53	DATA	Data Bus
54	DATA	Data Bus
55	DATA	Data Bus
56	DATA	Data Bus
57	DATA	Data Bus
58	DATA	Data Bus
59	DATA	Data Bus
60	DATA	Data Bus
61	DATA	Data Bus
62	DATA	Data Bus
63	DATA	Data Bus
64	DATA	Data Bus
65	DATA	Data Bus
66	DATA	Data Bus
67	DATA	Data Bus
68	DATA	Data Bus
69	DATA	Data Bus
70	DATA	Data Bus
71	DATA	Data Bus
72	DATA	Data Bus
73	DATA	Data Bus
74	DATA	Data Bus
75	DATA	Data Bus
76	DATA	Data Bus
77	DATA	Data Bus
78	DATA	Data Bus
79	DATA	Data Bus
80	DATA	Data Bus
81	DATA	Data Bus
82	DATA	Data Bus
83	DATA	Data Bus
84	DATA	Data Bus
85	DATA	Data Bus
86	DATA	Data Bus
87	DATA	Data Bus
88	DATA	Data Bus
89	DATA	Data Bus
90	DATA	Data Bus
91	DATA	Data Bus
92	DATA	Data Bus
93	DATA	Data Bus
94	DATA	Data Bus
95	DATA	Data Bus
96	DATA	Data Bus
97	DATA	Data Bus
98	DATA	Data Bus
99	DATA	Data Bus
100	DATA	Data Bus

6-2. STEADY SHOT CONTROL MICRO PROCESSOR PIN FUNCTION (VC BOARD IC777: CXP87132-010R) (CCD-TR82/TR400/TR550/TR750)

Pin No.	Signal Name	I/O	Function
1	MPX	O	Not used.
2	ADC STBY	O	Standby output to A/D converter (IC776). Normally "H".
3	C RESET	O	Reset signal to PITCH/YAW sensor amplifier (IC772 to IC774) in initializing. Normally "L".
4	PB0/PP08	O	Not used.
5	PC7/RT07	O	
6	PC6/RT06	O	
7	PC5/RT05	O	
8	PC4/RT04	O	
9	PC3/RT03	O	
10	PC2/PP018	O	
11	PC1/PP017	O	
12	PC0/PP016	O	
13	P17	O	
14	P16	O	
15	P15	O	
16	P14	O	
17	P13	O	
18	P12	O	
19	P11	O	
20	P10	O	
21	PD7	O	
22	PD6	O	Not used.
23	PD5	O	
24	PD4	O	
25	PD3	O	
26	PD2	O	
27	PD1	O	
28	PD0	O	
29	PH7	O	
30	PH6	O	
31	PH5	O	
32	PH4	O	
33	PH3	O	
34	PH2	O	
35	PH1	O	
36	PH0	O	
37	MP	I	Connected to GND.
38	VST RST	I	Reset signal from camera microprocessor (IC602). Normally "H".
39	VSS		GND. Connected to GND.
40	XTAL	O	Connected to 12 MHz crystal oscillator.

Pin No.	Signal Name	I/O	Function
41	EXTAL	I	Connected to 12 MHz crystal oscillator.
42	CS VISTA MICOM	I	Chip select signal from camera microprocessor (IC602).
43	S IN	I	Serial data input from camera microprocessor (IC602).
44	S OUT	O	Serial data output to camera microprocessor (IC602).
45	CAM SCK	I	Serial data transfer clock from/to camera microprocessor (IC602).
46	PF7/AN11	O	Not used.
47	PF6/AN10	O	
48	PF5/AN9	O	
49	PF4/AN8	O	
50	AVSS		A/D port GND. Connected to GND.
51	AVREF	I	A/D port reference voltage input. Connected to +3.6V.
52	AVDD		A/D port positive power supply. Connected to +3.6V.
53	PF3/AN7	I	Not used. Connected to +3.6V.
54	PF2/AN6	I	
55	PF1/AN5	I	
56	PF0/AN4	I	
57	AN3	I	
58	AN2	I	
59	AN1	I	Not used. Connected to GND.
60	AN0	I	
61	PG7/EX11	I	Not used. Connected to GND.
62	CGV	I	V SYNC from sync generator (IC610).
63	FLD	I	FLD signal from sync generator (IC610).
64	PG4/SYNC0	I	Not used. Connected to GND.
65	PG3/PBCTL	I	
66	PG2/DPG	I	
67	PG1/DRG	I	
68	PG0/CFG	I	Not used.
69	PE7/DAB1	O	
70	PE6/DAB0	O	
71	PE5/DAA1	O	Not used.
72	PE4/DAA0	O	
73	PE3/PWM1	O	
74	PE2/PWM0	O	
75	PE1/INT2	I	Not used. Connected to +3.6V.
76	PE0/INT0	I	
77	VST SI	I	Serial data input.
78	VST SO	O	Serial data output.
79	VST SCK	O	Serial data transfer clock.
80	P14/INT1	O	Not used.


6-3. CAMERA CORE PIN FUNCTION
(VC BOARD IC609: CXD2150R) (TR42/TR70/TR72/TR80/TR82/TR430)
(VC BOARD IC609: CXD2150AR) (TR400/TR550/TR750)

Pin No.	Signal Name	I/O	Function
81	P13/T0	O	Not used.
82	P12/PWM	O	
83	P11/P0	O	
84	P10/PCK	I	Not used. Connected to +3.6V.
85	PKO	I	
86	GND		GND
87	VDD		+3.6V power supply.
88	VPP		Connected to +3.6V.
89	(CS_DISP)	O	Not used.
90	PA0/PPO6	O	
91	/CS_ADC	O	Chip select signal to A/D converter (IC776).
92	/CS_ZTG	O	Chip select signal to timing generator (IC702).
93	/CS_ZVST	O	Chip select signal to IC613.
94	PA2/PPO2	O	Not used.
95	PA1/PPO1	O	
96	PA0/PPO0	O	
97	PB7/PPO15	O	
98	PB6/PPO14	O	
99	PB5/PPO13	O	
100	PB4/PPO12	O	

Pin No.	Signal Name	I/O	Function
1	OPD6	O	OPD (IC611) data output.
2	OPD5	O	OPD data output.
3	OPD4	O	OPD data output.
4	OPD3	O	OPD data output.
5	OPD2	O	OPD data output.
6	OPD1	O	OPD data output.
7	OPD0	O	OPD data output, LSB.
8	OPDID	O	OPD line discrimination signal.
9	VDD	—	Power supply (+3.6V).
10	CO3	O	C signal output, MSB (CCD-TR82/TR400/TR550).
11	CO2	O	C signal output (CCD-TR82/TR400/TR550).
12	CO1	O	C signal output (CCD-TR82/TR400/TR550).
13	CO0	O	C signal output, LSB (CCD-TR82/TR400/TR550).
14	VSS	—	GND
15	CI3	I	C signal input, MSB (CCD-TR82/TR400/TR550).
16	CI2	I	C signal input (CCD-TR82/TR400/TR550).
17	CI1	I	C signal input (CCD-TR82/TR400/TR550).
18	CI0	I	C signal input, LSB (CCD-TR82/TR400/TR550).
19	NRB	O	C signal. Color discrimination signal.
20	VDD	—	+3.6V power supply.
21	VBC		Connected to GND via 0.1 μ F capacitor.
22	AVSC		GND
23	IREFC		Connected to GND via 12 k Ω resistor.
24	VREFC	I	Full scale output value setting voltage.
25	VGC		Connected to +3.6V power supply via 0.1 μ F capacitor.
26	AVDC		+3.6V power supply.
27	IOC	O	Chroma signal output (Current output).
28	VDD	—	Y I/F power supply (+3.6V).
29	DICK	O	Memory interface reference clock (CCD-TR82/TR400/TR550).
30	CDIS	O	Digital output (chroma) color discrimination signal (CCD-TR82/TR400/TR550).
31	YO7	O	Y signal output, MSB (CCD-TR82/TR400/TR550).
32	YO6	O	Y signal output (CCD-TR82/TR400/TR550).
33	YO5	O	Y signal output (CCD-TR82/TR400/TR550).
34	YO4	O	Y signal output (CCD-TR82/TR400/TR550).
35	YO3	O	Y signal output (CCD-TR82/TR400/TR550).
36	YO2	O	Y signal output (CCD-TR82/TR400/TR550).
37	YO1	O	Y signal output (CCD-TR82/TR400/TR550).
38	YO0	O	Y signal output, LSB (CCD-TR82/TR400/TR550).
39	DATS	I	DA test pin. (Normally fixed at "L".)
40	Y17	I	Y signal input, MSB (CCD-TR82/TR400/TR550).

Pin No.	Signal Name	I/O	Function
41	Y16	I	Y signal input (CCD-TR82/TR400/TR550).
42	Y15	I	Y signal input (CCD-TR82/TR400/TR550).
43	Y14	I	Y signal input (CCD-TR82/TR400/TR550).
44	Y13	I	Y signal input (CCD-TR82/TR400/TR550).
45	Y12	I	Y signal input (CCD-TR82/TR400/TR550).
46	Y11	I	Y signal input (CCD-TR82/TR400/TR550).
47	Y10	I	Y signal input, LSB (CCD-TR82/TR400/TR550).
48	VSS	—	GND
49	IOY	O	Y signal output (current output).
50	AVDY		+3.6V power supply.
51	VGy		Connected to +3.6V power supply via 0.1 μ F capacitor.
52	VRFY	I	Full scale output value setting voltage.
53	IRFY		Connected to GND via 12 k Ω resistor.
54	AVSY		GND
55	VBY		Connected to GND via 0.1 μ F capacitor.
56	VDD	—	+3.6V power supply
57	BIN	I	Not used.
58	GIN	I	Not used.
59	RIN	I	Not used.
60	TIKEY	I	Not used.
61	WKEY	I	Wide ID signal input.
62	VCK	I	PAL 4 fsc modulation clock.
63	VHLD	I	Mosaic processing vertical hold control signal.
64	HHLd	I	Mosaic processing horizontal hold control signal.
65	CSYN	I	Sync signal (SYNC) input.
66	LALT	I	PAL line modulation inverted signal input.
67	CBK	I	Blanking signal (CBLK) input.
68	BF	I	Burst added signal input.
69	HD	I	Horizontal sync signal (HD) input.
70	VD	I	Vertical sync signal (VD) input.
71	AJST	I	Data sampling pulse input.
72	VDD	—	+3.6V power supply.
73	SCK	I	Serial interface clock input from camera microprocessor (IC602).
74	SI	I	Serial interface data input from camera microprocessor.
75	XCE	I	Serial interface enable input from camera microprocessor.
76	SO	O	Serial interface data output to camera microprocessor.
77	VSS	—	GND
78	CLK	I	Clock input.
79	DEF	I	Defect compensation position pulse.
80	ID	I	Color line discrimination signal.

Pin No.	Signal Name	I/O	Function
81	MCK	I	Main clock input.
82	VDD	—	+3.6V power supply.
83	XLCL	I	All clear input.
84	VDD	—	AD I/F power supply (+3.6V).
85	ADCK	O	AD converter clock output. Not used.
86	VSS	—	GND
87	AD0	I	AD data input from A/D converter (IC704), MSB.
88	AD1	I	AD data input from A/D converter.
89	AD2	I	AD data input from A/D converter.
90	AD3	I	AD data input from A/D converter.
91	AD4	I	AD data input from A/D converter.
92	AD5	I	AD data input from A/D converter.
93	AD6	I	AD data input from A/D converter.
94	AD7	I	AD data input from A/D converter.
95	AD8	I	AD data input from A/D converter.
96	AD9	I	AD data input from A/D converter, LSB.
97	VDD	—	+3.6V power supply.
98	OPD9	O	OPD (IC611) data output, MSB.
99	OPD8	O	OPD data output.
100	OPD7	O	OPD data output.



6-4. MECHANISM CONTROL MICRO PROCESSOR PIN FUNCTION (VS BOARD IC505: CXP87132-009R)

Note 1: CCD-TR72/TR80/TR400/TR430/TR750

Note 2: CCD-TR400

Pin No.

Signal Name

I/O

Function

1

RP PB MODE

O

REC/PB switching signal of REC/PB amplifier (VS board IC102) and ATF servo IC (VS board IC508). "H": PB.

2

FE/ON

O

Flying erase oscillation on/off control signal. "L": Oscillation.

3

JOG VD

O

False VD signal inserted in playback video signal during variable speed playback.

4

JOG

O

Variable speed playback/normal playback switching signal of video circuit. "H": Variable speed playback.

5

S JACK IN

I

(Note 2)

6

PB 1.7M DET

I

AFM stereo tape/monaural tape discrimination input. "H": During stereo or bilingual tape playback. (Note 1)

7

JACK MON/ST DET

I

Monaural/stereo discrimination input of audio input/output terminal. "L": When jack is inserted in right channel terminal. (Note 1)

8

INT VD

O

Internal VD signal.

9

SYSTEM SYNC (PBV)

O

System synchronizing signal.

10

SYNC DET

O

Sync detect output. "L" when sync is detect.

11

E/L DET

I

Normal/Hi8 discrimination input. "H" when Hi8 tape playback. (Note 2)

12

MIC MONO

I

External microphone monaural/stereo discrimination input. "L": When monaural microphone is used. (Note 1)

13

MODE SW 0

I

BL	END	EJECT	USE	LOAD	READY	TURN	REC/PB	FF
M SW 0	H	L	L	H	L	H	H	L
M SW 1	H	H	L	L	L	L	H	H
M SW 2	H	H	H	H	L	L	L	L

14

MODE SW 1

I

Mode switch input.

15

MODE SW 2

I

Mode switch input.

16

CC DOWN SW

I

Cassette compartment down switch input. "L": down

17

REC PROOF SW

I

Recording-proof switch input. "H": REC prohibition.

18

ME/MP SW

I

ME/MP switch input. "L": MP. "H": ME.

19

Hi8 MP SW

I

Hi8 MP switch input. "H": Hi8 MP. "L": Normal MP or ME.

20

LM LIM ON

O

Loading motor limiter on detection signal. Normally "H": "L" when limiter is on.

21

LINE MIX

O

Audio stereo/monaural control signal. (Note 1)

22

MX SEL 1

O

When recording: Monaural/stereo switching signal. When playing back: Monaural/stereo/bilingual switching signal.

23

MX SEL 2

O

Monaural	Stereo	Stereo	Main	Sub	Monaural
MX SEL 1	L	L	L	H	L
MX SEL 2	H	L	H	L	H

(Note 1)

24

MX ON/OFF

O

Matrix on/off signal. "H": Matrix on (stereo recording/playback) (Note 1)

25

COMP REC

O

Video input/S video input switching signal. "H": Video input.

26

CAM/LINE

O

Camera input/line input switching signal. "H": Camera input.

27

WIND

O

"L": Wind sound decrease on. (Note 1)

28

N.C.

Not used.

29

UNLOAD

O

Loading motor control signal. When unloading: "H" or "H" pulse.

30

LOAD

O

Loading motor control signal. When loading: "H" or "H" pulse.

Pin No.	Signal Name	I/O	Function
31	LM LIM CONT	O	Loading motor limiter control signal. Momentarily "H" when loading.
32	DRUM ON	O	Drum motor on/off signal. "H" (Approx. 1.3V): Drum on.
33	DRUM RVS	O	Drum rotation direction control signal. Normally "L".
34	N.C.		Not used. (open)
35	EDIT	O	Video circuit normal/EDIT switching signal. "L": When edit of menu display is at "ON".
36	EL OUT	O	Video circuit normal/Hi8 switching signal. "H": Hi8 mode. (Note 2)
37	MP		Connected to GND.
38	RESET	I	Reset signal from mode control micro processor (VS board IC503). When reset: "L".
39	VSS		GND
40	XTAL	O	11.89 MHz clock oscillation circuit.
41	EXTAL	I	
42	MECHA CONCS	I	Chip select signal from mode control micro processor (VS board IC503).
43	DATA TO SLAVE	I	Serial data input from mode control micro processor.
44	DATA TO MASTER	O	Serial data output to mode control micro processor.
45	MODECON SCK	I	Serial clock input from mode control micro processor.
46	AUDIO MUTE	O	Audio output mute signal. "H": Mute.
47	VIDEO MUTE	O	Video output mute signal. "H": Mute.
48	MONO REC (1.7M ON/OFF)	O	Monaural/stereo recording switching signal. "H": During monaural recording (1.7 MHz REC AFM carrier off). (Note 1)
49	N.C.		
50	AVSS		A/D converter system GND.
51	AVREF		A/D converter system reference voltage. Connected to SS3.6V.
52	AVDD		A/D converter system power supply. Connected to SS3.6V.
53	EXT MIC	I	External microphone discrimination input. Not used.
54	END SENS	I	Tape end detection signal. Normally: "L". "H" pulse at tape end.
55	TOP SENS	I	Tape top detection signal. Normally: "L". "H" pulse at tape top.
56	DEW DET	I	Condensation detection signal. "L" when condensation present.
57	N.C.		Not used. Connected to GND.
58	ATF ERROR	I	ATF error input.
59	S REEL FG	I	S reel FG signal input.
60	T REEL FG	I	T reel FG signal input.
61	NC		Not used. Connected to GND.
62	CAM V/D	I	VD signal from camera circuit sync generator (VC board IC610). V cycle pulse.
63	FLD	I	FIELD signal from camera circuit sync generator.
64	VTR SYNC	I	Composite sync signal separated from recording/playback Y signal.
65		I	Connected to GND.
66	DRUM PG	I	Drum PG signal input. For drum phase servo. 33.3 msec. cycle "H" pulse.
67	DRUM FG	I	Drum FG signal input. For drum speed servo. 2.8 msec. cycle pulse.
68	CAP FG	I	Capstan FG signal input.
69	N.C.	O	Not used.

4.4. **WILLIAMS' CONJECTURE, WEIGHT PROJECTIONS AND PLATONIC**

6-5. MODE CONTROL MICRO PROCESSOR PIN FUNCTIONS (VS BOARD IC503: MB89098PFV-G-107-BND)

Note 1: CCD-TR70/TR80

Note 2: CCD-TR400/TR750

Note 3: CCD-TR82/TR400/TR550

Pin No.	Signal Name	I/O	Function
1	TEST MODE 0	I	Connected to GND.
2	TEST MODE 1	I	Connected to GND.
3	X0	I	10 MHz clock oscillation circuit.
4	X1	O	
5	VSS		GND
6	RESET	I	Reset input.
7	DATA SW	I	Date (+) key (CK board S221) input. Normally "H". "L" when key is pressed.
8	TIME SW	I	Time key (CK board S222) input. Normally "H". "L" when key is pressed.
9	EJECT SW	I	Cassette eject switch (FK board S103) input. Normally "H". "L" when switch is pressed.
10	VTR MODE SW	I	Power supply switch (CK board S223) input. "L" when power supply switch is at "Video".
11	AGE SW	I	AGE switch input. "L" when key is pressed. Not used.
12	START/STOP SW	I	Start/stop key (FK board S102) input. "L" when key is pressed.
13	CC DOWN SW	I	CCDOWN switch (mechanism section) input. "L" when cassette compartment is locked.
14	CAMA-STBY SW	I	Power supply switch (CK board S223), stand-by switch (FK board S101) input. "L" when power supply switch is at "Camera" and stand-by switch at "Standby".
15	BATT IN	I	Main battery detection input. "H" when main battery is loaded or external power supply is connected.
16	PB V	I	System sync signal from mechanism control micro processor (VS board IC505).
17	RF SWP	I	RF switching pulse.
18	LANC POWER ON	I	Power on signal input from wired remote commander. "L" when power switch of remote commander is pressed.
19	LT PRE END	I	Lithium battery end detection input. "L" when lithium battery has worn out or has not been loaded.
20	EEPROM WE	O	EEPROM (VS board IC502) writing enable signal. "L" when writing data.
21			Not used.
22			
23	TALLY LED	O	Tally LED on/off signal.
24	SYSTEM RESET	O	Reset signal of all systems. Normally "H". "L" when reset.
25	N.C.	O	Not used.
26	BATT IN	I	Not used.
27	N.C.		
28	N.C.		Not used.
29	N.C.		
30	SIRCS SIG	I	Infrared remote commander signal input.
31	N.C.		Not used.
32			
33	CS EEPROM	O	Chip select signal to EEPROM (VS board IC502).
34	CS VIDEO	O	Chip select signal to video IC (VS board IC201).
35	EVF DA STB	O	Chip select signal to EVR of COLOR EVF (VF board IC903) (Note 1).
36	CS SG	O	Chip select signal to SYNC generator (VC board IC610).
37	CS DA	O	Strobe signal to DA (VS board IC951).
38	CS CAM	O	Chip select signal to camera micro processor (VC board IC602).
39	N.C.	O	Not used.
40	N.C.	O	

Pin No.	Signal Name	I/O	Function
70	T/E LED ON	O	TAPE LED on/off signal. 200 msec. cycle "H" pulse during REC/PB.
71	SP/LP	O	SP/LP switching signal. "L": LP.
72	ME/AF OUT	O	Recording current switching signal. "H": ME tape.
73	CAP PWM	O	Capstan error signal output. PWM signal.
74	DRUM PWM	O	Drum error signal output. PWM signal.
75	CFG HMS	I	Capstan FG signal input.
76	5.9M ATF CLK	O	Clock signal for ATF servo IC (IC508).
77	CS TO ATF	O	Chip select signal for ATF servo IC.
78	DATA TO ATF	O	Serial data output to ATF servo IC.
79	ATF SCK	O	Serial clock output to ATF servo IC.
80	ATF STBY	O	Standby signal for ATF servo IC.
81	SP/LP DET	I	Discriminates recording mode.
82	CLOG DET	I	Head clog detection signal. "L": Normal.
83	REF PILOT	O	Reference pilot signal for ATF servo.
84	N.C.		Not used. Connected to GND.
85	N.C.	I	
86	VSS		GND
87	VDD		Connected to SS3.6V.
88	VPP		
89	DRUM ACC	O	Drum motor acceleration signal.
90	DRUM BLK	O	Drum motor brake signal. Normally: "L".
91	N.C.		Not used. (open)
92	N.C.	O	
93	VIDEO IN/OUT	O	Video input/output switching signal. "L": Video output.
94	AUDIO IN/OUT	O	Audio input/output switching signal. "H": Audio output.
95	VA PB MODE	O	REC/PB switching signal of video; audio circuit. "H": PB.
96	VI SWP	O	RF switching pulse signal for video circuit.
97	RF SWP	O	RF switching pulse signal for REC/PB amp and audio circuit.
98	HEAD CHG	O	Head switching signal.
99	CAP ON	O	Capstan driver on/off control signal. "H": Capstan on.
100	CAP FWD/RVS	O	Capstan rotation direction control signal. "H": FWD. "L": RVS.

Pin No.	Signal Name	I/O	Function
41	N.C.		Not used.
42	N.C.		
43	SEG19	O	
44	SEG18	O	LCD segment terminal drive signal. Pulse of 4 values (0V, 1.2V, 2.4V and 3.6V). (Note 2)
45	SEG17	O	
46	SEG16	O	
47	VCC		+3.6V power supply (+3V power supply during backup).
48	SEG15	O	
49	SEG14	O	
50	SEG13	O	
51	SEG12	O	LCD segment terminal drive signal. Pulse of 4 values (0V, 1.2V, 2.4V and 3.6V). (Note 2)
52	SEG11	O	
53	SEG10	O	
54	SEG09	O	
55	SEG08	O	
56			GND
57	SEG07	O	
58	SEG06	O	
59	SEG05	O	
60	SEG04	O	LCD segment terminal drive signal. Pulse of 4 values (0V, 1.2V, 2.4V and 3.6V). (Note 2)
61	SEG03	O	
62	SEG02	O	
63	SEG01	O	
64	SEG00	O	
65	V3	I	3.6V
66	V2	I	2.4V
67	V1	I	1.2V
68	V0	I	0V
69	COM0	O	LCD drive bias voltage. (Note 2)
70	COM1	O	
71	COM2	O	
72	COM3	O	
73	CS OSD	O	Chip select signal to character generator (VC board IC614).
74	CS MECHA	O	Chip select signal to mechanism control micro processor (VS board IC505).
75	DATA TO MASTER	I	Serial data input signal.
76	DATA TO SLAVE	I	Serial data output signal.
77	MODECON SCK	O	Serial data transfer clock.
78	N.C.	O	Not used.
79	VTR DD ON	O	VTR DC-DC converter control signal. "H" when power switch is at "Player/video" or "Camera".
80	CAM DD ON	O	CAMERA DC-DC converter control signal.
81	AVSS		A/D port GND.

Pin No.	Signal Name	I/O	Function
82	K AD IN 0	I	Key input. A/D port. REC key (FK board S101, 106 (Note 2)) FF key (FK board S105) STOP key (FK board S104)
83	K AD IN 1	I	Key input. A/D port. PLAY key (FK board S111) REW key (FK board S110) PAUSE key (FK board S109)
84	K AD IN 2	I	Key input. A/D port. SET key (CK board S204) SELECT (-) key (CK board S203) SELECT (+) key (CK board S202) MENU key (CK board S201)
85	K AD IN 3	I	Key input. A/D port. FOCUS MANUAL key (CK board S211 (Note 2)) FADER key (CK board S208) BACK LIGHT/BRIGHT key (CK board S207) PROGRAM AE key (CK board S205)
86	K AD IN 4	I	Key input. A/D port. STEADY SHOT key (CK board S211 (Note 3)) EDIT SEARCH (-) key (CK board) EDIT SEARCH (+) key (CK board) COUNTER RESET key (CK board)
87	N.C.		Not used.
88	N.C.		
89	N.C.		
90	AVCC		A/D port power supply (+3.6V).
91	BATT SENS	I	For main battery voltage input. (Voltage divided into 1/3.14 by R586, R587).
92	N.C.	I	Not used.
93	BRIGHT B	I	Brightness adjusting dial input. Pulse input by dial rotation. (Note 2).
94	BRIGHT B	I	Brightness adjusting dial input. Pulse input by dial rotation. (Note 2).
95	LANC IN	I	LANC serial data input.
96	LANC OUT	O	LANC serial data output.
97	BUZZER	O	Buzzer output.
98	VCC		+3.6V power supply.
99	CL1	O	32 kHz clock oscillation circuit (for clock).
100	CL0	I	

Project Name		Project Number	
1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25	26	27	28
29	30	31	32
33	34	35	36
37	38	39	40
41	42	43	44
45	46	47	48
49	50	51	52
53	54	55	56
57	58	59	60
61	62	63	64
65	66	67	68
69	70	71	72
73	74	75	76
77	78	79	80
81	82	83	84
85	86	87	88
89	90	91	92
93	94	95	96
97	98	99	100

Project Name		Project Number	
101	102	103	104
105	106	107	108
109	110	111	112
113	114	115	116
117	118	119	120
121	122	123	124
125	126	127	128
129	130	131	132
133	134	135	136
137	138	139	140
141	142	143	144
145	146	147	148
149	150	151	152
153	154	155	156
157	158	159	160
161	162	163	164
165	166	167	168
169	170	171	172
173	174	175	176
177	178	179	180
181	182	183	184
185	186	187	188
189	190	191	192
193	194	195	196
197	198	199	200

SECTION 7 ADJUSTMENTS

7-1. CAMERA SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 7-30.

1-1. PREPARATIONS BEFORE ADJUSTMENT (CAMERA SECTION)

1-1-1. List of Service Tools

- Oscilloscope
- Adjusting driver
- Regulated power supply
- Color monitor
- Vectorscope
- Digital voltmeter

Ref. No.	Name	Parts Code	Usage
J-1	Filter for color temperature correction (C14)	J-6080-058-A	Auto white balance adjustment/check White balance adjustment/check
J-2	ND filter 1.0	J-6080-808-A	White balance check
	ND filter 0.3	J-6080-818-A	White balance check
J-3	Pattern box PTB-450	J-6082-200-A	
J-4	Color chart for pattern box	J-6020-250-A	
J-5	Adjusting remote commander (RM-95-remodeled partly) ^{Note 1}	J-6082-053-A	
J-6	Siemens star	J-6080-875-A	For checking the flange back
J-7	Extension cable (42P, 0.8 mm)	J-6082-285-A	For extension between the VC board (CN601) and VS board (CN203)
	Extension cable (34P, 0.8 mm)	J-6082-286-A	For extension between the AU-165 board CN1302 and VS board (CN202), For CCD-TR72/TR80/TR400/TR750
J-8	Extension cable (9P, 0.8 mm)	J-6082-288-A	For extension between the FK board and VS board (CN502)
	Extension cable (18P, 0.8 mm)	J-6080-289-A	For extension between the CK board and VS board (CN503)
J-9	Measuring pin tool for COLOR EVF	J-6082-192-A	For adjusting the COLOR EVF

Note 1: If the micro processor IC in the adjusting remote commander is not the new micro processor (UPD7503G-C56-12), the pages cannot be switched. In this case, replace with the new micro processor (8-759-148-35).




Fig. 7-1-1.

SECTION 7 ADJUSTMENTS

7-1. CAMERA SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 1-36.

1-1. PREPARATIONS BEFORE ADJUSTMENT (CAMERA SECTION)

1-1-1. List of Service Tools

- Oscilloscope
- Regulated power supply
- Multimeter
- Adjusting screw
- Color monitor
- Digital voltmeter

Part No.	Name	Part No.	Usage
24	Filter for color temperature adjusting (C14)	J-000-109-A	Use with feature adjustment tool. White balance adjustment tool.
25	IR filter 1.0	J-000-009-A	White balance check.
	IR filter 0.3	J-000-010-A	White balance check.
26	Pattern test P13-001	J-000-005-A	
24	Color chart for gamma test	J-000-100-A	
28	Adjusting screw magnetizer (SMT-55 mounted parts)*	J-000-003-A	
26	Resistor 10k	J-000-015-A	For checking the fringe test.
27	Resistor cable (10k, 100 ohm)	J-000-003-A	For connection between the VC input (CH1) and V1 input (CH2).
	Resistor cable (10k, 100 ohm)	J-000-004-A	For connection between the V1-101 input (CH1) and V1 input (CH2). For CCD-0101/1400/1430/1470.
28	Resistor cable (10k, 100 ohm)	J-000-004-A	For connection between the V1 input and V1 input (CH2).
	Resistor cable (10k, 100 ohm)	J-000-005-A	For connection between the V1 input and V1 input (CH2).
29	Mounting pin test for CCD-08 BVP	J-000-010-A	For adjusting the CCD-08 BVP.

Note 1: If the color processor IC in the adjusting screw magnetizer is not the new color processor (3907030-C06-13), the page cannot be printed. In this case, replace with the new color processor (3907030-C06-13).




Fig. 7-1-1.

1-1-2. Preparations

Note 1: For further details of how to remove the cabinet and each board, refer to "2. Disassembly".

Note 2: When adjusting only, the lens block and VC board need not be taken apart.

- 1) Connect the equipments for adjusting as shown in Fig. 7-1-3.
- 2) The F panel block (MA board) is not required in adjustments. Remove the following connector.
 1. CN1301 of the AU board
- 3) If remove the cabinet (R) (Power switch, camera function switch and electronic view-finder), set to the camera power supply ON mode (Note 1), and disconnect the following connectors.
 1. CN503 of VS board
 2. CN206 of VS board
 3. CN101 of ZB boardBe sure to exit this mode after completing the adjustment. (Note 2)
- 4) Turning OFF the Auto Focus Using the Adjusting Remote Commander
 1. Set data: 01 to page: 6, address: 25.
(The auto focus will turn OFF. The focus can be adjusted using the focus button on the adjusting remote commander. But the HOLD switch must be set to OFF.)
 2. After completing the adjustment/operation check, set data: 00 to page: 6, address: 25.
- 5) Turning OFF the STEADY SHOT Function Using the Adjusting Remote Commander (CCD-TR82/TR400/TR550/TR750)
 1. Set data: 02 to page: 6, address: 32.
 2. Set data: 01 to page: 6, address: 33.
(The STEADY SHOT will go OFF.)
 3. After completing the adjustment/operation check, return the data of address: 32 and address: 33 of page: 6 to 00.

Note 1: Setting the Forced Camera Power Supply ON Mode

- 1) Set data: 01 to page: 1, address: 00.
- 2) Set data: 21 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
By carrying out the above, the camera can be operated even if the cabinet (R) has been removed. Be sure to exit the forced camera power ON mode after completing the adjustment.

Note 2: Exiting the Forced Camera Power Supply ON Mode

- 1) Set data: 01 to page: 1, address: 00.
- 2) Set data: 00 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
- 3) Set data: 00 to page: 1, address: 00.




Fig. 7-1-2.





Fig. 7-1-3.



1-1-3. Precautions

1. Switch settings

Adjust the switches to the following positions, and adjust without loading the cassette tape, unless specified otherwise.

1. Camera/player power switch
(Control switch block (Control switch block (CK board))Camera
2. Standby switch (Control switch block (FK board)) .. Standby
3. PROGRAM AE button (Control switch block (CK board))
.....Off
4. FOCUS switch (Control switch block (CK board)) ...Manual
5. BACK LIGHT button (Control switch block (CK board))
.....Off
6. STEADY SHOT button (CCD-TR82/TR400/TR550/TR750)
(Control switch block (CK board)).....Off

2. Adjusting Procedure

Adjust in the given order.

3. Subject

- 1) Color bar chart (Standard picture frame)
Adjust the picture frame as shown in Fig. 7-1-4. if adjustments are performed using the color bar chart.
(Standard picture frame)
- 2) White pattern (Standard picture frame)
Remove the color bar chart from the pattern box, and so that the white pattern will be displayed.
Don't touch the zoom switch.




Fig. 7-1-4.

3) Chart for flange back adjustment

Combine a white A0 size (1189 mm × 841 mm) paper to a black one, and make the chart shown in Fig. 7-1-5.




Fig. 7-1-5.

Note: Use the non-reflecting and non-glazing vellum paper whose size is more than A0, and make the boundary between white and black to be smoothly flat.

1-1-4. Adjusting Remote Commander

The camera section is adjusted by changing the constant or coefficient of the digital signal processing calculation, or modifying the output voltage of the EVR IC (VC board IC603). This is controlled by the camera micro processor (VC board IC602), which reads the data written in the nonvolatile memory (VC board IC601: EEPROM), and transmits it to the digital signal processing circuit and EVR.

To perform adjustments, adjustment data written in the nonvolatile memory must be rewritten, using the adjusting remote commander.

The adjusting remote commander uses the remote commander signal line (LANC) to communicate mutually with the camera microprocessor. The page, address and the up/down commands of the data are transmitted from the adjusting remote commander to the camera micro processor. And, the page, address, and data are transmitted for the vice versa.

1. Using the adjusting remote commander

- 1) Connect the adjusting remote commander to the remote terminal.
- 2) Adjust the HOLD switch of the adjusting remote commander to "HOLD" (SERVICE position).

If it has been properly connected, the LCD on the adjusting remote commander will display as shown in Fig. 7-1-6.




Fig. 7-1-6.

- 3) Operate the adjusting remote commander as follows.

- Changing the page

The page increases when the EDIT SEARCH+ button is pressed, and decreases when the EDIT SEARCH- button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal notation	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
LCD Display	0	1	2	3	4	5	6	7	8	9	A	b	c	d	E	F
Decimal notation conversion value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

Table 7-1-1.

- Changing the address

The address increases when the FF (▶▶) button is pressed, and decreases when the REW (◀◀) button is pressed. There are altogether 256 addresses, from 00 to FF.

- Changing the data (Data setting)

The data increases when the PLAY (▶) button is pressed, and decreases when the STOP (■) button is pressed.

There are altogether 256 data, from 00 to FF.

- Writing the adjustment data

The PAUSE button must be pressed to write the adjustment data (F page) in the nonvolatile memory.

(The new adjustment data will not be recorded in the nonvolatile memory if this step is not performed.)

- 4) Select page: 6, address: 00, and adjust the data to 01. Page F, and enables the camera section (Addresses 01 to BF of page F) to be adjusted.
- 5) After completing all adjustments, turn off the main power supply (6.3V) once.

2. Precautions upon using the adjusting remote commander

Mishandling of the adjusting remote commander may erase the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment.

1-1-4. Adjusting Stereo Commander

The stereo section is adjusted by changing the constant or coefficient of the digital signal processing calculation, or modifying the output voltage of the DVS IC (VC board EX05). This is controlled by the stereo source processor (SC board EX05), which sends the data written in the non-volatile memory (VC board EX05) EXPR05G, and transmits it to the digital signal processing circuit and DVS.

To perform adjustment, adjustment data written in the non-volatile memory must be rewritten, using the adjusting stereo commander.

The adjusting stereo commander uses the stereo commander output line (LAMP) to communicate mutually with the stereo microprocessor. The page, address, and the adjustment constants of the data are transmitted from the adjusting stereo commander to the stereo micro-processor. And, the page, address, and data are transmitted back to the user once.

1. Using the adjusting stereo commander
 2. Compare the adjusting stereo commander to the stereo terminal
 3. Adjust the EXPR05 circuit of the adjusting stereo commander to "HOLD" (EXP/VC) position.
- If it has been properly connected, the LAMP of the adjusting stereo commander will light up as shown in Fig. 7-1-6.



Fig. 7-1-6.

4. Operate the adjusting stereo commander as follows.

• Changing the page

The page increases when the NEXT (HARD) button is pressed, and decreases when the PREV (HARD) button is pressed. There are altogether 28 pages, from 0 to 7.

Hexadecimal number	0 1 2 3 4 5 6 7 8 9 A B C D E F
USB display	0 1 2 3 4 5 6 7 8 9 A B C D E F
Decimal number (commander value)	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

Table 7-1-1.

• Changing the volume

The volume increases when the PP (+) button is pressed, and decreases when the DD (-) button is pressed. There are altogether 220 volumes, from 00 to 9F.

• Changing the data (data setting)

The data increases when the PLAY (▶) button is pressed, and decreases when the STOP (■) button is pressed.

There are altogether 256 data, from 00 to FF.

• Writing the adjustment data

The WRITE button must be pressed to write the adjustment data (7 pages) in the non-volatile memory.

(The new adjustment data will not be recorded in the non-volatile memory if this step is not performed.)

4. Select page 0, address 00, and adjust the data in 00. (Step 2), and modify the stereo section (Addresses 01 to 0F of page 0) to be adjusted.
5. After completing all adjustments, turn off the main power supply (L-PS) once.

5. Precautions upon using the adjusting stereo commander

Mishandling of the adjusting stereo commander may cause the correct adjustment data to show. To prevent this, it is recommended that all adjustments must be carried out before beginning adjustments and save adjustment data after each adjustment.

1-1-5. Page F Address List

Note 1: The data already listed in the adjustment data memo column are fixed values.

Note 2: The adjustment data initial values are values just after executing "Page F Data Initialization" and "Page F Data Modification". They are different from the values after executing all adjustments.

Note 3: In some cases, data have been input to the page F addresses C0 to FF. This has no relation to the adjustments.

Note 4: No mark : CCD-TR42/TR72/TR80/TR430

() : CCD-TR82/TR550

< > : CCD-TR70

《 》 : CCD-TR400/TR750

Address	Adjustment data	
	Initial value	Memo column
00	5C (5A) <5E> 《56》	5C (5A) <5E> 《56》
01	0A (00)	0A (00)
02	00	00
03	00 (07)	00 (07)
04	80	
05	80	
06	80	
07	80	
08	2D	
09	26	
0A	FA	
0B	F1	
0C	30	
0D	00	
0E	58	
0F	00	
10	E0	E0
11	8F	
12	6C	
13	36	
14	3C	
15	B6	
16	0D	
17	A3	
18	12	
19	8E	
1A	10	
1B	E2	
1C	0C	0C
1D	00	00
1E	80	
1F	80	
20	80 (79)	80 (79)
21	80 (79)	80 (79)
22	00	00
23	59	53
24	43	43
25	A5 (B5)	A5 (B5)
26	23	23
27	3A	3A
28	A2	A2
29	0B	0B

Table 7-1-2 (1).

1-4-B Page F Address List

Note 1: The data already listed in the adjustment data screen remains as final values.

Note 2: The adjustment data initial values are values just after executing "Page F Data Initialization" and "Page F Data Initialization". They are different from the values after executing all adjustments.

Note 3: In some cases, data have been input to the page F addresses 03 to 07. This has no relation to the adjustments.

Note 4: No mark: CCB-1944700/1944700

- 1 : CCB-1944700/
- 2 : CCB-1944700/
- 3 : CCB-1944700/
- 4 : CCB-1944700/

Address	Adjustment data	
	Initial values	Setting values
00	BC (BA) CCB-040	BC (BA) CCB-040
01	BA (00)	BA (00)
02	00	00
03	00 (00)	00 (00)
04	00	
05	00	
06	00	
07	00	
08	00	
09	00	
0A	00	
0B	00	
0C	00	
0D	00	
0E	00	
0F	00	
10	00	00
11	00	
12	00	
13	00	
14	00	
15	00	
16	00	
17	00	
18	00	
19	00	
1A	00	
1B	00	
1C	00	
1D	00	00
1E	00	00
1F	00	
20	00 (7F)	00 (7F)
21	00 (7F)	00 (7F)
22	00	00
23	00	00
24	00	00
25	00 (00)	00 (00)
26	00	00
27	00	00
28	00	00
29	00	00

Table 1-4-B (2)

Address	Adjustment data	
	Initial value	Memo column
2A	0C (2C)	0C (2C)
2B	58 (50)	58 (50)
2C	FF	FF
2D	06 ((04))	06 ((04))
2E	17 (16)	17 (16)
2F	22 (27) 《29》	22 (27) 《29》
30	08	08
31	00	00
32	50 (47) 《48》	50 (47) 《48》
33	68	68
34	00 (02)	00 (02)
35	30 (50)	30 (50)
36	02	02
37	00	00
38	76	76
39	6A	6A
3A	80	80
3B	20	20
3C	F0	F0
3D	03 (02)	03 (02)
3E	00	
3F	00	
40	00	
41	00	
42	00	
43	00	
44	00	
45	00	00
46	00	
47	00	
48	00	
49	00	
4A	00	
4B	00	
4C	00	
4D	00	
4E	00	00
4F	20	20
50	05 (32)	05 (32)
51	02	02
52	66	66
53	18	18

Table 7-1-2 (2).

Address	Adjustment data	
	Initial value	Memo column
54	66 (6B)	66 (6B)
55	9F	9F
56	66	66
57	66 (6C)	66 (6C)
58	59 (5C)	59 (5C)
59	83	83
5A	67	67
5B	5C	5C
5C	5C	5C
5D	4A	4A
5E	1E (20)	1E (20)
5F	5C	5C
60	3A (3C)	3A (3C)
61	33	33
62	0C	0C
63	26	26
64	04	04
65	02	02
66	00	00
67	00	00
68	00	00
69	00	00
6A	00	00
6B	00	00
6C	00	00
6D	00	00
6E	00	00
6F	34	34
70	10	10
71	26	26
72	0F	0F
73	0F	0F
74	00	00
75	23	23
76	1B	1B
77	E0	E0
78	A0	A0
79	30	30
7A	10	10
7B	50	50
7C	58	58
7D	88	88

Table 7-1-2 (3).

Address	Adjustment table	
	Initial value	Memory address
1A	00 (00)	00 (00)
1B	00 (00)	00 (00)
2C	00	00
2D	00 (00)	00 (00)
3E	00 (00)	00 (00)
3F	00 (00) (00)	00 (00) (00)
40	00	00
41	00	00
42	00 (00) (00)	00 (00) (00)
43	00	00
44	00 (00)	00 (00)
45	00 (00)	00 (00)
46	00	00
47	00	00
48	00	00
49	00	00
4A	00	00
4B	00	00
4C	00	00
4D	00	00
4E	00	00
4F	00	00
50	00	00
51	00	00
52	00	00
53	00	00
54	00	00
55	00	00
56	00	00
57	00	00
58	00	00
59	00	00
5A	00	00
5B	00	00
5C	00	00
5D	00	00
5E	00	00
5F	00	00
60	00	00
61	00	00
62	00	00
63	00	00
64	00	00
65	00	00
66	00	00
67	00	00
68	00	00
69	00	00
6A	00	00
6B	00	00
6C	00	00
6D	00	00
6E	00	00
6F	00	00
70	00 (00)	00 (00)
71	00	00
72	00	00
73	00	00

Table 7-1-4 (5)

Address	Adjustment table	
	Initial value	Memory address
74	00 (00)	00 (00)
75	00	00
76	00	00
77	00 (00)	00 (00)
78	00 (00)	00 (00)
79	00	00
7A	00	00
7B	00	00
7C	00	00
7D	00	00
7E	00	00
7F	00	00
80	00 (00)	00 (00)
81	00	00
82	00	00
83	00	00
84	00	00
85	00	00
86	00	00
87	00	00
88	00	00
89	00	00
8A	00	00
8B	00	00
8C	00	00
8D	00	00
8E	00	00
8F	00	00
90	00	00
91	00	00
92	00	00
93	00	00
94	00	00
95	00	00
96	00	00
97	00	00
98	00	00
99	00	00
9A	00	00
9B	00	00
9C	00	00
9D	00	00

Table 7-1-4 (6)

Address	Adjustment data	
	Initial value	Memo column
7E	66	66
7F	46	46
80	8F	8F
81	13	13
82	30	30
83	60	60
84	70	70
85	80	80
86	A0	A0
87	C0	C0
88	70	70
89	78	78
8A	80	80
8B	90	90
8C	A0	A0
8D	40	40
8E	FF	FF
8F	00	00
90	00 <11>	00 <11>
91	77	77
92	00	00
93	FB	FB
94	02	02
95	32	32
96	6B	6B
97	8D	8D
98	A1	A1
99	30	30
9A	30	30
9B	21	21
9C	72	72
9D	00	00
9E	00	00
9F	00	00
A0	00	00
A1	00	00
A2	00	00
A3	02	02
A4	80	80
A5	00	00
A6	80	80
A7	00	00

Table 7-1-2 (4).

Address	Adjustment data	
	Initial value	Memo column
A8	00	00
A9	80	80
AA	00	00
AB	00	00
AC	02	02
AD	44	44
AE	3D	3D
AF	1B (25)	1B (25)
B0	3D	3D
B1	1B (25)	1B (25)
B2	A4 (A2)	A4 (A2)
B3	4B	4B
B4	00	00
B5	20	20
B6	00	00
B7	05	05
B8	00	00
B9	20	20
BA	00	00
BB	70 (6E)	70 (6E)
BC	35 (32)	35 (32)
BD	54	54
BE		
BF		
C0 to EF		
F0		
F1		
F2		
F3		
F4		
F5		
F6		
F7		
F8		
F9		
FA		
FB		
FC		
FD		
FE		
FF		

Table 7-1-2 (5).

Address	Adjustment data	
	Initial value	Memory reference
7E	4E	4E
7F	4E	4E
80	4F	4F
81	1E	1E
82	3D	3D
83	8D	8D
84	7D	7D
85	8D	8D
86	4E	4E
87	0E	0E
88	7E	7E
89	7E	7E
8A	9E	9E
8B	4E	4E
8C	4E	4E
8D	4E	4E
8E	4F	4F
8F	8D	8D
90	0E (11)	0E (11)
91	7F	7F
92	9E	9E
93	7E	7E
94	8D	8D
95	3D	3D
96	8E	8E
97	8D	8D
98	4E	4E
99	3E	3E
9A	5E	5E
9B	2E	2E
9C	7D	7D
9D	8D	8D
9E	8D	8D
9F	8E	8E
AA	8E	8E
AB	8E	8E
AC	8D	8D
AD	8D	8D
AE	8D	8D
AF	8E	8E

Table 7-1-8 (8)

Address	Adjustment data	
	Initial value	Memory reference
AE	8D	8D
AF	8D	8D
AA	8D	8D
AB	8D	8D
AC	8E	8E
AD	4E	4E
AE	3D	3D
AF	0E (22)	0E (22)
BA	8D	8D
BB	0E (24)	0E (24)
BC	4E (A2)	4E (A2)
BD	8E	8E
BE	8D	8D
BF	3D	3D
C0	8D	8D
C1	8D	8D
C2	7E (8D)	7E (8D)
C3	8E (7E)	8E (7E)
C4	5E	5E
CE		
CF to DF		
FE		
FF		
FA		
FB		
FC		
FD		
FE		
FF		
FA		
FB		
FC		
FD		
FE		
FF		

Table 7-1-8 (9)

1-1-6. Data Processing

The calculation of the DDS display and the adjusting remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Table 7-1-3. indicates the hexadecimal notation-the decimal notation calculation table.

Hexadecimal notation-Decimal notation

The lower digits of the hexadecimal notation The upper digits of the hexadecimal notation																
	0	1	2	3	4	5	6	7	8	9	A (<i>A</i>)	B (<i>b</i>)	C (<i>c</i>)	D (<i>d</i>)	E (<i>E</i>)	F (<i>F</i>)
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
5	80	80	82	83	84	85	86	87	88	89	90	91	92	93	94	95
6	96	97	98	99	100	101	102	103	104	105	106	107	106	109	110	111
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
A (<i>A</i>)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
① → B (<i>b</i>)	176	177	178	179	180	180	182	183	184	185	186	187	188	189	190	191
C (<i>c</i>)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
D (<i>d</i>)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
E (<i>E</i>)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
F (<i>F</i>)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

Note: () indicate the adjusting remote control unit display.

(Example) In the case that the DDS display and the adjusting remote control unit display are BD (*b d*).

As the upper digit of the hexadecimal notation is B (*b*), and the lower digit is D (*d*), the intersection "189" of the ① and ② in the above table is the decimal notation to be calculated.

Table 7-1-3.

1-1-4. Data Presentation

The calculation of the COE display and the adjusting means (correction display data (functional relative) are required for obtaining the adjustment data of zero adjustment means. In this case, after converting the functional relative to decimal values, calculate and convert the result to functional relative, and use it as the adjustment data. Table 1-1-5, indicates the functional relative-to decimal values calculation table.

functional relative-to decimal values table

The lower digits of the functional relative The upper digits of the functional relative																
	0	1	2	3	4	5	6	7	8	9	0.00	0.01	0.02	0.03	0.04	0.05
0	0	1	2	3	4	5	6	7	8	9	00	11	22	33	44	55
1	16	27	38	49	60	71	82	93	04	15	26	37	48	59	70	81
2	32	43	54	65	76	87	98	09	20	31	42	53	64	75	86	97
3	48	59	70	81	92	03	14	25	36	47	58	69	80	91	02	13
4	64	75	86	97	08	19	30	41	52	63	74	85	96	07	18	29
5	80	91	02	13	24	35	46	57	68	79	90	01	12	23	34	45
6	96	07	18	29	40	51	62	73	84	95	06	17	28	39	50	61
7	112	123	134	145	156	167	178	189	200	211	222	233	244	255	266	277
8	228	239	250	261	272	283	294	305	316	327	338	349	360	371	382	393
9	344	355	366	377	388	399	410	421	432	443	454	465	476	487	498	509
A (°)	500	511	522	533	544	555	566	577	588	599	610	621	632	643	654	665
B (°)	676	687	698	709	720	731	742	753	764	775	786	797	808	819	830	841
C (°)	852	863	874	885	896	907	918	929	940	951	962	973	984	995	006	017
D (°)	028	039	050	061	072	083	094	105	116	127	138	149	160	171	182	193
E (°)	204	215	226	237	248	259	270	281	292	303	314	325	336	347	358	369
F (°)	380	391	402	413	424	435	446	457	468	479	490	501	512	523	534	545

Notes: () indicate the adjusting means round and display.

(Example) In the case that the COE display and the adjusting means round and display are 0.01 % of ϕ .

As the upper digit of the functional relative 0.01 % and the lower digit 0.01 % of the relative "0.01" of the 0.01 and 0.01 is the alternative value functional relative value calculation.

Table 1-1-5.

Using the PROGRAM AE Function

You can select from four PROGRAM AE (Auto Exposure) modes to suit your shooting situation. When you use PROGRAM AE, you can get a Portrait effect (the subject is in focus and the background is out of focus), capture high-speed action or night views.

Selecting the Best Mode

Select the best mode by using the following examples.



Portrait mode

- A still subject such as a person or flower
- Subject behind an obstacle such as a net
- Zooming in on a subject in telephoto

Sports mode

- Outdoor sports scenes such as football, tennis, golf or skiing
- A landscape in a moving car

High-speed shutter mode


- A golf swing or a tennis match in fine weather with the ball captured clearly
- Playing back certain scenes with high-speed movements in clear, sharp picture

Twilight mode

- Recording night views neon signs or fireworks

Using the PROGRAM AE Function

Press PROGRAM AE repeatedly so that the desired mode indicator appears inside the viewfinder.



Note on shutter speed

The shutter speed in each PROGRAM AE mode is as follows:

Portrait mode – between 1/60 to 1/2000

Sports mode – between 1/60 to 1/500

High-speed shutter mode – 1/4000

Twilight mode – 1/60

Normal mode – 1/60

Fade-in and Fade-out

You can fade in or fade out to give your recording a professional appearance. When fading in, the picture will gradually appear from black or mosaic. The sound will also gradually increase. When fading out, the picture will gradually fade to black or mosaic. The sound will also decrease.

When Fading in [a]



(1) During the camcorder is in Standby mode, press FADER. The fade indicator starts flashing.

(2) Press START/STOP to start recording. The fade indicator stops flashing.

When Fading out [b]

(1) During recording, press FADER. The fade indicator starts flashing.

(2) Press START/STOP to stop recording. The fade indicator stops flashing and recording stops.



To Cancel the Fade-in/out Function
Before pressing START/STOP, press FADER once or twice until the fade indicator disappears.

When the date/time indicator is displayed
The date/time does not fade in nor fade out.

Using the PROCESSIONAL Function

For recording and playback of the PROCESSIONAL function, use the following steps:

Recording the PROCESSIONAL Function

Press the **PROCESSIONAL** button to begin recording.



1. Press the **PROCESSIONAL** button to begin recording.
2. Press the **PROCESSIONAL** button to stop recording.
3. Press the **PROCESSIONAL** button to stop recording.

Playback the PROCESSIONAL Function

Press the **PROCESSIONAL** button to begin playback.



For more information, see the **PROCESSIONAL** function in the **PROCESSIONAL** section of the **PROCESSIONAL** manual.

Index and End-user

For more information, see the **Index** and **End-user** sections of the **PROCESSIONAL** manual.

Index

For more information, see the **Index** section of the **PROCESSIONAL** manual.

End-user

For more information, see the **End-user** section of the **PROCESSIONAL** manual.




For more information, see the **PROCESSIONAL** function in the **PROCESSIONAL** section of the **PROCESSIONAL** manual.

For more information, see the **PROCESSIONAL** function in the **PROCESSIONAL** section of the **PROCESSIONAL** manual.


Releasing the Steady Shot Function

— For the model with the STEADY SHOT switch (CCD-TR82 only)

When you shoot, the  indicator appears in the viewfinder. This indicates that the Steady Shot function is working and the camcorder compensates for camera-shake.

You can release the Steady Shot function. Do not use the Steady Shot function such as when shooting stationary object with a tripod.

Set STEADY SHOT to OFF.



To Activate the Steady Shot Function Again


Set STEADY SHOT to ON.

Notes on the Steady Shot Function

- The Steady Shot function will not correct excessive camera-shake.
- When you switch the STEADY SHOT, the exposure may vary.

Changing the Mode Settings

You can change the mode settings in the menu system to further enjoy the features and functions.
(1) Press MENU to display the menu in the viewfinder. **(2)** Press \uparrow or \downarrow to select the desired item, then press EXECUTE. **(3)** Press \uparrow or \downarrow to set the desired mode, then press EXECUTE. If you want to change the other modes, repeat steps 2 and 3. **(4)** Press MENU to erase the menu display.



Note on BACK UP

When BACK UP indicator appears on the menu display, the settings of items are retained even when the battery is removed, as long as the lithium battery is in place.

Selecting the Mode Setting of Each Item

Common Items in CAMERA and PLAYER Modes

- COMMANDER <ON/OFF>
- Select ON when using the supplied Remote Commander for the camcorder.
- Select OFF when not using the Remote Commander for the camcorder.

BEEP <ON/OFF>

- Select ON so that beeps sound when you start/stop recording.
- Select OFF when you do not want to hear the beep sound.

Rebuilding the Sturdy Shot Pattern

After the results with the **GRAIN** shot pattern (see 1001) are

shown that the **GRAIN** pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is



To achieve the **GRAIN** shot pattern, the


shot is the **GRAIN** shot pattern

the shot is the **GRAIN** shot pattern



Changing the Mode Settings

The **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is



shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

shown that the **GRAIN** shot pattern is the best, the value of the **GRAIN** shot pattern is

Changing the Mode Settings

Items in CAMERA mode

WIND <ON/OFF>

- For stereo models (CCD-TR72/TR80)
- Select ON to reduce wind noise when recording in strong wind.
- Normally select OFF.

AUTO DATE <ON/OFF>

- Select ON to record the date of recording automatically (AUTO DATE feature: p.12).
- Select OFF otherwise.

CLOCK SET

Select this item when you need to reset the clock (p.31).

AREA

Select the area number of the time zone where you will use the camcorder when you use the world clock (p.27).

D.S.T. <ON/OFF>

- Select ON to set the clock to Daylight Saving Time.
- Select OFF to set to standard time.

Items in PLAYER mode

EDIT <ON/OFF>

- Select ON to minimize the picture deterioration when editing.
- Normally select OFF.

HIFI SOUND <STEREO/1/2>


— For stereo models (CCD-TR72/TR80)

- Normally select STEREO.
- Select 1 or 2 to play back a dual soundtrack tape.

Using the World Clock


Reset the clock according to the local time zone by setting AREA and D.S.T. modes in the menu system. First find the area number in the "Time zone chart" on page 28.

- (1) Turn STANDBY up. (2) Press MENU to display the menu. (3) Select AREA item (p.26). Press \uparrow or \downarrow to select the area number where you will use the camcorder. Press EXECUTE. (4) Select D.S.T. item (p.26). Press \uparrow or \downarrow to select ON for Daylight Saving Time or OFF for standard time. Press EXECUTE.



Changing the Mode Settings

The area name appears in the viewfinder when using the world clock. The \star indicator appears in the viewfinder when setting to Daylight Saving Time.



To Check the Date

Press DATE. To turn off the date indicator, press DATE again.

To restore to Your Home Area Time

Reset the AREA mode in the menu system to your home area number.

See the next page for the Time Zone Chart. 27

Chromatography (GC-MS/MS)

Steps for GC/MS/MS

1. Prepare the sample (e.g., extract, dilute, etc.)
2. Inject the sample into the GC inlet
3. Carry out the separation
4. Collect the fractions
5. Analyze the fractions (e.g., GC-MS/MS)

GC-MS/MS

1. Prepare the sample (e.g., extract, dilute, etc.)
2. Inject the sample into the GC inlet
3. Carry out the separation
4. Collect the fractions
5. Analyze the fractions (e.g., GC-MS/MS)

GC-MS/MS

1. Prepare the sample (e.g., extract, dilute, etc.)
2. Inject the sample into the GC inlet
3. Carry out the separation
4. Collect the fractions
5. Analyze the fractions (e.g., GC-MS/MS)

GC-MS/MS

1. Prepare the sample (e.g., extract, dilute, etc.)
2. Inject the sample into the GC inlet
3. Carry out the separation
4. Collect the fractions
5. Analyze the fractions (e.g., GC-MS/MS)

GC-MS/MS

GC-MS/MS is a powerful tool for the analysis of complex samples.

GC-MS/MS is a powerful tool for the analysis of complex samples.

GC-MS/MS is a powerful tool for the analysis of complex samples.

GC-MS/MS is a powerful tool for the analysis of complex samples.



GC-MS/MS is a powerful tool for the analysis of complex samples.



GC-MS/MS

GC-MS/MS is a powerful tool for the analysis of complex samples.


GC-MS/MS is a powerful tool for the analysis of complex samples.

GC-MS/MS is a powerful tool for the analysis of complex samples.

GC-MS/MS is a powerful tool for the analysis of complex samples.

Changing the Mode Settings

Time Zone Chart



Area number	Area name	Nations or area*
1	LONDON	England, GMT (Greenwich Mean Time), Morocco, Portugal
2	PARIS	Austria, France, Germany, Italy, Netherlands, Spain, Sweden, Switzerland, CET
3	CAIRO	Egypt, Finland, Greece, Israel, Turkey
4	MOSCOW	Ethiopia, Iraq, Kenya, Saudi Arabia, former U.S.S.R. (west)
5	DUBAI	United Arab Emirates
6	KARACHI	Maldives, Pakistan
7	Dacca	Bangladesh, Myanmar
8	BANGKOK	Cambodia, Indonesia (Jakarta), Thailand, Vietnam
9	HONGKONG	Australia (west), China, Hong Kong, Indonesia (Bali, Borneo), Malaysia, Philippines, Singapore, Taiwan
10	TOKYO	Japan, Korea
11	SYDNEY	Australia (east), Guam, Saipan
12	SOLOMON	New Caledonia
13	WILLINGTN	Fiji, New Zealand
14	SAMOA	Western Samoa
15	HAWAII	HST (Hawaii Standard Time), Tahiti
16	ANCHORAGE	AST (Alaska Standard Time)
17	US, PST	PST (Pacific Standard Time)
18	US, MST	MST (Mountain Standard Time)
19	US, CST	CST (Central Standard Time), Mexico
20	US, EST	EST (East Standard Time), Peru
21	CARACAS	Chili, Dominica, Venezuela
22	RIO	Argentina, Brazil, Uruguay
23	FN ISL.	Fernando de Noronha
24	AZORES	Azores Islands


* These are common names. They may be different from formal country names.

Editing onto Another Tape

You can create your own video program by editing with any other 8 mm, Hi8, Hi8 VHS, S-VHS, Hi8 VHS, S-VHS, S-VHS, or Hi8 VHS VCR that has video/audio inputs.

Before Editing

After connecting the camcorder to the VCR, (1) Slide the POWER switch to **PLAYER**. (2) Set **EDIT** mode to **ON** in the menu system to minimise the picture deterioration (p.25).



Starting Editing

(1) Insert a blank tape (or a tape you want to record over) into the recording VCR. Then insert your recorded tape into the camcorder. (2) Play back the recorded tape on the camcorder until you locate the point where you want to start editing. Then set the camcorder to playback pause mode. (3) Set the recording VCR to recording pause mode. (4) Press **II** on the camcorder and VCR simultaneously to start editing.

To Edit More Scenes

Repeat steps 2 to 4.

To Stop Editing

Press **STOP** on the camcorder and VCR. When you finish editing, reset **EDIT** mode to **OFF** (p.25).

Use of the EDITSEARCH button

To play back a tape in the forward or reverse direction keep pressing **EDITSEARCH** during playback pause. You can play back still pictures successively at specific intervals by pressing **EDITSEARCH** intermittently.

Note on DISPLAY function


If you have displayed the viewfinder screen indicators on the TV (**DISPLAY** function), erase the indicators by pressing **DISPLAY** on the Remote Commander so that they will not be superimposed on the edited tape.

Changing the Mode Settings/Editing onto Another Tape

Additional Information


Changing the Lithium Battery In the Camcorder

Your camcorder is supplied with the lithium battery installed. The lithium battery lasts for about 1 year under normal operation. When the battery becomes weak or dead, the indicator flashes in the viewfinder for about 5 seconds when you set the POWER switch to CAM/ERA. In this case, **replace the battery with the Sony CR2025 or Duracell DL-2025 lithium battery. Use of another battery may present a risk of fire or explosion.**



Note on Lithium Battery

Note that the lithium battery has a positive (+) and a negative (-) terminals as illustrated. **Be sure to install the lithium battery so that terminals on the battery match the terminals on the camcorder.**




WARNING

The battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

Caution
Keep the lithium battery out of the reach of children. Should the battery be swallowed, consult a doctor immediately.

Changing the Lithium Battery


When replacing the lithium battery, keep the battery pack or other power source attached. Otherwise, you will need to reset the date, time and the other items with BACK UP indicator in the menu system. (1) Open the lid of the lithium battery compartment. (2) Push the battery down once and pull it out from the holder. (3) Install the lithium battery with the positive (+) side facing out. Close the lid of the battery compartment.



Resetting the Date and Time

Reset the date and time in the menu system.

(1) Press MENU to display the menu. (2) Press \uparrow or \downarrow to select CLOCK SET item (p.26). Press EXECUTE. (3) Press \uparrow or \downarrow to select the area number where you will use the camcorder. Press EXECUTE. (4) Select D.S.T. ON for Daylight Saving Time or OFF for standard time. Press EXECUTE. (5) Set year, month, day, time, minute by pressing \uparrow , \downarrow and EXECUTE. Note that when you keep \uparrow and \downarrow pressed, the digits advance faster. (6) Press MENU to erase the menu display.



Time Zones and Area Numbers and Names
"S.T.", in the following table stands for Standard Time.

Time Zones	Area Name	Area Number
Hawaii S.T.	HAWAI	15
Alaska S.T.	ANCHRGE	16
Pacific S.T./West Canada	US.PST	17
Mountain S.T.	US.MST	18
Central S.T.	US.CST	19
Eastern S.T./East Canada	US.EST	20

Diffusion Worksheet

Changing the Leftmost Battery in the Commander

The commander is made up of a circuit battery board. The battery board has three 1.5V AA batteries. When the commander is first turned on, the battery board will be in the "off" position. To turn the commander on, you must turn the battery board to the "on" position. The battery board will be in the "on" position when the commander is turned on.



Turn on Diffusion Battery

Turn on the diffusion battery by turning the switch to the "on" position. The switch is located on the left side of the battery board. The battery board will be in the "on" position when the commander is turned on.



Turn on the Commander

Turn on the commander by turning the switch to the "on" position. The switch is located on the left side of the battery board. The battery board will be in the "on" position when the commander is turned on.


Changing the Diffusion Battery

The commander is made up of a circuit battery board. The battery board has three 1.5V AA batteries. When the commander is first turned on, the battery board will be in the "off" position. To turn the commander on, you must turn the battery board to the "on" position. The battery board will be in the "on" position when the commander is turned on.



Resetting the Data and Time

The commander is made up of a circuit battery board. The battery board has three 1.5V AA batteries. When the commander is first turned on, the battery board will be in the "off" position. To turn the commander on, you must turn the battery board to the "on" position. The battery board will be in the "on" position when the commander is turned on.



Resetting the Data and Time

Reset Data	Reset Time	Reset Date	Reset Time	Reset Date
1	1	1	1	1
2	2	2	2	2
3	3	3	3	3
4	4	4	4	4
5	5	5	5	5
6	6	6	6	6
7	7	7	7	7
8	8	8	8	8
9	9	9	9	9
10	10	10	10	10

Resetting the Date and Time

To Correct the Date and Time Setting

Repeat steps 2 to 5.

To Check the Date and Time

Press DATE to display the date indicator in the viewfinder. Press TIME to display the time indicator. When you press the same button again, the indicator goes out.

To Reset to Standard Time

Change D.S.T. mode setting in the menu system (p.25).

The year indicator changes as follows:

1994 ↔ 1995 ↔ 2024

Note on the time indicator

The internal clock of the camcorder operates on a 12-hour cycle. 12:00:00 AM stands for midnight. 12:00:00 PM stands for noon.

Playback Modes

The playback mode is selected automatically according to the recording system (SP/LP mode) in which the tape was recorded.

Notes on AFM Hi-Fi stereo — For stereo models (CCD-TR72/TR80)

When you play back the tape, the sound is in monaural if:

- You record the tape using this camcorder, then play it back on an AFM Hi-Fi monaural video recorder/player.
- You record the tape on an AFM Hi-Fi monaural video recorder, then play it back on this camcorder.

LP (long play) mode

When you play back a tape recorded in LP mode, the LP indicator lights up in the viewfinder. This camcorder cannot record tape in LP mode.

Foreign 8 mm video

You cannot play software recorded on a different TV color system. Because the TV color systems differ from country to country, you may not be able to play back foreign pre-recorded software. Refer to page 39 to check the TV color system of foreign countries.

Tips for Using the Battery Pack

This section shows you how you can get the most out of your battery pack.

Preparing the Battery Pack

Always Carry Additional Batteries





Have sufficient battery pack power to do 2 to 3 times as much recording as you have planned.

Battery Life is Shorter in Cold Environment

Battery efficiency is decreased and the battery will be used up more quickly if you are recording in cold environment.

To Save Battery Power

Turn the STANDBY switch on the camcorder down when not recording to save battery power. [a] A smooth transition between scenes can be made even if recording is stopped and started again. While positioning the subject, selecting an angle, or looking through the viewfinder lens, the lens moves automatically and the battery is used. The battery is also used when a tape is inserted or removed.



Good Energy Use, Cycles, and Items

To Control the Rate and Time Spelling

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

Handbook Methods

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

Top Ten Diving Dive Diving Pool

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time



14



15



16

17



18

Tips for Using the Battery Pack

When to Replace the Battery Pack

While you are using your camcorder, the remaining battery indicator decreases gradually as battery power is used up.



When the remaining battery indicator reaches the lowest point, the **i** indicator appears and starts flashing in the viewfinder. [b] on page 33.

When the **CL** indicator in the viewfinder changes from slow flashing to rapid flashing while you are recording, slide the POWER switch to OFF on the camcorder and replace the battery pack. Leave the tape in the camcorder to obtain smooth transition between scenes after the battery pack is replaced.

Note on the remaining battery indicator

The remaining battery indicator of the camcorder may indicate a different remaining capacity from that of the battery pack with the remaining battery indicator (not supplied). The indicator of the battery pack is more accurate.

Notes on the Rechargeable Battery Pack

The Battery Heats Up

During charging or recording, the battery pack heats up. This is caused by energy that has been generated and a chemical change that has occurred inside the battery pack. This is not cause for concern.

Battery Care

- Remove the battery pack from the camcorder after using the battery pack, and keep it in a cool place. When the battery pack is attached to the camcorder, a small amount of current flows to the camcorder even if the POWER switch is set to OFF, which shortens battery life.
- The battery pack is always discharging even when it is not in use after charging. Therefore, you should charge the battery right before using the camcorder.

How to Use the Switch on the Battery Pack

This switch is provided so that you can mark the charged battery. Set the switch to the "no mark" position when charging is completed. Set the switch to the "red mark" position when the battery is used up (or in whichever direction you want to remind yourself). [c] on page 33.

The Life of the Battery Pack

The battery pack can be fully charged and discharged about 500 times under normal temperatures. If the **CL** indicator flashes rapidly just after turning on the camcorder with a fully charged battery pack, the battery pack should be replaced with a new fully charged one.

Charging Temperature

You should charge batteries at temperatures from 50°F to 86°F (from 10°C to 30°C). Lower temperatures require a longer charging time.

Notes on Charging

A Brand-new Battery

A brand-new battery pack is not charged. Before using the battery pack, charge it completely.

Before Recharging a Used Battery Pack

- Make sure to use up the battery before recharging.
- If recording is completed before the **CL** indicator appears in the viewfinder, you should remove the tape, slide the POWER switch to CAMERA, turn STANDBY up, and leave the camcorder until the battery indicator flashes rapidly.
- When you use the AC-S10 power adaptor, you can use the discharging function.
- **Charging the usable battery causes a lowering of battery capacity. Battery capacity can be recovered if you fully discharge and charge the battery again.**

After Long Storage

Recharge the battery pack after a long period of storage. If the battery pack is charged fully but not used for a long time (about 1 year), it becomes discharged. Charge it again, but in this case the battery life will be shorter than normal. After several charging and discharging cycles, the battery life will recover its original capacity.

Notes on the Terminals

If the terminals (metal parts on the back) are not clean, the battery duration will be shortened.

When the terminals are not clean or when the battery pack has not been used for a long time, repeat installing and removing the battery pack. This improves the contact condition. Also, wipe the + and - terminals with a soft cloth or paper.

Be Sure to Observe the Following



- **To prevent an accident caused by a short circuit, do not allow metal objects such as a necklace to touch the battery terminals. Carry the battery pack attaching to the terminal cover. [d] on page 33.**
- Keep the battery pack away from fire.
- Keep the battery pack dry.
- Do not open nor convert the battery pack.
- Do not expose the battery pack to any mechanical shock.

Maintenance Information and Precautions


Moisture Condensation

If the camcorder is brought directly from a cold place to a warm place, moisture may condense inside the camcorder, on the surface of the tape, or on the lens. If this happens, the tape may stick to the head drum and be damaged or the camcorder may not operate correctly. To prevent possible damage under these circumstances, the camcorder is furnished with moisture sensors. However, take the following precautions.


Inside the Camcorder

When  and  indicators flash in the viewfinder, moisture has condensed inside the camcorder. If this happens, none of the functions except cassette ejection will work. Eject the cassette turn off the camcorder, and leave it with the cassette compartment open for about 1 hour.


If the  indicator does not light up when you turn on the power, you can use the camcorder again.



On the Surface of the Tape

If there is moisture on the surface of the tape, when you insert cassette and press a tape transport button (▶ PLAY, etc.), the  indicator flashes in the viewfinder. If this happens, none of the functions except cassette ejection will work.

Eject the cassette and leave it for about 1 hour.

If the  indicator does not light up when you insert the cassette and press a tape transport button, you can use the camcorder again.

On the Lens

No indicator will appear, but the picture becomes dim. Turn off the power and do not use the camcorder for about 1 hour.

How to Prevent Moisture Condensation

When bringing the camcorder from a cold place to a warm place, put the camcorder in a plastic bag and allow it to adapt to room conditions over a period of time.

- (1) Be sure to tightly seal the plastic bag containing the camcorder.
- (2) Remove the bag when the air temperature inside it has reached the temperature surrounding it (after about one hour).

Video Head Cleaning

To ensure clear pictures, clean the video heads periodically. When playback pictures are "noisy" or hardly visible, the video heads may be contaminated.



[a] → [b]

[a] Slight contamination

[b] Critical contamination
If this happens, clean the video heads with the Sony V8-25CLH cleaning cassette (not supplied). After checking the picture, if it is still "noisy", repeat the cleaning. (Do not repeat cleaning more than 5 times.)

Caution


Do not use a commercially available wet-type cleaning cassette. It may damage the video heads.

Note

If the V8-25CLH cleaning cassette is not available in your area, consult your nearest Sony dealer.

Removing Dust from inside the Viewfinder

- (1) While sliding the viewfinder release knob to the left, flip open the viewfinder. (2) Clean the surface with a commercially available blower.



© 2004 Blackwell Publishing Ltd *Journal of Internal Medicine* 255: 105–112

100

[illegible]

1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 26

[illegible][illegible]

100

Abstract

[illegible]

100

References

1000



100


100

1000

100

100

© 2000 by The McGraw-Hill Companies, Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage or retrieval system, without prior written permission from The McGraw-Hill Companies, Inc.



Maintenance Information and Precautions

Precautions

Camcorder Operation

- Operate the camcorder using 6.0 V (battery pack), or 7.5 V (AC power adaptor).
- For DC or AC operation, use only the accessories recommended in this manual.
- Should any solid object or liquid fall into the casing, unplug the camcorder and have it checked by your nearest Sony dealer before operating it any further.
- Avoid rough handling or mechanical shock. Be particularly careful of the lens.
- Keep the POWER switch set to OFF when not using the camera.
- Do not wrap up the camcorder and operate it since heat may build up internally.
- Keep the camcorder away from strong magnetic fields or mechanical vibration.

On Handling Tapes

Do not insert anything into the small holes on the rear of the cassette. These holes are used to sense the type, thickness of tape, or if the tab is out or in.

Camcorder Care

- When the camcorder is not to be used for a long time, disconnect the power source and remove the tape. Periodically turn on the power, operate the camera and player sections and play back a tape for about 3 minutes.
- Clean the lens with a soft brush to remove dust. If there are fingerprints on the lens, remove them with a soft cloth.
- Clean the camcorder body with a soft dry cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent which may damage the finish.

AC Power Adaptor

Charging

- Use only for the specified battery pack. This unit cannot be used to charge an NIP-500 series battery pack.
- Attach the battery pack firmly.
- Charge the battery pack on a flat surface without vibration.


Others

- The model for USA or Canada: One blade of the plug is wider than the other for the purpose of safety and will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- Unplug the unit from the wall (mains) outlet when not in use for a long time. To disconnect the cord (mains lead), pull it out by the plug. Never pull the cord itself.
- Do not operate the unit with a damaged cord or if the unit has been dropped or damaged.
- Do not bend the AC power cord forcibly, or put a heavy object on it. This will damage the cord and may cause a fire or an electrical shock.
- Be sure that nothing metallic comes into contact with the metal parts of the connecting plate. If this happens, a short may occur and the unit may be damaged.
- Always keep the metal contacts clean.
- Do not disassemble the unit.
- Do not apply mechanical shock or drop the unit.
- While the unit is in use, particularly during charging, keep it away from AM receivers and video equipment because it will disturb AM reception and video operation.
- The unit becomes warm while in use. This is normal.
- Do not place the unit in locations that are:
 - Extremely hot or cold
 - Dusty or dirty
 - Very humid
 - Vibrating

If any difficulty should arise, unplug the unit and contact your nearest Sony dealer.

Identifying the Parts

The illustrations in this section are of CCD-TR82.



- | | |
|-------------------------------------|--------------------------------------|
| 1 COUNTER RESET button (p.12) | 5 Viewfinder release knob (p.14, 37) |
| 2 TIME button (p.20) | 6 Battery mounting surface (p.8) |
| 3 DATE button (p.20) | 7 START/STOP button (p.11) |
| 4 BATT (battery) release knob (p.8) | 8 STANDBY switch (p.10, 11) |
| | 9 Menu operation buttons (p.25, 31) |

Identifying the Parts

The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a lubricating fluid to reduce friction. The heart is also connected to a network of blood vessels called the coronary arteries, which supply the heart muscle with oxygen and nutrients.


The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a lubricating fluid to reduce friction. The heart is also connected to a network of blood vessels called the coronary arteries, which supply the heart muscle with oxygen and nutrients.

The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a lubricating fluid to reduce friction. The heart is also connected to a network of blood vessels called the coronary arteries, which supply the heart muscle with oxygen and nutrients.

The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a lubricating fluid to reduce friction. The heart is also connected to a network of blood vessels called the coronary arteries, which supply the heart muscle with oxygen and nutrients.


The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a lubricating fluid to reduce friction. The heart is also connected to a network of blood vessels called the coronary arteries, which supply the heart muscle with oxygen and nutrients.

Identifying the Parts



- 1. Right Atrium
- 2. Right Ventricle
- 3. Left Atrium
- 4. Left Ventricle
- 5. Aorta
- 6. Pulmonary Artery
- 7. Pulmonary Veins
- 8. Superior Vena Cava
- 9. Inferior Vena Cava
- 10. Coronary Arteries
- 11. Coronary Veins
- 12. Pericardium



Identifying the Parts



- 10 Hook for shoulder strap (below)
- 11 LANC \square control jack
Connect the LANC \square connecting cable to a wired remote control such as an editing controller. In this case, set the COMMANDER mode to OFF in the menu system (p.25).
 \square stands for Local Application Control Bus system. The \square control jack is used for controlling the tape transport of video equipment and peripherals connected to it. This jack has the same function as the connectors indicated as CONTROL L or REMOTE.
- 12 \square (earphone) jack (CCD-TR42/TR70/TR82) (p.15)
- 13 \square (headphones) jack (CCD-TR72/TR80) (p.15)
- 14 Hook for shoulder strap (below)
- 15 Lithium battery compartment (p.30)
- 16 Cassette compartment lid (p.9)
- 17 MIC (microphone) jack
- 18 VIDEO jack (p.16)
- 19 RFU DC OUT (RFU adaptor DC out) jack (p.16)
- 20 AUDIO jack (p.16)
- 21 Jack cover
- 22 Grip strap (p.14)
- 23 Tripod receptacle (p.14)
Attach a tripod (not supplied) here. When attaching a non-Sony tripod, make sure that the length of the camera mounting screw is shorter than 9/32 inches (6.5 mm). Otherwise, the screw might damage the inner part of the camcorder.

Attaching the shoulder strap

Attach the supplied shoulder strap to the hooks for the shoulder strap (10, 13).




- 23 Tape transport buttons (p.17)
 \blacksquare STOP
 \triangleleft REW (rewind)
 \triangleright PLAY (playback)
 \triangleright FF (fast forward)
 \blacksquare PAUSE
These buttons will function in PLAYER mode.
- 24 EJECT button (p.9)
- 25 EDITSEARCH button (p.15)
- 26 Built-in microphone
- 27 Camera recording/battery lamp
- 28 Remote sensor (p.49)
- 29 Lens cover
- 30 POWER switch (p.10, 11)
- 31 STEADY SHOT switch (p.24)
- 32 FADER button (p.23)
- 33 POWER ZOOM button (p.13)
- 34 Eyecup (p.14)
- 35 Viewfinder adjustment ring (p.10)
- 36 Viewfinder (p.10, 14)
- 37 BACK LIGHT button (p.21)
- 38 PROGRAM AE button (p.22)

Identifying the 2nd year



- 1. Head for double valve timing
- 2. Head for double valve timing
- 3. Head for double valve timing
- 4. Head for double valve timing
- 5. Head for double valve timing
- 6. Head for double valve timing
- 7. Head for double valve timing
- 8. Head for double valve timing
- 9. Head for double valve timing
- 10. Head for double valve timing

Identifying the 2nd year




- 1. Head for double valve timing
- 2. Head for double valve timing
- 3. Head for double valve timing
- 4. Head for double valve timing
- 5. Head for double valve timing
- 6. Head for double valve timing
- 7. Head for double valve timing
- 8. Head for double valve timing
- 9. Head for double valve timing
- 10. Head for double valve timing

Identifying the Parts

Remote Commander

The buttons that have the same name on the Remote Commander and on the camcorder function identically.



1 Transmitter (p.49)

Point toward the remote sensor to control the camcorder after turning on the POWER switch on the camcorder.

2 Tape transport buttons (p.17)

The zooming speed is unchangeable on the Remote Commander.

3 DISPLAY button (p.18)


4 Size AA (R6) battery holder

5 START/STOP button

6 Power zoom button

Preparing the Remote Commander

To use the Remote Commander, you must insert two size AA (R6) batteries. Use the supplied size AA (R6) batteries. (1) Remove the battery cover from the Remote Commander. (2) Insert both of the size AA (R6) batteries with correct polarity. (3) Put the battery cover back onto the Remote Commander.



Note on battery life


The batteries for the Remote Commander last about 6 months under normal operation. When the batteries become weak or dead, the Remote Commander does not work.

To avoid damage from possible battery leakage

Remove the batteries when you will not use the Remote Commander for a long time.


Using the Remote Commander

Make sure that the COMMANDER mode is set to ON in the menu system (p.25).



Remote Control Direction

Aim the Remote Commander to the remote sensor within the range as shown below.



Notes on the Remote Commander

- Keep the remote sensor away from strong light sources such as direct sunlight or illumination. Otherwise, the remote control may not be effective.
- Be sure that there is no obstacle between the remote sensor and the Remote Commander.
- This camcorder works at commander mode VTR 2. The commander modes (1, 2, and 3) are used to distinguish this camcorder from other Sony VCRs to avoid remote control misoperation. If you use another Sony VCR at commander mode VTR 2, we recommend you change the commander mode or cover the remote sensor of the VCR with black paper.

100



- [illegible]

100

Abstract



1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 2679, 26

100

[illegible]

100



100

1



100

11


100


100

1000

100

2-14. CIRCUIT BOARDS LOCATION







ZB-2 (BUZZER/LITHIUM BATTERY) PRINTED WIRING BOARD

— Ref. No. ZB-2 BOARD: 4000 series —

ZB-2 BOARD



- For printed wiring board of ZB-2 board.
- : Pattern from the side which enables seeing.
- : Pattern of the rear side.




ZB-2 (BUZZER/LITHIUM BATTERY) SCHEMATIC DIAGRAM

— Ref. No. ZB-2 BOARD: 4000 series —

ZB-2 BOARD

•CONTROL SWITCH BLOCK (CK)
Is replaced as a block, so that there
SCHEMATIC DIAGRAM
PRINTED WIRING BOARD
is omitted.




09


VF-65 (W/B EVF) PRINTED WIRING BOARD (TR42/TR72/TR82/TR400/TR430/TR550/TR750)

— Ref. No. VF-65 BOARD: 8000 series —

VF-65 BOARD (COMPONENT SIDE)




VF-65 BOARD (CONDUCTOR SIDE)



- For printed wiring boards.
- VF-65 board is a four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

— SEE THE VF-65 BOARD SPECIFICATIONS —

VF-65 BOARD (COMPONENT SIDE)




VF-65 BOARD (CONDUCTOR SIDE)




- For plated wiring boards.
- VF-65 board has a top layer plated board. However, the pattern of layer 2 is not shown/indicated in the diagram.

5-1-10. MECHANISM CHASSIS ASSEMBLY (1)




Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
801	A-7049-501-A	DRUM ASSY, UPPER (DGR-78-R) (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		810	3-945-702-01	ROLLER, LS	
801	A-7049-567-A	DRUM ASSY, UPPER (DGR-92-R) (TR400/TR750)		811	X-3941-262-1	ROLLER ASSY, TG2	
802	3-945-822-01	SPRING, LEAF, TG7 ARM		812	3-956-651-01	SPRING, COMPRESSION	
803	A-7040-305-A	ARM BLOCK ASSY, TG7		813	3-686-493-01	SCREW (M2X5), P1	
804	3-947-503-01	SCREW (M1.4X2.5)		814	1-568-323-11	CONNECTOR, BOARD TO BOARD 4P	
805	X-3941-255-1	PLATE (T) ASSY, SIDE		M901	A-7048-564-A	DRUM ASSY (DGH-78A-R) (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
806	3-945-735-01	ARM, HC CONVERSION		M901	A-7048-633-A	DRUM ASSY (DGH-92A-R) (TR400/TR750)	
807	3-713-786-71	SCREW (M2X5)		M902	8-835-477-12	MOTOR, DC SCE-0101A (CAPSTAN)	
808	3-945-691-01	PLATE (S), SIDE		M903	A-7040-304-A	MOTOR BLOCK ASSY, LM (LOADING)	
809	3-945-701-01	ARM, LS					

5-1-11. MECHANISM CHASSIS ASSEMBLY (2)



Note: 875 (FP-575 flexible board) is part that exchange the only leading part of 874 (FP-442 flexible board).

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
851	3-945-734-01	ARM, HC DRIVING		865	A-7040-303-A	CHASSIS ASSY, MECHANICAL	
852	3-728-103-11	SCREW (M1.4X1.6), SPECIAL HEAD		866	3-947-503-01	SCREW (M1.4X2.5)	
853	X-3941-259-1	ARM ASSY, PINCH PRESS		867	3-945-722-01	RETAINER, GEAR	
854	3-726-829-01	WASHER, STOPPER		868	X-3941-257-1	ARM ASSY, FF	
855	3-945-730-01	SLEEVE, EJECT		869	3-945-697-01	GEAR (B), L	
856	3-945-706-01	LEVER, EJECT		870	3-945-700-01	GEAR (A), L	
857	3-945-729-01	SPRING, COMPRESSION		871	1-641-643-12	FP-444 FLEXIBLE BOARD	
858	X-3941-256-1	GEAR ASSY, CHANGE		872	1-691-254-13	CONNECTOR, TRANSLATION 10P	
859	3-944-539-01	BELT, RELAY		873	3-945-756-01	SCREW (M1.4X3)	
860	3-945-695-01	PULLEY, RELAY		874	1-641-639-13	FP-442 FLEXIBLE BOARD	
861	X-3941-260-1	SLIDER ASSY, M		875	1-645-271-11	FP-575 FLEXIBLE BOARD	
862	3-945-696-02	CAM		S001	1-572-986-11	SWITCH, ROTARY (ENCODER)	
863	X-3941-258-1	ARM ASSY, GL		S005	1-570-771-21	SWITCH (C DOWN)	
864	3-713-786-71	SCREW (M2X5)					



Model 100 (PFA-100) Machine (new) is just the package the city (leading part of PFA-100) Machine (new).

Index	Date Recd.	Description
1000	10/1/1910	1000
1001	10/1/1910	1001
1002	10/1/1910	1002
1003	10/1/1910	1003
1004	10/1/1910	1004
1005	10/1/1910	1005
1006	10/1/1910	1006
1007	10/1/1910	1007
1008	10/1/1910	1008
1009	10/1/1910	1009
1010	10/1/1910	1010
1011	10/1/1910	1011
1012	10/1/1910	1012
1013	10/1/1910	1013
1014	10/1/1910	1014
1015	10/1/1910	1015
1016	10/1/1910	1016
1017	10/1/1910	1017
1018	10/1/1910	1018
1019	10/1/1910	1019
1020	10/1/1910	1020
1021	10/1/1910	1021
1022	10/1/1910	1022
1023	10/1/1910	1023
1024	10/1/1910	1024
1025	10/1/1910	1025
1026	10/1/1910	1026
1027	10/1/1910	1027
1028	10/1/1910	1028
1029	10/1/1910	1029
1030	10/1/1910	1030
1031	10/1/1910	1031
1032	10/1/1910	1032
1033	10/1/1910	1033
1034	10/1/1910	1034
1035	10/1/1910	1035
1036	10/1/1910	1036
1037	10/1/1910	1037
1038	10/1/1910	1038
1039	10/1/1910	1039
1040	10/1/1910	1040
1041	10/1/1910	1041
1042	10/1/1910	1042
1043	10/1/1910	1043
1044	10/1/1910	1044
1045	10/1/1910	1045
1046	10/1/1910	1046
1047	10/1/1910	1047
1048	10/1/1910	1048
1049	10/1/1910	1049
1050	10/1/1910	1050
1051	10/1/1910	1051
1052	10/1/1910	1052
1053	10/1/1910	1053
1054	10/1/1910	1054
1055	10/1/1910	1055
1056	10/1/1910	1056
1057	10/1/1910	1057
1058	10/1/1910	1058
1059	10/1/1910	1059
1060	10/1/1910	1060
1061	10/1/1910	1061
1062	10/1/1910	1062
1063	10/1/1910	1063
1064	10/1/1910	1064
1065	10/1/1910	1065
1066	10/1/1910	1066
1067	10/1/1910	1067
1068	10/1/1910	1068
1069	10/1/1910	1069
1070	10/1/1910	1070
1071	10/1/1910	1071
1072	10/1/1910	1072
1073	10/1/1910	1073
1074	10/1/1910	1074
1075	10/1/1910	1075
1076	10/1/1910	1076
1077	10/1/1910	1077
1078	10/1/1910	1078
1079	10/1/1910	1079
1080	10/1/1910	1080
1081	10/1/1910	1081
1082	10/1/1910	1082
1083	10/1/1910	1083
1084	10/1/1910	1084
1085	10/1/1910	1085
1086	10/1/1910	1086
1087	10/1/1910	1087
1088	10/1/1910	1088
1089	10/1/1910	1089
1090	10/1/1910	1090
1091	10/1/1910	1091
1092	10/1/1910	1092
1093	10/1/1910	1093
1094	10/1/1910	1094
1095	10/1/1910	1095
1096	10/1/1910	1096

[illegible]

AU-165

5-2. ELECTRICAL PARTS LIST

NOTE:

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms
METAL: Metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F : nonflammable
- Hardware (# mark) list is given in the last of this parts list.
- Canadian model is abbreviated as CND.

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u: μ , for example:
uA...: μ A..., uPA...: μ PA...,
uPB...: μ PB..., uPC...: μ PC...,
uPD...: μ PD...
- CAPACITORS
uF: μ F
- COILS
uH: μ H

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-7063-958-A	AU-165 BOARD, COMPLETE ***** (TR72/TR80/TR400/TR430/TR750) (Ref. No. 10, 000 Series)		C1345	1-162-967-11	CERAMIC CHIP 0.0033uF 10%	50V
		< CAPACITOR >		C1346	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1302	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V	C1347	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1303	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	C1348	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1304	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	C1349	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1305	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	C1350	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1306	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1352	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1307	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1353	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1308	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	C1355	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1309	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1356	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C1310	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1357	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C1311	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1358	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1312	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1359	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1313	1-162-953-11	CERAMIC CHIP 100PF 5%	50V	C1360	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1314	1-162-953-11	CERAMIC CHIP 100PF 5%	50V	C1361	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1315	1-126-209-11	ELECT 100uF 20%	4V	C1362	1-162-969-11	CERAMIC CHIP 0.0068uF 10%	25V
C1316	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V	C1363	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1318	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	C1364	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1319	1-162-953-11	CERAMIC CHIP 100PF 5%	50V			< CONNECTOR >	
C1321	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	CN1301	1-691-490-21	CONNECTOR, FFC/FPC 11P	
C1323	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	* CN1302	1-691-933-11	CONNECTOR, BOARD TO BOARD 34P	
C1326	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V			< DIODE >	
C1327	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	D1302	8-719-404-46	DIODE MA110	
C1328	1-135-091-21	TANTAL. CHIP 1uF 20%	16V	D1303	8-719-045-87	DIODE MA4Z082WA-TX	
C1329	1-135-091-21	TANTAL. CHIP 1uF 20%	16V	D1304	8-719-045-87	DIODE MA4Z082WA-TX	
C1330	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V			< FILTER >	
C1331	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V	FL402	1-236-838-21	FILTER, BAND PASS (1.7MHz)	
C1332	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	FL1302	1-236-837-21	FILTER, BAND PASS (1.5MHz)	
C1333	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V			< IC >	
C1334	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	IC402	8-759-234-77	IC TC4S66F	
C1335	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	IC1301	8-759-159-94	IC LA7491W-TBM	
C1336	1-135-148-21	TANTAL. CHIP 1.5uF 20%	10V			< TRANSISTOR >	
C1337	1-135-148-21	TANTAL. CHIP 1.5uF 20%	10V	Q1301	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1338	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1302	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1339	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1303	8-729-403-35	TRANSISTOR UN5113	
C1340	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1305	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1341	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1306	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1343	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V				
C1344	1-164-346-11	CERAMIC CHIP 1uF 16V					

AU-169**DD-60****DD-66**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C426	1-162-957-11	CERAMIC CHIP	220PF 5% 50V	R416	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
C428	1-128-006-11	ELECT CHIP	4.7uF 20% 25V	R417	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
C429	1-128-013-11	ELECT CHIP	1uF 20% 50V	R418	1-216-851-11	METAL CHIP	330K 5% 1/16W
C430	1-128-004-11	ELECT CHIP	10uF 20% 16V	R419	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
C431	1-162-969-11	CERAMIC CHIP	0.0068uF 10% 25V	R420	1-216-832-11	METAL CHIP	8.2K 5% 1/16W
C432	1-164-674-11	CERAMIC CHIP	1800PF 5% 16V	R421	1-216-864-11	METAL CHIP	0 5% 1/16W
C433	1-164-346-11	CERAMIC CHIP	1uF 10% 16V	R423	1-216-839-11	METAL CHIP	33K 5% 1/16W
C434	1-128-003-11	ELECT CHIP	22uF 20% 4V	R424	1-216-833-11	METAL CHIP	10K 5% 1/16W
C435	1-162-966-11	CERAMIC CHIP	0.0022uF 10% 50V	R425	1-216-810-11	METAL CHIP	120 5% 1/16W
C436	1-126-205-11	ELECT CHIP	47uF 20% 6.3V	R427	1-216-817-11	METAL CHIP	470 5% 1/16W
C437	1-126-205-11	ELECT CHIP	47uF 20% 6.3V	R428	1-216-833-11	METAL CHIP	10K 5% 1/16W
C438	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	R429	1-216-827-11	METAL CHIP	3.3K 5% 1/16W
C439	1-128-004-11	ELECT CHIP	10uF 20% 16V	R430	1-216-841-11	METAL CHIP	47K 5% 1/16W
C440	1-162-974-11	CERAMIC CHIP	0.01uF 50V	R431	1-216-823-11	METAL CHIP	1.5K 5% 1/16W
C441	1-126-205-11	ELECT CHIP	47uF 20% 6.3V	R432	1-216-825-11	METAL CHIP	2.2K 5% 1/16W
C442	1-162-974-11	CERAMIC CHIP	0.01uF 50V	R433	1-216-817-11	METAL CHIP	470 5% 1/16W
< CONNECTOR >				R434	1-216-821-11	METAL CHIP	1K 5% 1/16W
CN401	1-691-516-11	CONNECTOR, BOARD TO BOARD 24P		R435	1-216-836-11	METAL CHIP	18K 5% 1/16W
CN402	1-691-487-21	CONNECTOR, FFC/FPC 8P		R436	1-216-837-11	METAL CHIP	22K 5% 1/16W
< DIODE >				*****			
D402	8-719-045-87	DIODE MA4Z082WA-TX		*	A-7063-960-A	DD-60 BOARD, COMPLETE	
< IC >				*****			
IC401	8-759-823-19	IC CXA1488RR		(TR72/TR400/TR430/TR750)			
< COIL >				*	A-7066-009-A	DD-60 BOARD, COMPLETE (TR80)	
< TRANSISTOR >				*****			
Q402	8-729-230-63	TRANSISTOR 2SC4116		*	A-7063-954-A	DD-66 BOARD, COMPLETE (TR42/TR82/TR550)	
Q403	8-729-230-63	TRANSISTOR 2SC4116		*****			
Q404	8-729-402-81	TRANSISTOR XN4501		*	A-7066-006-A	DD-66 BOARD, COMPLETE (TR70)	
Q405	8-729-402-42	TRANSISTOR UN5213		*****			
Q406	8-729-403-35	TRANSISTOR UN5113		(Ref. No. 9,000 Series)			
< RESISTOR >				< CAPACITOR >			
R401	1-216-849-11	METAL CHIP	220K 5% 1/16W	C901	1-163-989-11	CERAMIC CHIP	0.033uF 10% 25V
R402	1-216-864-11	METAL CHIP	0 5% 1/16W	C902	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V
R403	1-216-859-11	METAL GLAZE	1.5M 5% 1/16W	C903	1-163-121-00	CERAMIC CHIP	150PF 5% 50V
R404	1-216-851-11	METAL CHIP	330K 5% 1/16W	C904	1-163-121-00	CERAMIC CHIP	150PF 5% 50V
R407	1-216-837-11	METAL CHIP	22K 5% 1/16W	C906	1-164-245-11	CERAMIC CHIP	0.015uF 10% 25V
R409	1-216-833-11	METAL CHIP	10K 5% 1/16W	C907	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R410	1-216-840-11	METAL CHIP	39K 5% 1/16W	C908	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R411	1-216-833-11	METAL CHIP	10K 5% 1/16W	C909	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R412	1-216-821-11	METAL CHIP	1K 5% 1/16W	C910	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
R413	1-216-835-11	METAL CHIP	15K 5% 1/16W	C911	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R415	1-216-849-11	METAL CHIP	220K 5% 1/16W	C912	1-128-530-11	ELECT CHIP	33uF 20% 10V
				C913	1-128-004-11	ELECT CHIP	10uF 20% 16V
				C914	1-128-004-11	ELECT CHIP	10uF 20% 16V
				C915	1-165-178-11	CERAMIC CHIP	6.8uF 16V
				C916	1-128-004-11	ELECT CHIP	10uF 20% 16V
				C917	1-165-178-11	CERAMIC CHIP	6.8uF 16V

Ref. No.	Part No.	Description	Remark
C918	1-165-178-11	CERAMIC CHIP 6. 8uF	16V
C920	1-165-178-11	CERAMIC CHIP 6. 8uF	16V
C921	1-165-178-11	CERAMIC CHIP 6. 8uF	16V
C923	1-165-178-11	CERAMIC CHIP 6. 8uF	16V
C924	1-165-178-11	CERAMIC CHIP 6. 8uF	16V
C925	1-164-337-11	CERAMIC CHIP 2. 2uF	16V
C926	1-164-337-11	CERAMIC CHIP 2. 2uF	16V
C927	1-165-178-11	CERAMIC CHIP 6. 8uF	16V
C928	1-165-178-11	CERAMIC CHIP 6. 8uF	16V
C929	1-135-216-11	TANTALUM CHIP 10uF 20%	10V
C930	1-107-418-11	ELECT CHIP 10uF 20%	35V
C931	1-128-004-11	ELECT CHIP 10uF 20%	16V
C932	1-128-004-11	ELECT CHIP 10uF 20%	16V
C934	1-128-004-11	ELECT CHIP 10uF 20%	16V
C935	1-128-004-11	ELECT CHIP 10uF 20%	16V
C936	1-128-004-11	ELECT CHIP 10uF 20%	16V
C937	1-128-004-11	ELECT CHIP 10uF 20%	16V
C938	1-128-004-11	ELECT CHIP 10uF 20%	16V
C939	1-163-023-00	CERAMIC CHIP 0. 015uF 5%	50V
C940	1-163-023-00	CERAMIC CHIP 0. 015uF 5%	50V
C941	1-163-019-00	CERAMIC CHIP 0. 0068uF 10%	50V
C942	1-163-009-11	CERAMIC CHIP 0. 001uF 10%	50V
C943	1-163-019-00	CERAMIC CHIP 0. 0068uF 10%	50V
C944	1-164-161-11	CERAMIC CHIP 0. 0022uF 10%	100V
C945	1-128-530-11	ELECT CHIP 33uF 20%	10V
C950	1-128-004-11	ELECT CHIP 10uF 20%	16V
< CONNECTOR >			
CN901	1-695-324-11	CONNECTOR, BOARD TO BOARD 42P	
< DIODE >			
D900	8-719-045-87	DIODE MA4Z082WA	
D901	8-719-027-77	DIODE MA796	
D902	8-719-045-87	DIODE MA4Z082WA	(TR72/TR80/TR400/TR430/TR750)
D909	8-719-404-49	DIODE MA111	
D910	8-719-404-49	DIODE MA111	
< FUSE >			
△F450	1-576-213-11	FUSE, CHIP (1. 6A 125V)	
△F451	1-576-213-11	FUSE, CHIP (1. 6A 125V)	
△F452	1-576-213-11	FUSE, CHIP (1. 6A 125V)	
< IC >			
IC901	8-759-249-14	IC MB3799-02PFV-GBND-ER	
< JACK >			
J901	1-537-281-41	TERMINAL BOARD (BATTERY)	
J902	1-565-276-21	JACK, ULTRA SMALL 1P (REMOTE)	

Ref. No.	Part No.	Description	Remark
J903	1-568-027-11	JACK, SMALL TYPE 1P (EARPHONE)	(TR42/TR70/TR82/TR550)
J903	1-569-809-11	JACK (SMALL TYPE) (HEADPHONES)	(TR72/TR80/TR400/TR430/TR750)
< COIL >			
L901	1-424-653-11	COIL, CHOKE 10uH	
L902	1-424-653-11	COIL, CHOKE 10uH	
L903	1-424-653-11	COIL, CHOKE 10uH	
L904	1-409-556-11	COIL, CHOKE 47uH	
L905	1-424-674-11	COIL, CHOKE 22uH	
L906	1-409-556-11	COIL, CHOKE 47uH	
L907	1-424-674-11	COIL, CHOKE 22uH	
L908	1-424-674-11	COIL, CHOKE 22uH	
L909	1-412-056-11	INDUCTOR CHIP 4. 7uH	
L910	1-412-056-11	INDUCTOR CHIP 4. 7uH	
L911	1-412-056-11	INDUCTOR CHIP 4. 7uH	
L912	1-412-056-11	INDUCTOR CHIP 4. 7uH	
L913	1-412-056-11	INDUCTOR CHIP 4. 7uH	
L914	1-412-064-11	INDUCTOR CHIP 100uH	
L915	1-412-064-11	INDUCTOR CHIP 100uH	
L916	1-412-056-11	INDUCTOR CHIP 4. 7uH	
L917	1-412-056-11	INDUCTOR CHIP 4. 7uH	
< TRANSISTOR >			
Q900	8-729-421-90	TRANSISTOR XN4113	(TR70/TR80)
Q901	8-729-420-12	TRANSISTOR XN4213	
Q902	8-729-804-41	TRANSISTOR 2SB1122	
Q903	8-729-823-82	TRANSISTOR FP101	
Q904	8-729-823-84	TRANSISTOR FP102	
Q905	8-729-823-82	TRANSISTOR FP101	
Q906	8-729-823-82	TRANSISTOR FP101	
Q907	8-729-823-82	TRANSISTOR FP101	
Q908	8-729-420-12	TRANSISTOR XN4213	(TR70/TR80)
Q909	8-729-805-25	TRANSISTOR 2SB1121	
Q910	8-729-429-32	TRANSISTOR UN9210-QRS	(TR70/TR80)
Q911	8-729-402-42	TRANSISTOR UN5213	
Q912	8-729-420-24	TRANSISTOR 2SB1218A	
Q914	8-729-402-42	TRANSISTOR UN5213	
Q915	8-729-402-42	TRANSISTOR UN5213	
< RESISTOR >			
R901	1-218-872-11	METAL CHIP 11K 0. 50% 1/16W	
R902	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R903	1-216-827-11	METAL CHIP 3. 3K 5% 1/16W	
R904	1-216-827-11	METAL CHIP 3. 3K 5% 1/16W	
R905	1-216-836-11	METAL CHIP 18K 5% 1/16W	
R906	1-216-827-11	METAL CHIP 3. 3K 5% 1/16W	
R907	1-216-035-00	METAL CHIP 270 5% 1/10W	
R908	1-216-834-11	METAL CHIP 12K 5% 1/16W	
R909	1-216-031-00	METAL CHIP 180 5% 1/10W	

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

DD-60**DD-66****FP-49****FP-89 (CD)**

Ref. No.	Part No.	Description	Remark
R910	1-216-029-00	METAL CHIP 150 5% 1/10W	
R911	1-216-029-00	METAL CHIP 150 5% 1/10W	
R912	1-216-029-00	METAL CHIP 150 5% 1/10W	
R913	1-216-041-00	METAL CHIP 470 5% 1/10W	
R915	1-216-864-11	METAL CHIP 0 5% 1/16W	
R918	1-216-819-11	METAL CHIP 680 5% 1/16W	
R919	1-216-836-11	METAL CHIP 18K 5% 1/16W	
R920	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R921	1-412-052-21	INDUCTOR CHIP 1uH	
R922	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R923	1-412-052-21	INDUCTOR CHIP 1uH	
R924	1-412-979-21	INDUCTOR 1uH	
R925	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R926	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R931	1-216-864-11	METAL CHIP 0 5% 1/16W	
R932	1-412-979-21	INDUCTOR 1uH	
R933	1-412-979-21	INDUCTOR 1uH (TR72/TR80/TR400/TR430/TR750)	
R934	1-216-864-11	METAL CHIP 0 5% 1/16W	
R936	1-412-979-21	INDUCTOR 1uH	
R937	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
R938	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
R939	1-216-864-11	METAL CHIP 0 5% 1/16W (TR70/TR80)	
R940	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
R941	1-218-849-11	METAL CHIP 1.2K 0.50% 1/16W	
R942	1-216-864-11	METAL CHIP 0 5% 1/16W	
R943	1-216-864-11	METAL CHIP 0 5% 1/16W (TR70/TR80)	
R944	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
R945	1-218-847-11	METAL CHIP 1K 0.50% 1/16W	
R946	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR70/TR80)	
R947	1-216-828-11	METAL CHIP 3.9K 5% 1/16W (TR70/TR80)	
R948	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR70/TR80)	
R949	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR70/TR80)	
< TRANSFORMER >			
T901	1-426-730-11	TRANSFORMER, CONVERTER	

Ref. No.	Part No.	Description	Remark
*	1-651-890-11	FP-49 FLEXIBLE BOARD ***** (TR82/TR400/TR550/TR750) (Ref. No. 3,000 Series)	
< SENSOR >			
SE691	1-810-024-31	SENSOR, ANGULAR VELOCITY	
SE692	1-810-024-41	SENSOR, ANGULAR VELOCITY	

*	A-7072-004-A	FP-89 (CD) BOARD, COMPLETE ***** (TR82/TR400/TR550/TR750)	
*	A-7072-005-A	FP-89 (CD) BOARD, COMPLETE ***** (TR42/TR70/TR72/TR80/TR430) (Ref. No. 3,000 Series)	
< CAPACITOR >			
C691	1-135-214-21	TANTAL. CHIP 4.7uF 20% 20V	
C692	1-135-210-11	TANTALUM CHIP 4.7uF 20% 10V	
C694	1-164-346-11	CERAMIC CHIP 1uF 16V	
C695	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
C696	1-104-908-11	TANTAL. CHIP 47uF 20% 4V	
< IC >			
IC691	A-7030-368-A	CCD BLOCK ASSY (AUTO) (054 SERVICE) (CCD IMAGER) (TR42/TR70/TR72/TR80/TR430)	
IC691	A-7030-373-A	CCD BLOCK ASSY (AUTO) (059V SERVICE) (CCD IMAGER) (TR82/TR400/TR550/TR750)	
< COIL >			
L691	1-412-963-11	INDUCTOR 100uH	
< TRANSISTOR >			
Q691	8-729-232-86	TRANSISTOR 2SK1875-BL/V	
Q692	8-729-117-73	TRANSISTOR 2SC4178-F14	
< RESISTOR >			
R691	1-216-295-00	METAL CHIP 0 5% 1/10W	
R692	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R693	1-216-839-11	METAL CHIP 33K 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	
R693	1-216-840-11	METAL CHIP 39K 5% 1/16W (TR82/TR400/TR550/TR750)	
R694	1-216-819-11	METAL CHIP 680 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	
R694	1-216-820-11	METAL CHIP 820 5% 1/16W (TR82/TR400/TR550/TR750)	
R695	1-216-845-11	METAL CHIP 100K 5% 1/16W (TR82/TR400/TR550/TR750)	

Be sure to read "Note on the CCD Imager replacement" on page 4-6 when changing the CCD imager.

Ref. No.	Part No.	Description	Quantity	Ref. No.	Part No.	Description	Quantity
850	1-03-08-01	WHL, CR7	80	8	1-03-08-11	ST-01 FLANGE, SHOT	1
851	1-03-08-01	WHL, CR7	80			*****	
852	1-03-08-01	WHL, CR7	80			CR7/CR8/CR9/CR10	
853	1-03-08-01	WHL, CR7	80			(Ref. No. 4, 10, 16, 18)	
854	1-03-08-01	WHL, CR7	80				
855	1-03-08-01	WHL, CR7	80				
856	1-03-08-01	WHL, CR7	80				
857	1-03-08-01	WHL, CR7	80				
858	1-03-08-01	WHL, CR7	80				
859	1-03-08-01	WHL, CR7	80				
860	1-03-08-01	WHL, CR7	80				
861	1-03-08-01	WHL, CR7	80				
862	1-03-08-01	WHL, CR7	80				
863	1-03-08-01	WHL, CR7	80				
864	1-03-08-01	WHL, CR7	80				
865	1-03-08-01	WHL, CR7	80				
866	1-03-08-01	WHL, CR7	80				
867	1-03-08-01	WHL, CR7	80				
868	1-03-08-01	WHL, CR7	80				
869	1-03-08-01	WHL, CR7	80				
870	1-03-08-01	WHL, CR7	80				
871	1-03-08-01	WHL, CR7	80				
872	1-03-08-01	WHL, CR7	80				
873	1-03-08-01	WHL, CR7	80				
874	1-03-08-01	WHL, CR7	80				
875	1-03-08-01	WHL, CR7	80				
876	1-03-08-01	WHL, CR7	80				
877	1-03-08-01	WHL, CR7	80				
878	1-03-08-01	WHL, CR7	80				
879	1-03-08-01	WHL, CR7	80				
880	1-03-08-01	WHL, CR7	80				
881	1-03-08-01	WHL, CR7	80				
882	1-03-08-01	WHL, CR7	80				
883	1-03-08-01	WHL, CR7	80				
884	1-03-08-01	WHL, CR7	80				
885	1-03-08-01	WHL, CR7	80				
886	1-03-08-01	WHL, CR7	80				
887	1-03-08-01	WHL, CR7	80				
888	1-03-08-01	WHL, CR7	80				
889	1-03-08-01	WHL, CR7	80				
890	1-03-08-01	WHL, CR7	80				
891	1-03-08-01	WHL, CR7	80				
892	1-03-08-01	WHL, CR7	80				
893	1-03-08-01	WHL, CR7	80				
894	1-03-08-01	WHL, CR7	80				
895	1-03-08-01	WHL, CR7	80				
896	1-03-08-01	WHL, CR7	80				
897	1-03-08-01	WHL, CR7	80				
898	1-03-08-01	WHL, CR7	80				
899	1-03-08-01	WHL, CR7	80				
900	1-03-08-01	WHL, CR7	80				
901	1-03-08-01	WHL, CR7	80				
902	1-03-08-01	WHL, CR7	80				
903	1-03-08-01	WHL, CR7	80				
904	1-03-08-01	WHL, CR7	80				
905	1-03-08-01	WHL, CR7	80				
906	1-03-08-01	WHL, CR7	80				
907	1-03-08-01	WHL, CR7	80				
908	1-03-08-01	WHL, CR7	80				
909	1-03-08-01	WHL, CR7	80				
910	1-03-08-01	WHL, CR7	80				
911	1-03-08-01	WHL, CR7	80				
912	1-03-08-01	WHL, CR7	80				
913	1-03-08-01	WHL, CR7	80				
914	1-03-08-01	WHL, CR7	80				
915	1-03-08-01	WHL, CR7	80				
916	1-03-08-01	WHL, CR7	80				
917	1-03-08-01	WHL, CR7	80				
918	1-03-08-01	WHL, CR7	80				
919	1-03-08-01	WHL, CR7	80				
920	1-03-08-01	WHL, CR7	80				
921	1-03-08-01	WHL, CR7	80				
922	1-03-08-01	WHL, CR7	80				
923	1-03-08-01	WHL, CR7	80				
924	1-03-08-01	WHL, CR7	80				
925	1-03-08-01	WHL, CR7	80				
926	1-03-08-01	WHL, CR7	80				
927	1-03-08-01	WHL, CR7	80				
928	1-03-08-01	WHL, CR7	80				
929	1-03-08-01	WHL, CR7	80				
930	1-03-08-01	WHL, CR7	80				
931	1-03-08-01	WHL, CR7	80				
932	1-03-08-01	WHL, CR7	80				
933	1-03-08-01	WHL, CR7	80				
934	1-03-08-01	WHL, CR7	80				
935	1-03-08-01	WHL, CR7	80				
936	1-03-08-01	WHL, CR7	80				
937	1-03-08-01	WHL, CR7	80				
938	1-03-08-01	WHL, CR7	80				
939	1-03-08-01	WHL, CR7	80				
940	1-03-08-01	WHL, CR7	80				
941	1-03-08-01	WHL, CR7	80				
942	1-03-08-01	WHL, CR7	80				
943	1-03-08-01	WHL, CR7	80				
944	1-03-08-01	WHL, CR7	80				
945	1-03-08-01	WHL, CR7	80				
946	1-03-08-01	WHL, CR7	80				
947	1-03-08-01	WHL, CR7	80				
948	1-03-08-01	WHL, CR7	80				
949	1-03-08-01	WHL, CR7	80				
950	1-03-08-01	WHL, CR7	80				
951	1-03-08-01	WHL, CR7	80				
952	1-03-08-01	WHL, CR7	80				
953	1-03-08-01	WHL, CR7	80				
954	1-03-08-01	WHL, CR7	80				
955	1-03-08-01	WHL, CR7	80				
956	1-03-08-01	WHL, CR7	80				
957	1-03-08-01	WHL, CR7	80				
958	1-03-08-01	WHL, CR7	80				
959	1-03-08-01	WHL, CR7	80				
960	1-03-08-01	WHL, CR7	80				
961	1-03-08-01	WHL, CR7	80				
962	1-03-08-01	WHL, CR7	80				
963	1-03-08-01	WHL, CR7	80				
964	1-03-08-01	WHL, CR7	80				
965	1-03-08-01	WHL, CR7	80				
966	1-03-08-01	WHL, CR7	80				
967	1-03-08-01	WHL, CR7	80				
968	1-03-08-01	WHL, CR7	80				
969	1-03-08-01	WHL, CR7	80				
970	1-03-08-01	WHL, CR7	80				
971	1-03-08-01	WHL, CR7	80				
972	1-03-08-01	WHL, CR7	80				
973	1-03-08-01	WHL, CR7	80				
974	1-03-08-01	WHL, CR7	80				
975	1-03-08-01	WHL, CR7	80				
976	1-03-08-01	WHL, CR7	80				
977	1-03-08-01	WHL, CR7	80				
978	1-03-08-01	WHL, CR7	80				
979	1-03-08-01	WHL, CR7	80				
980	1-03-08-01	WHL, CR7	80				
981	1-03-08-01	WHL, CR7	80				
982	1-03-08-01	WHL, CR7	80				
983	1-03-08-01	WHL, CR7	80				
984	1-03-08-01	WHL, CR7	80				
985	1-03-08-01	WHL, CR7	80				
986	1-03-08-01	WHL, CR7	80				
987	1-03-08-01	WHL, CR7	80				
988	1-03-08-01	WHL, CR7	80				
989	1-03-08-01	WHL, CR7	80				
990	1-03-08-01	WHL, CR7	80				
991	1-03-08-01	WHL, CR7	80				
992	1-03-08-01	WHL, CR7	80				
993	1-03-08-01	WHL, CR7	80				
994	1-03-08-01	WHL, CR7	80				
995	1-03-08-01	WHL, CR7	80				
996	1-03-08-01	WHL, CR7	80				
997	1-03-08-01	WHL, CR7	80				
998	1-03-08-01	WHL, CR7	80				
999	1-03-08-01	WHL, CR7	80				
1000	1-03-08-01	WHL, CR7	80				

Be sure to read "Notes on the CD-ROM replacement" on page 4 of this change log for CD-ROM.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R695	1-216-849-11	METAL CHIP	220K 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	C1144	1-162-918-11	CERAMIC CHIP	18PF 5% 50V
R696	1-216-809-11	METAL CHIP	100 5% 1/16W	C1146	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
R697	1-216-833-11	METAL CHIP	10K 5% 1/16W	C1150	1-162-913-11	CERAMIC CHIP	8PF 0.5PF 50V
*****				C1151	1-162-917-11	CERAMIC CHIP	15PF 5% 50V
* A-7066-078-A HE-14 BOARD, COMPLETE (TR400/TR750)				C1152	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
*****				C1155	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
(Ref. No. 20,000 Series)				C1156	1-164-360-11	CERAMIC CHIP	0.1uF 16V
< CAPACITOR >				C1157	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C1101	1-162-917-11	CERAMIC CHIP	15PF 5% 50V	C1158	1-162-922-11	CERAMIC CHIP	39PF 5% 50V
C1102	1-162-918-11	CERAMIC CHIP	18PF 5% 50V	C1160	1-164-360-11	CERAMIC CHIP	0.1uF 16V
C1103	1-162-917-11	CERAMIC CHIP	15PF 5% 50V	C1161	1-164-218-11	CERAMIC CHIP	180PF 0.25PF 50V
C1104	1-162-918-11	CERAMIC CHIP	18PF 5% 50V	C1162	1-162-949-11	CERAMIC CHIP	47PF 5% 50V
C1106	1-162-919-11	CERAMIC CHIP	22PF 5% 50V	C1163	1-162-941-11	CERAMIC CHIP	10PF 0.5PF 50V
C1107	1-162-975-11	CERAMIC CHIP	24PF 5% 50V	C1164	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C1108	1-162-923-11	CERAMIC CHIP	47PF 5% 50V	C1165	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V
C1109	1-162-928-11	CERAMIC CHIP	120PF 5% 50V	C1166	1-162-957-11	CERAMIC CHIP	220PF 5% 50V
C1110	1-162-910-11	CERAMIC CHIP	5PF 0.25PF 50V	C1167	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C1111	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C1168	1-162-959-11	CERAMIC CHIP	330PF 5% 50V
C1112	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1169	1-164-155-11	CERAMIC CHIP	75PF 5% 50V
C1113	1-164-005-11	CERAMIC CHIP	0.47uF 25V	C1171	1-162-974-11	CERAMIC CHIP	0.01uF 50V
C1114	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1173	1-162-952-11	CERAMIC CHIP	82PF 5% 50V
C1115	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1175	1-162-955-11	CERAMIC CHIP	150PF 5% 50V
C1116	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1176	1-162-949-11	CERAMIC CHIP	47PF 5% 50V
C1117	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1178	1-162-957-11	CERAMIC CHIP	220PF 5% 50V
C1118	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1179	1-162-943-11	CERAMIC CHIP	15PF 5% 50V
C1119	1-162-919-11	CERAMIC CHIP	22PF 5% 50V	C1181	1-164-218-11	CERAMIC CHIP	180PF 0.25PF 50V
C1121	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1182	1-162-955-11	CERAMIC CHIP	150PF 5% 50V
C1122	1-164-218-11	CERAMIC CHIP	180PF 0.25PF 50V	C1183	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C1123	1-164-005-11	CERAMIC CHIP	0.47uF 25V	C1184	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C1124	1-162-925-11	CERAMIC CHIP	68PF 5% 50V	C1185	1-164-149-11	CERAMIC CHIP	36PF 5% 50V
C1125	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1188	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C1126	1-162-925-11	CERAMIC CHIP	68PF 5% 50V	C1189	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C1127	1-162-910-11	CERAMIC CHIP	5PF 0.25PF 50V	C1192	1-164-360-11	CERAMIC CHIP	0.1uF 16V
C1128	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C1193	1-164-218-11	CERAMIC CHIP	180PF 0.25PF 50V
C1129	1-162-925-11	CERAMIC CHIP	68PF 5% 50V	< CONNECTOR >			
C1130	1-162-974-11	CERAMIC CHIP	0.01uF 50V	* CN1101 1-573-341-11 CONNECTOR, BOARD TO BOARD 26P			
C1131	1-162-974-11	CERAMIC CHIP	0.01uF 50V	< DIODE >			
C1132	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	D1101	8-719-404-49	DIODE	MA111
C1133	1-162-919-11	CERAMIC CHIP	22PF 5% 50V	D1102	8-719-027-48	DIODE	MA142WA
C1134	1-162-974-11	CERAMIC CHIP	0.01uF 50V	D1103	8-719-027-48	DIODE	MA142WA
C1135	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	D1105	8-719-404-49	DIODE	MA111
C1136	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V	< FILTER >			
C1137	1-162-974-11	CERAMIC CHIP	0.01uF 50V	FL1101	1-236-775-11	FILTER, LOW PASS (DEM)	
C1138	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	FL1102	1-239-112-21	FILTER, LOW PASS (Y)	
C1140	1-162-974-11	CERAMIC CHIP	0.01uF 50V	< IC >			
C1141	1-162-974-11	CERAMIC CHIP	0.01uF 50V	IC1101	8-752-058-02	IC	CXA1509AR
C1142	1-164-392-11	CERAMIC CHIP	390PF 5% 50V				
C1143	1-162-912-11	CERAMIC CHIP	7PF 0.5PF 50V				

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
IC1102	8-759-070-51	IC SN74HCU04ADB		Q1138	8-729-420-24	TRANSISTOR 2SB1218A	
		< COIL >				< RESISTOR >	
L1101	1-412-956-21	INDUCTOR 27uH		R1101	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1102	1-412-954-11	INDUCTOR 18uH		R1102	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1103	1-412-947-11	INDUCTOR 4.7uH		R1103	1-216-820-11	METAL CHIP 820 5%	1/16W
L1104	1-412-959-11	INDUCTOR 47uH		R1104	1-216-819-11	METAL CHIP 680 5%	1/16W
L1105	1-412-954-11	INDUCTOR 18uH		R1105	1-216-817-11	METAL CHIP 470 5%	1/16W
L1106	1-412-945-11	INDUCTOR 3.3uH		R1106	1-216-809-11	METAL CHIP 100 5%	1/16W
L1108	1-412-954-11	INDUCTOR 18uH		R1107	1-216-815-11	METAL CHIP 330 5%	1/16W
L1109	1-412-948-11	INDUCTOR 5.6uH		R1108	1-216-813-11	METAL CHIP 220 5%	1/16W
L1110	1-412-956-21	INDUCTOR 27uH		R1109	1-216-813-11	METAL CHIP 220 5%	1/16W
L1111	1-410-655-31	INDUCTOR CHIP 120uH		R1111	1-216-837-11	METAL CHIP 22K 5%	1/16W
L1112	1-412-058-11	INDUCTOR CHIP 10uH		R1112	1-216-837-11	METAL CHIP 22K 5%	1/16W
L1113	1-412-058-11	INDUCTOR CHIP 10uH		R1113	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1114	1-412-957-11	INDUCTOR 33uH		R1114	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1115	1-412-952-11	INDUCTOR 12uH		R1115	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1116	1-412-948-11	INDUCTOR 5.6uH		R1116	1-216-833-11	METAL CHIP 10K 5%	1/16W
L1118	1-412-953-11	INDUCTOR 15uH		R1118	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
L1119	1-412-949-21	INDUCTOR 6.8uH		R1119	1-216-816-11	METAL CHIP 390 5%	1/16W
L1121	1-412-947-11	INDUCTOR 4.7uH		R1120	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
L1122	1-412-954-11	INDUCTOR 18uH		R1123	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
L1123	1-412-949-21	INDUCTOR 6.8uH		R1124	1-216-826-11	METAL CHIP 2.7K 5%	1/16W
L1124	1-412-960-21	INDUCTOR 56uH		R1125	1-216-840-11	METAL CHIP 39K 5%	1/16W
		< TRANSISTOR >		R1127	1-216-841-11	METAL CHIP 47K 5%	1/16W
Q1102	8-729-402-42	TRANSISTOR UN5213		R1128	1-216-833-11	METAL CHIP 10K 5%	1/16W
Q1103	8-729-012-50	TRANSISTOR 2SC4400		R1130	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1107	8-729-402-42	TRANSISTOR UN5213		R1131	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1110	8-729-120-28	TRANSISTOR 2SC1623		R1132	1-216-820-11	METAL CHIP 820 5%	1/16W
Q1111	8-729-420-24	TRANSISTOR 2SB1218A		R1134	1-216-820-11	METAL CHIP 820 5%	1/16W
Q1113	8-729-012-50	TRANSISTOR 2SC4400		R1135	1-216-814-11	METAL CHIP 270 5%	1/16W
Q1114	8-729-402-81	TRANSISTOR XN4501		R1136	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1115	8-729-012-50	TRANSISTOR 2SC4400		R1138	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1117	8-729-230-63	TRANSISTOR 2SC4116		R1139	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1118	8-729-230-63	TRANSISTOR 2SC4116		R1148	1-216-837-11	METAL CHIP 22K 5%	1/16W
Q1119	8-729-402-42	TRANSISTOR UN5213		R1149	1-216-838-11	METAL CHIP 27K 5%	1/16W
Q1120	8-729-403-35	TRANSISTOR UN5113		R1151	1-216-826-11	METAL CHIP 2.7K 5%	1/16W
Q1121	8-729-420-24	TRANSISTOR 2SB1218A		R1152	1-216-833-11	METAL CHIP 10K 5%	1/16W
Q1123	8-729-012-50	TRANSISTOR 2SC4400		R1153	1-216-818-11	METAL CHIP 560 5%	1/16W
Q1125	8-729-420-24	TRANSISTOR 2SB1218A		R1154	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1126	8-729-012-50	TRANSISTOR 2SC4400		R1155	1-216-817-11	METAL CHIP 470 5%	1/16W
Q1127	8-729-403-35	TRANSISTOR UN5113		R1156	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
Q1128	8-729-230-63	TRANSISTOR 2SC4116		R1157	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
Q1129	8-729-012-50	TRANSISTOR 2SC4400		R1158	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
Q1131	8-729-824-02	TRANSISTOR 2SA1838		R1159	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
Q1132	8-729-012-50	TRANSISTOR 2SC4400		R1160	1-216-820-11	METAL CHIP 820 5%	1/16W
Q1133	8-729-012-50	TRANSISTOR 2SC4400		R1161	1-216-819-11	METAL CHIP 680 5%	1/16W
Q1134	8-729-402-42	TRANSISTOR UN5213		R1162	1-216-845-11	METAL CHIP 100K 5%	1/16W
Q1137	8-729-230-63	TRANSISTOR 2SC4116		R1163	1-216-817-11	METAL CHIP 470 5%	1/16W
				R1164	1-216-829-11	METAL CHIP 4.7K 5%	1/16W

HE-14**LB-35****LS-33****MA-179**

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R1165	1-216-814-11	METAL CHIP	270 5% 1/16W	*	A-7056-012-A	LB-35 BOARD, COMPLETE (TR70/80)	
R1166	1-216-815-11	METAL CHIP	330 5% 1/16W			*****	
R1167	1-216-864-11	METAL CHIP	0 5% 1/16W			(Ref. No. 4,000 Series)	
						< CONNECTOR >	
R1168	1-216-826-11	METAL CHIP	2.7K 5% 1/16W				
R1169	1-216-836-11	METAL CHIP	18K 5% 1/16W				
R1170	1-216-839-11	METAL CHIP	33K 5% 1/16W	CN801	1-573-812-11	CONNECTOR, BOARD TO BOARD 12P	
R1171	1-216-842-11	METAL CHIP	56K 5% 1/16W			< DIODE >	
R1172	1-216-837-11	METAL CHIP	22K 5% 1/16W				
				D801	8-719-037-83	DIODE LN1371G-(TR)	
R1173	1-216-837-11	METAL CHIP	22K 5% 1/16W			*****	
R1174	1-216-813-11	METAL CHIP	220 5% 1/16W			LS-33 BOARD	
R1175	1-216-813-11	METAL CHIP	220 5% 1/16W			*****	
R1176	1-216-821-11	METAL CHIP	1K 5% 1/16W			< DIODE >	
R1177	1-216-814-11	METAL CHIP	270 5% 1/16W				
				D001	8-719-989-52	DIODE GL4600S	
R1178	1-216-828-11	METAL CHIP	3.9K 5% 1/16W			< HALL >	
R1179	1-216-833-11	METAL CHIP	10K 5% 1/16W				
R1180	1-216-864-11	METAL CHIP	0 5% 1/16W	H001	8-719-987-62	DIODE LT140SAZ	
R1182	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	H002	8-719-987-62	DIODE LT140SAZ	
R1183	1-216-811-11	METAL CHIP	150 5% 1/16W			< TRANSISTOR >	
R1184	1-216-819-11	METAL CHIP	680 5% 1/16W	Q001	8-729-012-46	TRANSISTOR PT4600FS	
R1186	1-216-817-11	METAL CHIP	470 5% 1/16W	Q002	8-729-012-46	TRANSISTOR PT4600FS	
R1187	1-216-815-11	METAL CHIP	330 5% 1/16W			< RESISTOR >	
R1188	1-216-820-11	METAL CHIP	820 5% 1/16W				
R1189	1-216-864-11	METAL CHIP	0 5% 1/16W				
				R003	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1190	1-216-816-11	METAL CHIP	390 5% 1/16W	R004	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1191	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R010	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1194	1-216-819-11	METAL CHIP	680 5% 1/16W	R011	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1196	1-216-833-11	METAL CHIP	10K 5% 1/16W			< SWITCH >	
R1197	1-216-833-11	METAL CHIP	10K 5% 1/16W				
				S002	1-572-987-11	SWITCH, PUSH (3 KEY)	
R1198	1-216-819-11	METAL CHIP	680 5% 1/16W			*****	
R1199	1-216-819-11	METAL CHIP	680 5% 1/16W	*	A-7063-962-A	MA-179 BOARD, COMPLETE	
R1202	1-216-811-11	METAL CHIP	150 5% 1/16W			*****	
R1203	1-216-833-11	METAL CHIP	10K 5% 1/16W			(TR72/TR80/TR400/TR430/TR750)	
R1204	1-216-815-11	METAL CHIP	330 5% 1/16W			(Ref. No. 7,000 Series)	
						< CAPACITOR >	
R1205	1-216-817-11	METAL CHIP	470 5% 1/16W				
R1206	1-216-817-11	METAL CHIP	470 5% 1/16W	C001	1-164-343-11	CERAMIC CHIP 0.056uF 10% 25V	
R1207	1-216-815-11	METAL CHIP	330 5% 1/16W	C003	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
R1209	1-216-864-11	METAL CHIP	0 5% 1/16W	C005	1-163-023-00	CERAMIC CHIP 0.015uF 5% 50V	
R1210	1-216-831-11	METAL CHIP	6.8K 5% 1/16W	C006	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
				C007	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
R1214	1-216-820-11	METAL CHIP	820 5% 1/16W				
R1215	1-216-819-11	METAL CHIP	680 5% 1/16W	C008	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
R1216	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	C009	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
R1217	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	C010	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
R1218	1-216-817-11	METAL CHIP	470 5% 1/16W				
R1219	1-216-817-11	METAL CHIP	470 5% 1/16W				
R1220	1-216-864-11	METAL CHIP	0 5% 1/16W				
R1221	1-216-864-11	METAL CHIP	0 5% 1/16W				
R1223	1-216-864-11	METAL CHIP	0 5% 1/16W				
R1226	1-216-864-11	METAL CHIP	0 5% 1/16W				

[illegible]

Ref. No.	Part No.	Description		Remark
C011	1-164-232-11	CERAMIC CHIP	0.01uF	50V
C012	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C013	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C014	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C015	1-162-966-11	CERAMIC CHIP	0.0022uF 10%	50V
C019	1-164-232-11	CERAMIC CHIP	0.01uF	50V
C020	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C021	1-126-205-11	ELECT CHIP	47uF 20%	6.3V
C022	1-164-004-11	CERAMIC CHIP	0.1uF 10%	25V
C023	1-135-091-21	TANTAL. CHIP	1uF 20%	16V
C024	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C025	1-163-023-00	CERAMIC CHIP	0.015uF 5%	50V
C026	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C027	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C030	1-164-343-11	CERAMIC CHIP	0.056uF 10%	25V
C043	1-128-004-11	ELECT CHIP	10uF 20%	16V

< CONNECTOR >

CN001	1-691-490-21	CONNECTOR, FFC/FPC 11P
CN002	1-580-057-11	PIN, CONNECTOR 4P
CN003	1-580-057-11	PIN, CONNECTOR 4P

< DIODE >

D001	8-719-404-46	DIODE MA110
D002	8-719-404-46	DIODE MA110
D004	8-719-404-19	DIODE LN1251C (TALLY)

< IC >

IC001	8-759-084-53	IC CXA1618AN-E2
IC002	8-749-923-29	IC RS-20E-T

< JACK >

J001	1-691-737-11	JACK (SMALL TYPE)(EXT MIC)
------	--------------	----------------------------

< COIL >

L001	1-412-939-11	INDUCTOR 1uH
L002	1-412-939-11	INDUCTOR 1uH
L003	1-412-939-11	INDUCTOR 1uH

< TRANSISTOR >

Q001	8-729-230-63	TRANSISTOR 2SC4116-YG
Q003	8-729-402-42	TRANSISTOR UN5213

< RESISTOR >

R003	1-216-829-11	METAL CHIP	4.7K 5%	1/16W
R004	1-216-833-11	METAL CHIP	10K 5%	1/16W
R005	1-216-821-11	METAL CHIP	1K 5%	1/16W
R006	1-216-813-11	METAL CHIP	220 5%	1/16W
R007	1-216-834-11	METAL CHIP	12K 5%	1/16W

Ref. No.	Part No.	Description		Remark
R008	1-216-834-11	METAL CHIP	12K 5%	1/16W
R009	1-216-835-11	METAL CHIP	15K 5%	1/16W
R010	1-216-833-11	METAL CHIP	10K 5%	1/16W
R011	1-216-825-11	METAL CHIP	2.2K 5%	1/16W
R012	1-216-839-11	METAL CHIP	33K 5%	1/16W
R013	1-216-831-11	METAL CHIP	6.8K 5%	1/16W
R014	1-216-831-11	METAL CHIP	6.8K 5%	1/16W
R015	1-216-839-11	METAL CHIP	33K 5%	1/16W
R016	1-216-833-11	METAL CHIP	10K 5%	1/16W
R017	1-216-835-11	METAL CHIP	15K 5%	1/16W
R018	1-216-834-11	METAL CHIP	12K 5%	1/16W
R019	1-216-834-11	METAL CHIP	12K 5%	1/16W
R020	1-216-825-11	METAL CHIP	2.2K 5%	1/16W
R022	1-216-829-11	METAL CHIP	4.7K 5%	1/16W
R023	1-216-833-11	METAL CHIP	10K 5%	1/16W
R024	1-216-821-11	METAL CHIP	1K 5%	1/16W
R025	1-216-864-11	METAL CHIP	0 5%	1/16W
R027	1-216-864-11	METAL CHIP	0 5%	1/16W
R036	1-216-864-11	METAL CHIP	0 5%	1/16W
R037	1-216-839-11	METAL CHIP	33K 5%	1/16W
R039	1-216-824-11	METAL CHIP	1.8K 5%	1/16W
R043	1-216-815-11	METAL CHIP	330 5%	1/16W

* A-7063-956-A MA-199 BOARD, COMPLETE

(TR42/TR70/TR82/TR550)
(Ref. No. 5,000 Series)

< CAPACITOR >

C014	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C015	1-162-966-11	CERAMIC CHIP	0.0022uF 10%	50V
C032	1-164-346-11	CERAMIC CHIP	1uF	16V
C033	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C034	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C035	1-162-587-11	CERAMIC CHIP	0.039uF 10%	25V
C036	1-164-004-11	CERAMIC CHIP	0.1uF 10%	25V
C037	1-164-346-11	CERAMIC CHIP	1uF	16V
C040	1-126-205-11	ELECT CHIP	47uF 20%	6.3V
C041	1-164-345-11	CERAMIC CHIP	0.082uF 10%	25V
C043	1-128-004-11	ELECT CHIP	10uF 20%	16V

< CONNECTOR >

CN001	1-691-487-21	CONNECTOR, FFC/FPC 8P
CN003	1-580-057-11	PIN, CONNECTOR 4P

< DIODE >

D001	8-719-404-49	DIODE MA111
D002	8-719-404-49	DIODE MA111
D004	8-719-404-19	DIODE LN1251C (TALLY)

Ref. No.	Part No.	Description	Amount/Ref. No.	Part No.	Description	Amount			
001	1-100-00-11	CHASSIS, CRP	6.100	002	1-100-00-11	CHASSIS, CRP	1.00	00	1.000
002	1-100-00-11	CHASSIS, CRP	6.100	003	1-100-00-11	CHASSIS, CRP	1.00	00	1.000
003	1-100-00-11	CHASSIS, CRP	1.00	004	1-100-00-11	CHASSIS, CRP	1.00	00	1.000
004	1-100-00-11	CHASSIS, CRP	1.00	005	1-100-00-11	CHASSIS, CRP	1.00	00	1.000
005	1-100-00-11	CHASSIS, CRP	6.100	006	1-100-00-11	CHASSIS, CRP	1.00	00	1.000
006	1-100-00-11	CHASSIS, CRP	6.100	007	1-100-00-11	CHASSIS, CRP	1.00	00	1.000
007	1-100-00-11	CHASSIS, CRP	1.00	008	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
008	1-100-00-11	CHASSIS, CRP	6.100	009	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
009	1-100-00-11	CHASSIS, CRP	6.100	010	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
010	1-100-00-11	CHASSIS, CRP	6.100	011	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
011	1-100-00-11	CHASSIS, CRP	6.100	012	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
012	1-100-00-11	CHASSIS, CRP	6.100	013	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
013	1-100-00-11	CHASSIS, CRP	6.100	014	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
014	1-100-00-11	CHASSIS, CRP	6.100	015	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
015	1-100-00-11	CHASSIS, CRP	6.100	016	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
016	1-100-00-11	CHASSIS, CRP	6.100	017	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
017	1-100-00-11	CHASSIS, CRP	6.100	018	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
018	1-100-00-11	CHASSIS, CRP	6.100	019	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
019	1-100-00-11	CHASSIS, CRP	6.100	020	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
020	1-100-00-11	CHASSIS, CRP	6.100	021	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
021	1-100-00-11	CHASSIS, CRP	6.100	022	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
022	1-100-00-11	CHASSIS, CRP	6.100	023	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
023	1-100-00-11	CHASSIS, CRP	6.100	024	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
024	1-100-00-11	CHASSIS, CRP	6.100	025	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
025	1-100-00-11	CHASSIS, CRP	6.100	026	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
026	1-100-00-11	CHASSIS, CRP	6.100	027	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
027	1-100-00-11	CHASSIS, CRP	6.100	028	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
028	1-100-00-11	CHASSIS, CRP	6.100	029	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
029	1-100-00-11	CHASSIS, CRP	6.100	030	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
030	1-100-00-11	CHASSIS, CRP	6.100	031	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
031	1-100-00-11	CHASSIS, CRP	6.100	032	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
032	1-100-00-11	CHASSIS, CRP	6.100	033	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
033	1-100-00-11	CHASSIS, CRP	6.100	034	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
034	1-100-00-11	CHASSIS, CRP	6.100	035	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
035	1-100-00-11	CHASSIS, CRP	6.100	036	1-100-00-11	CHASSIS, CRP	6.100	00	1.000
036	1-100-00-11	CHASSIS, CRP	6.100	037	1-100-00-11	CHASSIS, CRP			

Ref. No.	Part No.	Description	Remark
< IC >			
IC002	8-749-923-29	IC RS-20ET	
IC003	8-759-822-37	IC LA7293M-TE	
< COIL >			
L002	1-412-939-11	INDUCTOR 1uH	
L003	1-412-939-11	INDUCTOR 1uH	
< JACK >			
J001	1-568-027-11	JACK, SMALL TYPE 1P (EXT MIC)	
< TRANSISTOR >			
Q002	8-729-402-63	TRANSISTOR 2SB1218A-Q	
< RESISTOR >			
R027	1-216-864-11	METAL CHIP 0 5% 1/16W	
R028	1-216-820-11	METAL CHIP 820 5% 1/16W	
R029	1-216-823-11	METAL CHIP 1.5K 5% 1/16W	
R030	1-216-830-11	METAL CHIP 5.6K 5% 1/16W	
R031	1-216-838-11	METAL CHIP 27K 5% 1/16W	
R032	1-216-831-11	METAL CHIP 6.8K 5% 1/16W	
R033	1-216-838-11	METAL CHIP 27K 5% 1/16W	
R043	1-216-815-11	METAL CHIP 330 5% 1/16W	
R044	1-216-853-11	METAL CHIP 470K 5% 1/16W	

*	A-7072-000-A	SL-38 BOARD, COMPLETE	

		(Ref. No. 4,000 Series)	
< CAPACITOR >			
C543	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C544	1-135-211-11	TANTAL. CHIP 6.8uF 20% 6.3V	
C545	1-135-211-11	TANTAL. CHIP 6.8uF 20% 6.3V	
C546	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C547	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C551	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C553	1-164-361-11	CERAMIC CHIP 0.047uF 16V	
C554	1-135-215-21	TANTAL. CHIP 6.8uF 20% 16V	
C555	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C556	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C557	1-135-149-21	TANTALUM CHIP 2.2uF 20% 10V	
C558	1-164-489-11	CERAMIC CHIP 0.22uF 10% 16V	
< CONNECTOR >			
CN500	1-691-473-21	CONNECTOR, FFC/FPC 7P	
CN501	1-691-472-21	CONNECTOR, FFC/FPC 6P	
CN502	1-691-482-21	CONNECTOR, FFC/FPC 15P	

Ref. No.	Part No.	Description	Remark
< IC >			
IC507	8-759-165-47	IC MPC1780VFUEB	
< COIL >			
L505	1-414-078-11	INDUCTOR 10uH	
< TRANSISTOR >			
Q560	8-729-805-25	TRANSISTOR 2SB1121	
Q561	8-729-425-50	TRANSISTOR 2SB1462Q	
Q562	8-729-402-81	TRANSISTOR XN4501	
< RESISTOR >			
R562	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R563	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R564	1-216-864-11	METAL CHIP 0 5% 1/16W	
R565	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R566	1-218-857-11	METAL CHIP 2.7K 0.50% 1/16W	
R567	1-216-295-00	METAL CHIP 0 5% 1/10W	
R568	1-216-168-00	METAL GLAZE 56 5% 1/8W	
R569	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R570	1-216-827-11	METAL CHIP 3.3K 5% 1/16W	
R571	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R572	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R590	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R591	1-216-832-11	METAL CHIP 8.2K 5% 1/16W	
< FLEXIBLE BOARD >			
W500	1-651-889-11	FP-48 FLEXIBLE BOARD	
W501	1-642-186-11	FP-437 FLEXIBLE BOARD	

VC-138

VC-145

Ref.No.	Part No.	Description	Remark
*	A-7063-961-A	VC-138 BOARD, COMPLETE (TR72/430) *****	
*	A-7066-018-A	VC-138 BOARD, COMPLETE (TR80) *****	
*	A-7066-080-A	VC-138 BOARD, COMPLETE (TR400/TR750) *****	
*	A-7063-955-A	VC-145 BOARD, COMPLETE (TR82) *****	
*	A-7066-007-A	VC-145 BOARD, COMPLETE (TR70) *****	
*	A-7066-084-A	VC-145 BOARD, COMPLETE (TR42) *****	
*	A-7066-088-A	VC-145 BOARD, COMPLETE (TR550) ***** (Ref. No. 1,000 Series)	
< CAPACITOR >			
C604	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C605	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C606	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C607	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C608	1-104-847-11	TANTAL. CHIP 22uF 20%	4V (TR42/TR72/TR82/TR430/TR550)
C609	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C610	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C611	1-164-360-11	CERAMIC CHIP 0.1uF	16V (TR42/TR72/TR82/TR430/TR550)
C613	1-162-974-11	CERAMIC CHIP 0.01uF	50V (TR42/TR72/TR82/TR430/TR550)
C614	1-162-974-11	CERAMIC CHIP 0.01uF	50V (TR42/TR72/TR82/TR430/TR550)
C616	1-135-091-21	TANTAL. CHIP 1uF 20%	16V
C617	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C618	1-165-176-11	CERAMIC CHIP 0.047uF 10%	16V
C619	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C620	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C621	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C622	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C623	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C624	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C627	1-162-946-11	CERAMIC CHIP 27PF 5%	50V
C628	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C629	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C630	1-162-946-11	CERAMIC CHIP 27PF 5%	50V
C631	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C632	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C633	1-162-946-11	CERAMIC CHIP 27PF 5%	50V (TR82/TR400/TR550/TR750)

Ref.No.	Part No.	Description	Remark
C633	1-162-947-11	CERAMIC CHIP 33PF 5%	50V (TR42/TR70/TR72/TR80/TR430)
C634	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C635	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V (TR82/TR400/TR550/TR750)
C636	1-164-360-11	CERAMIC CHIP 0.1uF	16V (TR82/TR400/TR550/TR750)
C637	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C638	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C639	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C699	1-162-954-11	CERAMIC CHIP 120PF 5%	50V (TR82/TR400/TR550/TR750)
C701	1-163-059-91	CERAMIC CHIP 0.01uF 10%	50V
C702	1-162-638-11	CERAMIC CHIP 1uF	16V
C703	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C704	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C705	1-135-145-11	TANTALUM CHIP 0.47uF 10%	35V
C706	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C708	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C709	1-135-214-21	TANTAL. CHIP 4.7uF 20%	20V
C710	1-162-971-11	CERAMIC CHIP 0.001uF	50V
C711	1-162-971-11	CERAMIC CHIP 0.001uF	50V
C712	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C713	1-107-685-11	TANTAL. CHIP 15uF 20%	6.3V
C714	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C715	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C716	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C717	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C718	1-162-637-11	CERAMIC CHIP 0.47uF	16V
C719	1-162-971-11	CERAMIC CHIP 0.001uF	50V
C720	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C721	1-162-916-11	CERAMIC CHIP 12PF 5%	50V
C722	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C724	1-162-925-11	CERAMIC CHIP 68PF 5%	50V (TR42/TR70/TR72/TR80/TR430)
C724	1-162-949-11	CERAMIC CHIP 47PF 5%	50V (TR82/TR400/TR550/TR750)
C725	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C726	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C727	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C728	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C729	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C730	1-163-077-00	CERAMIC CHIP 0.1uF 10%	25V (TR82/TR400/TR550/TR750)
C730	1-164-298-11	CERAMIC CHIP 0.15uF 10%	25V (TR42/TR70/TR72/TR80/TR430)
C731	1-135-091-21	TANTAL. CHIP 1uF 20%	16V
C732	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C733	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C734	1-135-091-21	TANTAL. CHIP 1uF 20%	16V
C735	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C737	1-162-946-11	CERAMIC CHIP 27PF 5%	50V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C739	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V	C789	1-164-245-11	CERAMIC CHIP	0.015uF 10% 25V (TR82/TR400/TR550/TR750)
C741	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V	C790	1-164-299-11	CERAMIC CHIP	0.22uF 10% 25V (TR82/TR400/TR550/TR750)
C742	1-164-360-11	CERAMIC CHIP	0.1uF 16V	C793	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)
C743	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C794	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR82/TR400/TR550/TR750)
C744	1-162-974-11	CERAMIC CHIP	0.01uF 50V	< CONNECTOR >			
C745	1-162-974-11	CERAMIC CHIP	0.01uF 50V	* CN601	1-764-395-21	CONNECTOR, BOARD TO BOARD 42P	
C746	1-164-360-11	CERAMIC CHIP	0.1uF 16V	CN701	1-750-630-11	CONNECTOR, FFC/FPC (ZIF) 16P	
C747	1-164-360-11	CERAMIC CHIP	0.1uF 16V	* CN751	1-764-528-11	CONNECTOR, FFC/FPC (ZIF) 21P	
C748	1-164-360-11	CERAMIC CHIP	0.1uF 16V	CN775	1-691-487-21	CONNECTOR, FFC/FPC 8P	(TR82/TR400/TR550/TR750)
C749	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V	< TRIMMER >			
C750	1-162-971-11	CERAMIC CHIP	0.001uF 50V	CT701	1-141-356-11	CAP, ADJ	
C751	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	< DIODE >			
C752	1-162-971-11	CERAMIC CHIP	0.001uF 50V	D701	8-719-404-49	DIODE MA111	
C753	1-162-974-11	CERAMIC CHIP	0.01uF 50V	D702	8-719-404-49	DIODE MA111	
C754	1-162-974-11	CERAMIC CHIP	0.01uF 50V	D703	8-719-404-49	DIODE MA111	
C755	1-162-974-11	CERAMIC CHIP	0.01uF 50V	D705	8-719-404-49	DIODE MA111	
C756	1-104-752-11	TANTAL. CHIP	33uF 20% 6.3V	< FILTER >			
C757	1-162-974-11	CERAMIC CHIP	0.01uF 50V	FL601	1-239-352-11	FILTER, LOW PASS	(TR82/TR400/TR550/TR750)
C771	1-164-245-11	CERAMIC CHIP	0.015uF 10% 25V (TR82/TR400/TR550/TR750)	FL601	1-239-766-11	FILTER, LOW PASS	(TR42/TR70/TR72/TR80/TR430)
C772	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (TR82/TR400/TR550/TR750)	< IC >			
C773	1-164-299-11	CERAMIC CHIP	0.22uF 10% 25V (TR82/TR400/TR550/TR750)	IC601	8-759-044-78	IC AK6420F-E1	
C774	1-128-257-21	ELECT CHIP	33uF 20% 10V (TR82/TR400/TR550/TR750)	IC602	8-759-260-67	IC SC424608MC68HC11MA8FU	(TR42/TR70/TR72/TR80/TR82/TR430)
C775	1-128-257-21	ELECT CHIP	33uF 20% 10V (TR82/TR400/TR550/TR750)	IC602	8-759-277-18	IC SC424609MC68HC11MA8FU	(TR400/TR550/TR750)
C776	1-162-953-11	CERAMIC CHIP	100PF 5% 50V (TR82/TR400/TR550/TR750)	IC603	8-759-064-36	IC MB88346BPV	
C777	1-162-568-11	CERAMIC CHIP	0.33uF 10% 16V (TR82/TR400/TR550/TR750)	IC604	8-759-710-29	IC NJM2235M	(TR42/TR72/TR82/TR430/TR550)
C778	1-162-953-11	CERAMIC CHIP	100PF 5% 50V (TR82/TR400/TR550/TR750)	IC609	8-752-365-71	IC CXD2150R	(TR42/TR70/TR72/TR80/TR82/TR430)
C779	1-162-568-11	CERAMIC CHIP	0.33uF 10% 16V (TR82/TR400/TR550/TR750)	IC609	8-752-369-24	IC CXD2150AR	(TR400/TR550/TR750)
C780	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR82/TR400/TR550/TR750)	IC610	8-752-365-72	IC CXD2151R	
C781	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR82/TR400/TR550/TR750)	IC611	8-759-262-36	IC CXD2133BR	
C782	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)	IC613	8-759-247-06	IC CXD2152REL	(TR82/TR400/TR550/TR750)
C783	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)	IC614	8-759-255-09	IC uPD6461GS-802-GLG-E2	
C784	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR82/TR400/TR550/TR750)	IC701	8-752-355-07	IC CXD1267N	
C785	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR82/TR400/TR550/TR750)	IC702	8-752-365-73	IC CXD2405R	(TR82/TR400/TR550/TR750)
C786	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)	IC702	8-752-365-74	IC CXD1266R	(TR42/TR70/TR72/TR80/TR430)
C788	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (TR82/TR400/TR550/TR750)	IC703	8-752-069-21	IC CXA1690Q	
				IC704	8-759-173-24	IC AD875JST-REEL	(TR70/TR72/TR80/TR430)

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
IC704	8-759-263-29	IC HD49315FEB (TR42/TR82/TR400/TR550/TR750)		Q701	8-729-403-27	TRANSISTOR XN4401	
IC705	8-752-365-76	IC CXD2407R		Q751	8-729-010-75	TRANSISTOR MSC4116	
IC751	8-759-701-24	IC NJM3414M		Q752	8-729-015-76	TRANSISTOR UN5211	
IC752	8-759-058-52	IC XRA10324AF		< RESISTOR >			
IC753	8-752-365-65	IC CXD2126N		R601	1-216-851-11	METAL CHIP 330K 5% 1/16W	
IC754	8-759-247-07	IC MPC17A34VMEL		R602	1-216-833-11	METAL CHIP 10K 5% 1/16W	
IC755	8-759-031-58	IC SC7SU04F		R603	1-216-857-11	METAL CHIP 1M 5% 1/16W	
IC772	8-759-234-77	IC TC4S66F (TR82/TR400/TR550/TR750)		R604	1-216-833-11	METAL CHIP 10K 5% 1/16W	
IC773	8-759-234-77	IC TC4S66F (TR82/TR400/TR550/TR750)		R605	1-216-864-11	METAL CHIP 0 5% 1/16W	
IC774	8-759-058-45	IC NJM3403AV(Te2) (TR82/TR400/TR550/TR750)		R606	1-216-847-11	METAL CHIP 150K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
IC775	8-759-080-34	IC TA75W01FU-TE12R (TR82/TR400/TR550/TR750)		R607	1-216-839-11	METAL CHIP 33K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
IC776	8-759-248-78	IC MB88102PFV-G-BND-ER (TR82/TR400/TR550/TR750)		R608	1-216-864-11	METAL CHIP 0 5% 1/16W	
IC777	8-752-850-54	IC CXP87132-010R (TR82/TR400/TR550/TR750)		R609	1-216-838-11	METAL CHIP 27K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
< COIL >				R610	1-216-839-11	METAL CHIP 33K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
L601	1-412-058-11	INDUCTOR CHIP 10uH		R611	1-216-838-11	METAL CHIP 27K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
L602	1-414-078-11	INDUCTOR 10uH		R612	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
L603	1-412-058-11	INDUCTOR CHIP 10uH		R613	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
L604	1-414-078-11	INDUCTOR 10uH		R614	1-216-825-11	METAL CHIP 2.2K 5% 1/16W (TR70/TR80/TR400/TR750)	
L605	1-410-391-11	INDUCTOR CHIP 68uH		R615	1-216-825-11	METAL CHIP 2.2K 5% 1/16W (TR70/TR80/TR400/TR750)	
L606	1-414-078-11	INDUCTOR 10uH		R616	1-216-864-11	METAL CHIP 0 5% 1/16W (TR82)	
L607	1-414-078-11	INDUCTOR 10uH (TR82/TR400/TR550/TR750)		R619	1-216-803-11	METAL CHIP 33 5% 1/16W	
L608	1-412-006-31	INDUCTOR CHIP 10uH		R620	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L609	1-412-979-21	INDUCTOR 1uH		R621	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L610	1-412-979-21	INDUCTOR 1uH		R622	1-216-864-11	METAL CHIP 0 5% 1/16W (TR70/TR80/TR400/TR750)	
L611	1-412-052-21	INDUCTOR CHIP 1uH		R624	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR70/TR72/TR80/TR400/TR430/TR550/TR750)	
L612	1-412-052-21	INDUCTOR CHIP 1uH		R626	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L613	1-412-052-21	INDUCTOR CHIP 1uH		R627	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L614	1-412-052-21	INDUCTOR CHIP 1uH		R628	1-216-834-11	METAL CHIP 12K 5% 1/16W (TR400/TR550/TR750)	
L702	1-412-058-11	INDUCTOR CHIP 10uH		R629	1-216-832-11	METAL CHIP 8.2K 5% 1/16W (TR400/TR550/TR750)	
L703	1-412-058-11	INDUCTOR CHIP 10uH		R629	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430)	
L704	1-412-058-11	INDUCTOR CHIP 10uH		R630	1-216-833-11	METAL CHIP 10K 5% 1/16W	
L705	1-412-058-11	INDUCTOR CHIP 10uH		R631	1-216-864-11	METAL CHIP 0 5% 1/16W	
L706	1-412-058-11	INDUCTOR CHIP 10uH		R634	1-216-821-11	METAL CHIP 1K 5% 1/16W	
L751	1-412-062-11	INDUCTOR CHIP 47uH		R635	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
L752	1-412-058-11	INDUCTOR CHIP 10uH		R636	1-216-845-11	METAL CHIP 100K 5% 1/16W	
L753	1-412-058-11	INDUCTOR CHIP 10uH		R637	1-216-837-11	METAL CHIP 22K 5% 1/16W	
L775	1-412-058-11	INDUCTOR CHIP 10uH (TR82/TR400/TR550/TR750)		R638	1-216-839-11	METAL CHIP 33K 5% 1/16W	
L777	1-414-078-11	INDUCTOR 10uH (TR82/TR400/TR550/TR750)		R639	1-216-864-11	METAL CHIP 0 5% 1/16W	
L778	1-414-078-11	INDUCTOR 10uH (TR82/TR400/TR550/TR750)		R640	1-216-815-11	METAL CHIP 330 5% 1/16W	
< TRANSISTOR >							
Q604	8-729-010-60	TRANSISTOR MSA1586					
Q605	8-729-010-60	TRANSISTOR MSA1586					
Q606	8-729-010-75	TRANSISTOR MSC4116					
Q607	8-729-010-75	TRANSISTOR MSC4116					

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R643	1-216-833-11	METAL CHIP	10K 5% 1/16W	R720	1-216-843-11	METAL CHIP	68K 5% 1/16W (TR82/TR400/TR550/TR750)
R645	1-216-834-11	METAL CHIP	12K 5% 1/16W	R720	1-216-844-11	METAL CHIP	82K 5% 1/16W (TR70/TR72/TR80/TR430)
R646	1-216-818-11	METAL CHIP	560 5% 1/16W	R721	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR82/TR400/TR550/TR750)
R647	1-216-834-11	METAL CHIP	12K 5% 1/16W	R722	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR82/TR400/TR550/TR750)
R648	1-216-818-11	METAL CHIP	560 5% 1/16W	R723	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR72/TR80/TR430)
R649	1-216-841-11	METAL CHIP	47K 5% 1/16W	R724	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR82/TR400/TR550/TR750)
R650	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R725	1-216-841-11	METAL CHIP	47K 5% 1/16W
R651	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R739	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42)
R652	1-216-841-11	METAL CHIP	47K 5% 1/16W	R740	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR72/TR80/TR82/TR400/TR430/TR550/TR750)
R653	1-216-864-11	METAL CHIP	0 5% 1/16W	R741	1-218-855-11	METAL CHIP	2.2K 0.50% 1/16W
R656	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	R742	1-218-865-11	METAL CHIP	5.6K 0.50% 1/16W
R657	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R743	1-216-833-11	METAL CHIP	10K 5% 1/16W
R658	1-216-864-11	METAL CHIP	0 5% 1/16W	R744	1-216-827-11	METAL CHIP	3.3K 5% 1/16W
R659	1-216-823-11	METAL CHIP	1.5K 5% 1/16W	R745	1-216-837-11	METAL CHIP	22K 5% 1/16W
R661	1-216-841-11	METAL CHIP	47K 5% 1/16W	R746	1-216-837-11	METAL CHIP	22K 5% 1/16W
R662	1-216-821-11	METAL CHIP	1K 5% 1/16W	R747	1-216-820-11	METAL CHIP	820 5% 1/16W
R663	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	R748	1-216-828-11	METAL CHIP	3.9K 5% 1/16W
R664	1-216-821-11	METAL CHIP	1K 5% 1/16W	R749	1-216-851-11	METAL CHIP	330K 5% 1/16W
R665	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	R750	1-216-841-11	METAL CHIP	47K 5% 1/16W
R666	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R751	1-216-809-11	METAL CHIP	100 5% 1/16W
R667	1-216-820-11	METAL CHIP	820 5% 1/16W	R752	1-216-821-11	METAL CHIP	1K 5% 1/16W
R668	1-216-824-11	METAL CHIP	1.8K 5% 1/16W	R753	1-216-845-11	METAL CHIP	100K 5% 1/16W
R669	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R754	1-216-848-11	METAL CHIP	180K 5% 1/16W
R670	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R755	1-216-855-11	METAL CHIP	680K 5% 1/16W
R701	1-216-857-11	METAL CHIP	1M 5% 1/16W	R756	1-216-848-11	METAL CHIP	180K 5% 1/16W
R702	1-216-833-11	METAL CHIP	10K 5% 1/16W	R757	1-216-833-11	METAL CHIP	10K 5% 1/16W
R703	1-216-845-11	METAL CHIP	100K 5% 1/16W	R758	1-216-837-11	METAL CHIP	22K 5% 1/16W
R704	1-216-840-11	METAL CHIP	39K 5% 1/16W (TR42/TR82/TR400/TR550/TR750)	R759	1-216-837-11	METAL CHIP	22K 5% 1/16W
R705	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R760	1-216-826-11	METAL CHIP	2.7K 5% 1/16W
R709	1-216-845-11	METAL CHIP	100K 5% 1/16W	R761	1-216-842-11	METAL CHIP	56K 5% 1/16W
R710	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	R762	1-216-842-11	METAL CHIP	56K 5% 1/16W
R711	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R764	1-216-828-11	METAL CHIP	3.9K 5% 1/16W
R712	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	R765	1-216-833-11	METAL CHIP	10K 5% 1/16W (TR82/TR400/TR550/TR750)
R713	1-216-807-11	METAL CHIP	68 5% 1/16W	R766	1-216-835-11	METAL CHIP	15K 5% 1/16W (TR82/TR400/TR550/TR750)
R714	1-216-864-11	METAL CHIP	0 5% 1/16W	R767	1-216-850-11	METAL CHIP	270K 5% 1/16W (TR82/TR400/TR550/TR750)
R715	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R768	1-216-833-11	METAL CHIP	10K 5% 1/16W (TR82/TR400/TR550/TR750)
R716	1-218-847-11	METAL CHIP	1K 0.50% 1/16W	R769	1-216-850-11	METAL CHIP	270K 5% 1/16W (TR82/TR400/TR550/TR750)
R717	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R770	1-216-835-11	METAL CHIP	15K 5% 1/16W (TR82/TR400/TR550/TR750)
R718	1-216-807-11	METAL CHIP	68 5% 1/16W	R771	1-216-803-11	METAL CHIP	33 5% 1/16W (TR82/TR400/TR550/TR750)
R719	1-218-876-11	METAL CHIP	16K 0.50% 1/16W				
R720	1-216-841-11	METAL CHIP	47K 5% 1/16W (TR42)				

VC-138

VC-145

VF-65

Ref. No.	Part No.	Description	Remark
R772	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R773	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R774	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R775	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R776	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R777	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R778	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR82/TR400/TR550/TR750)	
R779	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R780	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R781	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR82/TR400/TR550/TR750)	
R782	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R783	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R786	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R787	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R788	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R789	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R790	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR82/TR400/TR550/TR750)	
R791	1-216-864-11	METAL CHIP 0 5% 1/16W (TR82/TR400/TR550/TR750)	
R792	1-216-857-11	METAL CHIP 1M 5% 1/16W (TR82/TR400/TR550/TR750)	
R793	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
< VIBRATOR >			
X601	1-760-081-21	VIBRATOR, CERAMIC (24MHz)	
X701	1-760-320-11	VIBRATOR, CRYSTAL (28.6363MHz)	
X775	1-579-553-11	VIBRATOR (12MHz) (TR82/TR400/TR550/TR750)	

*	A-7063-957-A	VF-65 BOARD, COMPLETE	

		(TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
		(Ref. No. 8,000 Series)	
< CAPACITOR >			
C901	1-124-635-00	ELECT 220uF 20% 6.3V	

Ref. No.	Part No.	Description	Remark
C902	1-163-038-11	CERAMIC CHIP 0.1uF	25V
C903	1-135-091-21	TANTAL. CHIP 1uF	20% 16V
C904	1-163-011-11	CERAMIC CHIP 0.0015uF	10% 50V
C905	1-104-753-11	TANTAL. CHIP 47uF	20% 6.3V
C906	1-162-638-11	CERAMIC CHIP 1uF	16V
C907	1-137-306-11	FILM CHIP 0.1uF	5% 16V
C908	1-163-109-00	CERAMIC CHIP 47PF	5% 50V
C909	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V
△C910	1-164-758-11	CERAMIC CHIP 0.0039uF	5% 50V
△C911	1-164-715-11	CERAMIC CHIP 0.0068uF	5% 50V
C912	1-127-532-11	ELECT(SOLID) 47uF	20% 6.3V
C913	1-124-577-11	ELECT 82uF	20% 10V
C914	1-128-007-11	ELECT CHIP 2.2uF	20% 35V
C915	1-163-037-11	CERAMIC CHIP 0.022uF	10% 25V
C916	1-164-611-11	CERAMIC CHIP 0.001uF	10% 500V
< CONNECTOR >			
CN901	1-566-537-11	CONNECTOR, FPC (NON ZIF) 5P	
CN902	1-573-290-11	PIN, CONNECTOR (1.5MM) (SMD) 4P	
< DIODE >			
D901	8-719-404-19	DIODE LN1251 (TALLY)	
D903	8-719-400-20	DIODE MA152WA	
< IC >			
IC901	8-759-196-14	IC BA7149F-E2	
< COIL >			
L901	1-412-031-11	INDUCTOR CHIP 47uH	
L902	1-410-389-31	INDUCTOR CHIP 47uH	
△L903	1-402-680-21	COIL, FERRITE (HLC)	
< TRANSISTOR >			
△Q901	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
Q902	8-729-106-68	TRANSISTOR 2SD1615A-GP	
Q903	8-729-216-31	TRANSISTOR 2SA1163-G	
Q904	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
< RESISTOR >			
R901	1-216-041-00	METAL CHIP 470 5% 1/10W	
R902	1-216-041-00	METAL CHIP 470 5% 1/10W	
R903	1-216-035-00	METAL CHIP 270 5% 1/10W	
△R904	1-216-073-00	METAL CHIP 10K 5% 1/10W	
△R905	1-216-051-00	METAL CHIP 1.2K 5% 1/10W	
R906	1-216-047-00	METAL CHIP 820 5% 1/10W	
R907	1-216-097-00	METAL CHIP 100K 5% 1/10W	
R908	1-216-111-00	METAL CHIP 390K 5% 1/10W	
R909	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R910	1-216-077-00	METAL CHIP 15K 5% 1/10W	

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark		
R911	1-216-160-00	METAL GLAZE	27	5%	1/8W
R912	1-216-121-00	METAL CHIP	1M	5%	1/10W
R913	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R914	1-216-025-00	METAL CHIP	100	5%	1/10W
R915	1-216-308-00	METAL CHIP	4.7	5%	1/10W
R916	1-216-683-11	METAL CHIP	22K	0.5%	1/10W
R917	1-216-693-11	METAL CHIP	56K	0.5%	1/10W
R918	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R919	1-216-689-11	METAL CHIP	39K	0.5%	1/10W
R920	1-216-689-11	METAL CHIP	39K	0.5%	1/10W
R921	1-216-311-00	METAL CHIP	6.8	5%	1/10W
R922	1-216-101-00	METAL CHIP	150K	5%	1/10W
R923	1-216-121-00	METAL CHIP	1M	5%	1/10W
R924	1-216-131-11	METAL CHIP	2.7M	5%	1/10W
R925	1-216-131-11	METAL CHIP	2.7M	5%	1/10W
R926	1-216-295-00	METAL CHIP	0	5%	1/10W
R927	1-216-049-00	METAL CHIP	1K	5%	1/10W
R928	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
< VARIABLE RESISTOR >					
RV903	1-238-086-11	RES, ADJ, CERMET	470		
RV904	1-223-566-11	RES, ADJ, METAL GLAZE	1M		
< TRANSFORMER >					
△T901	1-453-124-11	TRANSFORMER ASSY, FLYBACK			
< THERMISTOR >					
TH901	1-809-350-21	THERMISTOR, NTC (2125)			
< SOCKET >					
△W901	1-540-019-21	SOCKET ASSY, CRT			

*	A-7066-010-A	VF-66 BOARD, COMPLETE (TR70/TR80)			

		(Ref. No. 4,000 Series)			
< CAPACITOR >					
C851	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V
C852	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C853	1-104-916-11	TANTAL. CHIP	6.8uF	20%	20V
C854	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C855	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C856	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
C857	1-164-676-11	CERAMIC CHIP	2200PF	5%	16V
C858	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
C859	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C860	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C861	1-104-917-11	TANTAL. CHIP	15uF	20%	20V

Ref. No.	Part No.	Description	Remark		
C862	1-165-178-11	CERAMIC CHIP	6.8uF		16V
C863	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C864	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C865	1-162-921-11	CERAMIC CHIP	33PF	5%	50V
C866	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C867	1-135-177-21	TANTALUM CHIP	1uF	20%	20V
C868	1-165-128-11	CERAMIC CHIP	0.22uF		16V
C869	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C870	1-162-974-11	CERAMIC CHIP	0.01uF		50V
< CONNECTOR >					
CN851	1-573-354-11	CONNECTOR, FFC/FPC 14P			
CN852	1-573-354-11	CONNECTOR, FFC/FPC 14P			
CN853	1-573-811-11	CONNECTOR, BOARD TO BOARD 12P			
< DIODE >					
D851	8-719-404-19	DIODE LN1251C (TALLY)			
D852	8-719-043-70	DIODE MA6S121			
D853	8-719-802-36	DIODE 1SS250			
< IC >					
IC851	8-759-097-75	IC MB3789PFV-G-BND-ER			
IC852	8-759-508-68	IC XRA10358F-E2			
< COIL >					
L851	1-412-033-11	INDUCTOR CHIP 220uH			
L852	1-412-029-11	INDUCTOR CHIP 10uH			
L853	1-412-033-11	INDUCTOR CHIP 220uH			
< TRANSISTOR >					
Q851	8-729-024-60	TRANSISTOR MTD6N15T4			
Q852	8-729-402-84	TRANSISTOR XN4601			
Q853	8-729-923-62	TRANSISTOR DTA123JK			
< RESISTOR >					
R851	1-216-819-11	METAL CHIP	680	5%	1/16W
R852	1-216-841-11	METAL CHIP	47K	5%	1/16W
R853	1-218-899-11	METAL CHIP	150K	0.50%	1/16W
R854	1-218-901-11	METAL CHIP	180K	0.50%	1/16W
R855	1-216-840-11	METAL CHIP	39K	5%	1/16W
R856	1-218-899-11	METAL CHIP	150K	0.50%	1/16W
R857	1-218-903-11	METAL CHIP	220K	0.50%	1/16W
R858	1-216-841-11	METAL CHIP	47K	5%	1/16W
R859	1-216-849-11	METAL CHIP	220K	5%	1/16W
R860	1-216-843-11	METAL CHIP	68K	5%	1/16W
R861	1-216-843-11	METAL CHIP	68K	5%	1/16W
R862	1-216-838-11	METAL CHIP	27K	5%	1/16W
R863	1-216-847-11	METAL CHIP	150K	5%	1/16W
R864	1-216-840-11	METAL CHIP	39K	5%	1/16W
R865	1-216-841-11	METAL CHIP	47K	5%	1/16W

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark		
R867	1-216-850-11	METAL CHIP	270K	5%	1/16W
R868	1-216-864-11	METAL CHIP	0	5%	1/16W
R869	1-216-843-11	METAL CHIP	68K	5%	1/16W
R870	1-216-842-11	METAL CHIP	56K	5%	1/16W
R871	1-216-850-11	METAL CHIP	270K	5%	1/16W
R872	1-216-833-11	METAL CHIP	10K	5%	1/16W
R873	1-216-851-11	METAL CHIP	330K	5%	1/16W
R874	1-216-847-11	METAL CHIP	150K	5%	1/16W
R875	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R876	1-216-833-11	METAL CHIP	10K	5%	1/16W
R877	1-216-794-11	METAL CHIP	5.6	5%	1/16W
R878	1-216-804-11	METAL CHIP	39	5%	1/16W
R879	1-216-837-11	METAL CHIP	22K	5%	1/16W
R880	1-216-839-11	METAL CHIP	33K	5%	1/16W
R881	1-216-853-11	METAL CHIP	470K	5%	1/16W
R891	1-216-296-00	METAL CHIP	0	5%	1/8W
< TRANSFORMER >					
△T851	0-396-458-00				

*	A-7066-011-A	VF-67 BOARD, COMPLETE (TR70/TR80)			

< CAPACITOR >					
C901	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C902	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C903	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C904	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C905	1-135-091-21	TANTAL. CHIP	1uF	20%	16V
C906	1-162-969-11	CERAMIC CHIP	0.0068uF	10%	25V
C907	1-135-091-21	TANTAL. CHIP	1uF	20%	16V
C908	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C909	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C910	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C911	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C913	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C914	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C915	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C916	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C917	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C920	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C921	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C925	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C926	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
C927	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C928	1-164-344-11	CERAMIC CHIP	0.068uF	10%	25V
C929	1-164-344-11	CERAMIC CHIP	0.068uF	10%	25V
C930	1-164-344-11	CERAMIC CHIP	0.068uF	10%	25V
C931	1-162-974-11	CERAMIC CHIP	0.01uF		50V

Ref. No.	Part No.	Description	Remark
C932	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C933	1-164-156-11	CERAMIC CHIP 0.1uF	25V
C934	1-135-145-11	TANTALUM CHIP 0.47uF 10%	35V
C935	1-135-179-21	TANTAL. CHIP 2.2uF 20%	16V
C936	1-162-967-11	CERAMIC CHIP 0.0033uF 10%	50V
C937	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C938	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C939	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C940	1-162-927-11	CERAMIC CHIP 100PF 5%	50V
C941	1-164-357-11	CERAMIC CHIP 1000PF 5%	50V
C942	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C943	1-164-156-11	CERAMIC CHIP 0.1uF	25V
C945	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C946	1-135-179-21	TANTAL. CHIP 2.2uF 20%	16V
C947	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C948	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C949	1-135-178-11	TANTAL. CHIP 1.5uF 20%	20V
C950	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C951	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C953	1-164-346-11	CERAMIC CHIP 1uF	16V
C954	1-162-974-11	CERAMIC CHIP 0.01uF	50V
< CONNECTOR >			
CN901	1-573-354-11	CONNECTOR, FFC/FPC 14P	
* CN902	1-573-984-11	CONNECTOR, BOARD TO BOARD 10P	
* CN903	1-573-356-11	CONNECTOR, FFC/FPC 16P	
< DIODE >			
D901	8-719-025-91	DIODE MA365(E)	
D903	8-719-404-49	DIODE MA111	
< IC >			
IC901	8-752-067-59	IC CXA1785R	
IC902	8-752-362-78	IC CXD2403R	
IC903	8-759-251-40	IC MB88E346PFV-G-BND-ER	
< COIL >			
L901	1-412-951-11	INDUCTOR 10uH	
L902	1-412-962-11	INDUCTOR 82uH	
L904	1-412-951-11	INDUCTOR 10uH	
L905	1-412-949-21	INDUCTOR 6.8uH	
L906	1-412-959-11	INDUCTOR 47uH	
< TRANSISTOR >			
Q901	8-729-402-84	TRANSISTOR XN4601	
Q902	8-729-402-42	TRANSISTOR UN5213	
< RESISTOR >			
R902	1-216-836-11	METAL CHIP 18K 5%	1/16W
R903	1-216-842-11	METAL CHIP 56K 5%	1/16W

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

VF-08

VF-67

Ref. No. Part No. Description

8887	1-012-001-01	WHEEL, COAT	270	02	1.000
8888	1-012-002-01	WHEEL, COAT	1	02	1.000
8889	1-012-003-01	WHEEL, COAT	100	02	1.000
8890	1-012-004-01	WHEEL, COAT	100	02	1.000
8891	1-012-005-01	WHEEL, COAT	1000	02	1.000

8892	1-012-006-01	WHEEL, COAT	100	02	1.000
8893	1-012-007-01	WHEEL, COAT	1000	02	1.000
8894	1-012-008-01	WHEEL, COAT	1000	02	1.000
8895	1-012-009-01	WHEEL, COAT	4.00	02	1.000
8896	1-012-010-01	WHEEL, COAT	100	02	1.000

8897	1-012-011-01	WHEEL, COAT	1.1	02	1.000
8898	1-012-012-01	WHEEL, COAT	100	02	1.000
8899	1-012-013-01	WHEEL, COAT	100	02	1.000
8900	1-012-014-01	WHEEL, COAT	100	02	1.000
8901	1-012-015-01	WHEEL, COAT	1000	02	1.000

8902	1-012-016-01	WHEEL, COAT	0	02	1.000
------	--------------	-------------	---	----	-------

(TRANSFER)

AIRC. 1-012-017-01

8903	1-012-018-01	WHEEL, COAT	1000	02	1.000
------	--------------	-------------	------	----	-------

(TRANSFER)

(TRANSFER)

(TRANSFER)

8904	1-012-019-01	WHEEL, COAT	0.000	02	1.000
8905	1-012-020-01	WHEEL, COAT	0.000	02	1.000
8906	1-012-021-01	WHEEL, COAT	0.000	02	1.000
8907	1-012-022-01	WHEEL, COAT	0.000	02	1.000
8908	1-012-023-01	WHEEL, COAT	0.000	02	1.000

8909	1-012-024-01	WHEEL, COAT	0.000	02	1.000
8910	1-012-025-01	WHEEL, COAT	0.000	02	1.000
8911	1-012-026-01	WHEEL, COAT	0.000	02	1.000
8912	1-012-027-01	WHEEL, COAT	0.000	02	1.000
8913	1-012-028-01	WHEEL, COAT	0.000	02	1.000

8914	1-012-029-01	WHEEL, COAT	0.000	02	1.000
8915	1-012-030-01	WHEEL, COAT	0.000	02	1.000
8916	1-012-031-01	WHEEL, COAT	0.000	02	1.000
8917	1-012-032-01	WHEEL, COAT	0.000	02	1.000
8918	1-012-033-01	WHEEL, COAT	0.000	02	1.000

8919	1-012-034-01	WHEEL, COAT	0.000	02	1.000
8920	1-012-035-01	WHEEL, COAT	0.000	02	1.000
8921	1-012-036-01	WHEEL, COAT	0.000	02	1.000
8922	1-012-037-01	WHEEL, COAT	0.000	02	1.000
8923	1-012-038-01	WHEEL, COAT	0.000	02	1.000

8924	1-012-039-01	WHEEL, COAT	0.000	02	1.000
8925	1-012-040-01	WHEEL, COAT	0.000	02	1.000
8926	1-012-041-01	WHEEL, COAT	0.000	02	1.000
8927	1-012-042-01	WHEEL, COAT	0.000	02	1.000
8928	1-012-043-01	WHEEL, COAT	0.000	02	1.000

Amount

Ref. No. Part No. Description

Amount

8929	1-012-044-01	WHEEL, COAT	0.000	02	1.000
8930	1-012-045-01	WHEEL, COAT	0.000	02	1.000
8931	1-012-046-01	WHEEL, COAT	0.000	02	1.000
8932	1-012-047-01	WHEEL, COAT	0.000	02	1.000
8933	1-012-048-01	WHEEL, COAT	0.000	02	1.000

8934	1-012-049-01	WHEEL, COAT	0.000	02	1.000
8935	1-012-050-01	WHEEL, COAT	0.000	02	1.000
8936	1-012-051-01	WHEEL, COAT	0.000	02	1.000
8937	1-012-052-01	WHEEL, COAT	0.000	02	1.000
8938	1-012-053-01	WHEEL, COAT	0.000	02	1.000

8939	1-012-054-01	WHEEL, COAT	0.000	02	1.000
8940	1-012-055-01	WHEEL, COAT	0.000	02	1.000
8941	1-012-056-01	WHEEL, COAT	0.000	02	1.000
8942	1-012-057-01	WHEEL, COAT	0.000	02	1.000
8943	1-012-058-01	WHEEL, COAT	0.000	02	1.000

8944	1-012-059-01	WHEEL, COAT	0.000	02	1.000
8945	1-012-060-01	WHEEL, COAT	0.000	02	1.000
8946	1-012-061-01	WHEEL, COAT	0.000	02	1.000
8947	1-012-062-01	WHEEL, COAT	0.000	02	1.000
8948	1-012-063-01	WHEEL, COAT	0.000	02	1.000

8949	1-012-064-01	WHEEL, COAT	0.000	02	1.000
------	--------------	-------------	-------	----	-------

(TRANSFER)

8950	1-012-065-01	WHEEL, COAT	0.000	02	1.000
8951	1-012-066-01	WHEEL, COAT	0.000	02	1.000
8952	1-012-067-01	WHEEL, COAT	0.000	02	1.000

(TRANSFER)

8953	1-012-068-01	WHEEL, COAT	0.000	02	1.000
8954	1-012-069-01	WHEEL, COAT	0.000	02	1.000

(TRANSFER)

8955	1-012-070-01	WHEEL, COAT	0.000	02	1.000
8956	1-012-071-01	WHEEL, COAT	0.000	02	1.000
8957	1-012-072-01	WHEEL, COAT	0.000	02	1.000

(TRANSFER)

8958	1-012-073-01	WHEEL, COAT	0.000	02	1.000
8959	1-012-074-01	WHEEL, COAT	0.000	02	1.000
8960	1-012-075-01	WHEEL, COAT	0.000	02	1.000
8961	1-012-076-01	WHEEL, COAT	0.000	02	1.000
8962	1-012-077-01	WHEEL, COAT	0.000	02	1.000

(TRANSFER)

8963	1-012-078-01	WHEEL, COAT	0.000	02	1.000
8964	1-012-079-01	WHEEL, COAT	0.000	02	1.000

(TRANSFER)

8965	1-012-080-01	WHEEL, COAT	0.000	02	1.000
8966	1-012-081-01	WHEEL, COAT	0.000	02	1.000

The information identified by this
 & is listed in this book & are
 subject to change.
 Repairs only with your number
 specified.

The information identified by this
 & is listed in this book & are
 subject to change.
 Repairs only with your number
 specified.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R904	1-216-857-11	METAL CHIP	1M 5% 1/16W	*	A-7063-959-A	VS-104 BOARD, COMPLETE (TR72)	
R906	1-216-841-11	METAL CHIP	47K 5% 1/16W			*****	
R907	1-216-833-11	METAL CHIP	10K 5% 1/16W	*	A-7066-008-A	VS-104 BOARD, COMPLETE (TR80)	
R908	1-216-821-11	METAL CHIP	1K 5% 1/16W			*****	
R910	1-216-814-11	METAL CHIP	270 5% 1/16W	*	A-7066-079-A	VS-104 (H) BOARD, COMPLETE (TR400)	
R911	1-216-864-11	METAL CHIP	0 5% 1/16W			*****	
R912	1-216-821-11	METAL CHIP	1K 5% 1/16W	*	A-7066-086-A	VS-104 BOARD, COMPLETE (TR430)	
R913	1-220-397-11	METAL GLAZE	4.7M 5% 1/16W			*****	
R914	1-216-832-11	METAL CHIP	8.2K 5% 1/16W	*	A-7066-134-A	VS-104 (H) BOARD, COMPLETE (TR750)	
R919	1-216-839-11	METAL CHIP	33K 5% 1/16W			*****	
R920	1-216-839-11	METAL CHIP	33K 5% 1/16W	*	A-7063-953-A	VS-112 BOARD, COMPLETE (TR82)	
R921	1-216-857-11	METAL CHIP	1M 5% 1/16W			*****	
R922	1-216-839-11	METAL CHIP	33K 5% 1/16W	*	A-7066-019-A	VS-112 BOARD, COMPLETE (TR70)	
R923	1-216-839-11	METAL CHIP	33K 5% 1/16W			*****	
R924	1-216-864-11	METAL CHIP	0 5% 1/16W	*	A-7066-047-A	VS-112 (LL) BOARD, COMPLETE (TR42)	
R925	1-216-830-11	METAL CHIP	5.6K 5% 1/16W			*****	
R926	1-216-832-11	METAL CHIP	8.2K 5% 1/16W	*	A-7066-085-A	VS-112 BOARD, COMPLETE (TR550)	
R930	1-216-833-11	METAL CHIP	10K 5% 1/16W			*****	
R931	1-216-839-11	METAL CHIP	33K 5% 1/16W			(Ref. No. 30,000 Series)	
R933	1-216-864-11	METAL CHIP	0 5% 1/16W			< CAPACITOR >	
R934	1-216-821-11	METAL CHIP	1K 5% 1/16W	C101	1-162-921-11	CERAMIC CHIP 33PF 5% 50V	
R936	1-218-873-11	METAL CHIP	12K 0.50% 1/16W			(TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R937	1-218-905-11	METAL CHIP	270K 0.50% 1/16W	C102	1-162-911-11	CERAMIC CHIP 6PF 0.5PF 50V	
R938	1-216-849-11	METAL CHIP	220K 5% 1/16W			(TR400/TR750)	
R939	1-216-837-11	METAL CHIP	22K 5% 1/16W	C102	1-162-922-11	CERAMIC CHIP 39PF 5% 50V	
R946	1-216-821-11	METAL CHIP	33K 5% 1/16W			(TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R947	1-216-807-11	METAL CHIP	68 5% 1/16W	C103	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R948	1-216-807-11	METAL CHIP	68 5% 1/16W	C104	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R949	1-216-807-11	METAL CHIP	68 5% 1/16W	C106	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
R953	1-216-840-11	METAL CHIP	39K 5% 1/16W	C107	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
R954	1-216-840-11	METAL CHIP	39K 5% 1/16W	C108	1-162-926-11	CERAMIC CHIP 82PF 5% 50V	
R959	1-216-844-11	METAL CHIP	82K 5% 1/16W	C109	1-164-227-11	CERAMIC CHIP 0.022uF 10% 25V	
R960	1-216-845-11	METAL CHIP	100K 5% 1/16W	C110	1-164-227-11	CERAMIC CHIP 0.022uF 10% 25V	
R961	1-216-850-11	METAL CHIP	270K 5% 1/16W	C111	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R969	1-216-839-11	METAL CHIP	33K 5% 1/16W	C112	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
R970	1-216-839-11	METAL CHIP	33K 5% 1/16W	C113	1-164-217-11	CERAMIC CHIP 150PF 5% 50V	
R971	1-216-844-11	METAL CHIP	82K 5% 1/16W	C114	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
R973	1-216-839-11	METAL CHIP	33K 5% 1/16W	C115	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R974	1-216-839-11	METAL CHIP	33K 5% 1/16W	C116	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
		< VIBRATOR >		C117	1-104-852-11	TANTAL. CHIP 22uF 20% 6.3V	
X901	1-579-466-11	VIBRATOR, CRYSTAL (3.58MHz)		C118	1-104-852-11	TANTAL. CHIP 22uF 20% 6.3V	
		*****		C119	1-162-961-11	CERAMIC CHIP 330PF 10% 50V	
				C120	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
				C121	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
				C122	1-162-961-11	CERAMIC CHIP 330PF 10% 50V	
				C123	1-162-974-11	CERAMIC CHIP 0.01uF 50V	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C124	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V	C172	1-162-921-11	CERAMIC CHIP 33PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
C128	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C173	1-164-155-11	CERAMIC CHIP 75PF 5% 50V (TR400/TR750)	
C131	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C175	1-162-915-11	CERAMIC CHIP 10PF 0.5PF 50V (TR400/TR750)	
C134	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C176	1-162-921-11	CERAMIC CHIP 33PF 5% 50V (TR400/TR750)	
C136	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C177	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C137	1-162-918-11	CERAMIC CHIP	18PF 5% 50V	C178	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C143	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V	C179	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C144	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V	C190	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C145	1-104-852-11	TANTAL. CHIP	22uF 20% 6.3V	C202	1-162-944-11	CERAMIC CHIP 18PF 5% 50V (TR400/TR750)	
C146	1-164-360-11	CERAMIC CHIP	0.1uF 16V	C203	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C147	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C204	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C148	1-162-958-11	CERAMIC CHIP	270PF 5% 50V	C205	1-162-974-11	CERAMIC CHIP 0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
C149	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C206	1-164-489-11	CERAMIC CHIP 0.22uF 10% 16V	
C150	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C207	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
C151	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C208	1-135-149-21	TANTALUM CHIP 2.2uF 20% 10V	
C152	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C209	1-126-246-11	ELECT CHIP 220uF 20% 4V	
C153	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C210	1-162-961-11	CERAMIC CHIP 330PF 10% 50V	
C154	1-162-945-11	CERAMIC CHIP	22PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C211	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
C155	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR400/TR750)	C212	1-162-995-11	CERAMIC CHIP 0.022uF 50V	
C157	1-162-918-11	CERAMIC CHIP	18PF 5% 50V	C213	1-135-176-21	TANTALUM CHIP 0.68uF 10% 20V	
C158	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C214	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
C159	1-162-922-11	CERAMIC CHIP	39PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C215	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C160	1-162-946-11	CERAMIC CHIP	27PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C216	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C161	1-162-966-11	CERAMIC CHIP	0.0022uF 10% 50V	C217	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
C163	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C218	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
C164	1-162-942-11	CERAMIC CHIP	12PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C220	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C165	1-162-956-11	CERAMIC CHIP	180PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C221	1-164-005-11	CERAMIC CHIP 0.47uF 25V (TR400/TR750)	
C166	1-162-958-11	CERAMIC CHIP	270PF 5% 50V	C222	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C167	1-162-926-11	CERAMIC CHIP	82PF 5% 50V (TR72/TR80/TR400/TR430/TR750)	C223	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C167	1-164-382-11	CERAMIC CHIP	91PF 5% 50V (TR42/TR70/TR82/TR550)	C225	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C168	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C226	1-162-926-11	CERAMIC CHIP 82PF 5% 50V	
C169	1-162-949-11	CERAMIC CHIP	47PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C227	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C170	1-162-915-11	CERAMIC CHIP	10PF 0.5PF 50V (TR400/TR750)	C228	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C171	1-162-927-11	CERAMIC CHIP	100PF 5% 50V (TR400/TR750)	C229	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
				C230	1-135-180-21	TANTALUM CHIP 3.3uF 20% 6.3V	
				C231	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
				C234	1-162-957-11	CERAMIC CHIP 220PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
				C234	1-164-471-11	CERAMIC CHIP 680PF 5% 50V (TR400/TR750)	
				C235	1-126-207-11	ELECT CHIP 33uF 20% 4V	
				C237	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
				C238	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
				C239	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
				C240	1-164-392-11	CERAMIC CHIP 390PF 5% 50V	

Part No.	Part No.	Description	Assembly No.	Part No.	Part No.	Description	Assembly No.
035	1-100-004-11	TAPPL. COU	50	036	1-100-004-11	CHAMFC COU	50
036	1-100-004-11	CHAMFC COU	50				
037	1-100-004-11	CHAMFC COU	50				
038	1-100-004-11	CHAMFC COU	50				
039	1-100-004-11	CHAMFC COU	50				
040	1-100-004-11	CHAMFC COU	50				
041	1-100-004-11	CHAMFC COU	50				
042	1-100-004-11	CHAMFC COU	50				
043	1-100-004-11	CHAMFC COU	50				
044	1-100-004-11	CHAMFC COU	50				
045	1-100-004-11	CHAMFC COU	50				
046	1-100-004-11	CHAMFC COU	50				
047	1-100-004-11	CHAMFC COU	50				
048	1-100-004-11	CHAMFC COU	50				
049	1-100-004-11	CHAMFC COU	50				
050	1-100-004-11	CHAMFC COU	50				
051	1-100-004-11	CHAMFC COU	50				
052	1-100-004-11	CHAMFC COU	50				
053	1-100-004-11	CHAMFC COU	50				
054	1-100-004-11	CHAMFC COU	50				
055	1-100-004-11	CHAMFC COU	50				
056	1-100-004-11	CHAMFC COU	50				
057	1-100-004-11	CHAMFC COU	50				
058	1-100-004-11	CHAMFC COU	50				
059	1-100-004-11	CHAMFC COU	50				
060	1-100-004-11	CHAMFC COU	50				
061	1-100-004-11	CHAMFC COU	50				
062	1-100-004-11	CHAMFC COU	50				
063	1-100-004-11	CHAMFC COU	50				
064	1-100-004-11	CHAMFC COU	50				
065	1-100-004-11	CHAMFC COU	50				
066	1-100-004-11	CHAMFC COU	50				
067	1-100-004-11	CHAMFC COU	50				
068	1-100-004-11	CHAMFC COU	50				
069	1-100-004-11	CHAMFC COU	50				
070	1-100-004-11	CHAMFC COU	50				
071	1-100-004-11	CHAMFC COU	50				
072	1-100-004-11	CHAMFC COU	50				
073	1-100-004-11	CHAMFC COU	50				
074	1-100-004-11	CHAMFC COU	50				
075	1-100-004-11	CHAMFC COU	50				
076	1-100-004-11	CHAMFC COU	50				
077	1-100-004-11	CHAMFC COU	50				
078	1-100-004-11	CHAMFC COU	50				
079	1-100-004-11	CHAMFC COU	50				
080	1-100-004-11	CHAMFC COU	50				
081	1-100-004-11	CHAMFC COU	50				
082	1-100-004-11	CHAMFC COU	50				
083	1-100-004-11	CHAMFC COU	50				
084	1-100-004-11	CHAMFC COU	50				
085	1-100-004-11	CHAMFC COU	50				
086	1-100-004-11	CHAMFC COU	50				
087	1-100-004-11	CHAMFC COU	50				
088	1-100-004-11	CHAMFC COU	50				
089	1-100-004-11	CHAMFC COU	50				
090	1-100-004-11	CHAMFC COU	50				
091	1-100-004-11	CHAMFC COU	50				
092	1-100-004-11	CHAMFC COU	50				
093	1-100-004-11	CHAMFC COU	50				
094	1-100-004-11	CHAMFC COU	50				
095	1-100-004-11	CHAMFC COU	50				
096	1-100-004-11	CHAMFC COU	50				
097	1-100-004-11	CHAMFC COU	50				
098	1-100-004-11	CHAMFC COU	50				
099	1-100-004-11	CHAMFC COU	50				
100	1-100-004-11	CHAMFC COU	50				

1-1-3. Precautions

1. Switch settings

Adjust the switches to the following positions, and adjust without loading the cassette tape, unless specified otherwise.

1. Camera/player power switch
(Control switch block (Control switch block (CK board))) Camera
2. Standby switch (Control switch block (FK board)) .. Standby
3. PROGRAM AE button (Control switch block (CK board))
..... Off
4. FOCUS switch (Control switch block (CK board)) ... Manual
5. BACK LIGHT button (Control switch block (CK board))
..... Off
6. STEADY SHOT button (CCD-TR82/TR400/TR550/TR750)
(Control switch block (CK board)) Off

2. Adjusting Procedure

Adjust in the given order.

3. Subject

- 1) Color bar chart (Standard picture frame)
Adjust the picture frame as shown in Fig. 7-1-4. if adjustments are performed using the color bar chart.
(Standard picture frame)
- 2) White pattern (Standard picture frame)
Remove the color bar chart from the pattern box, and so that the white pattern will be displayed.
Don't touch the zoom switch.




Fig. 7-1-4.

3) Chart for flange back adjustment

Combine a white A0 size (1189 mm × 841 mm) paper to a black one, and make the chart shown in Fig. 7-1-5.




Fig. 7-1-5.

Note: Use the non-reflecting and non-glazing vellum paper whose size is more than A0, and make the boundary between white and black to be smoothly flat.

7-1-2. Precautions

1. Switch settings

Adjust the switches in the following positions, and adjust without causing the screen wavy, unless specified otherwise.

1. **Color display power switch**
(Control switch block/Control switch block (CK board))
ON
2. **Standby switch** (Control switch block (FL board))—Standby
3. **PROGRAM A/D button** (Control switch block (FL board))
OFF
4. **FOCUS switch** (Control switch block (CK board))—Adjust
5. **BACK LIGHT button** (Control switch block (CK board))
OFF
6. **STEADY SHOT button** (CKC-38A/SteadyShot board/CKC board)
OFF

2. Adjusting Procedure

Adjust in the given order.

3. Subject

- 1) **Color bar chart** (Standard picture frame)
Adjust the picture frame as shown in Fig. 7-1-4. If adjustments are performed using the color bar chart, (Standard picture frame)
- 2) **White pattern** (Standard picture frame)
Remove the color bar chart from the picture box, and use the white pattern as the display.

Don't touch the screen surface.




Fig. 7-1-4.

4) Check for fringe/back adjustment

Consider a white A4 size (1.281 inch/32.7 mm) paper in a black box, and make the chart shown in Fig. 7-1-5.



Fig. 7-1-5.

Notes: Use the non-reflecting and non-glazing white paper whose size is more than A4, and make the boundary between white and black as horizontally thin.

1-1-4. Adjusting Remote Commander

The camera section is adjusted by changing the constant or coefficient of the digital signal processing calculation, or modifying the output voltage of the EVR IC (VC board IC603). This is controlled by the camera micro processor (VC board IC602), which reads the data written in the nonvolatile memory (VC board IC601: EEPROM), and transmits it to the digital signal processing circuit and EVR.

To perform adjustments, adjustment data written in the nonvolatile memory must be rewritten, using the adjusting remote commander.

The adjusting remote commander uses the remote commander signal line (LANC) to communicate mutually with the camera microprocessor. The page, address and the up/down commands of the data are transmitted from the adjusting remote commander to the camera micro processor. And, the page, address, and data are transmitted for the vice versa.

1. Using the adjusting remote commander

- 1) Connect the adjusting remote commander to the remote terminal.
- 2) Adjust the HOLD switch of the adjusting remote commander to "HOLD" (SERVICE position).

If it has been properly connected, the LCD on the adjusting remote commander will display as shown in Fig. 7-1-6.




Fig. 7-1-6.

- 3) Operate the adjusting remote commander as follows.

- Changing the page

The page increases when the EDIT SEARCH+ button is pressed, and decreases when the EDIT SEARCH- button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal notation	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
LCD Display	0	1	2	3	4	5	6	7	8	9	A	b	c	d	E	F
Decimal notation conversion value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

Table 7-1-1.

- Changing the address

The address increases when the FF (▶▶) button is pressed, and decreases when the REW (◀◀) button is pressed. There are altogether 256 addresses, from 00 to FF.

- Changing the data (Data setting)

The data increases when the PLAY (▶) button is pressed, and decreases when the STOP (■) button is pressed.

There are altogether 256 data, from 00 to FF.

- Writing the adjustment data

The PAUSE button must be pressed to write the adjustment data (F page) in the nonvolatile memory.

(The new adjustment data will not be recorded in the nonvolatile memory if this step is not performed.)

- 4) Select page: 6, address: 00, and adjust the data to 01. Page F, and enables the camera section (Addresses 01 to BF of page F) to be adjusted.
- 5) After completing all adjustments, turn off the main power supply (6.3V) once.

2. Precautions upon using the adjusting remote commander

Mishandling of the adjusting remote commander may erase the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment.

1-1-4. Adjusting Stereo Commander

The stereo section is adjusted by changing the constant or coefficient of the digital signal processing calculation, or modifying the output voltage of the DVS IC (VC board EX05). This is controlled by the stereo source processor (SC board EX05), which sends the data written in the non-volatile memory (VC board EX05) EXPR000, and transmits it to the digital signal processing circuit and DVS.

In perform adjustment, adjustment data written in the non-volatile memory must be rewritten, using the adjusting stereo commander.

The adjusting stereo commander uses the stereo commander output line (LAMP) to communicate mutually with the stereo microprocessor. The page, address, and the adjustment constants of the data are transmitted from the adjusting stereo commander to the stereo micro-processor. And, the page, address, and data are transmitted from the stereo micro-

1. Using the adjusting stereo commander
 2. Compare the adjusting stereo commander to the stereo terminal
 3. Adjust the EXPR000 variable of the adjusting stereo commander to "HOLD" (DATA/VC) position.
- If it has been properly connected, the LAMP of the adjusting stereo commander will light up as shown in Fig. 7-1-6.



Fig. 7-1-6.

4. Operate the adjusting stereo commander as follows.

• Changing the page

The page increases when the NEXT (DATA/VC) button is pressed, and decreases when the PREV (DATA/VC) button is pressed. There are altogether 28 pages, from 0 to 27.

Hexadecimal number	0 1 2 3 4 5 6 7 8 9 A B C D E F
USB display	0 1 2 3 4 5 6 7 8 9 A B C D E F
Decimal number (commander value)	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

Table 7-1-1.

• Changing the address

The address increases when the PP (+) button is pressed, and decreases when the BB (-) button is pressed. There are altogether 256 addresses, from 00 to FF.

• Changing the data (data writing)

The data increases when the PLAY (+) button is pressed, and decreases when the STOP (■) button is pressed.

There are altogether 256 data, from 00 to FF.

• Writing the adjustment data

The WRITE button must be pressed to write the adjustment data (7 pages) in the non-volatile memory.

(The new adjustment data (p0) can be recorded in the non-volatile memory if this step is not performed.)

4. Select page 0, address 00, and adjust the data in 00. (Step 2), and modify the stereo section (Addresses 01 to 0F of page 0) to be adjusted.
5. After completing all adjustments, turn off the stereo power supply (LVS) main.

5. Precautions upon using the adjusting stereo commander

Interfering of the adjusting stereo commander may cause the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be saved before before beginning adjustments and save adjustment data after each adjustment.

1-1-5. Page F Address List

Note 1: The data already listed in the adjustment data memo column are fixed values.

Note 2: The adjustment data initial values are values just after executing "Page F Data Initialization" and "Page F Data Modification". They are different from the values after executing all adjustments.

Note 3: In some cases, data have been input to the page F addresses C0 to FF. This has no relation to the adjustments.

Note 4: No mark : CCD-TR42/TR72/TR80/TR430

() : CCD-TR82/TR550

< > : CCD-TR70

《 》 : CCD-TR400/TR750

Address	Adjustment data	
	Initial value	Memo column
00	5C (5A) <5E> 《56》	5C (5A) <5E> 《56》
01	0A (00)	0A (00)
02	00	00
03	00 (07)	00 (07)
04	80	
05	80	
06	80	
07	80	
08	2D	
09	26	
0A	FA	
0B	F1	
0C	30	
0D	00	
0E	58	
0F	00	
10	E0	E0
11	8F	
12	6C	
13	36	
14	3C	
15	B6	
16	0D	
17	A3	
18	12	
19	8E	
1A	10	
1B	E2	
1C	0C	0C
1D	00	00
1E	80	
1F	80	
20	80 (79)	80 (79)
21	80 (79)	80 (79)
22	00	00
23	59	53
24	43	43
25	A5 (B5)	A5 (B5)
26	23	23
27	3A	3A
28	A2	A2
29	0B	0B

Table 7-1-2 (1).

1-4-B Page F Address List

Note 1: The data already listed in the adjustment data were entered as fixed values.

Note 2: The adjustment data initial values are values just after executing "Page F Data Initialization" and "Page F Data Initialization". They are different from the values after executing all adjustments.

Note 3: In some cases, data have been input to the page F addresses (32 to 39). This has no relation to the adjustments.

Note 4: No mark: CCB-1244700/12447000

- 1 : CCB-1244700/12447000
- 2 : CCB-1244700
- 3 : CCB-1244700/12447000

Address	Adjustment data	
	Initial value	Setting value
00	BC (BA) CCB-040	BC (BA) CCB-040
01	BA (CC)	BA (CC)
02	CC	BA
03	CC (CB)	CC (CB)
04	BD	
05	BD	
06	BD	
07	BD	
08	BD	
09	BD	
0A	BD	
0B	BD	
0C	BD	
0D	BD	
0E	BD	
0F	BD	
10	BD	BD
11	BD	
12	BD	
13	BD	
14	BD	
15	BD	
16	BD	
17	BD	
18	BD	
19	BD	
1A	BD	
1B	BD	
1C	BD	BD
1D	BD	BD
1E	BD	
1F	BD	
20	BD (7F)	BD (7F)
21	BD (7F)	BD (7F)
22	BD	BD
23	BD	BD
24	BD	BD
25	BD (BD)	BD (BD)
26	BD	BD
27	BD	BD
28	BD	BD
29	BD	BD

Table 1-4-B (2)

Address	Adjustment data	
	Initial value	Memo column
2A	0C (2C)	0C (2C)
2B	58 (50)	58 (50)
2C	FF	FF
2D	06 ((04))	06 ((04))
2E	17 (16)	17 (16)
2F	22 (27) 《29》	22 (27) 《29》
30	08	08
31	00	00
32	50 (47) 《48》	50 (47) 《48》
33	68	68
34	00 (02)	00 (02)
35	30 (50)	30 (50)
36	02	02
37	00	00
38	76	76
39	6A	6A
3A	80	80
3B	20	20
3C	F0	F0
3D	03 (02)	03 (02)
3E	00	
3F	00	
40	00	
41	00	
42	00	
43	00	
44	00	
45	00	00
46	00	
47	00	
48	00	
49	00	
4A	00	
4B	00	
4C	00	
4D	00	
4E	00	00
4F	20	20
50	05 (32)	05 (32)
51	02	02
52	66	66
53	18	18

Table 7-1-2 (2).

Address	Adjustment data	
	Initial value	Memo column
54	66 (6B)	66 (6B)
55	9F	9F
56	66	66
57	66 (6C)	66 (6C)
58	59 (5C)	59 (5C)
59	83	83
5A	67	67
5B	5C	5C
5C	5C	5C
5D	4A	4A
5E	1E (20)	1E (20)
5F	5C	5C
60	3A (3C)	3A (3C)
61	33	33
62	0C	0C
63	26	26
64	04	04
65	02	02
66	00	00
67	00	00
68	00	00
69	00	00
6A	00	00
6B	00	00
6C	00	00
6D	00	00
6E	00	00
6F	34	34
70	10	10
71	26	26
72	0F	0F
73	0F	0F
74	00	00
75	23	23
76	1B	1B
77	E0	E0
78	A0	A0
79	30	30
7A	10	10
7B	50	50
7C	58	58
7D	88	88

Table 7-1-2 (3).

Address	Adjustment table	
	Initial value	Memory address
1A	00 (00)	00 (00)
1B	00 (00)	00 (00)
2C	00	00
2D	00 (00)	00 (00)
3E	00 (00)	00 (00)
3F	00 (00) (00)	00 (00) (00)
40	00	00
41	00	00
42	00 (00) (00)	00 (00) (00)
43	00	00
44	00 (00)	00 (00)
45	00 (00)	00 (00)
46	00	00
47	00	00
48	00	00
49	00	00
4A	00	00
4B	00	00
4C	00	00
4D	00	00
4E	00	00
4F	00	00
50	00	00
51	00	00
52	00	00
53	00	00
54	00	00
55	00	00
56	00	00
57	00	00
58	00	00
59	00	00
5A	00	00
5B	00	00
5C	00	00
5D	00	00
5E	00	00
5F	00	00
60	00	00
61	00	00
62	00	00
63	00	00
64	00	00
65	00	00
66	00	00
67	00	00
68	00	00
69	00	00
6A	00	00
6B	00	00
6C	00	00
6D	00	00
6E	00	00
6F	00	00
70	00 (00)	00 (00)
71	00	00
72	00	00
73	00	00

Table 7-1-4 (5)

Address	Adjustment table	
	Initial value	Memory address
74	00 (00)	00 (00)
75	00	00
76	00	00
77	00 (00)	00 (00)
78	00 (00)	00 (00)
79	00	00
7A	00	00
7B	00	00
7C	00	00
7D	00	00
7E	00	00
7F	00	00
80	00 (00)	00 (00)
81	00	00
82	00	00
83	00	00
84	00	00
85	00	00
86	00	00
87	00	00
88	00	00
89	00	00
8A	00	00
8B	00	00
8C	00	00
8D	00	00
8E	00	00
8F	00	00
90	00	00
91	00	00
92	00	00
93	00	00
94	00	00
95	00	00
96	00	00
97	00	00
98	00	00
99	00	00
9A	00	00
9B	00	00
9C	00	00
9D	00	00

Table 7-1-4 (6)

Address	Adjustment data	
	Initial value	Memo column
7E	66	66
7F	46	46
80	8F	8F
81	13	13
82	30	30
83	60	60
84	70	70
85	80	80
86	A0	A0
87	C0	C0
88	70	70
89	78	78
8A	80	80
8B	90	90
8C	A0	A0
8D	40	40
8E	FF	FF
8F	00	00
90	00 <11>	00 <11>
91	77	77
92	00	00
93	FB	FB
94	02	02
95	32	32
96	6B	6B
97	8D	8D
98	A1	A1
99	30	30
9A	30	30
9B	21	21
9C	72	72
9D	00	00
9E	00	00
9F	00	00
A0	00	00
A1	00	00
A2	00	00
A3	02	02
A4	80	80
A5	00	00
A6	80	80
A7	00	00

Table 7-1-2 (4).

Address	Adjustment data	
	Initial value	Memo column
A8	00	00
A9	80	80
AA	00	00
AB	00	00
AC	02	02
AD	44	44
AE	3D	3D
AF	1B (25)	1B (25)
B0	3D	3D
B1	1B (25)	1B (25)
B2	A4 (A2)	A4 (A2)
B3	4B	4B
B4	00	00
B5	20	20
B6	00	00
B7	05	05
B8	00	00
B9	20	20
BA	00	00
BB	70 (6E)	70 (6E)
BC	35 (32)	35 (32)
BD	54	54
BE		
BF		
C0 to EF		
F0		
F1		
F2		
F3		
F4		
F5		
F6		
F7		
F8		
F9		
FA		
FB		
FC		
FD		
FE		
FF		

Table 7-1-2 (5).

Address	Adjustment data	
	Initial value	Memory reference
7E	4E	4E
7F	4E	4E
80	4F	4F
81	1E	1E
82	3D	3D
83	8D	8D
84	7D	7D
85	8D	8D
86	4E	4E
87	0E	0E
88	7E	7E
89	7E	7E
8A	9E	9E
8B	4E	4E
8C	4E	4E
8D	4E	4E
8E	4F	4F
8F	8D	8D
90	0E	0E
91	0E (11)	0E (11)
92	7F	7F
93	9E	9E
94	7E	7E
95	8E	8E
96	3E	3E
97	8E	8E
98	8E	8E
99	8E	8E
9A	4E	4E
9B	3E	3E
9C	7E	7E
9D	8E	8E
9E	8E	8E
9F	8E	8E
AA	8E	8E
AB	8E	8E
AC	8E	8E
AD	8E	8E
AE	8E	8E
AF	8E	8E

Table 7-1-8 (6)

Address	Adjustment data	
	Initial value	Memory reference
AE	8E	8E
AF	8E	8E
AA	8E	8E
AB	8E	8E
AC	8E	8E
AD	4E	4E
AE	3E	3E
AF	0E (22)	0E (22)
BA	8E	8E
BB	0E (24)	0E (24)
BC	4E (A2)	4E (A2)
BD	8E	8E
BE	8E	8E
BF	3E	3E
C0	8E	8E
C1	3E	3E
C2	0E	0E
C3	0E	0E
C4	3E	3E
C5	7E (8D)	7E (8D)
CC	0E (25)	0E (25)
CD	4E	4E
CE		
CF		
CF to DF		
FE		
FF		
FD		
FC		
FB		
FA		
F9		
F8		
F7		
F6		
F5		
F4		
F3		
F2		
F1		
FF		

Table 7-1-9 (6)

1-1-6. Data Processing

The calculation of the DDS display and the adjusting remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Table 7-1-3. indicates the hexadecimal notation-the decimal notation calculation table.

Hexadecimal notation-Decimal notation

The lower digits of the hexadecimal notation The upper digits of the hexadecimal notation																
	0	1	2	3	4	5	6	7	8	9	A (<i>A</i>)	B (<i>b</i>)	C (<i>c</i>)	D (<i>d</i>)	E (<i>E</i>)	F (<i>F</i>)
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
5	80	80	82	83	84	85	86	87	88	89	90	91	92	93	94	95
6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
A (<i>A</i>)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
① → B (<i>b</i>)	176	177	178	179	180	180	182	183	184	185	186	187	188	189	190	191
C (<i>c</i>)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
D (<i>d</i>)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
E (<i>E</i>)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
F (<i>F</i>)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

Note: () indicate the adjusting remote control unit display.

(Example) In the case that the DDS display and the adjusting remote control unit display are BD (*b d*).

As the upper digit of the hexadecimal notation is B (*b*), and the lower digit is D (*d*), the intersection "189" of the ① and ② in the above table is the decimal notation to be calculated.

Table 7-1-3.

1-1-4. Data Presentation

The calculation of the COE display and the adjusting means (correction display data (functional relative) are required for obtaining the adjustment data of zero adjustment means. In this case, after converting the functional relative to decimal values, calculate and convert the result to functional relative, and use it as the adjustment data. Table 1-1-5, indicates the functional relative-to decimal values calculation table.

functional relative-to decimal values table

The lower digits of the functional relative The upper digits of the functional relative	<div style="text-align: center;"> $\frac{1}{1000}$ </div>															
	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
A (H)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
B (h)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
C (x)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
D (d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
E (j)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
F (f)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

Notes: () indicate the adjusting means round-off display.

(Example) In the case that the COE display and the adjusting means round-off display are 00 (0.0%),

the lower digit of the functional relative is 0 (0.0%). And the lower digit of 0 (0.0%), for conversion "100" of the 0 and 0 is the alternative value functional relative value calculation.

Table 1-1-5.

Using the PROGRAM AE Function

You can select from four PROGRAM AE (Auto Exposure) modes to suit your shooting situation. When you use PROGRAM AE, you can get a Portrait effect (the subject is in focus and the background is out of focus), capture high-speed action or night views.

Selecting the Best Mode

Select the best mode by using the following examples.



Portrait mode

- A still subject such as a person or flower
- Subject behind an obstacle such as a net
- Zooming in on a subject in telephoto

Sports mode

- Outdoor sports scenes such as football, tennis, golf or skiing
- A landscape in a moving car

High-speed shutter mode


- A golf swing or a tennis match in fine weather with the ball captured clearly
- Playing back certain scenes with high-speed movements in clear, sharp picture

Twilight mode

- Recording night views neon signs or fireworks

Using the PROGRAM AE Function

Press PROGRAM AE repeatedly so that the desired mode indicator appears inside the viewfinder.



Note on shutter speed

The shutter speed in each PROGRAM AE mode is as follows:

Portrait mode – between 1/60 to 1/2000

Sports mode – between 1/60 to 1/500

High-speed shutter mode – 1/4000

Twilight mode – 1/60

Normal mode – 1/60

Fade-in and Fade-out

You can fade in or fade out to give your recording a professional appearance. When fading in, the picture will gradually appear from black or mosaic. The sound will also gradually increase. When fading out, the picture will gradually fade to black or mosaic. The sound will also decrease.

When Fading in [a]



(1) During the camcorder is in Standby mode, press FADER. The fade indicator starts flashing.

(2) Press START/STOP to start recording. The fade indicator stops flashing.

When Fading out [b]

(1) During recording, press FADER. The fade indicator starts flashing.

(2) Press START/STOP to stop recording. The fade indicator stops flashing and recording stops.



To Cancel the Fade-in/out Function

Before pressing START/STOP, press FADER once or twice until the fade indicator disappears.

When the date/time indicator is displayed

The date/time does not fade in nor fade out.

Using the PROCESSIONAL Function

For recording and playback of the PROCESSIONAL function, use the following steps:

Recording the PROCESSIONAL Function

Press the **PROCESSIONAL** button to begin recording.



1. Press the **PROCESSIONAL** button to begin recording.
2. Press the **PROCESSIONAL** button to stop recording.
3. Press the **PROCESSIONAL** button to stop recording.
4. Press the **PROCESSIONAL** button to stop recording.
5. Press the **PROCESSIONAL** button to stop recording.

Press the **PROCESSIONAL** button to stop recording.



Press the **PROCESSIONAL** button to stop recording.

Using the PROCESSIONAL Function

For recording and playback of the PROCESSIONAL function, use the following steps:

Recording the PROCESSIONAL Function

Press the **PROCESSIONAL** button to begin recording.


Press the **PROCESSIONAL** button to stop recording.



Press the **PROCESSIONAL** button to stop recording.


Releasing the Steady Shot Function

— For the model with the STEADY SHOT switch (CCD-TR82 only)

When you shoot, the  indicator appears in the viewfinder. This indicates that the Steady Shot function is working and the camcorder compensates for camera-shake.

You can release the Steady Shot function. Do not use the Steady Shot function such as when shooting stationary object with a tripod.

Set STEADY SHOT to OFF.







To Activate the Steady Shot Function Again


Set STEADY SHOT to ON.

Notes on the Steady Shot Function

- The Steady Shot function will not correct excessive camera-shake.
- When you switch the STEADY SHOT, the exposure may vary.

Changing the Mode Settings

You can change the mode settings in the menu system to further enjoy the features and functions.
(1) Press MENU to display the menu in the viewfinder. **(2)** Press  or  to select the desired item, then press EXECUTE. **(3)** Press  or  to set the desired mode, then press EXECUTE. If you want to change the other modes, repeat steps 2 and 3. **(4)** Press MENU to erase the menu display.



Note on BACK UP

When BACK UP indicator appears on the menu display, the settings of items are retained even when the battery is removed, as long as the lithium battery is in place.

Selecting the Mode Setting of Each Item

Common Items in CAMERA and PLAYER Modes

COMMANDER <ON/OFF>

- Select ON when using the supplied Remote Commander for the camcorder.
- Select OFF when not using the Remote Commander for the camcorder.

BEEP <ON/OFF>

- Select ON so that beeps sound when you start/stop recording.
- Select OFF when you do not want to hear the beep sound.

Rebuilding the Shady Spot Pattern

After the results with the **SHADY SPOT** sensor (with 1000 samples)

show that the Shady Spot sensor is the suitable for calibration the Shady Spot sensor working and the calibration equipment from external.

The new sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input

for external input is input




To activate the Shady Spot sensor, input

to 1000 (1000 is 100)

After the Shady Spot sensor
The new sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input

Changing the Mode Settings

The sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input



After the Shady Spot sensor

The new sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input

to 1000 (1000 is 100)

After the Shady Spot sensor

The new sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input

to 1000 (1000 is 100)

After the Shady Spot sensor

The new sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input

to 1000 (1000 is 100)

After the Shady Spot sensor

The new sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input

to 1000 (1000 is 100)

After the Shady Spot sensor

The new sensor is Shady Spot sensor. It is use the Shady Spot sensor and external using external input data is input

Changing the Mode Settings

Items in CAMERA mode

WIND <ON/OFF>

- For stereo models (CCD-TR72/TR80)
- Select ON to reduce wind noise when recording in strong wind.
- Normally select OFF.

AUTO DATE <ON/OFF>

- Select ON to record the date of recording automatically (AUTO DATE feature: p.12).
- Select OFF otherwise.

CLOCK SET

Select this item when you need to reset the clock (p.31).

AREA

Select the area number of the time zone where you will use the camcorder when you use the world clock (p.27).

D.S.T. <ON/OFF>

- Select ON to set the clock to Daylight Saving Time.
- Select OFF to set to standard time.

Items in PLAYER mode

EDIT <ON/OFF>

- Select ON to minimize the picture deterioration when editing.
- Normally select OFF.

HIFI SOUND <STEREO/1/2>


— For stereo models (CCD-TR72/TR80)

- Normally select STEREO.
- Select 1 or 2 to play back a dual soundtrack tape.

Using the World Clock


Reset the clock according to the local time zone by setting AREA and D.S.T. modes in the menu system. First find the area number in the "Time zone chart" on page 28.

- (1) Turn STANDBY up. (2) Press MENU to display the menu. (3) Select AREA item (p.26). Press \uparrow or \downarrow to select the area number where you will use the camcorder. Press EXECUTE. (4) Select D.S.T. item (p.26). Press \uparrow or \downarrow to select ON for Daylight Saving Time or OFF for standard time. Press EXECUTE.



Changing the Mode Settings

The area name appears in the viewfinder when using the world clock. The \star indicator appears in the viewfinder when setting to Daylight Saving Time.



To Check the Date

Press DATE. To turn off the date indicator, press DATE again.

To restore to Your Home Area Time

Reset the AREA mode in the menu system to your home area number.

See the next page for the Time Zone Chart. 27

Challenging 30-Second 10-Step

Steps to Complete

1. Prepare the 30-second video.
2. Prepare the 10-step video.
3. Prepare the 10-step video.
4. Prepare the 10-step video.
5. Prepare the 10-step video.
6. Prepare the 10-step video.
7. Prepare the 10-step video.
8. Prepare the 10-step video.
9. Prepare the 10-step video.
10. Prepare the 10-step video.

Notes

Notes for the 10-step video are provided in the 10-step video.

Notes

1. Prepare the 10-step video.
2. Prepare the 10-step video.
3. Prepare the 10-step video.
4. Prepare the 10-step video.
5. Prepare the 10-step video.
6. Prepare the 10-step video.
7. Prepare the 10-step video.
8. Prepare the 10-step video.
9. Prepare the 10-step video.
10. Prepare the 10-step video.

Notes for the 10-step video are provided in the 10-step video.



Notes for the 10-step video are provided in the 10-step video.



Notes

1. Prepare the 10-step video.
2. Prepare the 10-step video.
3. Prepare the 10-step video.
4. Prepare the 10-step video.
5. Prepare the 10-step video.
6. Prepare the 10-step video.
7. Prepare the 10-step video.
8. Prepare the 10-step video.
9. Prepare the 10-step video.
10. Prepare the 10-step video.

Notes for the 10-step video are provided in the 10-step video.

Figure 10.14: A 3D model of a house

From: [Figure 10.14](#)



Table 10.1: A 3D model of a house	
Room	Area (sq. ft.)
Living Room	1200
Kitchen	800
Bathroom	600
Bedroom	1000
Hallway	400
Garage	1500
Porch	200
Backyard	3000
Front Yard	2000
Driveway	1000
Screened Porch	400
Master Bedroom	1200
Guest Bedroom	800
Guest Bathroom	600
Breakfast Room	400
Living Room	1200
Kitchen	800
Bathroom	600
Bedroom	1000
Hallway	400
Garage	1500
Porch	200
Backyard	3000
Front Yard	2000
Driveway	1000
Screened Porch	400
Master Bedroom	1200
Guest Bedroom	800
Guest Bathroom	600
Breakfast Room	400

Table 10.1: A 3D model of a house

Figure 10.15: A 3D model of a house

From: [Figure 10.15](#)

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house




Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house


Figure 10.15: A 3D model of a house

Figure 10.15: A 3D model of a house

Additional Information


Changing the Lithium Battery In the Camcorder

Your camcorder is supplied with the lithium battery installed. The lithium battery lasts for about 1 year under normal operation. When the battery becomes weak or dead, the indicator flashes in the viewfinder for about 5 seconds when you set the POWER switch to CAM/ERA. In this case, **replace the battery with the Sony CR2025 or Duracell DL-2025 lithium battery. Use of another battery may present a risk of fire or explosion.**



Note on Lithium Battery

Note that the lithium battery has a positive (+) and a negative (-) terminals as illustrated. **Be sure to install the lithium battery so that terminals on the battery match the terminals on the camcorder.**




WARNING

The battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

Caution
Keep the lithium battery out of the reach of children. Should the battery be swallowed, consult a doctor immediately.

Changing the Lithium Battery


When replacing the lithium battery, keep the battery pack or other power source attached. Otherwise, you will need to reset the date, time and the other items with BACK UP indicator in the menu system. (1) Open the lid of the lithium battery compartment. (2) Push the battery down once and pull it out from the holder. (3) Install the lithium battery with the positive (+) side facing out. Close the lid of the battery compartment.



Resetting the Date and Time

Reset the date and time in the menu system.

(1) Press MENU to display the menu. (2) Press \uparrow or \downarrow to select CLOCK SET item (p.26). Press EXECUTE. (3) Press \uparrow or \downarrow to select the area number where you will use the camcorder. Press EXECUTE. (4) Select D.S.T. ON for Daylight Saving Time or OFF for standard time. Press EXECUTE. (5) Set year, month, day, time, minute by pressing \uparrow , \downarrow and EXECUTE. Note that when you keep \uparrow and \downarrow pressed, the digits advance faster. (6) Press MENU to erase the menu display.



Time Zones and Area Numbers and Names
"S.T.", in the following table stands for Standard Time.

Time Zones	Area Name	Area Number
Hawaii S.T.	HAWAI	15
Alaska S.T.	ANCHRGE	16
Pacific S.T./West Canada	US.PST	17
Mountain S.T.	US.MST	18
Central S.T.	US.CST	19
Eastern S.T./East Canada	US.EST	20

Diffusion Worksheet

Changing the Leftmost Battery in the Commander

The commander is made up of a circuit battery board. The battery board has three 1.5V AA batteries connected in series. When the commander is turned on, the battery board provides power to the commander's microcontroller. The commander's microcontroller is a small computer chip that controls the commander's actions. The commander's microcontroller is connected to the commander's sensors and actuators. The commander's sensors are used to detect the commander's environment. The commander's actuators are used to move the commander's body.



How to Change Battery

1. Turn the commander off. The commander's microcontroller will not work if the commander is turned on. The commander's microcontroller will not work if the commander is turned on. The commander's microcontroller will not work if the commander is turned on.



How to Change Battery

2. Turn the commander off. The commander's microcontroller will not work if the commander is turned on. The commander's microcontroller will not work if the commander is turned on. The commander's microcontroller will not work if the commander is turned on.


How to Change Battery

3. Turn the commander off. The commander's microcontroller will not work if the commander is turned on. The commander's microcontroller will not work if the commander is turned on. The commander's microcontroller will not work if the commander is turned on.



Resetting the Data and Time

The commander is made up of a circuit battery board. The battery board has three 1.5V AA batteries connected in series. When the commander is turned on, the battery board provides power to the commander's microcontroller. The commander's microcontroller is a small computer chip that controls the commander's actions. The commander's microcontroller is connected to the commander's sensors and actuators. The commander's sensors are used to detect the commander's environment. The commander's actuators are used to move the commander's body.



How to Reset Data and Time

Step	Action	Time
1	Turn the commander off.	10 seconds
2	Press the reset button.	10 seconds
3	Turn the commander on.	10 seconds
4	Press the reset button.	10 seconds
5	Turn the commander on.	10 seconds

Resetting the Date and Time

To Correct the Date and Time Setting

Repeat steps 2 to 5.

To Check the Date and Time

Press DATE to display the date indicator in the viewfinder. Press TIME to display the time indicator. When you press the same button again, the indicator goes out.

To Reset to Standard Time

Change D.S.T. mode setting in the menu system (p.25).

The year indicator changes as follows:

1994 ↔ 1995 ↔ 2024

Note on the time indicator

The internal clock of the camcorder operates on a 12-hour cycle. 12:00:00 AM stands for midnight. 12:00:00 PM stands for noon.

Playback Modes

The playback mode is selected automatically according to the recording system (SP/LP mode) in which the tape was recorded.

Notes on AFM Hi-Fi stereo — For stereo models (CCD-TR72/TR80)

When you play back the tape, the sound is in monaural if:

- You record the tape using this camcorder, then play it back on an AFM Hi-Fi monaural video recorder/player.
- You record the tape on an AFM Hi-Fi monaural video recorder, then play it back on this camcorder.

LP (long play) mode

When you play back a tape recorded in LP mode, the LP indicator lights up in the viewfinder. This camcorder cannot record tape in LP mode.

Foreign 8 mm video

You cannot play software recorded on a different TV color system. Because the TV color systems differ from country to country, you may not be able to play back foreign pre-recorded software. Refer to page 39 to check the TV color system of foreign countries.

Tips for Using the Battery Pack

This section shows you how you can get the most out of your battery pack.

Preparing the Battery Pack

Always Carry Additional Batteries





Have sufficient battery pack power to do 2 to 3 times as much recording as you have planned.

Battery Life is Shorter in Cold Environment

Battery efficiency is decreased and the battery will be used up more quickly if you are recording in cold environment.

To Save Battery Power

Turn the **STANDBY** switch on the camcorder down when not recording to save battery power. [a] A smooth transition between scenes can be made even if recording is stopped and started again. While positioning the subject, selecting an angle, or looking through the viewfinder lens, the lens moves automatically and the battery is used. The battery is also used when a tape is inserted or removed.



Good Energy Use, Cycles, and Items

To Control the Rate and Time Spelling

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

Handbook Methods

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

Top Ten Diving Dive Diving Pool

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

To Control the Rate and Time

Tips for Using the Battery Pack

When to Replace the Battery Pack

While you are using your camcorder, the remaining battery indicator decreases gradually as battery power is used up.



When the remaining battery indicator reaches the lowest point, the **i** indicator appears and starts flashing in the viewfinder. [b] on page 33.

When the **C** indicator in the viewfinder changes from slow flashing to rapid flashing while you are recording, slide the POWER switch to OFF on the camcorder and replace the battery pack. Leave the tape in the camcorder to obtain smooth transition between scenes after the battery pack is replaced.

Note on the remaining battery indicator

The remaining battery indicator of the camcorder may indicate a different remaining capacity from that of the battery pack with the remaining battery indicator (not supplied). The indicator of the battery pack is more accurate.

Notes on the Rechargeable Battery Pack

The Battery Heats Up

During charging or recording, the battery pack heats up. This is caused by energy that has been generated and a chemical change that has occurred inside the battery pack. This is not cause for concern.

Battery Care

- Remove the battery pack from the camcorder after using the battery pack, and keep it in a cool place. When the battery pack is attached to the camcorder, a small amount of current flows to the camcorder even if the POWER switch is set to OFF, which shortens battery life.
- The battery pack is always discharging even when it is not in use after charging. Therefore, you should charge the battery right before using the camcorder.

How to Use the Switch on the Battery Pack

This switch is provided so that you can mark the charged battery. Set the switch to the "no mark" position when charging is completed. Set the switch to the "red mark" position when the battery is used up (or in whichever direction you want to remind yourself). [c] on page 33.

The Life of the Battery Pack

The battery pack can be fully charged and discharged about 500 times under normal temperatures. If the **C** indicator flashes rapidly just after turning on the camcorder with a fully charged battery pack, the battery pack should be replaced with a new fully charged one.

Charging Temperature

You should charge batteries at temperatures from 50°F to 86°F (from 10°C to 30°C). Lower temperatures require a longer charging time.

Notes on Charging

A Brand-new Battery

A brand-new battery pack is not charged. Before using the battery pack, charge it completely.

Before Recharging a Used Battery Pack

- Make sure to use up the battery before recharging.
- If recording is completed before the **C** indicator appears in the viewfinder, you should remove the tape, slide the POWER switch to CAMERA, turn STANDBY up, and leave the camcorder until the battery indicator flashes rapidly.
- When you use the AC-S10 power adaptor, you can use the discharging function.
- **Charging the usable battery causes a lowering of battery capacity. Battery capacity can be recovered if you fully discharge and charge the battery again.**

After Long Storage

Recharge the battery pack after a long period of storage. If the battery pack is charged fully but not used for a long time (about 1 year), it becomes discharged. Charge it again, but in this case the battery life will be shorter than normal. After several charging and discharging cycles, the battery life will recover its original capacity.

Notes on the Terminals

If the terminals (metal parts on the back) are not clean, the battery duration will be shortened.

When the terminals are not clean or when the battery pack has not been used for a long time, repeat installing and removing the battery pack. This improves the contact condition. Also, wipe the + and - terminals with a soft cloth or paper.

Be Sure to Observe the Following

- **To prevent an accident caused by a short circuit, do not allow metal objects such as a necklace to touch the battery terminals. Carry the battery pack attaching to the terminal cover. [d] on page 33.**
- Keep the battery pack away from fire.
- Keep the battery pack dry.
- Do not open nor convert the battery pack.
- Do not expose the battery pack to any mechanical shock.

1000

1000

[illegible]

the 1990s, the number of people in the United States who are 65 years of age or older is projected to increase from 20 million to 35 million, and the number of people 75 years of age or older is projected to increase from 10 million to 15 million (U.S. Census Bureau, 1996). The number of people 85 years of age or older is projected to increase from 2 million to 4 million (U.S. Census Bureau, 1996). The number of people 90 years of age or older is projected to increase from 500,000 to 1 million (U.S. Census Bureau, 1996). The number of people 95 years of age or older is projected to increase from 100,000 to 200,000 (U.S. Census Bureau, 1996). The number of people 100 years of age or older is projected to increase from 10,000 to 20,000 (U.S. Census Bureau, 1996).

100

1. *Chlorophyll a* and *Chlorophyll b* were determined by the method of Lichtenthaler and Sponholz (1980). The total chlorophyll content was determined by the method of Arar and Cook (1980). The carotenoid content was determined by the method of Lichtenthaler and Sponholz (1980). The total carotenoid content was determined by the method of Lichtenthaler and Sponholz (1980). The total carotenoid content was determined by the method of Lichtenthaler and Sponholz (1980).

1. The first step in the process is to identify the problem or issue that needs to be addressed. This involves gathering information and understanding the context of the problem.

THE

the 1990s, the number of people in the United States who are 65 years of age or older is projected to increase from 20 million to 35 million, and the number of people 75 years of age or older is projected to increase from 10 million to 15 million (U.S. Census Bureau, 1996). The number of people 85 years of age or older is projected to increase from 2 million to 4 million (U.S. Census Bureau, 1996). The number of people 90 years of age or older is projected to increase from 500,000 to 1 million (U.S. Census Bureau, 1996). The number of people 95 years of age or older is projected to increase from 100,000 to 200,000 (U.S. Census Bureau, 1996). The number of people 100 years of age or older is projected to increase from 10,000 to 20,000 (U.S. Census Bureau, 1996).

1000

100

the 1990s, the number of people in the United States who are 65 years of age or older is projected to increase from 20 million to 35 million, and the number of people 75 years of age or older is projected to increase from 10 million to 15 million (U.S. Census Bureau, 1996). The number of people 85 years of age or older is projected to increase from 2 million to 4 million (U.S. Census Bureau, 1996). The number of people 90 years of age or older is projected to increase from 500,000 to 1 million (U.S. Census Bureau, 1996). The number of people 95 years of age or older is projected to increase from 100,000 to 200,000 (U.S. Census Bureau, 1996). The number of people 100 years of age or older is projected to increase from 10,000 to 20,000 (U.S. Census Bureau, 1996).

1. The first step in the process is to identify the problem or issue that needs to be addressed. This involves gathering information and understanding the context of the problem.

Figure 1. The effect of the concentration of the *Agrobacterium* suspension on the transformation efficiency of *Agrobacterium* strains.

THE UNIVERSITY OF CHICAGO PRESS

1000



100


Maintenance Information and Precautions


Moisture Condensation

If the camcorder is brought directly from a cold place to a warm place, moisture may condense inside the camcorder, on the surface of the tape, or on the lens. If this happens, the tape may stick to the head drum and be damaged or the camcorder may not operate correctly. To prevent possible damage under these circumstances, the camcorder is furnished with moisture sensors. However, take the following precautions.


Inside the Camcorder

When  and  indicators flash in the viewfinder, moisture has condensed inside the camcorder. If this happens, none of the functions except cassette ejection will work. Eject the cassette turn off the camcorder, and leave it with the cassette compartment open for about 1 hour.


If the  indicator does not light up when you turn on the power, you can use the camcorder again.



On the Surface of the Tape

If there is moisture on the surface of the tape, when you insert cassette and press a tape transport button (▶ PLAY, etc.), the  indicator flashes in the viewfinder. If this happens, none of the functions except cassette ejection will work.

Eject the cassette and leave it for about 1 hour.

If the  indicator does not light up when you insert the cassette and press a tape transport button, you can use the camcorder again.

On the Lens

No indicator will appear, but the picture becomes dim. Turn off the power and do not use the camcorder for about 1 hour.

How to Prevent Moisture Condensation

When bringing the camcorder from a cold place to a warm place, put the camcorder in a plastic bag and allow it to adapt to room conditions over a period of time.

- (1) Be sure to tightly seal the plastic bag containing the camcorder.
- (2) Remove the bag when the air temperature inside it has reached the temperature surrounding it (after about one hour).

Video Head Cleaning

To ensure clear pictures, clean the video heads periodically. When playback pictures are "noisy" or hardly visible, the video heads may be contaminated.



[a] → [b]

[a] Slight contamination

[b] Critical contamination
If this happens, clean the video heads with the Sony V8-25CLH cleaning cassette (not supplied). After checking the picture, if it is still "noisy", repeat the cleaning. (Do not repeat cleaning more than 5 times.)

Caution


Do not use a commercially available wet-type cleaning cassette. It may damage the video heads.

Note

If the V8-25CLH cleaning cassette is not available in your area, consult your nearest Sony dealer.

Removing Dust from inside the Viewfinder

- (1) While sliding the viewfinder release knob to the left, flip open the viewfinder. (2) Clean the surface with a commercially available blower.



Migratory Information and Protection

Information: The *Convention on the Conservation of Migratory Species of Wild Animals* (CMS) is an international agreement that provides a framework for the conservation and protection of migratory species. It was adopted in 1979 and entered into force in 1983. The Convention is the only international agreement that specifically addresses the conservation of migratory species. It provides a framework for the conservation and protection of migratory species, including the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries.

Protection: The CMS provides a framework for the conservation and protection of migratory species. It includes a list of 113 species of wild animals that are considered to be migratory. The Convention also provides for the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries. The CMS is a key international agreement for the conservation and protection of migratory species.



Key Features of the CMS: The CMS is a key international agreement for the conservation and protection of migratory species. It includes a list of 113 species of wild animals that are considered to be migratory. The Convention also provides for the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries. The CMS is a key international agreement for the conservation and protection of migratory species.

Key Features of the CMS: The CMS is a key international agreement for the conservation and protection of migratory species. It includes a list of 113 species of wild animals that are considered to be migratory. The Convention also provides for the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries. The CMS is a key international agreement for the conservation and protection of migratory species.


Information: The *Convention on the Conservation of Migratory Species of Wild Animals* (CMS) is an international agreement that provides a framework for the conservation and protection of migratory species. It was adopted in 1979 and entered into force in 1983. The Convention is the only international agreement that specifically addresses the conservation of migratory species. It provides a framework for the conservation and protection of migratory species, including the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries.



Protection: The CMS provides a framework for the conservation and protection of migratory species. It includes a list of 113 species of wild animals that are considered to be migratory. The Convention also provides for the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries. The CMS is a key international agreement for the conservation and protection of migratory species.

Key Features of the CMS: The CMS is a key international agreement for the conservation and protection of migratory species. It includes a list of 113 species of wild animals that are considered to be migratory. The Convention also provides for the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries. The CMS is a key international agreement for the conservation and protection of migratory species.

Key Features of the CMS: The CMS is a key international agreement for the conservation and protection of migratory species. It includes a list of 113 species of wild animals that are considered to be migratory. The Convention also provides for the establishment of protected areas, the implementation of conservation measures, and the exchange of information and cooperation between countries. The CMS is a key international agreement for the conservation and protection of migratory species.



Maintenance Information and Precautions

Precautions

Camcorder Operation

- Operate the camcorder using 6.0 V (battery pack), or 7.5 V (AC power adaptor).
- For DC or AC operation, use only the accessories recommended in this manual.
- Should any solid object or liquid fall into the casing, unplug the camcorder and have it checked by your nearest Sony dealer before operating it any further.
- Avoid rough handling or mechanical shock. Be particularly careful of the lens.
- Keep the POWER switch set to OFF when not using the camera.
- Do not wrap up the camcorder and operate it since heat may build up internally.
- Keep the camcorder away from strong magnetic fields or mechanical vibration.

On Handling Tapes

Do not insert anything into the small holes on the rear of the cassette. These holes are used to sense the type, thickness of tape, or if the tab is out or in.

Camcorder Care

- When the camcorder is not to be used for a long time, disconnect the power source and remove the tape. Periodically turn on the power, operate the camera and player sections and play back a tape for about 3 minutes.
- Clean the lens with a soft brush to remove dust. If there are fingerprints on the lens, remove them with a soft cloth.
- Clean the camcorder body with a soft dry cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent which may damage the finish.

AC Power Adaptor

Charging

- Use only for the specified battery pack. This unit cannot be used to charge an NIP-500 series battery pack.
- Attach the battery pack firmly.
- Charge the battery pack on a flat surface without vibration.


Others

- The model for USA or Canada: One blade of the plug is wider than the other for the purpose of safety and will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- Unplug the unit from the wall (mains) outlet when not in use for a long time. To disconnect the cord (mains lead), pull it out by the plug. Never pull the cord itself.
- Do not operate the unit with a damaged cord or if the unit has been dropped or damaged.
- Do not bend the AC power cord forcibly, or put a heavy object on it. This will damage the cord and may cause a fire or an electrical shock.
- Be sure that nothing metallic comes into contact with the metal parts of the connecting plate. If this happens, a short may occur and the unit may be damaged.
- Always keep the metal contacts clean.
- Do not disassemble the unit.
- Do not apply mechanical shock or drop the unit.
- While the unit is in use, particularly during charging, keep it away from AM receivers and video equipment because it will disturb AM reception and video operation.
- The unit becomes warm while in use. This is normal.
- Do not place the unit in locations that are:
 - Extremely hot or cold
 - Dusty or dirty
 - Very humid
 - Vibrating

If any difficulty should arise, unplug the unit and contact your nearest Sony dealer.

Identifying the Parts

The illustrations in this section are of CCD-TR82.



- | | |
|-------------------------------------|--------------------------------------|
| 1 COUNTER RESET button (p.12) | 5 Viewfinder release knob (p.14, 37) |
| 2 TIME button (p.20) | 6 Battery mounting surface (p.8) |
| 3 DATE button (p.20) | 7 START/STOP button (p.11) |
| 4 BATT (battery) release knob (p.8) | 8 STANDBY switch (p.10, 11) |
| | 9 Menu operation buttons (p.25, 31) |

Identifying the Parts

The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a small amount of fluid to reduce friction as the heart beats.


The heart is made of muscle and is about the size of a fist. It is divided into two main parts: the right heart and the left heart. The right heart receives blood from the body and pumps it to the lungs. The left heart receives blood from the lungs and pumps it to the rest of the body. The heart is connected to the rest of the body by a network of blood vessels called the circulatory system. The heart is also surrounded by a protective layer called the pericardium, which contains a small amount of fluid to reduce friction as the heart beats.

The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a small amount of fluid to reduce friction as the heart beats.

The heart is made of muscle and is about the size of a fist. It is divided into two main parts: the right heart and the left heart. The right heart receives blood from the body and pumps it to the lungs. The left heart receives blood from the lungs and pumps it to the rest of the body. The heart is connected to the rest of the body by a network of blood vessels called the circulatory system. The heart is also surrounded by a protective layer called the pericardium, which contains a small amount of fluid to reduce friction as the heart beats.


The heart is a muscular organ that pumps blood throughout the body. It is located in the chest cavity, between the lungs. The heart is divided into four chambers: the right atrium, right ventricle, left atrium, and left ventricle. The right side of the heart receives deoxygenated blood from the body, and the left side pumps oxygenated blood to the rest of the body. The heart is surrounded by a double-walled sac called the pericardium, which contains a small amount of fluid to reduce friction as the heart beats.

Identifying the Parts



- A. Superior vena cava (A, V, C)
- B. Right atrium (A, R, T)
- C. Right ventricle (A, R, T)
- D. Inferior vena cava (A, V, C)
- E. Left atrium (A, L, T)
- F. Left ventricle (A, L, T)
- G. Aorta (A, O, R, T)
- H. Pulmonary artery (A, R, T)
- I. Pulmonary vein (A, L, T)
- J. Coronary artery (A, R, T)



Identifying the Parts



- 10 Hook for shoulder strap (below)
- 11 LANC \square control jack
Connect the LANC \square connecting cable to a wired remote control such as an editing controller. In this case, set the COMMANDER mode to OFF in the menu system (p.25).
 \square stands for Local Application Control Bus system. The \square control jack is used for controlling the tape transport of video equipment and peripherals connected to it. This jack has the same function as the connectors indicated as CONTROL L or REMOTE.
- 12 \square (earphone) jack (CCD-TR42/TR70/TR82) (p.15)
- 13 \square (headphones) jack (CCD-TR72/TR80) (p.15)
- 14 Hook for shoulder strap (below)
- 15 Lithium battery compartment (p.30)
- 16 Cassette compartment lid (p.9)
- 17 MIC (microphone) jack
- 18 VIDEO jack (p.16)
- 19 RFU DC OUT (RFU adaptor DC out) jack (p.16)
- 20 AUDIO jack (p.16)
- 21 Jack cover
- 22 Grip strap (p.14)
- 23 Tripod receptacle (p.14)
Attach a tripod (not supplied) here. When attaching a non-Sony tripod, make sure that the length of the camera mounting screw is shorter than 9/32 inches (6.5 mm). Otherwise, the screw might damage the inner part of the camcorder.

Attaching the shoulder strap

Attach the supplied shoulder strap to the hooks for the shoulder strap (10, 13).




- 23 Tape transport buttons (p.17)
 \blacksquare STOP
 \triangleleft REW (rewind)
 \triangleright PLAY (playback)
 \triangleright FF (fast forward)
 \blacksquare PAUSE
These buttons will function in PLAYER mode.
- 24 EJECT button (p.9)
- 25 EDIT/SEARCH button (p.15)
- 26 Built-in microphone
- 27 Camera recording/battery lamp
- 28 Remote sensor (p.49)
- 29 Lens cover
- 30 POWER switch (p.10, 11)
- 31 STEADY SHOT switch (p.24)
- 32 FADER button (p.23)
- 33 POWER ZOOM button (p.13)
- 34 Eyecup (p.14)
- 35 Viewfinder adjustment ring (p.10)
- 36 Viewfinder (p.10, 14)
- 37 BACK LIGHT button (p.21)
- 38 PROGRAM AE button (p.22)

Worksheet for the 7th class



1. Fuel tank
2. Fuel filter
3. Fuel pump
4. Fuel injector
5. Spark plug
6. Piston
7. Crankshaft
8. Camshaft
9. Valve
10. Timing belt

Identify the components of the engine and label them with the numbers 1-10.




1. Fuel tank
2. Fuel filter
3. Fuel pump
4. Fuel injector
5. Spark plug
6. Piston
7. Crankshaft
8. Camshaft
9. Valve
10. Timing belt

Identify the components of the engine and label them with the numbers 1-10.

Identifying the Parts

Remote Commander

The buttons that have the same name on the Remote Commander and on the camcorder function identically.



1 Transmitter (p.49)

Point toward the remote sensor to control the camcorder after turning on the POWER switch on the camcorder.

2 Tape transport buttons (p.17)

The zooming speed is unchangeable on the Remote Commander.

3 DISPLAY button (p.18)

4 Size AA (R6) battery holder


5 START/STOP button

6 Power zoom button

The zooming speed is unchangeable on the Remote Commander.

Preparing the Remote Commander

To use the Remote Commander, you must insert two size AA (R6) batteries. Use the supplied size AA (R6) batteries. (1) Remove the battery cover from the Remote Commander. (2) Insert both of the size AA (R6) batteries with correct polarity. (3) Put the battery cover back onto the Remote Commander.



Note on battery life


The batteries for the Remote Commander last about 6 months under normal operation. When the batteries become weak or dead, the Remote Commander does not work.

To avoid damage from possible battery leakage

Remove the batteries when you will not use the Remote Commander for a long time.


Using the Remote Commander

Make sure that the COMMANDER mode is set to ON in the menu system (p.25).



Remote Control Direction

Aim the Remote Commander to the remote sensor within the range as shown below.



Notes on the Remote Commander

- Keep the remote sensor away from strong light sources such as direct sunlight or illumination. Otherwise, the remote control may not be effective.
- Be sure that there is no obstacle between the remote sensor and the Remote Commander.
- This camcorder works at commander mode VTR 2. The commander modes (1, 2, and 3) are used to distinguish this camcorder from other Sony VCRs to avoid remote control misoperation. If you use another Sony VCR at commander mode VTR 2, we recommend you change the commander mode or cover the remote sensor of the VCR with black paper.

Preparing the Network Components

The steps in this section prepare the network components and verify network function.



1. Power on the component.
2. Verify the component is ready to use.
3. Verify the component is ready to use.
4. Verify the component is ready to use.

Preparing the Network Component

To use the Network Component, you must perform the following tasks. The tasks are listed in the order in which they should be performed.



When you perform the tasks in this section, you must perform the tasks in the order in which they are listed. The tasks are listed in the order in which they should be performed.

Preparing the Network Component

To use the Network Component, you must perform the tasks in the order in which they are listed. The tasks are listed in the order in which they should be performed.

Using the Network Component

The steps in this section prepare the network components and verify network function.



Preparing the Network Component


To use the Network Component, you must perform the tasks in the order in which they are listed. The tasks are listed in the order in which they should be performed.




Preparing the Network Component

To use the Network Component, you must perform the tasks in the order in which they are listed. The tasks are listed in the order in which they should be performed.

2-14. CIRCUIT BOARDS LOCATION







ZB-2 (BUZZER/LITHIUM BATTERY) PRINTED WIRING BOARD

— Ref. No. ZB-2 BOARD: 4000 series —

ZB-2 BOARD



- For printed wiring board of ZB-2 board.
- : Pattern from the side which enables seeing.
- : Pattern of the rear side.




ZB-2 (BUZZER/LITHIUM BATTERY) SCHEMATIC DIAGRAM

— Ref. No. ZB-2 BOARD: 4000 series —

ZB-2 BOARD

•CONTROL SWITCH BLOCK (CK)
Is replaced as a block, so that there
SCHEMATIC DIAGRAM
PRINTED WIRING BOARD
is omitted.



09


ZB-2 (LITHIUM BATTERY) WIRING DIAGRAM

1 2 3 4 5 6 7

— See Fig. 100-100-000-000 —



ZB-2 BOARD

CONTROL SWITCH BLADE 200
Is connected to a fuse, on that blade
ELECTRIC CIRCUIT
POWER TO CONTROL BLADE
Is not used.




— Ref. No. VF-65 BOARD: 8000 series —

VF-65 BOARD (CONDUCTOR SIDE)




- **For printed wiring boards.**
- VF-65 board is a four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

VF-65 BOARD (COMPONENT SIDE)




VF-65 BOARD (CONDUCTOR SIDE)




- For printed wiring boards.
- VF-65 board has a top layer of gold plating. However, the pattern of layer 2 is not shown/indicated in the diagram.

5-1-10. MECHANISM CHASSIS ASSEMBLY (1)




Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
801	A-7049-501-A	DRUM ASSY, UPPER (DGR-78-R) (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		810	3-945-702-01	ROLLER, LS	
801	A-7049-567-A	DRUM ASSY, UPPER (DGR-92-R) (TR400/TR750)		811	X-3941-262-1	ROLLER ASSY, TG2	
802	3-945-822-01	SPRING, LEAF, TG7 ARM		812	3-956-651-01	SPRING, COMPRESSION	
803	A-7040-305-A	ARM BLOCK ASSY, TG7		813	3-686-493-01	SCREW (M2X5), P1	
804	3-947-503-01	SCREW (M1.4X2.5)		814	1-568-323-11	CONNECTOR, BOARD TO BOARD 4P	
805	X-3941-255-1	PLATE (T) ASSY, SIDE		M901	A-7048-564-A	DRUM ASSY (DGH-78A-R) (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
806	3-945-735-01	ARM, HC CONVERSION		M901	A-7048-633-A	DRUM ASSY (DGH-92A-R) (TR400/TR750)	
807	3-713-786-71	SCREW (M2X5)		M902	8-835-477-12	MOTOR, DC SCE-0101A (CAPSTAN)	
808	3-945-691-01	PLATE (S), SIDE		M903	A-7040-304-A	MOTOR BLOCK ASSY, LM (LOADING)	
809	3-945-701-01	ARM, LS					

5-1-11. MECHANISM CHASSIS ASSEMBLY (2)



Note: 875 (FP-575 flexible board) is part that exchange the only leading part of 874 (FP-442 flexible board).

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
851	3-945-734-01	ARM, HC DRIVING		865	A-7040-303-A	CHASSIS ASSY, MECHANICAL	
852	3-728-103-11	SCREW (M1.4X1.6), SPECIAL HEAD		866	3-947-503-01	SCREW (M1.4X2.5)	
853	X-3941-259-1	ARM ASSY, PINCH PRESS		867	3-945-722-01	RETAINER, GEAR	
854	3-726-829-01	WASHER, STOPPER		868	X-3941-257-1	ARM ASSY, FF	
855	3-945-730-01	SLEEVE, EJECT		869	3-945-697-01	GEAR (B), L	
856	3-945-706-01	LEVER, EJECT		870	3-945-700-01	GEAR (A), L	
857	3-945-729-01	SPRING, COMPRESSION		871	1-641-643-12	FP-444 FLEXIBLE BOARD	
858	X-3941-256-1	GEAR ASSY, CHANGE		872	1-691-254-13	CONNECTOR, TRANSLATION 10P	
859	3-944-539-01	BELT, RELAY		873	3-945-756-01	SCREW (M1.4X3)	
860	3-945-695-01	PULLEY, RELAY		874	1-641-639-13	FP-442 FLEXIBLE BOARD	
861	X-3941-260-1	SLIDER ASSY, M		875	1-645-271-11	FP-575 FLEXIBLE BOARD	
862	3-945-696-02	CAM		S001	1-572-986-11	SWITCH, ROTARY (ENCODER)	
863	X-3941-258-1	ARM ASSY, GL		S005	1-570-771-21	SWITCH (C DOWN)	
864	3-713-786-71	SCREW (M2X5)					



Note: 010 (PP-010) Module (base) is part that
mounts the only (main) part of 010
(PP-010) Module (base).

Ref. No.	Part No.	Description
001	001-001	001-001
002	002-001	002-001
003	003-001	003-001
004	004-001	004-001
005	005-001	005-001
006	006-001	006-001
007	007-001	007-001
008	008-001	008-001
009	009-001	009-001
010	010-001	010-001
011	011-001	011-001
012	012-001	012-001
013	013-001	013-001
014	014-001	014-001
015	015-001	015-001
016	016-001	016-001
017	017-001	017-001
018	018-001	018-001
019	019-001	019-001
020	020-001	020-001
021	021-001	021-001
022	022-001	022-001
023	023-001	023-001
024	024-001	024-001
025	025-001	025-001
026	026-001	026-001
027	027-001	027-001

Ref. No.	Part No.	Description	Ref. No.
028	028-001	028-001	028
029	029-001	029-001	029
030	030-001	030-001	030
031	031-001	031-001	031
032	032-001	032-001	032
033	033-001	033-001	033
034	034-001	034-001	034
035	035-001	035-001	035
036	036-001	036-001	036
037	037-001	037-001	037
038	038-001	038-001	038
039	039-001	039-001	039
040	040-001	040-001	040
041	041-001	041-001	041
042	042-001	042-001	042
043	043-001	043-001	043
044	044-001	044-001	044
045	045-001	045-001	045
046	046-001	046-001	046
047	047-001	047-001	047
048	048-001	048-001	048
049	049-001	049-001	049
050	050-001	050-001	050

AU-165

5-2. ELECTRICAL PARTS LIST

NOTE:

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms
METAL: Metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F : nonflammable
- Hardware (# mark) list is given in the last of this parts list.
- Canadian model is abbreviated as CND.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u: μ , for example:
uA...: μ A..., uPA...: μ PA...,
uPB...: μ PB..., uPC...: μ PC...,
uPD...: μ PD...
- CAPACITORS
uF: μ F
- COILS
uH: μ H

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-7063-958-A	AU-165 BOARD, COMPLETE ***** (TR72/TR80/TR400/TR430/TR750) (Ref. No. 10, 000 Series)		C1345	1-162-967-11	CERAMIC CHIP 0.0033uF 10%	50V
		< CAPACITOR >		C1346	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1302	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V	C1347	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1303	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	C1348	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1304	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	C1349	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1305	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	C1350	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1306	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1352	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1307	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1353	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1308	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	C1355	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C1309	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1356	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C1310	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1357	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C1311	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1358	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1312	1-126-205-11	ELECT CHIP 47uF 20%	6.3V	C1359	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1313	1-162-953-11	CERAMIC CHIP 100PF 5%	50V	C1360	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1314	1-162-953-11	CERAMIC CHIP 100PF 5%	50V	C1361	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1315	1-126-209-11	ELECT 100uF 20%	4V	C1362	1-162-969-11	CERAMIC CHIP 0.0068uF 10%	25V
C1316	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V	C1363	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1318	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	C1364	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C1319	1-162-953-11	CERAMIC CHIP 100PF 5%	50V			< CONNECTOR >	
C1321	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	CN1301	1-691-490-21	CONNECTOR, FFC/FPC 11P	
C1323	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	* CN1302	1-691-933-11	CONNECTOR, BOARD TO BOARD 34P	
C1326	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V			< DIODE >	
C1327	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	D1302	8-719-404-46	DIODE MA110	
C1328	1-135-091-21	TANTAL. CHIP 1uF 20%	16V	D1303	8-719-045-87	DIODE MA4Z082WA-TX	
C1329	1-135-091-21	TANTAL. CHIP 1uF 20%	16V	D1304	8-719-045-87	DIODE MA4Z082WA-TX	
C1330	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V			< FILTER >	
C1331	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V	FL402	1-236-838-21	FILTER, BAND PASS (1.7MHz)	
C1332	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V	FL1302	1-236-837-21	FILTER, BAND PASS (1.5MHz)	
C1333	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V			< IC >	
C1334	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	IC402	8-759-234-77	IC TC4S66F	
C1335	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	IC1301	8-759-159-94	IC LA7491W-TBM	
C1336	1-135-148-21	TANTAL. CHIP 1.5uF 20%	10V			< TRANSISTOR >	
C1337	1-135-148-21	TANTAL. CHIP 1.5uF 20%	10V	Q1301	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1338	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1302	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1339	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1303	8-729-403-35	TRANSISTOR UN5113	
C1340	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1305	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1341	1-162-966-11	CERAMIC CHIP 0.0022uF 10%	50V	Q1306	8-729-230-63	TRANSISTOR 2SC4116-YG	
C1343	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V				
C1344	1-164-346-11	CERAMIC CHIP 1uF 16V					

1115

W **M** **T** **F**

100

The newspaper should be made
it is noted for its work in
social forestry.

Les enseignants choisissent par exemple d'insérer des articles dans le manuel.

When making plans for retirement, consider your future needs. The best way to ensure you have enough money to live on is to start saving early and consistently.

- [illegible]

- **Notes:** $\text{methyl}^{12}\text{C}^{17}\text{O}^+$ can not be used as a proxy for CO because of the isotopic fractionation required for kinetic reactions. Other alcohols should be interpreted with caution when inferring from them.
- **Notes:** **CONCENTRATIONS**
 in each row is a 10^{-17} example
 CH_3OH , H_2CO , CH_3CN , CH_3CCH_3
 $\text{CH}_3\text{CH}_2\text{OH}$, $\text{CH}_3\text{CH}_2\text{CH}_3$, $\text{CH}_3\text{CH}_2\text{CN}$
 $\text{CH}_3\text{CH}_2\text{CH}_2\text{OH}$
- **CONCENTRATIONS**
 10^{17} , 10^{17}
- **CHOLIN**
 $\text{CH}_3\text{CH}_2\text{CH}_2\text{OH}$

[illegible]

AU-169**DD-60****DD-66**

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C426	1-162-957-11	CERAMIC CHIP	220PF 5% 50V	R416	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
C428	1-128-006-11	ELECT CHIP	4.7uF 20% 25V	R417	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
C429	1-128-013-11	ELECT CHIP	1uF 20% 50V	R418	1-216-851-11	METAL CHIP	330K 5% 1/16W
C430	1-128-004-11	ELECT CHIP	10uF 20% 16V	R419	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
C431	1-162-969-11	CERAMIC CHIP	0.0068uF 10% 25V	R420	1-216-832-11	METAL CHIP	8.2K 5% 1/16W
C432	1-164-674-11	CERAMIC CHIP	1800PF 5% 16V	R421	1-216-864-11	METAL CHIP	0 5% 1/16W
C433	1-164-346-11	CERAMIC CHIP	1uF 10% 16V	R423	1-216-839-11	METAL CHIP	33K 5% 1/16W
C434	1-128-003-11	ELECT CHIP	22uF 20% 4V	R424	1-216-833-11	METAL CHIP	10K 5% 1/16W
C435	1-162-966-11	CERAMIC CHIP	0.0022uF 10% 50V	R425	1-216-810-11	METAL CHIP	120 5% 1/16W
C436	1-126-205-11	ELECT CHIP	47uF 20% 6.3V	R427	1-216-817-11	METAL CHIP	470 5% 1/16W
C437	1-126-205-11	ELECT CHIP	47uF 20% 6.3V	R428	1-216-833-11	METAL CHIP	10K 5% 1/16W
C438	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	R429	1-216-827-11	METAL CHIP	3.3K 5% 1/16W
C439	1-128-004-11	ELECT CHIP	10uF 20% 16V	R430	1-216-841-11	METAL CHIP	47K 5% 1/16W
C440	1-162-974-11	CERAMIC CHIP	0.01uF 50V	R431	1-216-823-11	METAL CHIP	1.5K 5% 1/16W
C441	1-126-205-11	ELECT CHIP	47uF 20% 6.3V	R432	1-216-825-11	METAL CHIP	2.2K 5% 1/16W
C442	1-162-974-11	CERAMIC CHIP	0.01uF 50V	R433	1-216-817-11	METAL CHIP	470 5% 1/16W
< CONNECTOR >				R434	1-216-821-11	METAL CHIP	1K 5% 1/16W
CN401	1-691-516-11	CONNECTOR, BOARD TO BOARD 24P		R435	1-216-836-11	METAL CHIP	18K 5% 1/16W
CN402	1-691-487-21	CONNECTOR, FFC/FPC 8P		R436	1-216-837-11	METAL CHIP	22K 5% 1/16W
< DIODE >				*****			
D402	8-719-045-87	DIODE MA4Z082WA-TX		*	A-7063-960-A	DD-60 BOARD, COMPLETE	
< IC >				*****			
IC401	8-759-823-19	IC CXA1488RR		(TR72/TR400/TR430/TR750)			
< COIL >				*	A-7066-009-A	DD-60 BOARD, COMPLETE (TR80)	
< TRANSISTOR >				*****			
Q402	8-729-230-63	TRANSISTOR 2SC4116		*	A-7063-954-A	DD-66 BOARD, COMPLETE (TR42/TR82/TR550)	
Q403	8-729-230-63	TRANSISTOR 2SC4116		*****			
Q404	8-729-402-81	TRANSISTOR XN4501		*	A-7066-006-A	DD-66 BOARD, COMPLETE (TR70)	
Q405	8-729-402-42	TRANSISTOR UN5213		*****			
Q406	8-729-403-35	TRANSISTOR UN5113		(Ref. No. 9,000 Series)			
< RESISTOR >				< CAPACITOR >			
R401	1-216-849-11	METAL CHIP	220K 5% 1/16W	C901	1-163-989-11	CERAMIC CHIP	0.033uF 10% 25V
R402	1-216-864-11	METAL CHIP	0 5% 1/16W	C902	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V
R403	1-216-859-11	METAL GLAZE	1.5M 5% 1/16W	C903	1-163-121-00	CERAMIC CHIP	150PF 5% 50V
R404	1-216-851-11	METAL CHIP	330K 5% 1/16W	C904	1-163-121-00	CERAMIC CHIP	150PF 5% 50V
R407	1-216-837-11	METAL CHIP	22K 5% 1/16W	C906	1-164-245-11	CERAMIC CHIP	0.015uF 10% 25V
R409	1-216-833-11	METAL CHIP	10K 5% 1/16W	C907	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R410	1-216-840-11	METAL CHIP	39K 5% 1/16W	C908	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R411	1-216-833-11	METAL CHIP	10K 5% 1/16W	C909	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R412	1-216-821-11	METAL CHIP	1K 5% 1/16W	C910	1-162-964-11	CERAMIC CHIP	0.001uF 10% 50V
R413	1-216-835-11	METAL CHIP	15K 5% 1/16W	C911	1-162-963-11	CERAMIC CHIP	680PF 10% 50V
R415	1-216-849-11	METAL CHIP	220K 5% 1/16W	C912	1-128-530-11	ELECT CHIP	33uF 20% 10V
				C913	1-128-004-11	ELECT CHIP	10uF 20% 16V
				C914	1-128-004-11	ELECT CHIP	10uF 20% 16V
				C915	1-165-178-11	CERAMIC CHIP	6.8uF 16V
				C916	1-128-004-11	ELECT CHIP	10uF 20% 16V
				C917	1-165-178-11	CERAMIC CHIP	6.8uF 16V

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C918	1-165-178-11	CERAMIC CHIP 6. 8uF	16V	J903	1-568-027-11	JACK, SMALL TYPE 1P (EARPHONE) (TR42/TR70/TR82/TR550)	
C920	1-165-178-11	CERAMIC CHIP 6. 8uF	16V	J903	1-569-809-11	JACK (SMALL TYPE) (HEADPHONES) (TR72/TR80/TR400/TR430/TR750)	
C921	1-165-178-11	CERAMIC CHIP 6. 8uF	16V			< COIL >	
C923	1-165-178-11	CERAMIC CHIP 6. 8uF	16V	L901	1-424-653-11	COIL, CHOKE 10uH	
C924	1-165-178-11	CERAMIC CHIP 6. 8uF	16V	L902	1-424-653-11	COIL, CHOKE 10uH	
C925	1-164-337-11	CERAMIC CHIP 2. 2uF	16V	L903	1-424-653-11	COIL, CHOKE 10uH	
C926	1-164-337-11	CERAMIC CHIP 2. 2uF	16V	L904	1-409-556-11	COIL, CHOKE 47uH	
C927	1-165-178-11	CERAMIC CHIP 6. 8uF	16V	L905	1-424-674-11	COIL, CHOKE 22uH	
C928	1-165-178-11	CERAMIC CHIP 6. 8uF	16V	L906	1-409-556-11	COIL, CHOKE 47uH	
C929	1-135-216-11	TANTALUM CHIP 10uF 20%	10V	L907	1-424-674-11	COIL, CHOKE 22uH	
C930	1-107-418-11	ELECT CHIP 10uF 20%	35V	L908	1-424-674-11	COIL, CHOKE 22uH	
C931	1-128-004-11	ELECT CHIP 10uF 20%	16V	L909	1-412-056-11	INDUCTOR CHIP 4. 7uH	
C932	1-128-004-11	ELECT CHIP 10uF 20%	16V	L910	1-412-056-11	INDUCTOR CHIP 4. 7uH	
C934	1-128-004-11	ELECT CHIP 10uF 20%	16V	L911	1-412-056-11	INDUCTOR CHIP 4. 7uH	
C935	1-128-004-11	ELECT CHIP 10uF 20%	16V	L912	1-412-056-11	INDUCTOR CHIP 4. 7uH	
C936	1-128-004-11	ELECT CHIP 10uF 20%	16V	L913	1-412-056-11	INDUCTOR CHIP 4. 7uH	
C937	1-128-004-11	ELECT CHIP 10uF 20%	16V	L914	1-412-064-11	INDUCTOR CHIP 100uH	
C938	1-128-004-11	ELECT CHIP 10uF 20%	16V	L915	1-412-064-11	INDUCTOR CHIP 100uH	
C939	1-163-023-00	CERAMIC CHIP 0. 015uF 5%	50V	L916	1-412-056-11	INDUCTOR CHIP 4. 7uH	
C940	1-163-023-00	CERAMIC CHIP 0. 015uF 5%	50V	L917	1-412-056-11	INDUCTOR CHIP 4. 7uH	
C941	1-163-019-00	CERAMIC CHIP 0. 0068uF 10%	50V			< TRANSISTOR >	
C942	1-163-009-11	CERAMIC CHIP 0. 001uF 10%	50V	Q900	8-729-421-90	TRANSISTOR XN4113 (TR70/TR80)	
C943	1-163-019-00	CERAMIC CHIP 0. 0068uF 10%	50V	Q901	8-729-420-12	TRANSISTOR XN4213	
C944	1-164-161-11	CERAMIC CHIP 0. 0022uF 10%	100V	Q902	8-729-804-41	TRANSISTOR 2SB1122	
C945	1-128-530-11	ELECT CHIP 33uF 20%	10V	Q903	8-729-823-82	TRANSISTOR FP101	
C950	1-128-004-11	ELECT CHIP 10uF 20%	16V	Q904	8-729-823-84	TRANSISTOR FP102	
		< CONNECTOR >		Q905	8-729-823-82	TRANSISTOR FP101	
CN901	1-695-324-11	CONNECTOR, BOARD TO BOARD 42P		Q906	8-729-823-82	TRANSISTOR FP101	
		< DIODE >		Q907	8-729-823-82	TRANSISTOR FP101	
D900	8-719-045-87	DIODE MA4Z082WA		Q908	8-729-420-12	TRANSISTOR XN4213 (TR70/TR80)	
D901	8-719-027-77	DIODE MA796		Q909	8-729-805-25	TRANSISTOR 2SB1121	
D902	8-719-045-87	DIODE MA4Z082WA (TR72/TR80/TR400/TR430/TR750)		Q910	8-729-429-32	TRANSISTOR UN9210-QRS (TR70/TR80)	
D909	8-719-404-49	DIODE MA111		Q911	8-729-402-42	TRANSISTOR UN5213	
D910	8-719-404-49	DIODE MA111		Q912	8-729-420-24	TRANSISTOR 2SB1218A	
		< FUSE >		Q914	8-729-402-42	TRANSISTOR UN5213	
△F450	1-576-213-11	FUSE, CHIP (1. 6A 125V)		Q915	8-729-402-42	TRANSISTOR UN5213	
△F451	1-576-213-11	FUSE, CHIP (1. 6A 125V)				< RESISTOR >	
△F452	1-576-213-11	FUSE, CHIP (1. 6A 125V)		R901	1-218-872-11	METAL CHIP 11K 0. 50% 1/16W	
		< IC >		R902	1-216-833-11	METAL CHIP 10K 5% 1/16W	
IC901	8-759-249-14	IC MB3799-02PFV-GBND-ER		R903	1-216-827-11	METAL CHIP 3. 3K 5% 1/16W	
		< JACK >		R904	1-216-827-11	METAL CHIP 3. 3K 5% 1/16W	
J901	1-537-281-41	TERMINAL BOARD (BATTERY)		R905	1-216-836-11	METAL CHIP 18K 5% 1/16W	
J902	1-565-276-21	JACK, ULTRA SMALL 1P (REMOTE)		R906	1-216-827-11	METAL CHIP 3. 3K 5% 1/16W	
				R907	1-216-035-00	METAL CHIP 270 5% 1/10W	
				R908	1-216-834-11	METAL CHIP 12K 5% 1/16W	
				R909	1-216-031-00	METAL CHIP 180 5% 1/10W	

The components identified by mark
△ or dotted line with mark △ are
critical for safety.
Replace only with part number
specified.

Les composants identifiés par une
marque △ sont critiques pour la
sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

FP-89 (CD)

Ref.No.	Part No.	Description				Remark	Ref.No.	Part No.	Description				Remark
R910	1-216-029-00	METAL CHIP	150	5%	1/10W		*	1-651-890-11	FP-49 FLEXIBLE BOARD ***** (TR82/TR400/TR550/TR750) (Ref. No. 3,000 Series)				
R911	1-216-029-00	METAL CHIP	150	5%	1/10W								
R912	1-216-029-00	METAL CHIP	150	5%	1/10W								
R913	1-216-041-00	METAL CHIP	470	5%	1/10W								
R915	1-216-864-11	METAL CHIP	0	5%	1/16W				< SENSOR >				
R918	1-216-819-11	METAL CHIP	680	5%	1/16W								
R919	1-216-836-11	METAL CHIP	18K	5%	1/16W		SE691	1-810-024-31	SENSOR, ANGULAR VELOCITY				
R920	1-216-841-11	METAL CHIP	47K	5%	1/16W		SE692	1-810-024-41	SENSOR, ANGULAR VELOCITY				
R921	1-412-052-21	INDUCTOR CHIP 1uH					*****						
R922	1-216-833-11	METAL CHIP	10K	5%	1/16W								
R923	1-412-052-21	INDUCTOR CHIP 1uH					*	A-7072-004-A	FP-89 (CD) BOARD, COMPLETE ***** (TR82/TR400/TR550/TR750)				
R924	1-412-979-21	INDUCTOR 1uH											
R925	1-216-825-11	METAL CHIP	2.2K	5%	1/16W								
R926	1-216-841-11	METAL CHIP	47K	5%	1/16W		*	A-7072-005-A	FP-89 (CD) BOARD, COMPLETE ***** (TR42/TR70/TR72/TR80/TR430) (Ref. No. 3,000 Series)				
R931	1-216-864-11	METAL CHIP	0	5%	1/16W								
R932	1-412-979-21	INDUCTOR 1uH											
R933	1-412-979-21	INDUCTOR 1uH (TR72/TR80/TR400/TR430/TR750)							< CAPACITOR >				
R934	1-216-864-11	METAL CHIP	0	5%	1/16W		C691	1-135-214-21	TANTAL. CHIP	4.7uF	20%	20V	
R936	1-412-979-21	INDUCTOR 1uH					C692	1-135-210-11	TANTALUM CHIP	4.7uF	20%	10V	
R937	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		C694	1-164-346-11	CERAMIC CHIP	1uF		16V	
R938	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		C695	1-164-156-11	CERAMIC CHIP	0.1uF		25V	
R939	1-216-864-11	METAL CHIP	0	5%	1/16W (TR70/TR80)		C696	1-104-908-11	TANTAL. CHIP	47uF	20%	4V	
R940	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)				< IC >				
R941	1-218-849-11	METAL CHIP	1.2K	0.50%	1/16W		IC691	A-7030-368-A	CCD BLOCK ASSY (AUTO) (054 SERVICE) (CCD IMAGER) (TR42/TR70/TR72/TR80/TR430)				
R942	1-216-864-11	METAL CHIP	0	5%	1/16W		IC691	A-7030-373-A	CCD BLOCK ASSY (AUTO) (059V SERVICE) (CCD IMAGER) (TR82/TR400/TR550/TR750)				
R943	1-216-864-11	METAL CHIP	0	5%	1/16W (TR70/TR80)				< COIL >				
R944	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)		L691	1-412-963-11	INDUCTOR 100uH				
R945	1-218-847-11	METAL CHIP	1K	0.50%	1/16W				< TRANSISTOR >				
R946	1-216-841-11	METAL CHIP	47K	5%	1/16W (TR70/TR80)		Q691	8-729-232-86	TRANSISTOR	2SK1875-BL/V			
R947	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (TR70/TR80)		Q692	8-729-117-73	TRANSISTOR	ZSC4178-F14			
R948	1-216-837-11	METAL CHIP	22K	5%	1/16W (TR70/TR80)				< RESISTOR >				
R949	1-216-841-11	METAL CHIP	47K	5%	1/16W (TR70/TR80)		R691	1-216-295-00	METAL CHIP	0	5%	1/10W	
		< TRANSFORMER >					R692	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	
T901	1-426-730-11	TRANSFORMER, CONVERTER					R693	1-216-839-11	METAL CHIP	33K	5%	1/16W (TR42/TR70/TR72/TR80/TR430)	
*****							R693	1-216-840-11	METAL CHIP	39K	5%	1/16W (TR82/TR400/TR550/TR750)	
							R694	1-216-819-11	METAL CHIP	680	5%	1/16W (TR42/TR70/TR72/TR80/TR430)	
							R694	1-216-820-11	METAL CHIP	820	5%	1/16W (TR82/TR400/TR550/TR750)	
							R695	1-216-845-11	METAL CHIP	100K	5%	1/16W (TR82/TR400/TR550/TR750)	

Be sure to read “Note on the CCD Imager replacement” on page 4-6 when changing the CCD imager.

Ref. No.	Part No.	Description	Quantity	Ref. No.	Part No.	Description	Quantity
850	1-03-08-01	WHL, CMT	80	8	1-03-08-11	ST-01 FLANGE BRG	1
851	1-03-08-01	WHL, CMT	80			*****	
852	1-03-08-01	WHL, CMT	80			CHG/THG/THG/THG/THG	
853	1-03-08-01	WHL, CMT	80			(Ref. No. 1, 10, 10, 10)	
854	1-03-08-01	WHL, CMT	80				
855	1-03-08-01	WHL, CMT	80				
856	1-03-08-01	WHL, CMT	80				
857	1-03-08-01	WHL, CMT	80				
858	1-03-08-01	WHL, CMT	80				
859	1-03-08-01	WHL, CMT	80				
860	1-03-08-01	WHL, CMT	80				
861	1-03-08-01	WHL, CMT	80				
862	1-03-08-01	WHL, CMT	80				
863	1-03-08-01	WHL, CMT	80				
864	1-03-08-01	WHL, CMT	80				
865	1-03-08-01	WHL, CMT	80				
866	1-03-08-01	WHL, CMT	80				
867	1-03-08-01	WHL, CMT	80				
868	1-03-08-01	WHL, CMT	80				
869	1-03-08-01	WHL, CMT	80				
870	1-03-08-01	WHL, CMT	80				
871	1-03-08-01	WHL, CMT	80				
872	1-03-08-01	WHL, CMT	80				
873	1-03-08-01	WHL, CMT	80				
874	1-03-08-01	WHL, CMT	80				
875	1-03-08-01	WHL, CMT	80				
876	1-03-08-01	WHL, CMT	80				
877	1-03-08-01	WHL, CMT	80				
878	1-03-08-01	WHL, CMT	80				
879	1-03-08-01	WHL, CMT	80				
880	1-03-08-01	WHL, CMT	80				
881	1-03-08-01	WHL, CMT	80				
882	1-03-08-01	WHL, CMT	80				
883	1-03-08-01	WHL, CMT	80				
884	1-03-08-01	WHL, CMT	80				
885	1-03-08-01	WHL, CMT	80				
886	1-03-08-01	WHL, CMT	80				
887	1-03-08-01	WHL, CMT	80				
888	1-03-08-01	WHL, CMT	80				
889	1-03-08-01	WHL, CMT	80				
890	1-03-08-01	WHL, CMT	80				
891	1-03-08-01	WHL, CMT	80				
892	1-03-08-01	WHL, CMT	80				
893	1-03-08-01	WHL, CMT	80				
894	1-03-08-01	WHL, CMT	80				
895	1-03-08-01	WHL, CMT	80				
896	1-03-08-01	WHL, CMT	80				
897	1-03-08-01	WHL, CMT	80				
898	1-03-08-01	WHL, CMT	80				
899	1-03-08-01	WHL, CMT	80				
900	1-03-08-01	WHL, CMT	80				
901	1-03-08-01	WHL, CMT	80				
902	1-03-08-01	WHL, CMT	80				
903	1-03-08-01	WHL, CMT	80				
904	1-03-08-01	WHL, CMT	80				
905	1-03-08-01	WHL, CMT	80				
906	1-03-08-01	WHL, CMT	80				
907	1-03-08-01	WHL, CMT	80				
908	1-03-08-01	WHL, CMT	80				
909	1-03-08-01	WHL, CMT	80				
910	1-03-08-01	WHL, CMT	80				
911	1-03-08-01	WHL, CMT	80				
912	1-03-08-01	WHL, CMT	80				
913	1-03-08-01	WHL, CMT	80				
914	1-03-08-01	WHL, CMT	80				
915	1-03-08-01	WHL, CMT	80				
916	1-03-08-01	WHL, CMT	80				
917	1-03-08-01	WHL, CMT	80				
918	1-03-08-01	WHL, CMT	80				
919	1-03-08-01	WHL, CMT	80				
920	1-03-08-01	WHL, CMT	80				
921	1-03-08-01	WHL, CMT	80				
922	1-03-08-01	WHL, CMT	80				
923	1-03-08-01	WHL, CMT	80				
924	1-03-08-01	WHL, CMT	80				
925	1-03-08-01	WHL, CMT	80				
926	1-03-08-01	WHL, CMT	80				
927	1-03-08-01	WHL, CMT	80				
928	1-03-08-01	WHL, CMT	80				
929	1-03-08-01	WHL, CMT	80				
930	1-03-08-01	WHL, CMT	80				
931	1-03-08-01	WHL, CMT	80				
932	1-03-08-01	WHL, CMT	80				
933	1-03-08-01	WHL, CMT	80				
934	1-03-08-01	WHL, CMT	80				
935	1-03-08-01	WHL, CMT	80				
936	1-03-08-01	WHL, CMT	80				
937	1-03-08-01	WHL, CMT	80				
938	1-03-08-01	WHL, CMT	80				
939	1-03-08-01	WHL, CMT	80				
940	1-03-08-01	WHL, CMT	80				
941	1-03-08-01	WHL, CMT	80				
942	1-03-08-01	WHL, CMT	80				
943	1-03-08-01	WHL, CMT	80				
944	1-03-08-01	WHL, CMT	80				
945	1-03-08-01	WHL, CMT	80				
946	1-03-08-01	WHL, CMT	80				
947	1-03-08-01	WHL, CMT	80				
948	1-03-08-01	WHL, CMT	80				
949	1-03-08-01	WHL, CMT	80				
950	1-03-08-01	WHL, CMT	80				
951	1-03-08-01	WHL, CMT	80				
952	1-03-08-01	WHL, CMT	80				
953	1-03-08-01	WHL, CMT	80				
954	1-03-08-01	WHL, CMT	80				
955	1-03-08-01	WHL, CMT	80				
956	1-03-08-01	WHL, CMT	80				
957	1-03-08-01	WHL, CMT	80				
958	1-03-08-01	WHL, CMT	80				
959	1-03-08-01	WHL, CMT	80				
960	1-03-08-01	WHL, CMT	80				
961	1-03-08-01	WHL, CMT	80				
962	1-03-08-01	WHL, CMT	80				
963	1-03-08-01	WHL, CMT	80				
964	1-03-08-01	WHL, CMT	80				
965	1-03-08-01	WHL, CMT	80				
966	1-03-08-01	WHL, CMT	80				
967	1-03-08-01	WHL, CMT	80				
968	1-03-08-01	WHL, CMT	80				
969	1-03-08-01	WHL, CMT	80				
970	1-03-08-01	WHL, CMT	80				
971	1-03-08-01	WHL, CMT	80				
972	1-03-08-01	WHL, CMT	80				
973	1-03-08-01	WHL, CMT	80				
974	1-03-08-01	WHL, CMT	80				
975	1-03-08-01	WHL, CMT	80				
976	1-03-08-01	WHL, CMT	80				
977	1-03-08-01	WHL, CMT	80				
978	1-03-08-01	WHL, CMT	80				
979	1-03-08-01	WHL, CMT	80				
980	1-03-08-01	WHL, CMT	80				
981	1-03-08-01	WHL, CMT	80				
982	1-03-08-01	WHL, CMT	80				
983	1-03-08-01	WHL, CMT	80				
984	1-03-08-01	WHL, CMT	80				
985	1-03-08-01	WHL, CMT	80				
986	1-03-08-01	WHL, CMT	80				
987	1-03-08-01	WHL, CMT	80				
988	1-03-08-01	WHL, CMT	80				
989	1-03-08-01	WHL, CMT	80				
990	1-03-08-01	WHL, CMT	80				
991	1-03-08-01	WHL, CMT	80				
992	1-03-08-01	WHL, CMT	80				
993	1-03-08-01	WHL, CMT	80				
994	1-03-08-01	WHL, CMT	80				
995	1-03-08-01	WHL, CMT	80				
996	1-03-08-01	WHL, CMT	80				
997	1-03-08-01	WHL, CMT	80				
998	1-03-08-01	WHL, CMT	80				
999	1-03-08-01	WHL, CMT	80				
1000	1-03-08-01	WHL, CMT	80				

Be sure to read "Notes on the CD-ROM" on page 4 of the accompanying CD-ROM.

Ref. No.	Part No.	Description	Remark
R695	1-216-849-11	METAL CHIP 220K 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	
R696	1-216-809-11	METAL CHIP 100 5% 1/16W	
R697	1-216-833-11	METAL CHIP 10K 5% 1/16W	

* A-7066-078-A HE-14 BOARD, COMPLETE (TR400/TR750)

(Ref. No. 20,000 Series)

< CAPACITOR >

C1101	1-162-917-11	CERAMIC CHIP 15PF 5% 50V	
C1102	1-162-918-11	CERAMIC CHIP 18PF 5% 50V	
C1103	1-162-917-11	CERAMIC CHIP 15PF 5% 50V	
C1104	1-162-918-11	CERAMIC CHIP 18PF 5% 50V	
C1106	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C1107	1-162-975-11	CERAMIC CHIP 24PF 5% 50V	
C1108	1-162-923-11	CERAMIC CHIP 47PF 5% 50V	
C1109	1-162-928-11	CERAMIC CHIP 120PF 5% 50V	
C1110	1-162-910-11	CERAMIC CHIP 5PF 0.25PF 50V	
C1111	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C1112	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1113	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
C1114	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1115	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1116	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1117	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1118	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1119	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C1121	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1122	1-164-218-11	CERAMIC CHIP 180PF 0.25PF 50V	
C1123	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
C1124	1-162-925-11	CERAMIC CHIP 68PF 5% 50V	
C1125	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1126	1-162-925-11	CERAMIC CHIP 68PF 5% 50V	
C1127	1-162-910-11	CERAMIC CHIP 5PF 0.25PF 50V	
C1128	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1129	1-162-925-11	CERAMIC CHIP 68PF 5% 50V	
C1130	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C1131	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C1132	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1133	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C1134	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C1135	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1136	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1137	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C1138	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C1140	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C1141	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C1142	1-164-392-11	CERAMIC CHIP 390PF 5% 50V	
C1143	1-162-912-11	CERAMIC CHIP 7PF 0.5PF 50V	

Ref. No.	Part No.	Description	Remark
C1144	1-162-918-11	CERAMIC CHIP 18PF 5% 50V	
C1146	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1150	1-162-913-11	CERAMIC CHIP 8PF 0.5PF 50V	
C1151	1-162-917-11	CERAMIC CHIP 15PF 5% 50V	
C1152	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	

C1155	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1156	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C1157	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1158	1-162-922-11	CERAMIC CHIP 39PF 5% 50V	
C1160	1-164-360-11	CERAMIC CHIP 0.1uF 16V	

C1161	1-164-218-11	CERAMIC CHIP 180PF 0.25PF 50V	
C1162	1-162-949-11	CERAMIC CHIP 47PF 5% 50V	
C1163	1-162-941-11	CERAMIC CHIP 10PF 0.5PF 50V	
C1164	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1165	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V	

C1166	1-162-957-11	CERAMIC CHIP 220PF 5% 50V	
C1167	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1168	1-162-959-11	CERAMIC CHIP 330PF 5% 50V	
C1169	1-164-155-11	CERAMIC CHIP 75PF 5% 50V	
C1171	1-162-974-11	CERAMIC CHIP 0.01uF 50V	

C1173	1-162-952-11	CERAMIC CHIP 82PF 5% 50V	
C1175	1-162-955-11	CERAMIC CHIP 150PF 5% 50V	
C1176	1-162-949-11	CERAMIC CHIP 47PF 5% 50V	
C1178	1-162-957-11	CERAMIC CHIP 220PF 5% 50V	
C1179	1-162-943-11	CERAMIC CHIP 15PF 5% 50V	

C1181	1-164-218-11	CERAMIC CHIP 180PF 0.25PF 50V	
C1182	1-162-955-11	CERAMIC CHIP 150PF 5% 50V	
C1183	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1184	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1185	1-164-149-11	CERAMIC CHIP 36PF 5% 50V	

C1188	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1189	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C1192	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C1193	1-164-218-11	CERAMIC CHIP 180PF 0.25PF 50V	

< CONNECTOR >

* CN1101 1-573-341-11 CONNECTOR, BOARD TO BOARD 26P

< DIODE >

D1101	8-719-404-49	DIODE MA111	
D1102	8-719-027-48	DIODE MA142WA	
D1103	8-719-027-48	DIODE MA142WA	
D1105	8-719-404-49	DIODE MA111	

< FILTER >

FL1101	1-236-775-11	FILTER, LOW PASS (DEM)	
FL1102	1-239-112-21	FILTER, LOW PASS (Y)	

< IC >

IC1101	8-752-058-02	IC CXA1509AR	
--------	--------------	--------------	--

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
IC1102	8-759-070-51	IC SN74HCU04ADB		Q1138	8-729-420-24	TRANSISTOR 2SB1218A	
		< COIL >				< RESISTOR >	
L1101	1-412-956-21	INDUCTOR 27uH		R1101	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1102	1-412-954-11	INDUCTOR 18uH		R1102	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1103	1-412-947-11	INDUCTOR 4.7uH		R1103	1-216-820-11	METAL CHIP 820 5%	1/16W
L1104	1-412-959-11	INDUCTOR 47uH		R1104	1-216-819-11	METAL CHIP 680 5%	1/16W
L1105	1-412-954-11	INDUCTOR 18uH		R1105	1-216-817-11	METAL CHIP 470 5%	1/16W
L1106	1-412-945-11	INDUCTOR 3.3uH		R1106	1-216-809-11	METAL CHIP 100 5%	1/16W
L1108	1-412-954-11	INDUCTOR 18uH		R1107	1-216-815-11	METAL CHIP 330 5%	1/16W
L1109	1-412-948-11	INDUCTOR 5.6uH		R1108	1-216-813-11	METAL CHIP 220 5%	1/16W
L1110	1-412-956-21	INDUCTOR 27uH		R1109	1-216-813-11	METAL CHIP 220 5%	1/16W
L1111	1-410-655-31	INDUCTOR CHIP 120uH		R1111	1-216-837-11	METAL CHIP 22K 5%	1/16W
L1112	1-412-058-11	INDUCTOR CHIP 10uH		R1112	1-216-837-11	METAL CHIP 22K 5%	1/16W
L1113	1-412-058-11	INDUCTOR CHIP 10uH		R1113	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1114	1-412-957-11	INDUCTOR 33uH		R1114	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1115	1-412-952-11	INDUCTOR 12uH		R1115	1-216-821-11	METAL CHIP 1K 5%	1/16W
L1116	1-412-948-11	INDUCTOR 5.6uH		R1116	1-216-833-11	METAL CHIP 10K 5%	1/16W
L1118	1-412-953-11	INDUCTOR 15uH		R1118	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
L1119	1-412-949-21	INDUCTOR 6.8uH		R1119	1-216-816-11	METAL CHIP 390 5%	1/16W
L1121	1-412-947-11	INDUCTOR 4.7uH		R1120	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
L1122	1-412-954-11	INDUCTOR 18uH		R1123	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
L1123	1-412-949-21	INDUCTOR 6.8uH		R1124	1-216-826-11	METAL CHIP 2.7K 5%	1/16W
L1124	1-412-960-21	INDUCTOR 56uH		R1125	1-216-840-11	METAL CHIP 39K 5%	1/16W
		< TRANSISTOR >		R1127	1-216-841-11	METAL CHIP 47K 5%	1/16W
Q1102	8-729-402-42	TRANSISTOR UN5213		R1128	1-216-833-11	METAL CHIP 10K 5%	1/16W
Q1103	8-729-012-50	TRANSISTOR 2SC4400		R1130	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1107	8-729-402-42	TRANSISTOR UN5213		R1131	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1110	8-729-120-28	TRANSISTOR 2SC1623		R1132	1-216-820-11	METAL CHIP 820 5%	1/16W
Q1111	8-729-420-24	TRANSISTOR 2SB1218A		R1134	1-216-820-11	METAL CHIP 820 5%	1/16W
Q1113	8-729-012-50	TRANSISTOR 2SC4400		R1135	1-216-814-11	METAL CHIP 270 5%	1/16W
Q1114	8-729-402-81	TRANSISTOR XN4501		R1136	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1115	8-729-012-50	TRANSISTOR 2SC4400		R1138	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1117	8-729-230-63	TRANSISTOR 2SC4116		R1139	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1118	8-729-230-63	TRANSISTOR 2SC4116		R1148	1-216-837-11	METAL CHIP 22K 5%	1/16W
Q1119	8-729-402-42	TRANSISTOR UN5213		R1149	1-216-838-11	METAL CHIP 27K 5%	1/16W
Q1120	8-729-403-35	TRANSISTOR UN5113		R1151	1-216-826-11	METAL CHIP 2.7K 5%	1/16W
Q1121	8-729-420-24	TRANSISTOR 2SB1218A		R1152	1-216-833-11	METAL CHIP 10K 5%	1/16W
Q1123	8-729-012-50	TRANSISTOR 2SC4400		R1153	1-216-818-11	METAL CHIP 560 5%	1/16W
Q1125	8-729-420-24	TRANSISTOR 2SB1218A		R1154	1-216-821-11	METAL CHIP 1K 5%	1/16W
Q1126	8-729-012-50	TRANSISTOR 2SC4400		R1155	1-216-817-11	METAL CHIP 470 5%	1/16W
Q1127	8-729-403-35	TRANSISTOR UN5113		R1156	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
Q1128	8-729-230-63	TRANSISTOR 2SC4116		R1157	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
Q1129	8-729-012-50	TRANSISTOR 2SC4400		R1158	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
Q1131	8-729-824-02	TRANSISTOR 2SA1838		R1159	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
Q1132	8-729-012-50	TRANSISTOR 2SC4400		R1160	1-216-820-11	METAL CHIP 820 5%	1/16W
Q1133	8-729-012-50	TRANSISTOR 2SC4400		R1161	1-216-819-11	METAL CHIP 680 5%	1/16W
Q1134	8-729-402-42	TRANSISTOR UN5213		R1162	1-216-845-11	METAL CHIP 100K 5%	1/16W
Q1137	8-729-230-63	TRANSISTOR 2SC4116		R1163	1-216-817-11	METAL CHIP 470 5%	1/16W
				R1164	1-216-829-11	METAL CHIP 4.7K 5%	1/16W

HE-14**LB-35****LS-33****MA-179**

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R1165	1-216-814-11	METAL CHIP	270 5% 1/16W	*	A-7056-012-A	LB-35 BOARD, COMPLETE (TR70/80)	
R1166	1-216-815-11	METAL CHIP	330 5% 1/16W			*****	
R1167	1-216-864-11	METAL CHIP	0 5% 1/16W			(Ref. No. 4,000 Series)	
						< CONNECTOR >	
R1168	1-216-826-11	METAL CHIP	2.7K 5% 1/16W				
R1169	1-216-836-11	METAL CHIP	18K 5% 1/16W				
R1170	1-216-839-11	METAL CHIP	33K 5% 1/16W	CN801	1-573-812-11	CONNECTOR, BOARD TO BOARD 12P	
R1171	1-216-842-11	METAL CHIP	56K 5% 1/16W			< DIODE >	
R1172	1-216-837-11	METAL CHIP	22K 5% 1/16W				
				D801	8-719-037-83	DIODE LN1371G-(TR)	
R1173	1-216-837-11	METAL CHIP	22K 5% 1/16W			*****	
R1174	1-216-813-11	METAL CHIP	220 5% 1/16W			LS-33 BOARD	
R1175	1-216-813-11	METAL CHIP	220 5% 1/16W			*****	
R1176	1-216-821-11	METAL CHIP	1K 5% 1/16W			< DIODE >	
R1177	1-216-814-11	METAL CHIP	270 5% 1/16W				
				D001	8-719-989-52	DIODE GL4600S	
R1178	1-216-828-11	METAL CHIP	3.9K 5% 1/16W			< HALL >	
R1179	1-216-833-11	METAL CHIP	10K 5% 1/16W				
R1180	1-216-864-11	METAL CHIP	0 5% 1/16W	H001	8-719-987-62	DIODE LT140SAZ	
R1182	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	H002	8-719-987-62	DIODE LT140SAZ	
R1183	1-216-811-11	METAL CHIP	150 5% 1/16W			< TRANSISTOR >	
R1184	1-216-819-11	METAL CHIP	680 5% 1/16W	Q001	8-729-012-46	TRANSISTOR PT4600FS	
R1186	1-216-817-11	METAL CHIP	470 5% 1/16W	Q002	8-729-012-46	TRANSISTOR PT4600FS	
R1187	1-216-815-11	METAL CHIP	330 5% 1/16W			< RESISTOR >	
R1188	1-216-820-11	METAL CHIP	820 5% 1/16W				
R1189	1-216-864-11	METAL CHIP	0 5% 1/16W				
				R003	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1190	1-216-816-11	METAL CHIP	390 5% 1/16W	R004	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1191	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R010	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1194	1-216-819-11	METAL CHIP	680 5% 1/16W	R011	1-216-033-00	METAL CHIP 220 5% 1/10W	
R1196	1-216-833-11	METAL CHIP	10K 5% 1/16W			< SWITCH >	
R1197	1-216-833-11	METAL CHIP	10K 5% 1/16W				
				S002	1-572-987-11	SWITCH, PUSH (3 KEY)	
R1198	1-216-819-11	METAL CHIP	680 5% 1/16W			*****	
R1199	1-216-819-11	METAL CHIP	680 5% 1/16W	*	A-7063-962-A	MA-179 BOARD, COMPLETE	
R1202	1-216-811-11	METAL CHIP	150 5% 1/16W			*****	
R1203	1-216-833-11	METAL CHIP	10K 5% 1/16W			(TR72/TR80/TR400/TR430/TR750)	
R1204	1-216-815-11	METAL CHIP	330 5% 1/16W			(Ref. No. 7,000 Series)	
						< CAPACITOR >	
R1205	1-216-817-11	METAL CHIP	470 5% 1/16W				
R1206	1-216-817-11	METAL CHIP	470 5% 1/16W	C001	1-164-343-11	CERAMIC CHIP 0.056uF 10% 25V	
R1207	1-216-815-11	METAL CHIP	330 5% 1/16W	C003	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
R1209	1-216-864-11	METAL CHIP	0 5% 1/16W	C005	1-163-023-00	CERAMIC CHIP 0.015uF 5% 50V	
R1210	1-216-831-11	METAL CHIP	6.8K 5% 1/16W	C006	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
				C007	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
R1214	1-216-820-11	METAL CHIP	820 5% 1/16W				
R1215	1-216-819-11	METAL CHIP	680 5% 1/16W	C008	1-163-037-11	CERAMIC CHIP 0.022uF 10% 25V	
R1216	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	C009	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
R1217	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	C010	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
R1218	1-216-817-11	METAL CHIP	470 5% 1/16W				
R1219	1-216-817-11	METAL CHIP	470 5% 1/16W				
R1220	1-216-864-11	METAL CHIP	0 5% 1/16W				
R1221	1-216-864-11	METAL CHIP	0 5% 1/16W				
R1223	1-216-864-11	METAL CHIP	0 5% 1/16W				
R1226	1-216-864-11	METAL CHIP	0 5% 1/16W				

Ref. No.	Part No.	Description		Remark
C011	1-164-232-11	CERAMIC CHIP	0.01uF	50V
C012	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C013	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C014	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C015	1-162-966-11	CERAMIC CHIP	0.0022uF 10%	50V
C019	1-164-232-11	CERAMIC CHIP	0.01uF	50V
C020	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C021	1-126-205-11	ELECT CHIP	47uF 20%	6.3V
C022	1-164-004-11	CERAMIC CHIP	0.1uF 10%	25V
C023	1-135-091-21	TANTAL. CHIP	1uF 20%	16V
C024	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C025	1-163-023-00	CERAMIC CHIP	0.015uF 5%	50V
C026	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C027	1-163-037-11	CERAMIC CHIP	0.022uF 10%	25V
C030	1-164-343-11	CERAMIC CHIP	0.056uF 10%	25V
C043	1-128-004-11	ELECT CHIP	10uF 20%	16V

< CONNECTOR >

CN001	1-691-490-21	CONNECTOR, FFC/FPC 11P
CN002	1-580-057-11	PIN, CONNECTOR 4P
CN003	1-580-057-11	PIN, CONNECTOR 4P

< DIODE >

D001	8-719-404-46	DIODE MA110
D002	8-719-404-46	DIODE MA110
D004	8-719-404-19	DIODE LN1251C (TALLY)

< IC >

IC001	8-759-084-53	IC CXA1618AN-E2
IC002	8-749-923-29	IC RS-20E-T

< JACK >

J001	1-691-737-11	JACK (SMALL TYPE)(EXT MIC)
------	--------------	----------------------------

< COIL >

L001	1-412-939-11	INDUCTOR 1uH
L002	1-412-939-11	INDUCTOR 1uH
L003	1-412-939-11	INDUCTOR 1uH

< TRANSISTOR >

Q001	8-729-230-63	TRANSISTOR 2SC4116-YG
Q003	8-729-402-42	TRANSISTOR UN5213

< RESISTOR >

R003	1-216-829-11	METAL CHIP	4.7K 5%	1/16W
R004	1-216-833-11	METAL CHIP	10K 5%	1/16W
R005	1-216-821-11	METAL CHIP	1K 5%	1/16W
R006	1-216-813-11	METAL CHIP	220 5%	1/16W
R007	1-216-834-11	METAL CHIP	12K 5%	1/16W

Ref. No.	Part No.	Description		Remark
R008	1-216-834-11	METAL CHIP	12K 5%	1/16W
R009	1-216-835-11	METAL CHIP	15K 5%	1/16W
R010	1-216-833-11	METAL CHIP	10K 5%	1/16W
R011	1-216-825-11	METAL CHIP	2.2K 5%	1/16W
R012	1-216-839-11	METAL CHIP	33K 5%	1/16W
R013	1-216-831-11	METAL CHIP	6.8K 5%	1/16W
R014	1-216-831-11	METAL CHIP	6.8K 5%	1/16W
R015	1-216-839-11	METAL CHIP	33K 5%	1/16W
R016	1-216-833-11	METAL CHIP	10K 5%	1/16W
R017	1-216-835-11	METAL CHIP	15K 5%	1/16W
R018	1-216-834-11	METAL CHIP	12K 5%	1/16W
R019	1-216-834-11	METAL CHIP	12K 5%	1/16W
R020	1-216-825-11	METAL CHIP	2.2K 5%	1/16W
R022	1-216-829-11	METAL CHIP	4.7K 5%	1/16W
R023	1-216-833-11	METAL CHIP	10K 5%	1/16W
R024	1-216-821-11	METAL CHIP	1K 5%	1/16W
R025	1-216-864-11	METAL CHIP	0 5%	1/16W
R027	1-216-864-11	METAL CHIP	0 5%	1/16W
R036	1-216-864-11	METAL CHIP	0 5%	1/16W
R037	1-216-839-11	METAL CHIP	33K 5%	1/16W
R039	1-216-824-11	METAL CHIP	1.8K 5%	1/16W
R043	1-216-815-11	METAL CHIP	330 5%	1/16W

* A-7063-956-A MA-199 BOARD, COMPLETE

(TR42/TR70/TR82/TR550)
(Ref. No. 5,000 Series)

< CAPACITOR >

C014	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C015	1-162-966-11	CERAMIC CHIP	0.0022uF 10%	50V
C032	1-164-346-11	CERAMIC CHIP	1uF	16V
C033	1-162-953-11	CERAMIC CHIP	100PF 5%	50V
C034	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C035	1-162-587-11	CERAMIC CHIP	0.039uF 10%	25V
C036	1-164-004-11	CERAMIC CHIP	0.1uF 10%	25V
C037	1-164-346-11	CERAMIC CHIP	1uF	16V
C040	1-126-205-11	ELECT CHIP	47uF 20%	6.3V
C041	1-164-345-11	CERAMIC CHIP	0.082uF 10%	25V
C043	1-128-004-11	ELECT CHIP	10uF 20%	16V

< CONNECTOR >

CN001	1-691-487-21	CONNECTOR, FFC/FPC 8P
CN003	1-580-057-11	PIN, CONNECTOR 4P

< DIODE >

D001	8-719-404-49	DIODE MA111
D002	8-719-404-49	DIODE MA111
D004	8-719-404-19	DIODE LN1251C (TALLY)

[illegible]

Ref. No.	Part No.	Description	Remark
< IC >			
IC002	8-749-923-29	IC RS-20ET	
IC003	8-759-822-37	IC LA7293M-TE	
< COIL >			
L002	1-412-939-11	INDUCTOR 1uH	
L003	1-412-939-11	INDUCTOR 1uH	
< JACK >			
J001	1-568-027-11	JACK, SMALL TYPE 1P (EXT MIC)	
< TRANSISTOR >			
Q002	8-729-402-63	TRANSISTOR 2SB1218A-Q	
< RESISTOR >			
R027	1-216-864-11	METAL CHIP 0 5% 1/16W	
R028	1-216-820-11	METAL CHIP 820 5% 1/16W	
R029	1-216-823-11	METAL CHIP 1.5K 5% 1/16W	
R030	1-216-830-11	METAL CHIP 5.6K 5% 1/16W	
R031	1-216-838-11	METAL CHIP 27K 5% 1/16W	
R032	1-216-831-11	METAL CHIP 6.8K 5% 1/16W	
R033	1-216-838-11	METAL CHIP 27K 5% 1/16W	
R043	1-216-815-11	METAL CHIP 330 5% 1/16W	
R044	1-216-853-11	METAL CHIP 470K 5% 1/16W	

* A-7072-000-A SL-38 BOARD, COMPLETE			

(Ref. No. 4,000 Series)			
< CAPACITOR >			
C543	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C544	1-135-211-11	TANTAL. CHIP 6.8uF 20% 6.3V	
C545	1-135-211-11	TANTAL. CHIP 6.8uF 20% 6.3V	
C546	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C547	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C551	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C553	1-164-361-11	CERAMIC CHIP 0.047uF 16V	
C554	1-135-215-21	TANTAL. CHIP 6.8uF 20% 16V	
C555	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C556	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C557	1-135-149-21	TANTALUM CHIP 2.2uF 20% 10V	
C558	1-164-489-11	CERAMIC CHIP 0.22uF 10% 16V	
< CONNECTOR >			
CN500	1-691-473-21	CONNECTOR, FFC/FPC 7P	
CN501	1-691-472-21	CONNECTOR, FFC/FPC 6P	
CN502	1-691-482-21	CONNECTOR, FFC/FPC 15P	

Ref. No.	Part No.	Description	Remark
< IC >			
IC507	8-759-165-47	IC MPC1780VFUEB	
< COIL >			
L505	1-414-078-11	INDUCTOR 10uH	
< TRANSISTOR >			
Q560	8-729-805-25	TRANSISTOR 2SB1121	
Q561	8-729-425-50	TRANSISTOR 2SB1462Q	
Q562	8-729-402-81	TRANSISTOR XN4501	
< RESISTOR >			
R562	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R563	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R564	1-216-864-11	METAL CHIP 0 5% 1/16W	
R565	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R566	1-218-857-11	METAL CHIP 2.7K 0.50% 1/16W	
R567	1-216-295-00	METAL CHIP 0 5% 1/10W	
R568	1-216-168-00	METAL GLAZE 56 5% 1/8W	
R569	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R570	1-216-827-11	METAL CHIP 3.3K 5% 1/16W	
R571	1-218-879-11	METAL CHIP 22K 0.50% 1/16W	
R572	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R590	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R591	1-216-832-11	METAL CHIP 8.2K 5% 1/16W	
< FLEXIBLE BOARD >			
W500	1-651-889-11	FP-48 FLEXIBLE BOARD	
W501	1-642-186-11	FP-437 FLEXIBLE BOARD	

VC-138

VC-145

Ref.No.	Part No.	Description	Remark
*	A-7063-961-A	VC-138 BOARD, COMPLETE (TR72/430) *****	
*	A-7066-018-A	VC-138 BOARD, COMPLETE (TR80) *****	
*	A-7066-080-A	VC-138 BOARD, COMPLETE (TR400/TR750) *****	
*	A-7063-955-A	VC-145 BOARD, COMPLETE (TR82) *****	
*	A-7066-007-A	VC-145 BOARD, COMPLETE (TR70) *****	
*	A-7066-084-A	VC-145 BOARD, COMPLETE (TR42) *****	
*	A-7066-088-A	VC-145 BOARD, COMPLETE (TR550) ***** (Ref. No. 1,000 Series)	
< CAPACITOR >			
C604	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C605	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C606	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C607	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C608	1-104-847-11	TANTAL. CHIP 22uF 20%	4V (TR42/TR72/TR82/TR430/TR550)
C609	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C610	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C611	1-164-360-11	CERAMIC CHIP 0.1uF	16V (TR42/TR72/TR82/TR430/TR550)
C613	1-162-974-11	CERAMIC CHIP 0.01uF	50V (TR42/TR72/TR82/TR430/TR550)
C614	1-162-974-11	CERAMIC CHIP 0.01uF	50V (TR42/TR72/TR82/TR430/TR550)
C616	1-135-091-21	TANTAL. CHIP 1uF 20%	16V
C617	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C618	1-165-176-11	CERAMIC CHIP 0.047uF 10%	16V
C619	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C620	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C621	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C622	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C623	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C624	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C627	1-162-946-11	CERAMIC CHIP 27PF 5%	50V
C628	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C629	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C630	1-162-946-11	CERAMIC CHIP 27PF 5%	50V
C631	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C632	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C633	1-162-946-11	CERAMIC CHIP 27PF 5%	50V (TR82/TR400/TR550/TR750)

Ref.No.	Part No.	Description	Remark
C633	1-162-947-11	CERAMIC CHIP 33PF 5%	50V (TR42/TR70/TR72/TR80/TR430)
C634	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C635	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V (TR82/TR400/TR550/TR750)
C636	1-164-360-11	CERAMIC CHIP 0.1uF	16V (TR82/TR400/TR550/TR750)
C637	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C638	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C639	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C699	1-162-954-11	CERAMIC CHIP 120PF 5%	50V (TR82/TR400/TR550/TR750)
C701	1-163-059-91	CERAMIC CHIP 0.01uF 10%	50V
C702	1-162-638-11	CERAMIC CHIP 1uF	16V
C703	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C704	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C705	1-135-145-11	TANTALUM CHIP 0.47uF 10%	35V
C706	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C708	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C709	1-135-214-21	TANTAL. CHIP 4.7uF 20%	20V
C710	1-162-971-11	CERAMIC CHIP 0.001uF	50V
C711	1-162-971-11	CERAMIC CHIP 0.001uF	50V
C712	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C713	1-107-685-11	TANTAL. CHIP 15uF 20%	6.3V
C714	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C715	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C716	1-164-360-11	CERAMIC CHIP 0.1uF	16V
C717	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C718	1-162-637-11	CERAMIC CHIP 0.47uF	16V
C719	1-162-971-11	CERAMIC CHIP 0.001uF	50V
C720	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C721	1-162-916-11	CERAMIC CHIP 12PF 5%	50V
C722	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C724	1-162-925-11	CERAMIC CHIP 68PF 5%	50V (TR42/TR70/TR72/TR80/TR430)
C724	1-162-949-11	CERAMIC CHIP 47PF 5%	50V (TR82/TR400/TR550/TR750)
C725	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C726	1-135-259-11	TANTAL. CHIP 10uF 20%	6.3V
C727	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C728	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C729	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C730	1-163-077-00	CERAMIC CHIP 0.1uF 10%	25V (TR82/TR400/TR550/TR750)
C730	1-164-298-11	CERAMIC CHIP 0.15uF 10%	25V (TR42/TR70/TR72/TR80/TR430)
C731	1-135-091-21	TANTAL. CHIP 1uF 20%	16V
C732	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C733	1-135-181-21	TANTALUM CHIP 4.7uF 20%	6.3V
C734	1-135-091-21	TANTAL. CHIP 1uF 20%	16V
C735	1-162-974-11	CERAMIC CHIP 0.01uF	50V
C737	1-162-946-11	CERAMIC CHIP 27PF 5%	50V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C739	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V	C789	1-164-245-11	CERAMIC CHIP	0.015uF 10% 25V (TR82/TR400/TR550/TR750)
C741	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V	C790	1-164-299-11	CERAMIC CHIP	0.22uF 10% 25V (TR82/TR400/TR550/TR750)
C742	1-164-360-11	CERAMIC CHIP	0.1uF 16V	C793	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)
C743	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C794	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR82/TR400/TR550/TR750)
C744	1-162-974-11	CERAMIC CHIP	0.01uF 50V	< CONNECTOR >			
C745	1-162-974-11	CERAMIC CHIP	0.01uF 50V	* CN601	1-764-395-21	CONNECTOR, BOARD TO BOARD 42P	
C746	1-164-360-11	CERAMIC CHIP	0.1uF 16V	CN701	1-750-630-11	CONNECTOR, FFC/FPC (ZIF) 16P	
C747	1-164-360-11	CERAMIC CHIP	0.1uF 16V	* CN751	1-764-528-11	CONNECTOR, FFC/FPC (ZIF) 21P	
C748	1-164-360-11	CERAMIC CHIP	0.1uF 16V	CN775	1-691-487-21	CONNECTOR, FFC/FPC 8P	(TR82/TR400/TR550/TR750)
C749	1-135-181-21	TANTALUM CHIP	4.7uF 20% 6.3V	< TRIMMER >			
C750	1-162-971-11	CERAMIC CHIP	0.001uF 50V	CT701	1-141-356-11	CAP, ADJ	
C751	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V	< DIODE >			
C752	1-162-971-11	CERAMIC CHIP	0.001uF 50V	D701	8-719-404-49	DIODE MA111	
C753	1-162-974-11	CERAMIC CHIP	0.01uF 50V	D702	8-719-404-49	DIODE MA111	
C754	1-162-974-11	CERAMIC CHIP	0.01uF 50V	D703	8-719-404-49	DIODE MA111	
C755	1-162-974-11	CERAMIC CHIP	0.01uF 50V	D705	8-719-404-49	DIODE MA111	
C756	1-104-752-11	TANTAL. CHIP	33uF 20% 6.3V	< FILTER >			
C757	1-162-974-11	CERAMIC CHIP	0.01uF 50V	FL601	1-239-352-11	FILTER, LOW PASS	(TR82/TR400/TR550/TR750)
C771	1-164-245-11	CERAMIC CHIP	0.015uF 10% 25V (TR82/TR400/TR550/TR750)	FL601	1-239-766-11	FILTER, LOW PASS	(TR42/TR70/TR72/TR80/TR430)
C772	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (TR82/TR400/TR550/TR750)	< IC >			
C773	1-164-299-11	CERAMIC CHIP	0.22uF 10% 25V (TR82/TR400/TR550/TR750)	IC601	8-759-044-78	IC AK6420F-E1	
C774	1-128-257-21	ELECT CHIP	33uF 20% 10V (TR82/TR400/TR550/TR750)	IC602	8-759-260-67	IC SC424608MC68HC11MA8FU	(TR42/TR70/TR72/TR80/TR82/TR430)
C775	1-128-257-21	ELECT CHIP	33uF 20% 10V (TR82/TR400/TR550/TR750)	IC602	8-759-277-18	IC SC424609MC68HC11MA8FU	(TR400/TR550/TR750)
C776	1-162-953-11	CERAMIC CHIP	100PF 5% 50V (TR82/TR400/TR550/TR750)	IC603	8-759-064-36	IC MB88346BPV	
C777	1-162-568-11	CERAMIC CHIP	0.33uF 10% 16V (TR82/TR400/TR550/TR750)	IC604	8-759-710-29	IC NJM2235M	(TR42/TR72/TR82/TR430/TR550)
C778	1-162-953-11	CERAMIC CHIP	100PF 5% 50V (TR82/TR400/TR550/TR750)	IC609	8-752-365-71	IC CXD2150R	(TR42/TR70/TR72/TR80/TR82/TR430)
C779	1-162-568-11	CERAMIC CHIP	0.33uF 10% 16V (TR82/TR400/TR550/TR750)	IC609	8-752-369-24	IC CXD2150AR	(TR400/TR550/TR750)
C780	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR82/TR400/TR550/TR750)	IC610	8-752-365-72	IC CXD2151R	
C781	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR82/TR400/TR550/TR750)	IC611	8-759-262-36	IC CXD2133BR	
C782	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)	IC613	8-759-247-06	IC CXD2152REL	(TR82/TR400/TR550/TR750)
C783	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)	IC614	8-759-255-09	IC uPD6461GS-802-GLG-E2	
C784	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR82/TR400/TR550/TR750)	IC701	8-752-355-07	IC CXD1267N	
C785	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR82/TR400/TR550/TR750)	IC702	8-752-365-73	IC CXD2405R	(TR82/TR400/TR550/TR750)
C786	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR82/TR400/TR550/TR750)	IC702	8-752-365-74	IC CXD1266R	(TR42/TR70/TR72/TR80/TR430)
C788	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (TR82/TR400/TR550/TR750)	IC703	8-752-069-21	IC CXA1690Q	
				IC704	8-759-173-24	IC AD875JST-REEL	(TR70/TR72/TR80/TR430)

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
IC704	8-759-263-29	IC HD49315FEB (TR42/TR82/TR400/TR550/TR750)		Q701	8-729-403-27	TRANSISTOR XN4401	
IC705	8-752-365-76	IC CXD2407R		Q751	8-729-010-75	TRANSISTOR MSC4116	
IC751	8-759-701-24	IC NJM3414M		Q752	8-729-015-76	TRANSISTOR UN5211	
IC752	8-759-058-52	IC XRA10324AF		< RESISTOR >			
IC753	8-752-365-65	IC CXD2126N		R601	1-216-851-11	METAL CHIP 330K 5% 1/16W	
IC754	8-759-247-07	IC MPC17A34VMEL		R602	1-216-833-11	METAL CHIP 10K 5% 1/16W	
IC755	8-759-031-58	IC SC7SU04F		R603	1-216-857-11	METAL CHIP 1M 5% 1/16W	
IC772	8-759-234-77	IC TC4S66F (TR82/TR400/TR550/TR750)		R604	1-216-833-11	METAL CHIP 10K 5% 1/16W	
IC773	8-759-234-77	IC TC4S66F (TR82/TR400/TR550/TR750)		R605	1-216-864-11	METAL CHIP 0 5% 1/16W	
IC774	8-759-058-45	IC NJM3403AV(Te2) (TR82/TR400/TR550/TR750)		R606	1-216-847-11	METAL CHIP 150K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
IC775	8-759-080-34	IC TA75W01FU-TE12R (TR82/TR400/TR550/TR750)		R607	1-216-839-11	METAL CHIP 33K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
IC776	8-759-248-78	IC MB88102PFV-G-BND-ER (TR82/TR400/TR550/TR750)		R608	1-216-864-11	METAL CHIP 0 5% 1/16W	
IC777	8-752-850-54	IC CXP87132-010R (TR82/TR400/TR550/TR750)		R609	1-216-838-11	METAL CHIP 27K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
< COIL >				R610	1-216-839-11	METAL CHIP 33K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
L601	1-412-058-11	INDUCTOR CHIP 10uH		R611	1-216-838-11	METAL CHIP 27K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
L602	1-414-078-11	INDUCTOR 10uH		R612	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
L603	1-412-058-11	INDUCTOR CHIP 10uH		R613	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
L604	1-414-078-11	INDUCTOR 10uH		R614	1-216-825-11	METAL CHIP 2.2K 5% 1/16W (TR70/TR80/TR400/TR750)	
L605	1-410-391-11	INDUCTOR CHIP 68uH		R615	1-216-825-11	METAL CHIP 2.2K 5% 1/16W (TR70/TR80/TR400/TR750)	
L606	1-414-078-11	INDUCTOR 10uH		R616	1-216-864-11	METAL CHIP 0 5% 1/16W (TR82)	
L607	1-414-078-11	INDUCTOR 10uH (TR82/TR400/TR550/TR750)		R619	1-216-803-11	METAL CHIP 33 5% 1/16W	
L608	1-412-006-31	INDUCTOR CHIP 10uH		R620	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L609	1-412-979-21	INDUCTOR 1uH		R621	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L610	1-412-979-21	INDUCTOR 1uH		R622	1-216-864-11	METAL CHIP 0 5% 1/16W (TR70/TR80/TR400/TR750)	
L611	1-412-052-21	INDUCTOR CHIP 1uH		R624	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR70/TR72/TR80/TR400/TR430/TR550/TR750)	
L612	1-412-052-21	INDUCTOR CHIP 1uH		R626	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L613	1-412-052-21	INDUCTOR CHIP 1uH		R627	1-216-841-11	METAL CHIP 47K 5% 1/16W	
L614	1-412-052-21	INDUCTOR CHIP 1uH		R628	1-216-834-11	METAL CHIP 12K 5% 1/16W (TR400/TR550/TR750)	
L702	1-412-058-11	INDUCTOR CHIP 10uH		R629	1-216-832-11	METAL CHIP 8.2K 5% 1/16W (TR400/TR550/TR750)	
L703	1-412-058-11	INDUCTOR CHIP 10uH		R629	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430)	
L704	1-412-058-11	INDUCTOR CHIP 10uH		R630	1-216-833-11	METAL CHIP 10K 5% 1/16W	
L705	1-412-058-11	INDUCTOR CHIP 10uH		R631	1-216-864-11	METAL CHIP 0 5% 1/16W	
L706	1-412-058-11	INDUCTOR CHIP 10uH		R634	1-216-821-11	METAL CHIP 1K 5% 1/16W	
L751	1-412-062-11	INDUCTOR CHIP 47uH		R635	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
L752	1-412-058-11	INDUCTOR CHIP 10uH		R636	1-216-845-11	METAL CHIP 100K 5% 1/16W	
L753	1-412-058-11	INDUCTOR CHIP 10uH		R637	1-216-837-11	METAL CHIP 22K 5% 1/16W	
L775	1-412-058-11	INDUCTOR CHIP 10uH (TR82/TR400/TR550/TR750)		R638	1-216-839-11	METAL CHIP 33K 5% 1/16W	
L777	1-414-078-11	INDUCTOR 10uH (TR82/TR400/TR550/TR750)		R639	1-216-864-11	METAL CHIP 0 5% 1/16W	
L778	1-414-078-11	INDUCTOR 10uH (TR82/TR400/TR550/TR750)		R640	1-216-815-11	METAL CHIP 330 5% 1/16W	
< TRANSISTOR >							
Q604	8-729-010-60	TRANSISTOR MSA1586					
Q605	8-729-010-60	TRANSISTOR MSA1586					
Q606	8-729-010-75	TRANSISTOR MSC4116					
Q607	8-729-010-75	TRANSISTOR MSC4116					

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R643	1-216-833-11	METAL CHIP	10K 5% 1/16W	R720	1-216-843-11	METAL CHIP	68K 5% 1/16W (TR82/TR400/TR550/TR750)
R645	1-216-834-11	METAL CHIP	12K 5% 1/16W	R720	1-216-844-11	METAL CHIP	82K 5% 1/16W (TR70/TR72/TR80/TR430)
R646	1-216-818-11	METAL CHIP	560 5% 1/16W	R721	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR82/TR400/TR550/TR750)
R647	1-216-834-11	METAL CHIP	12K 5% 1/16W	R722	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR82/TR400/TR550/TR750)
R648	1-216-818-11	METAL CHIP	560 5% 1/16W	R723	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR72/TR80/TR430)
R649	1-216-841-11	METAL CHIP	47K 5% 1/16W	R724	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR82/TR400/TR550/TR750)
R650	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R725	1-216-841-11	METAL CHIP	47K 5% 1/16W
R651	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R739	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42)
R652	1-216-841-11	METAL CHIP	47K 5% 1/16W	R740	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR72/TR80/TR82/TR400/TR430/TR550/TR750)
R653	1-216-864-11	METAL CHIP	0 5% 1/16W	R741	1-218-855-11	METAL CHIP	2.2K 0.50% 1/16W
R656	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	R742	1-218-865-11	METAL CHIP	5.6K 0.50% 1/16W
R657	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R743	1-216-833-11	METAL CHIP	10K 5% 1/16W
R658	1-216-864-11	METAL CHIP	0 5% 1/16W	R744	1-216-827-11	METAL CHIP	3.3K 5% 1/16W
R659	1-216-823-11	METAL CHIP	1.5K 5% 1/16W	R745	1-216-837-11	METAL CHIP	22K 5% 1/16W
R661	1-216-841-11	METAL CHIP	47K 5% 1/16W	R746	1-216-837-11	METAL CHIP	22K 5% 1/16W
R662	1-216-821-11	METAL CHIP	1K 5% 1/16W	R747	1-216-820-11	METAL CHIP	820 5% 1/16W
R663	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	R748	1-216-828-11	METAL CHIP	3.9K 5% 1/16W
R664	1-216-821-11	METAL CHIP	1K 5% 1/16W	R749	1-216-851-11	METAL CHIP	330K 5% 1/16W
R665	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	R750	1-216-841-11	METAL CHIP	47K 5% 1/16W
R666	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R751	1-216-809-11	METAL CHIP	100 5% 1/16W
R667	1-216-820-11	METAL CHIP	820 5% 1/16W	R752	1-216-821-11	METAL CHIP	1K 5% 1/16W
R668	1-216-824-11	METAL CHIP	1.8K 5% 1/16W	R753	1-216-845-11	METAL CHIP	100K 5% 1/16W
R669	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R754	1-216-848-11	METAL CHIP	180K 5% 1/16W
R670	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R755	1-216-855-11	METAL CHIP	680K 5% 1/16W
R701	1-216-857-11	METAL CHIP	1M 5% 1/16W	R756	1-216-848-11	METAL CHIP	180K 5% 1/16W
R702	1-216-833-11	METAL CHIP	10K 5% 1/16W	R757	1-216-833-11	METAL CHIP	10K 5% 1/16W
R703	1-216-845-11	METAL CHIP	100K 5% 1/16W	R758	1-216-837-11	METAL CHIP	22K 5% 1/16W
R704	1-216-840-11	METAL CHIP	39K 5% 1/16W (TR42/TR82/TR400/TR550/TR750)	R759	1-216-837-11	METAL CHIP	22K 5% 1/16W
R705	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R760	1-216-826-11	METAL CHIP	2.7K 5% 1/16W
R709	1-216-845-11	METAL CHIP	100K 5% 1/16W	R761	1-216-842-11	METAL CHIP	56K 5% 1/16W
R710	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	R762	1-216-842-11	METAL CHIP	56K 5% 1/16W
R711	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R764	1-216-828-11	METAL CHIP	3.9K 5% 1/16W
R712	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR430)	R765	1-216-833-11	METAL CHIP	10K 5% 1/16W (TR82/TR400/TR550/TR750)
R713	1-216-807-11	METAL CHIP	68 5% 1/16W	R766	1-216-835-11	METAL CHIP	15K 5% 1/16W (TR82/TR400/TR550/TR750)
R714	1-216-864-11	METAL CHIP	0 5% 1/16W	R767	1-216-850-11	METAL CHIP	270K 5% 1/16W (TR82/TR400/TR550/TR750)
R715	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R768	1-216-833-11	METAL CHIP	10K 5% 1/16W (TR82/TR400/TR550/TR750)
R716	1-218-847-11	METAL CHIP	1K 0.50% 1/16W	R769	1-216-850-11	METAL CHIP	270K 5% 1/16W (TR82/TR400/TR550/TR750)
R717	1-216-864-11	METAL CHIP	0 5% 1/16W (TR82/TR400/TR550/TR750)	R770	1-216-835-11	METAL CHIP	15K 5% 1/16W (TR82/TR400/TR550/TR750)
R718	1-216-807-11	METAL CHIP	68 5% 1/16W	R771	1-216-803-11	METAL CHIP	33 5% 1/16W (TR82/TR400/TR550/TR750)
R719	1-218-876-11	METAL CHIP	16K 0.50% 1/16W				
R720	1-216-841-11	METAL CHIP	47K 5% 1/16W (TR42)				

VC-138

VC-145

VF-65

Ref. No.	Part No.	Description	Remark
R772	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R773	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R774	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R775	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R776	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R777	1-216-837-11	METAL CHIP 22K 5% 1/16W (TR82/TR400/TR550/TR750)	
R778	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR82/TR400/TR550/TR750)	
R779	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R780	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R781	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR82/TR400/TR550/TR750)	
R782	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R783	1-218-911-11	METAL CHIP 470K 0.50% 1/16W (TR82/TR400/TR550/TR750)	
R786	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R787	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R788	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R789	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
R790	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR82/TR400/TR550/TR750)	
R791	1-216-864-11	METAL CHIP 0 5% 1/16W (TR82/TR400/TR550/TR750)	
R792	1-216-857-11	METAL CHIP 1M 5% 1/16W (TR82/TR400/TR550/TR750)	
R793	1-216-841-11	METAL CHIP 47K 5% 1/16W (TR82/TR400/TR550/TR750)	
< VIBRATOR >			
X601	1-760-081-21	VIBRATOR, CERAMIC (24MHz)	
X701	1-760-320-11	VIBRATOR, CRYSTAL (28.6363MHz)	
X775	1-579-553-11	VIBRATOR (12MHz) (TR82/TR400/TR550/TR750)	

*	A-7063-957-A	VF-65 BOARD, COMPLETE	

		(TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
		(Ref. No. 8,000 Series)	
< CAPACITOR >			
C901	1-124-635-00	ELECT 220uF 20% 6.3V	

Ref. No.	Part No.	Description	Remark
C902	1-163-038-11	CERAMIC CHIP 0.1uF	25V
C903	1-135-091-21	TANTAL. CHIP 1uF	20% 16V
C904	1-163-011-11	CERAMIC CHIP 0.0015uF	10% 50V
C905	1-104-753-11	TANTAL. CHIP 47uF	20% 6.3V
C906	1-162-638-11	CERAMIC CHIP 1uF	16V
C907	1-137-306-11	FILM CHIP 0.1uF	5% 16V
C908	1-163-109-00	CERAMIC CHIP 47PF	5% 50V
C909	1-163-009-11	CERAMIC CHIP 0.001uF	10% 50V
△C910	1-164-758-11	CERAMIC CHIP 0.0039uF	5% 50V
△C911	1-164-715-11	CERAMIC CHIP 0.0068uF	5% 50V
C912	1-127-532-11	ELECT(SOLID) 47uF	20% 6.3V
C913	1-124-577-11	ELECT 82uF	20% 10V
C914	1-128-007-11	ELECT CHIP 2.2uF	20% 35V
C915	1-163-037-11	CERAMIC CHIP 0.022uF	10% 25V
C916	1-164-611-11	CERAMIC CHIP 0.001uF	10% 500V
< CONNECTOR >			
CN901	1-566-537-11	CONNECTOR, FPC (NON ZIF) 5P	
CN902	1-573-290-11	PIN, CONNECTOR (1.5MM) (SMD) 4P	
< DIODE >			
D901	8-719-404-19	DIODE LN1251 (TALLY)	
D903	8-719-400-20	DIODE MA152WA	
< IC >			
IC901	8-759-196-14	IC BA7149F-E2	
< COIL >			
L901	1-412-031-11	INDUCTOR CHIP 47uH	
L902	1-410-389-31	INDUCTOR CHIP 47uH	
△L903	1-402-680-21	COIL, FERRITE (HLC)	
< TRANSISTOR >			
△Q901	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
Q902	8-729-106-68	TRANSISTOR 2SD1615A-GP	
Q903	8-729-216-31	TRANSISTOR 2SA1163-G	
Q904	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
< RESISTOR >			
R901	1-216-041-00	METAL CHIP 470 5% 1/10W	
R902	1-216-041-00	METAL CHIP 470 5% 1/10W	
R903	1-216-035-00	METAL CHIP 270 5% 1/10W	
△R904	1-216-073-00	METAL CHIP 10K 5% 1/10W	
△R905	1-216-051-00	METAL CHIP 1.2K 5% 1/10W	
R906	1-216-047-00	METAL CHIP 820 5% 1/10W	
R907	1-216-097-00	METAL CHIP 100K 5% 1/10W	
R908	1-216-111-00	METAL CHIP 390K 5% 1/10W	
R909	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R910	1-216-077-00	METAL CHIP 15K 5% 1/10W	

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

[illegible]

The companies identified by you
do not share our view that it is
worth pursuing.

Les composés dissolus par les
solvants de nos analyses sont les
suivants :

Ref. No.	Part No.	Description	Remark		
R911	1-216-160-00	METAL GLAZE	27	5%	1/8W
R912	1-216-121-00	METAL CHIP	1M	5%	1/10W
R913	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R914	1-216-025-00	METAL CHIP	100	5%	1/10W
R915	1-216-308-00	METAL CHIP	4.7	5%	1/10W
R916	1-216-683-11	METAL CHIP	22K	0.5%	1/10W
R917	1-216-693-11	METAL CHIP	56K	0.5%	1/10W
R918	1-216-069-00	METAL CHIP	6.8K	5%	1/10W
R919	1-216-689-11	METAL CHIP	39K	0.5%	1/10W
R920	1-216-689-11	METAL CHIP	39K	0.5%	1/10W
R921	1-216-311-00	METAL CHIP	6.8	5%	1/10W
R922	1-216-101-00	METAL CHIP	150K	5%	1/10W
R923	1-216-121-00	METAL CHIP	1M	5%	1/10W
R924	1-216-131-11	METAL CHIP	2.7M	5%	1/10W
R925	1-216-131-11	METAL CHIP	2.7M	5%	1/10W
R926	1-216-295-00	METAL CHIP	0	5%	1/10W
R927	1-216-049-00	METAL CHIP	1K	5%	1/10W
R928	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
< VARIABLE RESISTOR >					
RV903	1-238-086-11	RES, ADJ, CERMET	470		
RV904	1-223-566-11	RES, ADJ, METAL GLAZE	1M		
< TRANSFORMER >					
△T901	1-453-124-11	TRANSFORMER ASSY, FLYBACK			
< THERMISTOR >					
TH901	1-809-350-21	THERMISTOR, NTC (2125)			
< SOCKET >					
△W901	1-540-019-21	SOCKET ASSY, CRT			

*	A-7066-010-A	VF-66 BOARD, COMPLETE (TR70/TR80)			

		(Ref. No. 4,000 Series)			
< CAPACITOR >					
C851	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V
C852	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C853	1-104-916-11	TANTAL. CHIP	6.8uF	20%	20V
C854	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C855	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C856	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
C857	1-164-676-11	CERAMIC CHIP	2200PF	5%	16V
C858	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V
C859	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C860	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C861	1-104-917-11	TANTAL. CHIP	15uF	20%	20V

Ref. No.	Part No.	Description	Remark		
C862	1-165-178-11	CERAMIC CHIP	6.8uF		16V
C863	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C864	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C865	1-162-921-11	CERAMIC CHIP	33PF	5%	50V
C866	1-162-974-11	CERAMIC CHIP	0.01uF		50V
C867	1-135-177-21	TANTALUM CHIP	1uF	20%	20V
C868	1-165-128-11	CERAMIC CHIP	0.22uF		16V
C869	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C870	1-162-974-11	CERAMIC CHIP	0.01uF		50V
< CONNECTOR >					
CN851	1-573-354-11	CONNECTOR, FFC/FPC 14P			
CN852	1-573-354-11	CONNECTOR, FFC/FPC 14P			
CN853	1-573-811-11	CONNECTOR, BOARD TO BOARD 12P			
< DIODE >					
D851	8-719-404-19	DIODE LN1251C (TALLY)			
D852	8-719-043-70	DIODE MA6S121			
D853	8-719-802-36	DIODE 1SS250			
< IC >					
IC851	8-759-097-75	IC MB3789PFV-G-BND-ER			
IC852	8-759-508-68	IC XRA10358F-E2			
< COIL >					
L851	1-412-033-11	INDUCTOR CHIP 220uH			
L852	1-412-029-11	INDUCTOR CHIP 10uH			
L853	1-412-033-11	INDUCTOR CHIP 220uH			
< TRANSISTOR >					
Q851	8-729-024-60	TRANSISTOR MTD6N15T4			
Q852	8-729-402-84	TRANSISTOR XN4601			
Q853	8-729-923-62	TRANSISTOR DTA123JK			
< RESISTOR >					
R851	1-216-819-11	METAL CHIP	680	5%	1/16W
R852	1-216-841-11	METAL CHIP	47K	5%	1/16W
R853	1-218-899-11	METAL CHIP	150K	0.50%	1/16W
R854	1-218-901-11	METAL CHIP	180K	0.50%	1/16W
R855	1-216-840-11	METAL CHIP	39K	5%	1/16W
R856	1-218-899-11	METAL CHIP	150K	0.50%	1/16W
R857	1-218-903-11	METAL CHIP	220K	0.50%	1/16W
R858	1-216-841-11	METAL CHIP	47K	5%	1/16W
R859	1-216-849-11	METAL CHIP	220K	5%	1/16W
R860	1-216-843-11	METAL CHIP	68K	5%	1/16W
R861	1-216-843-11	METAL CHIP	68K	5%	1/16W
R862	1-216-838-11	METAL CHIP	27K	5%	1/16W
R863	1-216-847-11	METAL CHIP	150K	5%	1/16W
R864	1-216-840-11	METAL CHIP	39K	5%	1/16W
R865	1-216-841-11	METAL CHIP	47K	5%	1/16W

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
R867	1-216-850-11	METAL CHIP 270K 5% 1/16W	
R868	1-216-864-11	METAL CHIP 0 5% 1/16W	
R869	1-216-843-11	METAL CHIP 68K 5% 1/16W	
R870	1-216-842-11	METAL CHIP 56K 5% 1/16W	
R871	1-216-850-11	METAL CHIP 270K 5% 1/16W	
R872	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R873	1-216-851-11	METAL CHIP 330K 5% 1/16W	
R874	1-216-847-11	METAL CHIP 150K 5% 1/16W	
R875	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R876	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R877	1-216-794-11	METAL CHIP 5.6 5% 1/16W	
R878	1-216-804-11	METAL CHIP 39 5% 1/16W	
R879	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R880	1-216-839-11	METAL CHIP 33K 5% 1/16W	
R881	1-216-853-11	METAL CHIP 470K 5% 1/16W	
R891	1-216-296-00	METAL CHIP 0 5% 1/8W	
< TRANSFORMER >			
△T851	0-396-458-00		

*	A-7066-011-A	VF-67 BOARD, COMPLETE (TR70/TR80)	

< CAPACITOR >			
C901	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C902	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C903	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C904	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C905	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
C906	1-162-969-11	CERAMIC CHIP 0.0068uF 10% 25V	
C907	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
C908	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C909	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C910	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C911	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C913	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
C914	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C915	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C916	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C917	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C920	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
C921	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C925	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
C926	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V	
C927	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C928	1-164-344-11	CERAMIC CHIP 0.068uF 10% 25V	
C929	1-164-344-11	CERAMIC CHIP 0.068uF 10% 25V	
C930	1-164-344-11	CERAMIC CHIP 0.068uF 10% 25V	
C931	1-162-974-11	CERAMIC CHIP 0.01uF 50V	

Ref. No.	Part No.	Description	Remark
C932	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C933	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
C934	1-135-145-11	TANTALUM CHIP 0.47uF 10% 35V	
C935	1-135-179-21	TANTAL. CHIP 2.2uF 20% 16V	
C936	1-162-967-11	CERAMIC CHIP 0.0033uF 10% 50V	
C937	1-135-181-21	TANTALUM CHIP 4.7uF 20% 6.3V	
C938	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C939	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C940	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
C941	1-164-357-11	CERAMIC CHIP 1000PF 5% 50V	
C942	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C943	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
C945	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C946	1-135-179-21	TANTAL. CHIP 2.2uF 20% 16V	
C947	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C948	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C949	1-135-178-11	TANTAL. CHIP 1.5uF 20% 20V	
C950	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C951	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C953	1-164-346-11	CERAMIC CHIP 1uF 16V	
C954	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
< CONNECTOR >			
CN901	1-573-354-11	CONNECTOR, FFC/FPC 14P	
* CN902	1-573-984-11	CONNECTOR, BOARD TO BOARD 10P	
* CN903	1-573-356-11	CONNECTOR, FFC/FPC 16P	
< DIODE >			
D901	8-719-025-91	DIODE MA365(E)	
D903	8-719-404-49	DIODE MA111	
< IC >			
IC901	8-752-067-59	IC CXA1785R	
IC902	8-752-362-78	IC CXD2403R	
IC903	8-759-251-40	IC MB88E346PFV-G-BND-ER	
< COIL >			
L901	1-412-951-11	INDUCTOR 10uH	
L902	1-412-962-11	INDUCTOR 82uH	
L904	1-412-951-11	INDUCTOR 10uH	
L905	1-412-949-21	INDUCTOR 6.8uH	
L906	1-412-959-11	INDUCTOR 47uH	
< TRANSISTOR >			
Q901	8-729-402-84	TRANSISTOR XN4601	
Q902	8-729-402-42	TRANSISTOR UN5213	
< RESISTOR >			
R902	1-216-836-11	METAL CHIP 18K 5% 1/16W	
R903	1-216-842-11	METAL CHIP 56K 5% 1/16W	

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

VF-08

VF-67

Ref. No. Part No. Description

8887	1-012-001-01	WHEEL, CDF	270	00	1.000
8888	1-012-002-01	WHEEL, CDF	1	00	1.000
8889	1-012-003-01	WHEEL, CDF	100	00	1.000
8890	1-012-004-01	WHEEL, CDF	100	00	1.000
8891	1-012-005-01	WHEEL, CDF	1000	00	1.000

8892	1-012-006-01	WHEEL, CDF	100	00	1.000
8893	1-012-007-01	WHEEL, CDF	1000	00	1.000
8894	1-012-008-01	WHEEL, CDF	1000	00	1.000
8895	1-012-009-01	WHEEL, CDF	4.00	00	1.000
8896	1-012-010-01	WHEEL, CDF	100	00	1.000

8897	1-012-011-01	WHEEL, CDF	1.1	00	1.000
8898	1-012-012-01	WHEEL, CDF	100	00	1.000
8899	1-012-013-01	WHEEL, CDF	100	00	1.000
8900	1-012-014-01	WHEEL, CDF	100	00	1.000
8901	1-012-015-01	WHEEL, CDF	1000	00	1.000

8902	1-012-016-01	WHEEL, CDF	0	00	1.000
------	--------------	------------	---	----	-------

< TRANSFER >

AIRC. 1-012-017-01

8903	1-012-018-01	WHEEL, CDF	1000	00	1.000
------	--------------	------------	------	----	-------

1-012-019-01 1-012-020-01 1-012-021-01

< TRANSFER >

< TRANSFER >

8904	1-012-022-01	WHEEL, CDF	0.000	00	1.000
8905	1-012-023-01	WHEEL, CDF	0.000	00	1.000
8906	1-012-024-01	WHEEL, CDF	0.000	00	1.000
8907	1-012-025-01	WHEEL, CDF	0.000	00	1.000
8908	1-012-026-01	WHEEL, CDF	0.000	00	1.000

8909	1-012-027-01	WHEEL, CDF	0.000	00	1.000
8910	1-012-028-01	WHEEL, CDF	0.000	00	1.000
8911	1-012-029-01	WHEEL, CDF	0.000	00	1.000
8912	1-012-030-01	WHEEL, CDF	0.000	00	1.000
8913	1-012-031-01	WHEEL, CDF	0.000	00	1.000

8914	1-012-032-01	WHEEL, CDF	0.000	00	1.000
8915	1-012-033-01	WHEEL, CDF	0.000	00	1.000
8916	1-012-034-01	WHEEL, CDF	0.000	00	1.000
8917	1-012-035-01	WHEEL, CDF	0.000	00	1.000
8918	1-012-036-01	WHEEL, CDF	0.000	00	1.000

8919	1-012-037-01	WHEEL, CDF	0.000	00	1.000
8920	1-012-038-01	WHEEL, CDF	0.000	00	1.000
8921	1-012-039-01	WHEEL, CDF	0.000	00	1.000
8922	1-012-040-01	WHEEL, CDF	0.000	00	1.000
8923	1-012-041-01	WHEEL, CDF	0.000	00	1.000

8924	1-012-042-01	WHEEL, CDF	0.000	00	1.000
8925	1-012-043-01	WHEEL, CDF	0.000	00	1.000
8926	1-012-044-01	WHEEL, CDF	0.000	00	1.000
8927	1-012-045-01	WHEEL, CDF	0.000	00	1.000
8928	1-012-046-01	WHEEL, CDF	0.000	00	1.000

Remark

Ref. No. Part No. Description

8929	1-012-047-01	WHEEL, CDF	0.000	00	1.000
8930	1-012-048-01	WHEEL, CDF	0.000	00	1.000
8931	1-012-049-01	WHEEL, CDF	0.000	00	1.000
8932	1-012-050-01	WHEEL, CDF	0.000	00	1.000
8933	1-012-051-01	WHEEL, CDF	0.000	00	1.000

8934	1-012-052-01	WHEEL, CDF	0.000	00	1.000
8935	1-012-053-01	WHEEL, CDF	0.000	00	1.000
8936	1-012-054-01	WHEEL, CDF	0.000	00	1.000
8937	1-012-055-01	WHEEL, CDF	0.000	00	1.000
8938	1-012-056-01	WHEEL, CDF	0.000	00	1.000

8939	1-012-057-01	WHEEL, CDF	0.000	00	1.000
8940	1-012-058-01	WHEEL, CDF	0.000	00	1.000
8941	1-012-059-01	WHEEL, CDF	0.000	00	1.000
8942	1-012-060-01	WHEEL, CDF	0.000	00	1.000
8943	1-012-061-01	WHEEL, CDF	0.000	00	1.000

8944	1-012-062-01	WHEEL, CDF	0.000	00	1.000
8945	1-012-063-01	WHEEL, CDF	0.000	00	1.000
8946	1-012-064-01	WHEEL, CDF	0.000	00	1.000
8947	1-012-065-01	WHEEL, CDF	0.000	00	1.000
8948	1-012-066-01	WHEEL, CDF	0.000	00	1.000

8949	1-012-067-01	WHEEL, CDF	0.000	00	1.000
------	--------------	------------	-------	----	-------

< TRANSFER >

8950	1-012-068-01	WHEEL, CDF	0.000	00	1.000
8951	1-012-069-01	WHEEL, CDF	0.000	00	1.000
8952	1-012-070-01	WHEEL, CDF	0.000	00	1.000

< TRANSFER >

8953	1-012-071-01	WHEEL, CDF	0.000	00	1.000
8954	1-012-072-01	WHEEL, CDF	0.000	00	1.000

< TRANSFER >

8955	1-012-073-01	WHEEL, CDF	0.000	00	1.000
8956	1-012-074-01	WHEEL, CDF	0.000	00	1.000
8957	1-012-075-01	WHEEL, CDF	0.000	00	1.000
8958	1-012-076-01	WHEEL, CDF	0.000	00	1.000

< TRANSFER >

8959	1-012-077-01	WHEEL, CDF	0.000	00	1.000
8960	1-012-078-01	WHEEL, CDF	0.000	00	1.000
8961	1-012-079-01	WHEEL, CDF	0.000	00	1.000
8962	1-012-080-01	WHEEL, CDF	0.000	00	1.000
8963	1-012-081-01	WHEEL, CDF	0.000	00	1.000

< TRANSFER >

8964	1-012-082-01	WHEEL, CDF	0.000	00	1.000
8965	1-012-083-01	WHEEL, CDF	0.000	00	1.000

< TRANSFER >

8966	1-012-084-01	WHEEL, CDF	0.000	00	1.000
8967	1-012-085-01	WHEEL, CDF	0.000	00	1.000

The components identified by part
in this list are not to be used
unless they are replaced by the
original.

The components identified by part
in this list are not to be used
unless they are replaced by the
original.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R904	1-216-857-11	METAL CHIP	1M 5% 1/16W	*	A-7063-959-A	VS-104 BOARD, COMPLETE (TR72)	
R906	1-216-841-11	METAL CHIP	47K 5% 1/16W			*****	
R907	1-216-833-11	METAL CHIP	10K 5% 1/16W	*	A-7066-008-A	VS-104 BOARD, COMPLETE (TR80)	
R908	1-216-821-11	METAL CHIP	1K 5% 1/16W			*****	
R910	1-216-814-11	METAL CHIP	270 5% 1/16W	*	A-7066-079-A	VS-104 (H) BOARD, COMPLETE (TR400)	
R911	1-216-864-11	METAL CHIP	0 5% 1/16W			*****	
R912	1-216-821-11	METAL CHIP	1K 5% 1/16W	*	A-7066-086-A	VS-104 BOARD, COMPLETE (TR430)	
R913	1-220-397-11	METAL GLAZE	4.7M 5% 1/16W			*****	
R914	1-216-832-11	METAL CHIP	8.2K 5% 1/16W	*	A-7066-134-A	VS-104 (H) BOARD, COMPLETE (TR750)	
R919	1-216-839-11	METAL CHIP	33K 5% 1/16W			*****	
R920	1-216-839-11	METAL CHIP	33K 5% 1/16W	*	A-7063-953-A	VS-112 BOARD, COMPLETE (TR82)	
R921	1-216-857-11	METAL CHIP	1M 5% 1/16W			*****	
R922	1-216-839-11	METAL CHIP	33K 5% 1/16W	*	A-7066-019-A	VS-112 BOARD, COMPLETE (TR70)	
R923	1-216-839-11	METAL CHIP	33K 5% 1/16W			*****	
R924	1-216-864-11	METAL CHIP	0 5% 1/16W	*	A-7066-047-A	VS-112 (LL) BOARD, COMPLETE (TR42)	
R925	1-216-830-11	METAL CHIP	5.6K 5% 1/16W			*****	
R926	1-216-832-11	METAL CHIP	8.2K 5% 1/16W	*	A-7066-085-A	VS-112 BOARD, COMPLETE (TR550)	
R930	1-216-833-11	METAL CHIP	10K 5% 1/16W			*****	
R931	1-216-839-11	METAL CHIP	33K 5% 1/16W			(Ref. No. 30,000 Series)	
R933	1-216-864-11	METAL CHIP	0 5% 1/16W			< CAPACITOR >	
R934	1-216-821-11	METAL CHIP	1K 5% 1/16W	C101	1-162-921-11	CERAMIC CHIP 33PF 5% 50V	
R936	1-218-873-11	METAL CHIP	12K 0.50% 1/16W			(TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R937	1-218-905-11	METAL CHIP	270K 0.50% 1/16W	C102	1-162-911-11	CERAMIC CHIP 6PF 0.5PF 50V	
R938	1-216-849-11	METAL CHIP	220K 5% 1/16W			(TR400/TR750)	
R939	1-216-837-11	METAL CHIP	22K 5% 1/16W	C102	1-162-922-11	CERAMIC CHIP 39PF 5% 50V	
R946	1-216-821-11	METAL CHIP	33K 5% 1/16W			(TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R947	1-216-807-11	METAL CHIP	68 5% 1/16W	C103	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R948	1-216-807-11	METAL CHIP	68 5% 1/16W	C104	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R949	1-216-807-11	METAL CHIP	68 5% 1/16W	C106	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
R953	1-216-840-11	METAL CHIP	39K 5% 1/16W	C107	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
R954	1-216-840-11	METAL CHIP	39K 5% 1/16W	C108	1-162-926-11	CERAMIC CHIP 82PF 5% 50V	
R959	1-216-844-11	METAL CHIP	82K 5% 1/16W	C109	1-164-227-11	CERAMIC CHIP 0.022uF 10% 25V	
R960	1-216-845-11	METAL CHIP	100K 5% 1/16W	C110	1-164-227-11	CERAMIC CHIP 0.022uF 10% 25V	
R961	1-216-850-11	METAL CHIP	270K 5% 1/16W	C111	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R969	1-216-839-11	METAL CHIP	33K 5% 1/16W	C112	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
R970	1-216-839-11	METAL CHIP	33K 5% 1/16W	C113	1-164-217-11	CERAMIC CHIP 150PF 5% 50V	
R971	1-216-844-11	METAL CHIP	82K 5% 1/16W	C114	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
R973	1-216-839-11	METAL CHIP	33K 5% 1/16W	C115	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R974	1-216-839-11	METAL CHIP	33K 5% 1/16W	C116	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
		< VIBRATOR >		C117	1-104-852-11	TANTAL. CHIP 22uF 20% 6.3V	
X901	1-579-466-11	VIBRATOR, CRYSTAL (3.58MHz)		C118	1-104-852-11	TANTAL. CHIP 22uF 20% 6.3V	
		*****		C119	1-162-961-11	CERAMIC CHIP 330PF 10% 50V	
				C120	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
				C121	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
				C122	1-162-961-11	CERAMIC CHIP 330PF 10% 50V	
				C123	1-162-974-11	CERAMIC CHIP 0.01uF 50V	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C124	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V	C172	1-162-921-11	CERAMIC CHIP 33PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
C128	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C173	1-164-155-11	CERAMIC CHIP 75PF 5% 50V (TR400/TR750)	
C131	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C175	1-162-915-11	CERAMIC CHIP 10PF 0.5PF 50V (TR400/TR750)	
C134	1-162-974-11	CERAMIC CHIP	0.01uF 50V				
C136	1-162-974-11	CERAMIC CHIP	0.01uF 50V				
C137	1-162-918-11	CERAMIC CHIP	18PF 5% 50V				
C143	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V	C176	1-162-921-11	CERAMIC CHIP 33PF 5% 50V (TR400/TR750)	
C144	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V	C177	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C145	1-104-852-11	TANTAL. CHIP	22uF 20% 6.3V	C178	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C146	1-164-360-11	CERAMIC CHIP	0.1uF 16V	C179	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C147	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C190	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C148	1-162-958-11	CERAMIC CHIP	270PF 5% 50V				
C149	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C202	1-162-944-11	CERAMIC CHIP 18PF 5% 50V (TR400/TR750)	
C150	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C203	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C151	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C204	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C152	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C205	1-162-974-11	CERAMIC CHIP 0.01uF 50V (TR42/TR72/TR82/TR430/TR550)	
C153	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C206	1-164-489-11	CERAMIC CHIP 0.22uF 10% 16V	
C154	1-162-945-11	CERAMIC CHIP	22PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C207	1-162-927-11	CERAMIC CHIP 100PF 5% 50V	
C155	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR400/TR750)	C208	1-135-149-21	TANTALUM CHIP 2.2uF 20% 10V	
C157	1-162-918-11	CERAMIC CHIP	18PF 5% 50V	C209	1-126-246-11	ELECT CHIP 220uF 20% 4V	
C158	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C210	1-162-961-11	CERAMIC CHIP 330PF 10% 50V	
C159	1-162-922-11	CERAMIC CHIP	39PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C211	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
C160	1-162-946-11	CERAMIC CHIP	27PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C212	1-162-995-11	CERAMIC CHIP 0.022uF 50V	
C161	1-162-966-11	CERAMIC CHIP	0.0022uF 10% 50V	C213	1-135-176-21	TANTALUM CHIP 0.68uF 10% 20V	
C163	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C214	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
C164	1-162-942-11	CERAMIC CHIP	12PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C215	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
C165	1-162-956-11	CERAMIC CHIP	180PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C216	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C166	1-162-958-11	CERAMIC CHIP	270PF 5% 50V	C217	1-135-091-21	TANTAL. CHIP 1uF 20% 16V	
C167	1-162-926-11	CERAMIC CHIP	82PF 5% 50V (TR72/TR80/TR400/TR430/TR750)	C218	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
C167	1-164-382-11	CERAMIC CHIP	91PF 5% 50V (TR42/TR70/TR82/TR550)	C220	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C168	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C221	1-164-005-11	CERAMIC CHIP 0.47uF 25V (TR400/TR750)	
C169	1-162-949-11	CERAMIC CHIP	47PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C222	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
C170	1-162-915-11	CERAMIC CHIP	10PF 0.5PF 50V (TR400/TR750)	C223	1-164-360-11	CERAMIC CHIP 0.1uF 16V	
C171	1-162-927-11	CERAMIC CHIP	100PF 5% 50V (TR400/TR750)	C225	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
				C226	1-162-926-11	CERAMIC CHIP 82PF 5% 50V	
				C227	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
				C228	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
				C229	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
				C230	1-135-180-21	TANTALUM CHIP 3.3uF 20% 6.3V	
				C231	1-164-005-11	CERAMIC CHIP 0.47uF 25V	
				C234	1-162-957-11	CERAMIC CHIP 220PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
				C234	1-164-471-11	CERAMIC CHIP 680PF 5% 50V (TR400/TR750)	
				C235	1-126-207-11	ELECT CHIP 33uF 20% 4V	
				C237	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
				C238	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	
				C239	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
				C240	1-164-392-11	CERAMIC CHIP 390PF 5% 50V	

Part No.	Part No.	Description	Assembly No.	Part No.	Part No.	Description	Assembly No.
035	1-100-00-11	TAPPL. COY	50	036	1-100-00-11	CHAMIC COY	50
036	1-100-00-11	CHAMIC COY	50				
037	1-100-00-11	CHAMIC COY	50				
038	1-100-00-11	CHAMIC COY	50				
039	1-100-00-11	CHAMIC COY	50				
040	1-100-00-11	CHAMIC COY	50				
041	1-100-00-11	CHAMIC COY	50				
042	1-100-00-11	CHAMIC COY	50				
043	1-100-00-11	CHAMIC COY	50				
044	1-100-00-11	CHAMIC COY	50				
045	1-100-00-11	CHAMIC COY	50				
046	1-100-00-11	CHAMIC COY	50				
047	1-100-00-11	CHAMIC COY	50				
048	1-100-00-11	CHAMIC COY	50				
049	1-100-00-11	CHAMIC COY	50				
050	1-100-00-11	CHAMIC COY	50				
051	1-100-00-11	CHAMIC COY	50				
052	1-100-00-11	CHAMIC COY	50				
053	1-100-00-11	CHAMIC COY	50				
054	1-100-00-11	CHAMIC COY	50				
055	1-100-00-11	CHAMIC COY	50				
056	1-100-00-11	CHAMIC COY	50				
057	1-100-00-11	CHAMIC COY	50				
058	1-100-00-11	CHAMIC COY	50				
059	1-100-00-11	CHAMIC COY	50				
060	1-100-00-11	CHAMIC COY	50				
061	1-100-00-11	CHAMIC COY	50				
062	1-100-00-11	CHAMIC COY	50				
063	1-100-00-11	CHAMIC COY	50				
064	1-100-00-11	CHAMIC COY	50				
065	1-100-00-11	CHAMIC COY	50				
066	1-100-00-11	CHAMIC COY	50				
067	1-100-00-11	CHAMIC COY	50				
068	1-100-00-11	CHAMIC COY	50				
069	1-100-00-11	CHAMIC COY	50				
070	1-100-00-11	CHAMIC COY	50				
071	1-100-00-11	CHAMIC COY	50				
072	1-100-00-11	CHAMIC COY	50				
073	1-100-00-11	CHAMIC COY	50				
074	1-100-00-11	CHAMIC COY	50				
075	1-100-00-11	CHAMIC COY	50				
076	1-100-00-11	CHAMIC COY	50				
077	1-100-00-11	CHAMIC COY	50				
078	1-100-00-11	CHAMIC COY	50				
079	1-100-00-11	CHAMIC COY	50				
080	1-100-00-11	CHAMIC COY	50				
081	1-100-00-11	CHAMIC COY	50				
082	1-100-00-11	CHAMIC COY	50				
083	1-100-00-11	CHAMIC COY	50				
084	1-100-00-11	CHAMIC COY	50				
085	1-100-00-11	CHAMIC COY	50				
086	1-100-00-11	CHAMIC COY	50				
087	1-100-00-11	CHAMIC COY	50				
088	1-100-00-11	CHAMIC COY	50				
089	1-100-00-11	CHAMIC COY	50				
090	1-100-00-11	CHAMIC COY	50				
091	1-100-00-11	CHAMIC COY	50				
092	1-100-00-11	CHAMIC COY	50				
093	1-100-00-11	CHAMIC COY	50				
094	1-100-00-11	CHAMIC COY	50				
095	1-100-00-11	CHAMIC COY	50				
096	1-100-00-11	CHAMIC COY	50				
097	1-100-00-11	CHAMIC COY	50				
098	1-100-00-11	CHAMIC COY	50				
099	1-100-00-11	CHAMIC COY	50				
100	1-100-00-11	CHAMIC COY	50				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C241	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V	C294	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR400/TR750)
C242	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V	C295	1-135-180-21	TANTALUM CHIP	3.3uF 20% 6.3V (TR400/TR750)
C243	1-135-091-21	TANTAL. CHIP	1uF 20% 16V	C296	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR400/TR750)
C244	1-162-959-11	CERAMIC CHIP	330PF 5% 50V	C297	1-135-180-21	TANTALUM CHIP	3.3uF 20% 6.3V (TR400/TR750)
C245	1-164-360-11	CERAMIC CHIP	0.1uF 16V	C298	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR400/TR750)
C247	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C299	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)
C248	1-164-217-11	CERAMIC CHIP	150PF 5% 50V (TR400/TR750)	C300	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR400/TR750)
C250	1-164-217-11	CERAMIC CHIP	150PF 5% 50V (TR400/TR750)	C301	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)
C251	1-162-949-11	CERAMIC CHIP	47PF 5% 50V (TR400/TR750)	C302	1-135-180-21	TANTALUM CHIP	3.3uF 20% 6.3V (TR400/TR750)
C251	1-162-956-11	CERAMIC CHIP	180PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C303	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR400/TR750)
C258	1-164-346-11	CERAMIC CHIP	1uF 16V	C304	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR400/TR750)
C262	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C305	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)
C263	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C306	1-162-921-11	CERAMIC CHIP	33PF 5% 50V (TR400/TR750)
C264	1-135-180-21	TANTALUM CHIP	3.3uF 20% 6.3V	C307	1-162-974-11	CERAMIC CHIP	0.01uF 50V
C265	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C310	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V
C266	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C311	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR400/TR750)
C267	1-135-180-21	TANTALUM CHIP	3.3uF 20% 6.3V	C312	1-162-974-11	CERAMIC CHIP	0.01uF 50V
C268	1-164-360-11	CERAMIC CHIP	0.1uF 16V	C319	1-164-360-11	CERAMIC CHIP	0.1uF 16V
C271	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C322	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR42/TR72/TR82/TR430/TR550)
C272	1-135-180-21	TANTALUM CHIP	3.3uF 20% 6.3V	C323	1-164-360-11	CERAMIC CHIP	0.1uF 16V (TR42/TR72/TR82/TR430/TR550)
C273	1-162-974-11	CERAMIC CHIP	0.01uF 50V	C324	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR72/TR82/TR430/TR550)
C274	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V	C328	1-164-361-11	CERAMIC CHIP	0.047uF 16V
C275	1-162-955-11	CERAMIC CHIP	150PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C331	1-162-974-11	CERAMIC CHIP	0.01uF 50V
C276	1-162-944-11	CERAMIC CHIP	18PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C333	1-162-941-11	CERAMIC CHIP	10PF 0.5PF 50V
C278	1-162-949-11	CERAMIC CHIP	47PF 5% 50V	C334	1-162-935-11	CERAMIC CHIP	4PF 0.25PF 50V
C279	1-164-145-11	CERAMIC CHIP	390PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C500	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V
C281	1-162-954-11	CERAMIC CHIP	120PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C501	1-164-360-11	CERAMIC CHIP	0.1uF 16V
C282	1-162-927-11	CERAMIC CHIP	100PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C502	1-164-361-11	CERAMIC CHIP	0.047uF 16V
C284	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C503	1-124-778-00	ELECT CHIP	22uF 20% 6.3V
C285	1-135-318-11	TANTAL. CHIP	33uF 20% 4V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C504	1-162-974-11	CERAMIC CHIP	0.01uF 50V
C286	1-135-259-11	TANTAL. CHIP	10uF 20% 6.3V	C506	1-124-778-00	ELECT CHIP	22uF 20% 6.3V
C287	1-162-949-11	CERAMIC CHIP	47PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C507	1-162-918-11	CERAMIC CHIP	18PF 5% 50V
C289	1-164-360-11	CERAMIC CHIP	0.1uF 16V	C508	1-162-919-11	CERAMIC CHIP	22PF 5% 50V
C290	1-162-974-11	CERAMIC CHIP	0.01uF 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C509	1-162-974-11	CERAMIC CHIP	0.01uF 50V
C291	1-162-949-11	CERAMIC CHIP	47PF 5% 50V (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	C510	1-164-360-11	CERAMIC CHIP	0.1uF 16V
C292	1-164-346-11	CERAMIC CHIP	1uF 16V (TR400/TR750)	C511	1-164-361-11	CERAMIC CHIP	0.047uF 16V

Ref.No.	Part No.	Description		Remark	Ref.No.	Part No.	Description		Remark
C512	1-164-360-11	CERAMIC CHIP	0. 1uF	16V	C951	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
C513	1-164-361-11	CERAMIC CHIP	0. 047uF	16V	C952	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V
C514	1-162-974-11	CERAMIC CHIP	0. 01uF	50V	C953	1-126-205-11	ELECT CHIP	47uF	20% 6. 3V
C515	1-162-974-11	CERAMIC CHIP	0. 01uF	50V	C955	1-162-974-11	CERAMIC CHIP	0. 01uF	50V
C516	1-164-361-11	CERAMIC CHIP	0. 047uF	16V	C959	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
C518	1-164-004-11	CERAMIC CHIP	0. 1uF	10% 25V			(TR42/TR72/TR82/TR430/TR550)		
C519	1-164-346-11	CERAMIC CHIP	1uF	16V	C961	1-164-346-11	CERAMIC CHIP	1uF	16V
C521	1-164-004-11	CERAMIC CHIP	0. 1uF	10% 25V			(TR42/TR72/TR82/TR430/TR550)		
C522	1-164-361-11	CERAMIC CHIP	0. 047uF	16V	C1251	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
C523	1-164-492-11	CERAMIC CHIP	0. 15uF	10% 16V			(TR70/TR80/TR400/TR750)		
C524	1-164-492-11	CERAMIC CHIP	0. 15uF	10% 16V	C1252	1-164-505-11	CERAMIC CHIP	2. 2uF	16V
C526	1-164-227-11	CERAMIC CHIP	0. 022uF	10% 25V			(TR70/TR80/TR400/TR750)		
C527	1-164-004-11	CERAMIC CHIP	0. 1uF	10% 25V	C1254	1-162-970-11	CERAMIC CHIP	0. 01uF	10% 25V
C528	1-164-004-11	CERAMIC CHIP	0. 1uF	10% 25V			(TR400/TR750)		
C529	1-164-677-11	CERAMIC CHIP	0. 033uF	10% 16V	C1255	1-164-005-11	CERAMIC CHIP	0. 47uF	25V
C530	1-162-970-11	CERAMIC CHIP	0. 01uF	10% 25V			(TR400/TR750)		
C531	1-162-970-11	CERAMIC CHIP	0. 01uF	10% 25V	C1256	1-164-005-11	CERAMIC CHIP	0. 47uF	25V
C532	1-162-970-11	CERAMIC CHIP	0. 01uF	10% 25V			(TR70/TR80/TR400/TR750)		
C533	1-162-964-11	CERAMIC CHIP	0. 001uF	10% 50V	C1257	1-126-246-11	ELECT CHIP	220uF	20% 4V
C534	1-162-964-11	CERAMIC CHIP	0. 001uF	10% 50V			(TR400/TR750)		
C535	1-162-969-11	CERAMIC CHIP	0. 0068uF	10% 25V	C1258	1-135-149-21	TANTALUM CHIP	2. 2uF	20% 10V
C536	1-162-969-11	CERAMIC CHIP	0. 0068uF	10% 25V			(TR400/TR750)		
C537	1-164-360-11	CERAMIC CHIP	0. 1uF	16V	C1260	1-162-970-11	CERAMIC CHIP	0. 01uF	10% 25V
C538	1-162-995-11	CERAMIC CHIP	0. 022uF	50V			(TR400/TR750)		
C539	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V	C1261	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
C540	1-162-913-11	CERAMIC CHIP	8PF	0. 5PF 50V			(TR400/TR750)		
C541	1-164-360-11	CERAMIC CHIP	0. 1uF	16V	C1262	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V
C543	1-162-913-11	CERAMIC CHIP	8PF	0. 5PF 50V			(TR400/TR750)		
C544	1-162-974-11	CERAMIC CHIP	0. 01uF	50V	C1263	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V
C545	1-162-974-11	CERAMIC CHIP	0. 01uF	50V			(TR70/TR80/TR400/TR750)		
C547	1-164-360-11	CERAMIC CHIP	0. 1uF	16V	C1264	1-164-156-11	CERAMIC CHIP	0. 1uF	25V
C548	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V			(TR70/TR80/TR400/TR750)		
C549	1-162-995-11	CERAMIC CHIP	0. 022uF	50V	C1268	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V
C550	1-128-530-11	ELECT CHIP	33uF	20% 10V			(TR70/TR80/TR400/TR750)		
C552	1-164-362-11	CERAMIC CHIP	470PF	5% 50V	C1274	1-164-005-11	CERAMIC CHIP	0. 47uF	25V
C559	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V			(TR400/TR750)		
C560	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V	C1275	1-162-945-11	CERAMIC CHIP	22PF	5% 50V
C561	1-128-004-11	ELECT CHIP	10uF	20% 16V			(TR400/TR750)		
C562	1-162-974-11	CERAMIC CHIP	0. 01uF	50V	< CONNECTOR >				
C563	1-164-816-11	CERAMIC CHIP	220PF	2% 50V	CN101	1-691-492-21	CONNECTOR, FFC/FPC	13P	
C564	1-164-816-11	CERAMIC CHIP	220PF	2% 50V	CN102	1-580-789-11	PIN, CONNECTOR (SMD)	6P	
C565	1-162-995-11	CERAMIC CHIP	0. 022uF	50V	CN201	1-573-353-11	CONNECTOR, FFC/FPC	13P	
C566	1-162-995-11	CERAMIC CHIP	0. 022uF	50V	CN202	1-691-536-11	CONNECTOR, BOARD TO BOARD	24P	
C567	1-164-173-11	CERAMIC CHIP	0. 0039uF	10% 50V			(TR42/TR70/TR82/TR550)		
C568	1-162-974-11	CERAMIC CHIP	0. 01uF	50V	* CN202	1-691-929-11	CONNECTOR, BOARD TO BOARD	34P	
C569	1-162-974-11	CERAMIC CHIP	0. 01uF	50V			(TR72/TR80/TR400/TR430/TR750)		
C570	1-165-176-11	CERAMIC CHIP	0. 047uF	10% 16V	* CN203	1-764-396-21	CONNECTOR, BOARD TO BOARD	42P	
C571	1-164-004-11	CERAMIC CHIP	0. 1uF	10% 25V	* CN205	1-573-313-11	CONNECTOR, BOARD TO BOARD	26P	
C572	1-135-259-11	TANTAL. CHIP	10uF	20% 6. 3V			(TR400/TR750)		
C573	1-162-909-11	CERAMIC CHIP	4PF	0. 25PF 50V	CN206	1-573-923-21	CONNECTOR, FFC/FPC (ZIF)	14P	
					CN501	1-691-388-11	CONNECTOR, FFC/FPC (ZIF)	24P	
							(TR400/TR750)		
					* CN502	1-764-708-11	CONNECTOR, FFC/FPC (LIF)	9P	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* CN503	1-764-717-11	CONNECTOR, FFC/FPC (LIF) 18P				< COIL >	
CN504	1-695-325-11	CONNECTOR, BOARD TO BOARD 42P		L102	1-412-066-21	INDUCTOR CHIP 220uH	
* CN505	1-764-397-21	CONNECTOR, BOARD TO BOARD 42P		L103	1-412-066-21	INDUCTOR CHIP 220uH	
		< DIODE >		L104	1-412-951-11	INDUCTOR 10uH	
D101	8-719-800-76	DIODE 1SS226 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		L105	1-412-066-21	INDUCTOR CHIP 220uH	
D102	8-719-404-49	DIODE MA111		L108	1-412-060-11	INDUCTOR CHIP 22uH	
D201	8-719-027-50	DIODE MA142WK		L109	1-412-957-11	INDUCTOR 33uH	
D204	8-719-027-50	DIODE MA142WK		L110	1-410-657-21	INDUCTOR CHIP 180uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
D208	8-719-027-50	DIODE MA142WK		L111	1-412-950-11	INDUCTOR 8. 2uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
D216	8-719-027-50	DIODE MA142WK		L112	1-412-280-31	INDUCTOR 330uH	
D217	8-719-404-49	DIODE MA111		L113	1-412-957-11	INDUCTOR 33uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
D218	8-719-800-76	DIODE 1SS226		L114	1-412-282-41	INDUCTOR 470uH	
D321	8-719-045-87	DIODE MA4Z082WA		L115	1-412-280-31	INDUCTOR 330uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
D323	8-719-017-25	DIODE 02DZ13-TPH3 (TR400/TR750)		L116	1-410-657-21	INDUCTOR CHIP 180uH	
D324	8-719-017-25	DIODE 02DZ13-TPH3 (TR400/TR750)		L118	1-410-655-31	INDUCTOR CHIP 120uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
△D501	8-719-421-27	DIODE MA728		L119	1-412-953-11	INDUCTOR 15uH (TR400/TR750)	
D504	8-719-404-49	DIODE MA111		L120	1-412-951-11	INDUCTOR 10uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
D505	8-719-404-49	DIODE MA111		L121	1-412-951-11	INDUCTOR 10uH (TR400/TR750)	
D1251	8-719-027-50	DIODE MA142WK (TR400/TR750)		L122	1-412-058-11	INDUCTOR CHIP 10uH	
D1252	8-719-027-50	DIODE MA142WK (TR400/TR750)		L123	1-412-949-21	INDUCTOR 6. 8uH (TR400/TR750)	
D1253	8-719-045-87	DIODE MA4Z082WA (TR400/TR750)		L201	1-412-963-11	INDUCTOR 100uH (TR400/TR750)	
D1254	8-719-045-87	DIODE MA4Z082WA (TR400/TR750)		L202	1-414-078-11	INDUCTOR 10uH	
D1255	8-719-017-25	DIODE 02DZ13-TPH3 (TR400/TR750)		L203	1-412-955-11	INDUCTOR 22uH	
		< FILTER >		L204	1-412-963-11	INDUCTOR 100uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
FL201	1-236-757-21	FILTER, LOW PASS (C)		L207	1-412-945-11	INDUCTOR 3. 3uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
FL202	1-236-773-21	FILTER, LOW PASS (Y) (TR400/TR750)		L209	1-412-960-21	INDUCTOR 56uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
		< IC >		L213	1-412-953-11	INDUCTOR 15uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
IC102	8-752-069-78	IC CXA1704R		L214	1-412-962-11	INDUCTOR 82uH (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
IC201	8-752-068-58	IC CXA1700R (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		L500	1-414-078-11	INDUCTOR 10uH	
IC201	8-752-069-22	IC CXA1810R (TR400/TR750)		L501	1-414-078-11	INDUCTOR 10uH	
IC203	8-752-351-22	IC CXL5502N		L502	1-414-072-11	INDUCTOR 1uH	
IC204	8-752-351-22	IC CXL5502N (TR400/TR750)		L503	1-412-961-11	INDUCTOR 68uH	
IC205	8-752-053-21	IC CXA1211M		L504	1-414-078-11	INDUCTOR 10uH	
IC207	8-759-031-58	IC SC7SU04F (TR400/TR750)		L506	1-414-078-11	INDUCTOR 10uH	
IC208	8-759-710-07	IC NJM2234M (TR42/TR72/TR82/TR430/TR550)		L951	1-414-078-11	INDUCTOR 10uH	
IC251	8-752-069-60	IC CXA1812Q-T4 (TR70/TR80/TR400/TR750)		L952	1-414-072-11	INDUCTOR 1uH	
IC501	8-759-044-78	IC AK6420F-E1		L1251	1-414-078-11	INDUCTOR 10uH (TR400/TR750)	
IC502	8-759-197-68	IC S-8423DFT		L1252	1-414-078-11	INDUCTOR 10uH (TR70/TR80/TR400/TR750)	
IC503	8-759-267-67	IC MB89098PFV-G-107-BND		L1253	1-412-963-11	INDUCTOR 100uH (TR400/TR750)	
IC505	8-752-851-37	IC CXP87132-009R					
IC506	8-759-169-11	IC CXA1575M-E2					
IC508	8-759-249-80	IC MB4470PFQ-G-BND-ER					
IC951	8-759-169-02	IC MB88344BPFV-G-BND-ER					

The components identified by mark
△ or dotted line with mark △ are
critical for safety.
Replace only with part number
specified.

Les composants identifiés par une
marque △ sont critiques pour la
sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

Ref. No.	Part No.	Description	Amount	Ref. No.	Part No.	Description	Amount
1 (200)	1-754-07-12	CONNECTOR, PLUG (200) 100% 100					
2 (200)	1-404-00-12	CONNECTOR, PLUG TO PLUG 100					
3 (200)	1-754-00-12	CONNECTOR, PLUG TO PLUG 100					
		< 200 >					
1001	1-754-00-12	100% 100% 100%					
		(100% 100% 100% 100% 100% 100%)					
1002	1-754-00-12	100% 100% 100%					
1003	1-754-00-12	100% 100% 100%					
1004	1-754-00-12	100% 100% 100%					
1005	1-754-00-12	100% 100% 100%					
1006	1-754-00-12	100% 100% 100%					
1007	1-754-00-12	100% 100% 100%					
1008	1-754-00-12	100% 100% 100%					
1009	1-754-00-12	100% 100% 100%					
1010	1-754-00-12	100% 100% 100%					
1011	1-754-00-12	100% 100% 100%					
1012	1-754-00-12	100% 100% 100%					
1013	1-754-00-12	100% 100% 100%					
1014	1-754-00-12	100% 100% 100%					
1015	1-754-00-12	100% 100% 100%					
1016	1-754-00-12	100% 100% 100%					
1017	1-754-00-12	100% 100% 100%					
1018	1-754-00-12	100% 100% 100%					
1019	1-754-00-12	100% 100% 100%					
1020	1-754-00-12	100% 100% 100%					
1021	1-754-00-12	100% 100% 100%					
1022	1-754-00-12	100% 100% 100%					
1023	1-754-00-12	100% 100% 100%					
1024	1-754-00-12	100% 100% 100%					
1025	1-754-00-12	100% 100% 100%					
1026	1-754-00-12	100% 100% 100%					
1027	1-754-00-12	100% 100% 100%					
1028	1-754-00-12	100% 100% 100%					
1029	1-754-00-12	100% 100% 100%					
1030	1-754-00-12	100% 100% 100%					
1031	1-754-00-12	100% 100% 100%					
1032	1-754-00-12	100% 100% 100%					
1033	1-754-00-12	100% 100% 100%					
1034	1-754-00-12	100% 100% 100%					
1035	1-754-00-12	100% 100% 100%					
1036	1-754-00-12	100% 100% 100%					
1037	1-754-00-12	100% 100% 100%					
1038	1-754-00-12	100% 100% 100%					
1039	1-754-00-12	100% 100% 100%					
1040	1-754-00-12	100% 100% 100%					
1041	1-754-00-12	100% 100% 100%					
1042	1-754-00-12	100% 100% 100%					
1043	1-754-00-12	100% 100% 100%					
1044	1-754-00-12	100% 100% 100%					
1045	1-754-00-12	100% 100% 100%					
1046	1-754-00-12	100% 100% 100%					
1047	1-754-00-12	100% 100% 100%					
1048	1-754-00-12	100% 100% 100%					
1049	1-754-00-12	100% 100% 100%					
1050	1-754-00-12	100% 100% 100%					
1051	1-754-00-12	100% 100% 100%					
1052	1-754-00-12	100% 100% 100%					
1053	1-754-00-12	100% 100% 100%					
1054	1-754-00-12	100% 100% 100%					
1055	1-754-00-12	100% 100% 100%					
1056	1-754-00-12	100% 100% 100%					
1057	1-754-00-12	100% 100% 100%					
1058	1-754-00-12	100% 100% 100%					
1059	1-754-00-12	100% 100% 100%					
1060	1-754-00-12	100% 100% 100%					
1061	1-754-00-12	100% 100% 100%					
1062	1-754-00-12	100% 100% 100%					
1063	1-754-00-12	100% 100% 100%					
1064	1-754-00-12	100% 100% 100%					
1065	1-754-00-12	100% 100% 100%					
1066	1-754-00-12	100% 100% 100%					
1067	1-754-00-12	100% 100% 100%					
1068	1-754-00-12	100% 100% 100%					
1069	1-754-00-12	100% 100% 100%					
1070	1-754-00-12	100% 100% 100%					
1071	1-754-00-12	100% 100% 100%					
1072	1-754-00-12	100% 100% 100%					
1073	1-754-00-12	100% 100% 100%					
1074	1-754-00-12	100% 100% 100%					
1075	1-754-00-12	100% 100% 100%					
1076	1-754-00-12	100% 100% 100%					
1077	1-754-00-12	100% 100% 100%					
1078	1-754-00-12	100% 100% 100%					
1079	1-754-00-12	100% 100% 100%					
1080	1-754-00-12	100% 100% 100%					
1081	1-754-00-12	100% 100% 100%					
1082	1-754-00-12	100% 100% 100%					
1083	1-754-00-12	100% 100% 100%					
1084	1-754-00-12	100% 100% 100%					
1085	1-754-00-12	100% 100% 100%					
1086	1-754-00-12	100% 100% 100%					
1087	1-754-00-12	100% 100% 100%					
1088	1-754-00-12	100% 100% 100%					
1089	1-754-00-12	100% 100% 100%					
1090	1-754-00-12	100% 100% 100%					
1091	1-754-00-12	100% 100% 100%					
1092	1-754-00-12	100% 100% 100%					
1093	1-754-00-12	100% 100% 100%					
1094	1-754-00-12	100% 100% 100%					
1095	1-754-00-12	100% 100% 100%					
1096	1-754-00-12	100% 100% 100%					
1097	1-754-00-12	100% 100% 100%					
1098	1-754-00-12	100% 100% 100%					
1099	1-754-00-12	100% 100% 100%					
1100	1-754-00-12	100% 100% 100%					

The components supplied by this
 job are listed here with serial & in
 quantity only.

The components supplied by this
 job are listed here with serial & in
 quantity only.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
< IC LINK >							
△PS500	1-576-122-21	LINK, IC CCP2E10 0.4A		Q232	8-729-420-24	TRANSISTOR 2SB1218A (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
△PS501	1-576-122-21	LINK, IC CCP2E10 0.4A		Q234	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
< TRANSISTOR >				Q235	8-729-420-24	TRANSISTOR 2SB1218A	
Q101	8-729-905-23	TRANSISTOR 2SA1576		Q236	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q102	8-729-420-24	TRANSISTOR 2SB1218A		Q237	8-729-402-81	TRANSISTOR XN4501	
Q103	8-729-216-22	TRANSISTOR 2SA1162		Q238	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q104	8-729-230-63	TRANSISTOR 2SC4116		Q240	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q105	8-729-402-42	TRANSISTOR UN5213		Q242	8-729-420-24	TRANSISTOR 2SB1218A (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q106	8-729-402-42	TRANSISTOR UN5213		Q243	8-729-402-42	TRANSISTOR UN5213 (TR400/TR750)	
Q109	8-729-230-63	TRANSISTOR 2SC4116		Q244	8-729-402-42	TRANSISTOR UN5213	
Q111	8-729-015-74	TRANSISTOR UN5111 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		Q245	8-729-403-35	TRANSISTOR UN5113 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q112	8-729-117-73	TRANSISTOR 2SC4178 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		Q246	8-729-402-81	TRANSISTOR XN4501 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q113	8-729-420-24	TRANSISTOR 2SB1218A (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		Q247	8-729-402-42	TRANSISTOR UN5213 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q114	8-729-230-63	TRANSISTOR 2SC4116		Q248	8-729-420-24	TRANSISTOR 2SB1218A (TR400/TR750)	
Q115	8-729-012-50	TRANSISTOR 2SC4400 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		Q249	8-729-230-63	TRANSISTOR 2SC4116 (TR400/TR750)	
Q116	8-729-012-50	TRANSISTOR 2SC4400 (TR400/TR750)		Q253	8-729-025-16	TRANSISTOR UN511D (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q117	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		Q254	8-729-403-35	TRANSISTOR UN5113	
Q118	8-729-420-24	TRANSISTOR 2SB1218A (TR400/TR750)		Q255	8-729-230-63	TRANSISTOR 2SC4116	
Q119	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		Q256	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q120	8-729-402-42	TRANSISTOR UN5213 (TR400/TR750)		Q257	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q121	8-729-012-50	TRANSISTOR 2SC4400 (TR400/TR750)		Q258	8-729-420-24	TRANSISTOR 2SB1218A	
Q124	8-729-230-63	TRANSISTOR 2SC4116 (TR400/TR750)		Q259	8-729-230-63	TRANSISTOR 2SC4116	
Q125	8-729-402-42	TRANSISTOR UN5213 (TR400/TR750)		Q260	8-729-230-63	TRANSISTOR 2SC4116	
Q126	8-729-230-63	TRANSISTOR 2SC4116		Q261	8-729-230-63	TRANSISTOR 2SC4116 (TR42/TR72/TR82/TR430/TR550)	
Q129	8-729-230-63	TRANSISTOR 2SC4116		Q265	8-729-823-16	TRANSISTOR 2SC4555 (TR400/TR750)	
Q132	8-729-230-63	TRANSISTOR 2SC4116		Q266	8-729-402-42	TRANSISTOR UN5213 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q133	8-729-012-50	TRANSISTOR 2SC4400		Q267	8-729-230-63	TRANSISTOR 2SC4116	
Q134	8-729-402-42	TRANSISTOR UN5213		Q500	8-729-420-24	TRANSISTOR 2SB1218A (TR72/TR80/TR400/TR430/TR750)	
Q135	8-729-402-42	TRANSISTOR UN5213		Q501	8-729-403-27	TRANSISTOR XN4401	
Q202	8-729-420-24	TRANSISTOR 2SB1218A		Q502	8-729-120-28	TRANSISTOR 2SC1623	
Q204	8-729-402-42	TRANSISTOR UN5213		Q503	8-729-402-81	TRANSISTOR XN4501	
Q216	8-729-402-42	TRANSISTOR UN5213		Q504	8-729-120-28	TRANSISTOR 2SC1623	
Q217	8-729-420-12	TRANSISTOR XN4213 (TR42/TR70/TR72/TR80/TR82/TR430/TR550)		Q506	8-729-402-42	TRANSISTOR UN5213	
Q219	8-729-230-63	TRANSISTOR 2SC4116		Q507	8-729-120-28	TRANSISTOR 2SC1623	
Q221	8-729-013-15	TRANSISTOR 2SC4909 (TR400/TR750)		Q951	8-729-101-07	TRANSISTOR 2SB798	
Q222	8-729-403-35	TRANSISTOR UN5113 (TR400/TR750)		Q952	8-729-230-63	TRANSISTOR 2SC4116	
Q223	8-729-013-15	TRANSISTOR 2SC4909 (TR400/TR750)		Q956	8-729-230-63	TRANSISTOR 2SC4116	
Q224	8-729-402-42	TRANSISTOR UN5213 (TR400/TR750)					
Q225	8-729-015-76	TRANSISTOR UN5211					
Q226	8-729-807-86	TRANSISTOR 2SB1295					
Q227	8-729-402-42	TRANSISTOR UN5213					
Q228	8-729-807-86	TRANSISTOR 2SB1295					

The components identified by mark
△ or dotted line with mark △ are
critical for safety.
Replace only with part number
specified.

Les composants identifiés par une
marque △ sont critiques pour la
sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

Index Part No. Description

4 IN LENS *

A-7500 1-750-001-00 LENS, 40-DEGREE 4 IN

A-7501 1-750-002-00 LENS, 40-DEGREE 4 IN

4 TELESCOPE *

0-01 0-750-001-00 TELESCOPE 001-00

0-02 0-750-002-00 TELESCOPE 002-00

0-03 0-750-010-00 TELESCOPE 003-00

0-04 0-750-020-00 TELESCOPE 004-00

0-05 0-750-030-00 TELESCOPE 005-00

0-06 0-750-040-00 TELESCOPE 006-00

0-07 0-750-050-00 TELESCOPE 007-00

0-11 0-750-010-00 TELESCOPE 011-00

0-12 0-750-017-00 TELESCOPE 012-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-13 0-750-017-00 TELESCOPE 013-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-14 0-750-020-00 TELESCOPE 014-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-15 0-750-020-00 TELESCOPE 015-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-16 0-750-020-00 TELESCOPE 016-00

0-17 0-750-010-00 TELESCOPE 017-00

0-18 0-750-010-00 TELESCOPE 018-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-19 0-750-010-00 TELESCOPE 019-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-21 0-750-010-00 TELESCOPE 021-00

0-22 0-750-010-00 TELESCOPE 022-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-23 0-750-010-00 TELESCOPE 023-00

0-24 0-750-010-00 TELESCOPE 024-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-25 0-750-010-00 TELESCOPE 025-00

0-26 0-750-010-00 TELESCOPE 026-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-27 0-750-010-00 TELESCOPE 027-00

0-28 0-750-010-00 TELESCOPE 028-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-29 0-750-010-00 TELESCOPE 029-00

0-30 0-750-010-00 TELESCOPE 030-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-31 0-750-010-00 TELESCOPE 031-00

0-32 0-750-010-00 TELESCOPE 032-00

0-33 0-750-010-00 TELESCOPE 033-00

0-34 0-750-010-00 TELESCOPE 034-00

0-35 0-750-010-00 TELESCOPE 035-00

0-36 0-750-010-00 TELESCOPE 036-00

0-37 0-750-010-00 TELESCOPE 037-00

0-38 0-750-010-00 TELESCOPE 038-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-39 0-750-010-00 TELESCOPE 039-00

0-40 0-750-010-00 TELESCOPE 040-00

0-41 0-750-010-00 TELESCOPE 041-00

0-42 0-750-010-00 TELESCOPE 042-00

0-43 0-750-010-00 TELESCOPE 043-00

0-44 0-750-010-00 TELESCOPE 044-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-45 0-750-010-00 TELESCOPE 045-00

0-46 0-750-010-00 TELESCOPE 046-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-47 0-750-010-00 TELESCOPE 047-00

0-48 0-750-010-00 TELESCOPE 048-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-49 0-750-010-00 TELESCOPE 049-00

0-50 0-750-010-00 TELESCOPE 050-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-51 0-750-010-00 TELESCOPE 051-00

0-52 0-750-010-00 TELESCOPE 052-00

0-53 0-750-010-00 TELESCOPE 053-00

0-54 0-750-010-00 TELESCOPE 054-00

0-55 0-750-010-00 TELESCOPE 055-00

Index Part No. Description

0-56 0-750-010-00 TELESCOPE 056-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-57 0-750-010-00 TELESCOPE 057-00

0-58 0-750-010-00 TELESCOPE 058-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-59 0-750-010-00 TELESCOPE 059-00

0-60 0-750-010-00 TELESCOPE 060-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-61 0-750-010-00 TELESCOPE 061-00

0-62 0-750-010-00 TELESCOPE 062-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-63 0-750-010-00 TELESCOPE 063-00

0-64 0-750-010-00 TELESCOPE 064-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-65 0-750-010-00 TELESCOPE 065-00

0-66 0-750-010-00 TELESCOPE 066-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-67 0-750-010-00 TELESCOPE 067-00

0-68 0-750-010-00 TELESCOPE 068-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-69 0-750-010-00 TELESCOPE 069-00

0-70 0-750-010-00 TELESCOPE 070-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-71 0-750-010-00 TELESCOPE 071-00

0-72 0-750-010-00 TELESCOPE 072-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-73 0-750-010-00 TELESCOPE 073-00

0-74 0-750-010-00 TELESCOPE 074-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-75 0-750-010-00 TELESCOPE 075-00

0-76 0-750-010-00 TELESCOPE 076-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-77 0-750-010-00 TELESCOPE 077-00

0-78 0-750-010-00 TELESCOPE 078-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-79 0-750-010-00 TELESCOPE 079-00

0-80 0-750-010-00 TELESCOPE 080-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-81 0-750-010-00 TELESCOPE 081-00

0-82 0-750-010-00 TELESCOPE 082-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-83 0-750-010-00 TELESCOPE 083-00

0-84 0-750-010-00 TELESCOPE 084-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-85 0-750-010-00 TELESCOPE 085-00

0-86 0-750-010-00 TELESCOPE 086-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-87 0-750-010-00 TELESCOPE 087-00

0-88 0-750-010-00 TELESCOPE 088-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-89 0-750-010-00 TELESCOPE 089-00

0-90 0-750-010-00 TELESCOPE 090-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-91 0-750-010-00 TELESCOPE 091-00

0-92 0-750-010-00 TELESCOPE 092-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-93 0-750-010-00 TELESCOPE 093-00

0-94 0-750-010-00 TELESCOPE 094-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-95 0-750-010-00 TELESCOPE 095-00

0-96 0-750-010-00 TELESCOPE 096-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-97 0-750-010-00 TELESCOPE 097-00

0-98 0-750-010-00 TELESCOPE 098-00 (CHAL, THT, THT, THT, THT, THT, THT)

0-99 0-750-010-00 TELESCOPE 099-00

1-00 0-750-010-00 TELESCOPE 100-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-01 0-750-010-00 TELESCOPE 101-00

1-02 0-750-010-00 TELESCOPE 102-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-03 0-750-010-00 TELESCOPE 103-00

1-04 0-750-010-00 TELESCOPE 104-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-05 0-750-010-00 TELESCOPE 105-00

1-06 0-750-010-00 TELESCOPE 106-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-07 0-750-010-00 TELESCOPE 107-00

1-08 0-750-010-00 TELESCOPE 108-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-09 0-750-010-00 TELESCOPE 109-00

1-10 0-750-010-00 TELESCOPE 110-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-11 0-750-010-00 TELESCOPE 111-00

1-12 0-750-010-00 TELESCOPE 112-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-13 0-750-010-00 TELESCOPE 113-00

1-14 0-750-010-00 TELESCOPE 114-00 (CHAL, THT, THT, THT, THT, THT, THT)

1-15 0-750-010-00 TELESCOPE 115-00

For component identification, see
A or B data file with part no. and
quantity in table.
Revised, only parts past revision
specimens.

See component identifier on end
drawing. It was different part no.
specimens.
The last numbers are not plus
specimens to make a part.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
Q958	8-729-230-63	TRANSISTOR	2SC4116 (TR42/TR72/TR82/TR430/TR550)	R130	1-216-823-11	METAL CHIP 1.5K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q960	8-729-230-63	TRANSISTOR	2SC4116 (TR42/TR72/TR82/TR430/TR550)	R132	1-216-823-11	METAL CHIP 1.5K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q1252	8-729-402-42	TRANSISTOR	UN5213 (TR400/TR750)	R133	1-216-819-11	METAL CHIP 680 5% 1/16W	
Q1253	8-729-823-16	TRANSISTOR	2SC4555 (TR400/TR750)	R134	1-216-834-11	METAL CHIP 12K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q1254	8-729-823-16	TRANSISTOR	2SC4555 (TR400/TR750)	R135	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q1257	8-729-420-24	TRANSISTOR	2SB1218A (TR70/TR80)	R136	1-216-820-11	METAL CHIP 820 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q1258	8-729-230-63	TRANSISTOR	2SC4116 (TR400/TR750)	R137	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
Q1259	8-729-420-20	TRANSISTOR	XN4312 (TR400/TR750)				
< RESISTOR >				R138	1-216-835-11	METAL CHIP 15K 5% 1/16W	
R101	1-216-864-11	METAL CHIP	0 5% 1/16W	R139	1-216-839-11	METAL CHIP 33K 5% 1/16W	
R102	1-216-837-11	METAL CHIP	22K 5% 1/16W	R140	1-216-813-11	METAL CHIP 220 5% 1/16W	
R103	1-216-839-11	METAL CHIP	33K 5% 1/16W	R141	1-216-817-11	METAL CHIP 470 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R104	1-216-815-11	METAL CHIP	330 5% 1/16W (TR400/TR750)	R142	1-216-818-11	METAL CHIP 560 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R104	1-216-819-11	METAL CHIP	680 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R143	1-216-808-11	METAL CHIP 82 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R105	1-216-816-11	METAL CHIP	390 5% 1/16W (TR400/TR750)	R144	1-216-818-11	METAL CHIP 560 5% 1/16W	
R105	1-216-819-11	METAL CHIP	680 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R146	1-216-809-11	METAL CHIP 100 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R106	1-216-814-11	METAL CHIP	270 5% 1/16W	R147	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R107	1-216-813-11	METAL CHIP	220 5% 1/16W	R148	1-216-813-11	METAL CHIP 220 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R108	1-216-800-11	METAL GLAZE	18 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R149	1-216-813-11	METAL CHIP 220 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R108	1-216-801-11	METAL CHIP	22 5% 1/16W (TR400/TR750)	R150	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R109	1-216-803-11	METAL CHIP	33 5% 1/16W (TR400/TR750)	R151	1-216-823-11	METAL CHIP 1.5K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R109	1-216-804-11	METAL CHIP	39 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R152	1-216-824-11	METAL CHIP 1.8K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R110	1-216-818-11	METAL CHIP	560 5% 1/16W	R153	1-216-830-11	METAL CHIP 5.6K 5% 1/16W (TR42/TR70/TR82/TR550)	
R111	1-218-875-11	METAL CHIP	15K 0.50% 1/16W	R153	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR72/TR80/TR400/TR430/TR750)	
R112	1-216-836-11	METAL CHIP	18K 5% 1/16W	R154	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R114	1-216-828-11	METAL CHIP	3.9K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R155	1-216-820-11	METAL CHIP 820 5% 1/16W (TR400/TR750)	
R114	1-216-829-11	METAL CHIP	4.7K 5% 1/16W (TR400/TR750)	R156	1-216-817-11	METAL CHIP 470 5% 1/16W (TR400/TR750)	
R118	1-216-836-11	METAL CHIP	18K 5% 1/16W	R157	1-216-817-11	METAL CHIP 470 5% 1/16W (TR400/TR750)	
R119	1-216-864-11	METAL CHIP	0 5% 1/16W	R158	1-216-836-11	METAL CHIP 18K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R120	1-216-831-11	METAL CHIP	6.8K 5% 1/16W	R159	1-216-836-11	METAL CHIP 18K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R122	1-216-853-11	METAL CHIP	470K 5% 1/16W	R160	1-216-818-11	METAL CHIP 560 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R123	1-216-833-11	METAL CHIP	10K 5% 1/16W (TR72/TR80/TR400/TR430/TR750)				
R123	1-216-836-11	METAL CHIP	18K 5% 1/16W (TR42/TR70/TR82/TR550)				
R124	1-216-864-11	METAL CHIP	0 5% 1/16W				
R126	1-216-837-11	METAL CHIP	22K 5% 1/16W				
R127	1-216-837-11	METAL CHIP	22K 5% 1/16W				
R128	1-216-825-11	METAL CHIP	2.2K 5% 1/16W				

VS-104**VS-112**

Ref. No.	Part No.	Description	Remark
R161	1-216-817-11	METAL CHIP 470 5% 1/16W (TR400/TR750)	
R162	1-216-818-11	METAL CHIP 560 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R163	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R164	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R165	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R166	1-216-816-11	METAL CHIP 390 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R167	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR400/TR750)	
R168	1-216-815-11	METAL CHIP 330 5% 1/16W (TR400/TR750)	
R169	1-216-816-11	METAL CHIP 390 5% 1/16W (TR400/TR750)	
R170	1-216-822-11	METAL CHIP 1.2K 5% 1/16W (TR400/TR750)	
R171	1-216-823-11	METAL CHIP 1.5K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R173	1-216-828-11	METAL CHIP 3.9K 5% 1/16W (TR400/TR750)	
R174	1-216-816-11	METAL CHIP 390 5% 1/16W (TR400/TR750)	
R175	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R178	1-216-809-11	METAL CHIP 100 5% 1/16W	
R179	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R180	1-216-809-11	METAL CHIP 100 5% 1/16W	
R181	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R182	1-216-864-11	METAL CHIP 0 5% 1/16W (TR400/TR750)	
R185	1-216-847-11	METAL CHIP 150K 5% 1/16W	
R186	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R187	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R188	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R189	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R190	1-216-817-11	METAL CHIP 470 5% 1/16W (TR400/TR750)	
R191	1-216-815-11	METAL CHIP 330 5% 1/16W (TR400/TR750)	
R193	1-216-815-11	METAL CHIP 330 5% 1/16W	
R194	1-216-818-11	METAL CHIP 560 5% 1/16W	
R195	1-216-839-11	METAL CHIP 33K 5% 1/16W	
R196	1-216-836-11	METAL CHIP 18K 5% 1/16W	
R197	1-216-864-11	METAL CHIP 0 5% 1/16W	
R198	1-216-864-11	METAL CHIP 0 5% 1/16W (TR70/TR80)	
R199	1-216-864-11	METAL CHIP 0 5% 1/16W (TR70/TR80)	
R200	1-216-864-11	METAL CHIP 0 5% 1/16W (TR400/TR750)	

Ref. No.	Part No.	Description	Remark
R201	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R202	1-216-832-11	METAL CHIP 8.2K 5% 1/16W	
R203	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R205	1-216-864-11	METAL CHIP 0 5% 1/16W	
R206	1-216-817-11	METAL CHIP 470 5% 1/16W (TR400/TR750)	
R206	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R207	1-216-804-11	METAL CHIP 39 5% 1/16W	
R208	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR400/TR750)	
R209	1-216-814-11	METAL CHIP 270 5% 1/16W	
R210	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R211	1-216-803-11	METAL CHIP 33 5% 1/16W	
R213	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R214	1-216-828-11	METAL CHIP 3.9K 5% 1/16W	
R215	1-216-819-11	METAL CHIP 680 5% 1/16W	
R216	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R218	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R219	1-216-831-11	METAL CHIP 6.8K 5% 1/16W	
R220	1-216-829-11	METAL CHIP 4.7K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
R221	1-216-829-11	METAL CHIP 4.7K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
R222	1-216-829-11	METAL CHIP 4.7K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
R223	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	
R224	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R226	1-216-831-11	METAL CHIP 6.8K 5% 1/16W	
R230	1-216-830-11	METAL CHIP 5.6K 5% 1/16W	
R231	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R232	1-216-830-11	METAL CHIP 5.6K 5% 1/16W	
R234	1-216-864-11	METAL CHIP 0 5% 1/16W	
R235	1-218-877-11	METAL CHIP 18K 0.50% 1/16W	
R241	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R245	1-216-829-11	METAL CHIP 4.7K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R246	1-216-819-11	METAL CHIP 680 5% 1/16W	
R247	1-216-815-11	METAL CHIP 330 5% 1/16W	
R253	1-218-849-11	METAL CHIP 1.2K 0.50% 1/16W	
R255	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R256	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R259	1-218-859-11	METAL CHIP 3.3K 0.50% 1/16W	
R261	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R262	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R263	1-218-839-11	METAL GLAZE 470 0.50% 1/16W	
R264	1-216-828-11	METAL CHIP 3.9K 5% 1/16W (TR400/TR750)	
R265	1-216-818-11	METAL CHIP 560 5% 1/16W	
R266	1-218-837-11	METAL GLAZE 390 0.50% 1/16W (TR400/TR750)	

Ref. No.	Part No.	Description	QTY	Unit	Price	Ref. No.	Part No.	Description	QTY	Unit	Price
0001	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0001	1-000-001-01	WHEEL, CTR	1.75	EA	1.7500
		(CHASSIS/FRAME)				0002	1-000-001-01	WHEEL, CTR	0.80	EA	1.7500
0002	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0003	1-000-001-01	WHEEL, CTR	0.75	EA	1.7500
		(CHASSIS/FRAME/VEHICLE/VEHICLE/VEHICLE/VEHICLE)				0004	1-000-001-01	WHEEL, CTR	1	EA	1.7500
0003	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0005	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME/VEHICLE/VEHICLE/VEHICLE/VEHICLE)				0006	1-000-001-01	WHEEL, CTR	1	EA	1.7500
0004	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0007	1-000-001-01	WHEEL, CTR	1	EA	1.7500
		(CHASSIS/FRAME/VEHICLE/VEHICLE/VEHICLE/VEHICLE)				0008	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0005	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0009	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME/VEHICLE/VEHICLE/VEHICLE/VEHICLE)				0010	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0006	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0011	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME/VEHICLE/VEHICLE/VEHICLE/VEHICLE)				0012	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0007	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0013	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0014	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0008	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0015	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0016	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0009	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0017	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0018	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0010	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0019	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0020	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0011	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0021	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME/VEHICLE/VEHICLE/VEHICLE/VEHICLE)				0022	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0012	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0023	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME/VEHICLE/VEHICLE/VEHICLE/VEHICLE)				0024	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0013	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0025	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0026	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0014	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0027	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0028	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0015	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0029	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0030	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0016	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0031	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0032	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0017	1-000-001-01	WHEEL, CTR	100	EA	1.7500	0033	1-000-001-01	WHEEL, CTR	100	EA	1.7500
		(CHASSIS/FRAME)				0034	1-000-001-01	WHEEL, CTR	100	EA	1.7500
0018	1-000-001-01	WHEEL, CTR	100	EA	1.7500</						

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R272	1-216-826-11	METAL CHIP	2.7K 5% 1/16W	R318	1-216-820-11	METAL CHIP 820 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R273	1-216-830-11	METAL CHIP	5.6K 5% 1/16W	R319	1-216-818-11	METAL CHIP 560 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R274	1-216-823-11	METAL CHIP	1.5K 5% 1/16W	R321	1-216-813-11	METAL CHIP 220 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R275	1-216-295-00	METAL CHIP	0 5% 1/10W	R322	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R276	1-216-296-00	METAL CHIP	0 5% 1/8W	R323	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R277	1-216-295-00	METAL CHIP	0 5% 1/10W (TR400/TR750)	R324	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R278	1-216-296-00	METAL CHIP	0 5% 1/8W (TR400/TR750)	R325	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R279	1-216-819-11	METAL CHIP	680 5% 1/16W	R326	1-216-813-11	METAL CHIP 220 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R280	1-216-841-11	METAL CHIP	47K 5% 1/16W	R328	1-216-820-11	METAL CHIP 820 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R281	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR80/TR400/TR750)	R329	1-216-833-11	METAL CHIP 10K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R282	1-216-827-11	METAL CHIP	3.3K 5% 1/16W	R331	1-216-825-11	METAL CHIP 2.2K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R283	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R333	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R285	1-216-857-11	METAL CHIP	1M 5% 1/16W	R334	1-216-815-11	METAL CHIP 330 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R286	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R338	1-216-812-11	METAL CHIP 180 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R288	1-216-844-11	METAL CHIP	82K 5% 1/16W	R339	1-216-827-11	METAL CHIP 3.3K 5% 1/16W	
R289	1-216-821-11	METAL CHIP	1K 5% 1/16W	R342	1-216-831-11	METAL CHIP 6.8K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R290	1-216-864-11	METAL CHIP	0 5% 1/16W	R343	1-216-853-11	METAL CHIP 470K 5% 1/16W (TR400/TR750)	
R291	1-216-833-11	METAL CHIP	10K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R346	1-216-857-11	METAL CHIP 1M 5% 1/16W (TR400/TR750)	
R293	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR400/TR750)	R347	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R295	1-216-864-11	METAL CHIP	0 5% 1/16W	R348	1-216-839-11	METAL CHIP 33K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R296	1-216-815-11	METAL CHIP	330 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R349	1-216-864-11	METAL CHIP 0 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R297	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R350	1-216-844-11	METAL CHIP 82K 5% 1/16W (TR400/TR750)	
R300	1-216-817-11	METAL CHIP	470 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R351	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR400/TR750)	
R302	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R354	1-216-825-11	METAL CHIP 2.2K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R303	1-216-810-11	METAL CHIP	120 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R355	1-216-842-11	METAL CHIP 56K 5% 1/16W (TR400/TR750)	
R304	1-216-833-11	METAL CHIP	10K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R356	1-216-839-11	METAL CHIP 33K 5% 1/16W (TR400/TR750)	
R305	1-216-820-11	METAL CHIP	820 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R357	1-216-829-11	METAL CHIP 4.7K 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
R307	1-216-813-11	METAL CHIP	220 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	R358	1-216-821-11	METAL CHIP 1K 5% 1/16W (TR400/TR750)	
R308	1-216-842-11	METAL CHIP	56K 5% 1/16W	R359	1-216-817-11	METAL CHIP 470 5% 1/16W (TR400/TR750)	
R309	1-216-839-11	METAL CHIP	33K 5% 1/16W	R360	1-216-826-11	METAL CHIP 2.7K 5% 1/16W (TR400/TR750)	
R312	1-216-821-11	METAL CHIP	1K 5% 1/16W	R361	1-216-825-11	METAL CHIP 2.2K 5% 1/16W (TR400/TR750)	
R313	1-216-817-11	METAL CHIP	470 5% 1/16W				
R314	1-216-864-11	METAL CHIP	0 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)				
R315	1-216-821-11	METAL CHIP	1K 5% 1/16W				
R316	1-216-815-11	METAL CHIP	330 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)				
R317	1-216-820-11	METAL CHIP	820 5% 1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)				

Ref. No.	Part. No.	Description	QTY	UNIT	PRICE
0001	1-000-000-01	WHEEL, COT	1.00	EA	1.00
0002	1-000-000-02	WHEEL, COT	1.00	EA	1.00
0003	1-000-000-03	WHEEL, COT	1.00	EA	1.00
0004	1-000-000-04	WHEEL, COT	0	EA	1.00
0005	1-000-000-05	WHEEL, COT	0	EA	1.00
0006	1-000-000-06	WHEEL, COT	0	EA	1.00
0007	1-000-000-07	WHEEL, COT	0	EA	1.00
0008	1-000-000-08	WHEEL, COT	0	EA	1.00
0009	1-000-000-09	WHEEL, COT	0	EA	1.00
0010	1-000-000-10	WHEEL, COT	0	EA	1.00
0011	1-000-000-11	WHEEL, COT	0	EA	1.00
0012	1-000-000-12	WHEEL, COT	0	EA	1.00
0013	1-000-000-13	WHEEL, COT	0	EA	1.00
0014	1-000-000-14	WHEEL, COT	0	EA	1.00
0015	1-000-000-15	WHEEL, COT	0	EA	1.00
0016	1-000-000-16	WHEEL, COT	0	EA	1.00
0017	1-000-000-17	WHEEL, COT	0	EA	1.00
0018	1-000-000-18	WHEEL, COT	0	EA	1.00
0019	1-000-000-19	WHEEL, COT	0	EA	1.00
0020	1-000-000-20	WHEEL, COT	0	EA	1.00
0021	1-000-000-21	WHEEL, COT	0	EA	1.00
0022	1-000-000-22	WHEEL, COT	0	EA	1.00
0023	1-000-000-23	WHEEL, COT	0	EA	1.00
0024	1-000-000-24	WHEEL, COT	0	EA	1.00
0025	1-000-000-25	WHEEL, COT	0	EA	1.00
0026	1-000-000-26	WHEEL, COT	0	EA	1.00
0027	1-000-000-27	WHEEL, COT	0	EA	1.00
0028	1-000-000-28	WHEEL, COT	0	EA	1.00
0029	1-000-000-29	WHEEL, COT	0	EA	1.00
0030	1-000-000-30	WHEEL, COT	0	EA	1.00
0031	1-000-000-31	WHEEL, COT	0	EA	1.00
0032	1-000-000-32	WHEEL, COT	0	EA	1.00
0033	1-000-000-33	WHEEL, COT	0	EA	1.00
0034	1-000-000-34	WHEEL, COT	0	EA	1.00
0035	1-000-000-35	WHEEL, COT	0	EA	1.00
0036	1-000-000-36	WHEEL, COT	0	EA	1.00
0037	1-000-000-37	WHEEL, COT	0	EA	1.00
0038	1-000-000-38	WHEEL, COT	0	EA	1.00
0039	1-000-000-39	WHEEL, COT	0	EA	1.00
0040	1-000-000-40	WHEEL, COT	0	EA	1.00
0041	1-000-000-41	WHEEL, COT	0	EA	1.00
0042	1-000-000-42	WHEEL, COT	0	EA	1.00
0043	1-000-000-43	WHEEL, COT	0	EA	1.00
0044	1-000-000-44	WHEEL, COT	0	EA	1.00
0045	1-000-000-45	WHEEL, COT	0	EA	1.00
0046	1-000-000-46	WHEEL, COT	0	EA	1.00
0047	1-000-000-47	WHEEL, COT	0	EA	1.00
0048	1-000-000-48	WHEEL, COT	0	EA	1.00
0049	1-000-000-49	WHEEL, COT	0	EA	1.00
0050	1-000-000-50	WHEEL, COT	0	EA	1.00
0051	1-000-000-51	WHEEL, COT	0	EA	1.00
0052	1-000-000-52	WHEEL, COT	0	EA	1.00
0053	1-000-000-53	WHEEL, COT	0	EA	1.00
0054	1-000-000-54	WHEEL, COT	0	EA	1.00
0055	1-000-000-55	WHEEL, COT	0	EA	1.00
0056	1-000-000-56	WHEEL, COT	0	EA	1.00
0057	1-000-000-57	WHEEL, COT	0	EA	1.00
0058	1-000-000-58	WHEEL, COT	0	EA	1.00
0059	1-000-000-59	WHEEL, COT	0	EA	1.00
0060	1-000-000-60	WHEEL, COT	0	EA	1.00
0061	1-000-000-61	WHEEL, COT	0	EA	1.00
0062	1-000-000-62	WHEEL, COT	0	EA	1.00
0063	1-000-000-63	WHEEL, COT	0	EA	1.00
0064	1-000-000-64	WHEEL, COT	0	EA	1.0

Alt. No.	Part No.	Item Name	QTY	UNIT	PRICE
0000	1-000-000-01	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-02	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-03	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-04	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	1.00	sq	1.7000
0000	1-000-000-05	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	1.00	sq	1.7000
0000	1-000-000-06	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	10	sq	1.7000
0000	1-000-000-07	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	10	sq	1.7000
0000	1-000-000-08	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-09	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-10	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-11	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	10	sq	1.7000
0000	1-000-000-12	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-13	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-14	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-15	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-16	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-17	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-18	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-19	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-20	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-21	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-22	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-23	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-24	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-25	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-26	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-27	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-28	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-29	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-30	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-31	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000
0000	1-000-000-32	WALL, CIP (CIP, 100% FILL, 100% REINFORCED)	100	sq	1.7000

VS-104**VS-112**

Ref. No.	Part No.	Description	Remark		
R362	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W (TR400/TR750)
R363	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W (TR400/TR750)
R364	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)
R366	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR70/TR72/TR80/TR82/TR430/TR550)
R368	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R373	1-216-833-11	METAL CHIP	10K	5%	1/16W
R375	1-216-864-11	METAL CHIP	0	5%	1/16W (TR400/TR750)
R377	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR72/TR82/TR430/TR550)
R378	1-216-864-11	METAL CHIP	0	5%	1/16W (TR42/TR72/TR82/TR430/TR550)
R380	1-216-837-11	METAL CHIP	22K	5%	1/16W
R381	1-216-837-11	METAL CHIP	22K	5%	1/16W
R383	1-216-842-11	METAL CHIP	56K	5%	1/16W
R387	1-216-825-11	METAL CHIP	2. 2K	5%	1/16W
R391	1-216-864-11	METAL CHIP	0	5%	1/16W
R398	1-216-821-11	METAL CHIP	1K	5%	1/16W
R399	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R500	1-216-841-11	METAL CHIP	47K	5%	1/16W
R501	1-216-833-11	METAL CHIP	10K	5%	1/16W
R502	1-216-295-00	METAL CHIP	0	5%	1/10W
R503	1-216-841-11	METAL CHIP	47K	5%	1/16W
R505	1-216-864-11	METAL CHIP	0	5%	1/16W
R506	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W (TR70/TR80)
R506	1-216-841-11	METAL CHIP	47K	5%	1/16W (TR42/TR72/TR82/TR400/TR430/TR550/TR750)
R507	1-216-857-11	METAL CHIP	1M	5%	1/16W
R508	1-216-821-11	METAL CHIP	1K	5%	1/16W
R509	1-216-851-11	METAL CHIP	330K	5%	1/16W
R510	1-216-841-11	METAL CHIP	47K	5%	1/16W
R511	1-216-839-11	METAL CHIP	33K	5%	1/16W
R512	1-216-837-11	METAL CHIP	22K	5%	1/16W
R513	1-216-837-11	METAL CHIP	22K	5%	1/16W
R514	1-216-845-11	METAL CHIP	100K	5%	1/16W
R515	1-216-853-11	METAL CHIP	470K	5%	1/16W
R517	1-216-821-11	METAL CHIP	1K	5%	1/16W
R518	1-216-857-11	METAL CHIP	1M	5%	1/16W
R519	1-216-817-11	METAL CHIP	470	5%	1/16W
R520	1-216-845-11	METAL CHIP	100K	5%	1/16W
R522	1-216-841-11	METAL CHIP	47K	5%	1/16W
R523	1-216-831-11	METAL CHIP	6. 8K	5%	1/16W
R525	1-216-853-11	METAL CHIP	470K	5%	1/16W
R526	1-216-841-11	METAL CHIP	47K	5%	1/16W
R527	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R528	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R529	1-216-845-11	METAL CHIP	100K	5%	1/16W

Ref. No.	Part No.	Description	Remark		
R530	1-216-019-00	METAL CHIP	56	5%	1/10W
R531	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R532	1-216-833-11	METAL CHIP	10K	5%	1/16W
R533	1-217-671-11	METAL CHIP	1	5%	1/10W
R534	1-217-671-11	METAL CHIP	1	5%	1/10W
R535	1-217-671-11	METAL CHIP	1	5%	1/10W
R536	1-217-671-11	METAL CHIP	1	5%	1/10W
R537	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R538	1-216-821-11	METAL CHIP	1K	5%	1/16W
R539	1-216-841-11	METAL CHIP	47K	5%	1/16W
R540	1-216-829-11	METAL CHIP	4. 7K	5%	1/16W
R541	1-216-835-11	METAL CHIP	15K	5%	1/16W
R542	1-216-864-11	METAL CHIP	0	5%	1/16W
R543	1-216-864-11	METAL CHIP	0	5%	1/16W
R544	1-216-833-11	METAL CHIP	10K	5%	1/16W
R546	1-216-833-11	METAL CHIP	10K	5%	1/16W
R548	1-216-845-11	METAL CHIP	100K	5%	1/16W
R549	1-216-821-11	METAL CHIP	1K	5%	1/16W
R550	1-216-841-11	METAL CHIP	47K	5%	1/16W
R551	1-216-864-11	METAL CHIP	0	5%	1/16W
R552	1-216-833-11	METAL CHIP	10K	5%	1/16W
R553	1-216-821-11	METAL CHIP	1K	5%	1/16W
R554	1-216-841-11	METAL CHIP	47K	5%	1/16W
R555	1-216-864-11	METAL CHIP	0	5%	1/16W
R556	1-216-841-11	METAL CHIP	47K	5%	1/16W
R558	1-216-841-11	METAL CHIP	47K	5%	1/16W
R560	1-216-296-00	METAL CHIP	0	5%	1/8W
R561	1-216-833-11	METAL CHIP	10K	5%	1/16W
R562	1-216-851-11	METAL CHIP	330K	5%	1/16W
R563	1-216-841-11	METAL CHIP	47K	5%	1/16W
R567	1-216-821-11	METAL CHIP	1K	5%	1/16W
R569	1-216-845-11	METAL CHIP	100K	5%	1/16W (TR72/TR80/TR400/TR430/TR750)
R570	1-216-821-11	METAL CHIP	1K	5%	1/16W
R572	1-216-841-11	METAL CHIP	47K	5%	1/16W
R573	1-216-845-11	METAL CHIP	100K	5%	1/16W
R575	1-216-864-11	METAL CHIP	0	5%	1/16W
R577	1-216-845-11	METAL CHIP	100K	5%	1/16W
R578	1-216-833-11	METAL CHIP	10K	5%	1/16W
R579	1-216-864-11	METAL CHIP	0	5%	1/16W
R580	1-216-845-11	METAL CHIP	100K	5%	1/16W
R581	1-216-821-11	METAL CHIP	1K	5%	1/16W
R582	1-216-821-11	METAL CHIP	1K	5%	1/16W
R583	1-216-833-11	METAL CHIP	10K	5%	1/16W (TR42/TR70/TR82/TR550)
R584	1-216-864-11	METAL CHIP	0	5%	1/16W
R585	1-216-821-11	METAL CHIP	1K	5%	1/16W
R586	1-216-849-11	METAL CHIP	220K	5%	1/16W
R587	1-216-853-11	METAL CHIP	470K	5%	1/16W
R588	1-216-827-11	METAL CHIP	3. 3K	5%	1/16W

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R589	1-216-864-11	METAL CHIP	0 5% 1/16W	R1270	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR80/TR400/TR750)
R591	1-216-821-11	METAL CHIP	1K 5% 1/16W	R1279	1-216-837-11	METAL CHIP	22K 5% 1/16W (TR400/TR750)
R592	1-216-841-11	METAL CHIP	47K 5% 1/16W	R1280	1-216-837-11	METAL CHIP	22K 5% 1/16W (TR400/TR750)
R593	1-216-845-11	METAL CHIP	100K 5% 1/16W	R1281	1-216-829-11	METAL CHIP	4.7K 5% 1/16W (TR400/TR750)
R594	1-216-821-11	METAL CHIP	1K 5% 1/16W	R1282	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR400/TR750)
R595	1-216-821-11	METAL CHIP	1K 5% 1/16W				
R596	1-216-833-11	METAL CHIP	10K 5% 1/16W				
R597	1-216-821-11	METAL CHIP	1K 5% 1/16W				
R943	1-216-864-11	METAL CHIP	0 5% 1/16W (TR80)	R1283	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR80)
R954	1-216-138-00	METAL CHIP	3.3 5% 1/8W	R1284	1-216-864-11	METAL CHIP	0 5% 1/16W (TR400/TR750)
R955	1-216-830-11	METAL CHIP	5.6K 5% 1/16W	R1285	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR80)
R956	1-216-836-11	METAL CHIP	18K 5% 1/16W	R1286	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR400/TR750)
R957	1-216-820-11	METAL CHIP	820 5% 1/16W	R1287	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR400/TR750)
R961	1-216-818-11	METAL CHIP	560 5% 1/16W				
R962	1-216-837-11	METAL CHIP	22K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R1400	1-216-864-11	METAL CHIP	0 5% 1/16W
R964	1-216-822-11	METAL CHIP	1.2K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R1401	1-216-864-11	METAL CHIP	0 5% 1/16W
R965	1-216-826-11	METAL CHIP	2.7K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R1403	1-216-845-11	METAL CHIP	100K 5% 1/16W
R966	1-216-826-11	METAL CHIP	2.7K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R1404	1-216-845-11	METAL CHIP	100K 5% 1/16W
R967	1-216-832-11	METAL CHIP	8.2K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	R1406	1-216-821-11	METAL CHIP	1K 5% 1/16W
R968	1-216-834-11	METAL CHIP	12K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	< NETWORK >			
R972	1-216-823-11	METAL CHIP	1.5K 5% 1/16W (TR42/TR72/TR82/TR430/TR550)	RB199	1-236-971-11	NETWORK, RES 0	(TR70/TR80)
R1251	1-216-829-11	METAL CHIP	4.7K 5% 1/16W (TR400/TR750)	RB500	1-236-436-11	NETWORK, RES 100K	
R1252	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR80)	RB501	1-236-432-11	NETWORK, RES 47K	
R1254	1-216-864-11	METAL CHIP	0 5% 1/16W (TR70/TR80)	RB502	1-236-971-11	NETWORK, RES 0	
R1276	1-216-829-11	METAL CHIP	4.7K 5% 1/16W (TR70/TR80)	RB503	1-236-432-11	NETWORK, RES 47K	
R1277	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR70/TR80)	RB504	1-236-412-11	NETWORK, RES 1.0K	
R1278	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (TR70/TR80)	RB505	1-236-412-11	NETWORK, RES 1.0K	
R1259	1-216-821-11	METAL CHIP	1K 5% 1/16W (TR400/TR750)	RB506	1-236-412-11	NETWORK, RES 1.0K	
R1260	1-216-815-11	METAL CHIP	330 5% 1/16W (TR400/TR750)	RB507	1-236-448-11	NETWORK, RES 1.0M	
R1265	1-216-804-11	METAL CHIP	39 5% 1/16W (TR400/TR750)	RB508	1-236-436-11	NETWORK, RES 100K	
R1266	1-216-803-11	METAL CHIP	33 5% 1/16W (TR400/TR750)	RB509	1-236-444-11	NETWORK, RES 470K	
R1267	1-216-804-11	METAL CHIP	39 5% 1/16W (TR400/TR750)	RB510	1-236-412-11	NETWORK, RES 1.0K	
R1268	1-216-803-11	METAL CHIP	33 5% 1/16W (TR400/TR750)	RB512	1-236-412-11	NETWORK, RES 1.0K	
				RB513	1-236-971-11	NETWORK, RES 0	
				RB514	1-236-907-11	RESISTOR, NETWORK (CHIP TYPE) 100K	
				RB515	1-236-904-11	RESISTOR, NETWORK (CHIP TYPE) 1K	
				RB516	1-236-904-11	RESISTOR, NETWORK (CHIP TYPE) 1K	
				RB518	1-236-971-11	NETWORK, RES 0	
				RB519	1-236-971-11	NETWORK, RES 0	
				RB520	1-236-904-11	RESISTOR, NETWORK (CHIP TYPE) 1K	
				RB521	1-236-412-11	NETWORK, RES 1.0K	
				RB522	1-236-448-11	NETWORK, RES 1.0M	
				RB523	1-236-432-11	NETWORK, RES 47K	
				RB524	1-236-908-11	RESISTOR, NETWORK (CHIP TYPE) 10K	
				RB525	1-236-424-11	NETWORK, RES 10K	

VS-104**VS-112****ZB-2**

Ref. No.	Part No.	Description	Remark
RB526	1-236-908-11	RESISTOR, NETWORK (CHIP TYPE) 10K	
RB527	1-236-424-11	NETWORK, RES 10K	
RB528	1-236-424-11	NETWORK, RES 10K	
RB529	1-236-424-11	NETWORK, RES 10K	
RB530	1-236-424-11	NETWORK, RES 10K	
RB531	1-236-424-11	NETWORK, RES 10K	
RB532	1-236-424-11	NETWORK, RES 10K	
RB533	1-236-412-11	NETWORK, RES 1.0K	
RB534	1-236-412-11	NETWORK, RES 1.0K	
RB535	1-236-908-11	RESISTOR, NETWORK (CHIP TYPE) 10K	
RB536	1-236-412-11	NETWORK, RES 1.0K	
RB537	1-236-412-11	NETWORK, RES 1.0K	
RB542	1-236-412-11	NETWORK, RES 1.0K	
RB543	1-236-412-11	NETWORK, RES 1.0K	
RB544	1-236-412-11	NETWORK, RES 1.0K	
RB547	1-236-444-11	NETWORK, RES 470K (TR72/TR80/TR400/TR430/TR750)	
RB548	1-236-416-11	NETWORK, RES 2.2K	
RB549	1-236-971-11	NETWORK, RES 0	
RB550	1-236-971-11	NETWORK, RES 0	
RB551	1-236-412-11	NETWORK, RES 1.0K	
RB552	1-236-412-11	NETWORK, RES 1.0K	
RB553	1-236-412-11	NETWORK, RES 1.0K	
RB554	1-236-971-11	NETWORK, RES 0	
< VARIABLE RESISTOR >			
RV202	1-238-086-11	RES, ADJ, CERMET 470	
< VIBRATOR >			
X201	1-579-365-21	VIBRATOR, CRYSTAL (3.58MHz)	
X501	1-579-550-11	VIBRATOR, CRYSTAL (32kHz)	
X502	1-760-314-11	VIBRATOR, CRYSTAL (11.895MHz)	
< VIBRATOR >			
XTL501	1-579-369-21	VIBRATOR (10MHz)	

*	A-7072-002-A	ZB-2 BOARD, COMPLETE ***** (Ref. No. 4,000 Series)	
< BUZZER >			
BU101	1-529-107-11	BUZZER, PIEZOELECTRIC	
< CAPACITOR >			
C102	1-164-346-11	CERAMIC CHIP 1uF	16V
C103	1-164-346-11	CERAMIC CHIP 1uF	16V

Ref. No.	Part No.	Description	Remark
< CONNECTOR >			
CN101	1-691-483-21	CONNECTOR, FFC/FPC 4P	
< BATTERY HOLDER >			
LI101	1-550-104-11	HOLDER, BATTERY	

MISCELLANEOUS *****			
110	1-810-535-11	DISPLAY PANEL, LIQUID CRYSTAL (TR400/TR750)	
111	1-467-676-11	SWITCH BLOCK, CONTROL (CK) (TR42/TR82/TR550)	
111	1-467-676-21	SWITCH BLOCK, CONTROL (CK) (TR70/TR72/TR430)	
111	1-467-676-41	SWITCH BLOCK, CONTROL (CK) (TR400/TR750)	
△162	1-452-673-11	CRT ASSY (M01KXX90WB) (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
163	1-651-894-11	FP-86 FLEXIBLE BOARD (TR42/TR72/TR82/TR400/TR430/TR550/TR750)	
167	1-651-903-11	FP-92 FLEXIBLE BOARD (TR70/TR80)	
168	1-651-893-11	FP-85 FLEXIBLE BOARD (TR70/TR80)	
171	1-517-325-11	LANP, FLUORESCENT (0.55 INCH) (TR70/TR80)	
181	8-753-015-00	LCX005AK-1 (TR70/TR80)	
201	1-467-649-12	SWITCH BLOCK, CONTROL (FK) (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
201	1-467-649-31	SWITCH BLOCK, CONTROL (FK) (TR400/TR750)	
208	1-691-471-11	CONNECTOR, TRANSLATION 11P	
212	1-651-891-11	FP-52 FLEXIBLE BOARD (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
212	1-651-892-11	FP-53 FLEXIBLE BOARD (TR400/TR750)	
260	1-765-361-11	CABLE, FLAT (FFC-115) (TR72/TR80/TR400/TR430/TR750)	
260	1-765-362-11	CABLE, FLAT (FFC-134) (TR42/TR70/TR82/TR550)	
262	1-547-716-11	LENS, ZOOM (VCL-5412WA) (TYPE II)	
262	8-848-704-01	DEVICE, LENS LSV-140A (TYPE I)	
264	1-547-529-21	FILTER BLOCK, OPTICAL (TR82/TR400/TR550/TR750)	
264	1-547-558-21	FILTER BLOCK, OPTICAL (TR42/TR70/TR80/TR430)	
871	1-641-643-12	FP-444 FLEXIBLE BOARD	
872	1-691-254-13	CONNECTOR, TRANSLATION 10P	
IC691	A-7030-373-A	CCD BLOCK ASSY (AUTO) (059V SERVICE) (CCD IMAGER) (TR82/TR400/TR550/TR750)	
IC691	A-7030-368-A	CCD BLOCK ASSY (AUTO) (054 SERVICE) (CCD IMAGER) (TR42/TR70/TR72/TR80/TR430)	
J201	1-537-731-11	TERMINAL BOARD (TR42/TR70/TR82/TR550)	
J201	1-537-731-21	TERMINAL BOARD (TR72/TR80/TR430)	
J201	1-537-731-31	TERMINAL BOARD (TR400/TR750)	
M002	1-542-162-11	MICROPHONE UNIT	

The components identified by mark
△ or dotted line with mark △ are
critical for safety.
Replace only with part number
specified.

Les composants identifiés par une
marque △ sont critiques pour la
sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

6-6. INTERFACE

6-6-1. System Control – Video/Audio Block Interface (VS BOARD)

NAME	I/O	No.	VTR MODE				CAMERA MODE	
			STOP	FF	REW	PB	STAND BY	REC
SP/LP	O	IC505 71	H	H	H	*1	H	H
VA PB MODE	O	IC505 65	L	L	L	H	L	L
AUDIO MUTE	O	IC505 46	L	L	L	L	L	L
VIDEO MUTE	O	IC505 47	H	H	H	*8	L	L
CAM/LINE	O	IC505 26	L	L	L	L	H	H
JOG VD	O	IC505 3	L	L	L	L	L	L
RP PB MODE	O	IC505 1	H	H	H	H	H	L
FEON	O	IC505 2	H	H	H	H	H	L
RF SWP	O	IC505 57	L	*2	*2	*2	*2	*2
JOG	O	IC505 4	L	L	L	L	L	L
CS VIDEO	O	IC505 24	V period "L" pulse					
CS DA	O	IC505 37	V period "H" pulse					
DATA TO SLVE	O	IC503 16	V period pulse train					
MODECON SCK	I	IC503 77	V period pulse train					
SP/LP DET	I	IC505 61	L	*3	*3	L	H	H
CLOG DET	I	IC505 62	L	*4	*4	*4	*4	H
VTR SYNC	I	IC505 64	L	*5	*5	*5	*5	*5
COMP REC	O	IC505 25	L	L	L	L	L	L

- *1. Outputs discrimination result of the playback tape.
 "H": SP mode, "L": LP mode.
 *2. 30 Hz duty 50% pulse (synchronized with drum rotation)
 *3. "H": SP recording area on tape, "L": LP recording area.
 *4. "H": no recording area.
 *5. Composite sync signal.
 *6. "H" when tape no signal.

6-6-2. System Control – Servo Block Interface

NAME	I/O	No.	VTR MODE				CAMERA MODE	
			STOP	FF	REW	PB	STAND BY	REC
T.REEL FG	I	IC505 60	-	*1	*1	*1	-	*1
S.REEL FG	I	IC505 59	-	*1	*1	*1	-	*1
ATF ERROR	I	IC505 58	-	*2	*2	*2	*2	*2
DRUM PG	I	IC505 66	-	*3	*3	*3	*3	*3
DRUM FG	I	IC505 67	-	*4	*4	*4	*4	*4
CAP FG/CFG HMS	I	IC505 68, 75	-	*5	*5	*5	*5	*5
CAP ON	O	IC505 69	L	H	H	H	L	H
REF PILOT	O	IC505 83	*7	*8	*8	*8	*6	*8
RP PB MODE	O	IC505 1	H	H	H	H	H	L
DRUM RVS *9	O	IC505 33	H	H	H	H	H	H
CAP FWD/RVS	O	IC505 10	L	H	L	H	L	H
DRUM PWM	O	IC505 74	L	*8	*8	*8	*8	*8
CAP PWM	O	IC505 73	L	*8	*8	*8	L	*8
LM LIM CONT *10	O	IC505 31	L	L	L	L	L	L
DRUM ON *11	O	IC505 22	L	H	H	H	H	H
DRUM ACC	O	IC505 89	L	L	L	L	L	L
DRUM BRK	O	IC505 90	L	L	L	L	L	L

- *1. Inputting waveform.
 *2. ATF error voltage input.
 *3. One PG pulse input.
 *4. FG pulses input.
 *5. FG pulses input.
 *6. Four frequencies.
 *7. f₁ (102.54 kHz) or f₃ (165.21 kHz) output
 *8. PWM signal.
 *9. Normally "H".
 *10. Temporary "L" when load (drum reverse rotation).
 *11. Temporary "H" when cassette loading (finger catch protection).
 "H": approx. 1.3 Vdc.

1-2. CAMERA SYSTEM ADJUSTMENT

1. Power Supply Voltage Check (DD board)

Subject	Option
Measuring instrument	Digital voltmeter
D5V check	
Measurement point	Pins ②③ of CN901
Specified value	4.9 ± 0.1 Vdc
D3.6V check	
Measurement point	Pins ①① and ②② of CN901
Specified value	3.6 ± 0.1 Vdc
CAM 5V check	
Measurement point	Pins ⑤⑤ and ⑥⑥ of CN901
Specified value	4.85 ± 0.1 Vdc
CAM 15V check	
Measurement point	Pin ⑦⑦ of CN901
Specified value	15 ± 0.3 Vdc
CAM -9V check	
Measurement point	Pin ③① of CN901
Specified value	$-8.5^{+0.25}_{-0.4}$ Vdc

Checking method:

- 1) Check that each power supply voltage satisfies the specified value.

2. Page F Data Initialization

Note: It is necessary to perform all adjustments of the camera section from the beginning again if the data of page F has been initialized.

Initializing method:

- 1) Page: 6, address: 00, data: 01
- 2) Check that the data of page: 6, address: 11 is 00.
- 3) Set data: 2D to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 4) Check that the data of page: 6, address: 11 is 01.
- 5) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 6) After performing "Page F data modification", perform all the adjustments of the camera section (page F).

1-12. CAMERA SYSTEM ADJUSTMENT

1. Power Supply Voltage Check (DC-Source)

Subject	Option
Measuring instrument	Digital voltmeter
OVV check	
Measurement point	Pin ② of C2001
Specified value	4.1 ± 0.1 Vdc
OVV check	
Measurement point	Pin ② and ③ of C2001
Specified value	1.0 ± 0.1 Vdc
C2001PV check	
Measurement point	Pin ② and ③ of C2001
Specified value	4.00 ± 0.1 Vdc
C2001PV check	
Measurement point	Pin ② of C2001
Specified value	1.2 ± 0.2 Vdc
C2001-4V check	
Measurement point	Pin ② of C2001
Specified value	-0.1 ~ 0.1 Vdc

Checking method:

- 1) Check that each power supply voltage satisfies the specified value.

2. Page F Data Initialization

Note: It is necessary to perform all adjustments of the camera section from the beginning again if the data of page F has been corrupted.

Initializing method:

- 1) Page 4, address 00, data 01
- 2) Check that the data of page 4, address 01 is 00.
- 3) Set data 00 on page 4, address 01 and press the F4L200 button of the adjusting remote commander.
- 4) Check that the data of page 4, address 01 is 01.
- 5) Set data 01 on page 4, address 01, and press the F4L200 button of the adjusting remote commander.
- 6) After performing "Page F data initialization", perform all the adjustments of the camera section (page 7).

3. Page F Data Modification 1

The data (initial data) that is automatically written on page F after the initialization of the page F data will differ according to some camera micro processor versions. Change the data by manual input, and arrange it.

Note 1: When changing the data, to write the data to the non-volatile memory, press the PAUSE button of the adjusting remote commander every time the new data is set.

Note 2: When changing address: 00, set the data of page: 6, address: 00 to 80.

CCD-TR42/TR70/TR72/TR80/TR430

Address	Data
00	5C [5E]
01	0A
03	00
25	A5
27	3A
28	A2
2A	0C
2B	58
<2D>	<04>
2E	17
2F	22
30	08
32	50
34	00
35	30
3B	20
3D	03
50	05
54	66
57	66
58	59
5E	1E
60	3A
77	E0
[90]	[11]
9C	91
A4	02
BD	70
BE	35
BF	54

[] : CCD-TR70 only

< > : CCD-TR430 only

CCD-TR82/TR550

Address	Data
00	5A
20	79
21	79
27	3A
28	A2
2B	50
[2D]	[04]
2F	27
30	08
32	47
3B	20
3D	02
50	32
77	E0
9C	91
A4	02
B1	25
B3	25
B4	A2
BD	6E
BE	32
BF	54

[] : CCD-TR550 only

CCD-TR400/TR750

Address	Data
00	56
20	79
21	79
27	3A
28	A2
2B	50
[2D]	[04]
2F	29
30	08
32	48
3B	20
3D	02
50	32
77	E0
9C	91
A4	02
B1	25
B3	25
B4	A2
BD	6E
BE	32
BF	54

[] : CCD-TR750 only

[Distinguishing the Camera Micro Computer (IC602) Versions]

Each version can be distinguished by looking at the part name of the camera micro processor or the data of page: 6, address: 10.

Version	Part Name	Page: 6 Address: 10
Ver.1.0	SC424608	10

[Distinguishing the Steady Shot Control Micro Computer (IC777) Versions] (CCD-TR82/TR400/TR550/TR750)

Each version can be distinguished by looking at the part name of the steady shot control micro processor or the data of page: 6, address: 30.

Version	Part Name	Page: 6 Address: 30
Ver.1.0	CXP87132-010R	01

2. Page F Data Modification 1

The date (year) data that is automatically written on page F also for initialization of the page F data will differ according to date when value parameter is set. Change the date by manual input, and average it.

Note 1: When changing the date, to write the date to the non-volatile memory, press the **WRITE** button of the adjusting screen immediately every time the date data is set.

Note 2: When changing address 02, set the date of page 0, address 00 to 02.

CCD-TR40/TV40/CR40/TV40

Address	Date
00	00 (00)
01	0A
02	00
20	00
21	0A
03	0A
04	0C
05	0A
000	00A
00	07
01	00
02	00
03	00
04	00
05	00
06	00
07	00
08	00
09	00
0A	00
0B	00
0C	00
0D	00
0E	00
0F	00
10	00
11	00
12	00
13	00
14	00
15	00
16	00
17	00

[] : CCD-TR40 only

[] : CCD-TR40 only

CCD-TR4000

Address	Date
00	0A
01	00
02	00
03	0A
04	0A
05	00
000	00A
01	00
02	0A
03	00
04	00
05	00
06	00
07	00
08	00
09	00
0A	00
0B	00
0C	00
0D	00
0E	00
0F	00

[] : CCD-TR400 only

CCD-TR400TR40

Address	Date
00	00
01	00
02	00
03	0A
04	0A
05	00
06	0A
07	00
08	0A
09	00
0A	00
0B	00
0C	00
0D	00
0E	00
0F	00

[] : CCD-TR400 only

2.2.2.2 Identifying the Camera Model Computer (CAMC) Version

Each version can be distinguished by looking at the part name of the upper value parameter in Section of page 0, address 00.

Version	Part Name	Page: 0 Address: 00
Ver1.0	CC-0000	00

2.2.2.3 Identifying the Steady Shot Control Micro Computer (SCMC) Version (CCD-TR40/CR40/TV40/TV40)

Each version can be distinguished by looking at the part name of the steady shot control value parameter in the data of page 0, address 00.

Version	Part Name	Page: 0 Address: 00
Ver1.0	CC-0000-0000	00

4. Page F Data Modification 2 (CCD-TR82/TR550)

Change the data of page: F, address: 2B according to the type of IC used for the camera core (IC609).

Changing Method:

- 1) Page: 6, address: 00, data: 01
- 2) Set data: 16 to page: 6, address: 02.
- 3) Select page: A.
- 4) Read the data displayed on the adjusting remote commander (4 digits) and take the second number as X.
- 5) When X is 2, set 53 to page: F, address: 2B. When X is 6, set 50.
- 6) Press the PAUSE button of the adjusting remote commander.

5. Page E Data Write (CCD-TR42/TR70/TR72/TR80/TR430)

Adjustment Page	E
Adjustment Address	00 to 10

Writing method:

- 1) Page: 6, address: 00, data: 80
- 2) Select page E, and input the data shown in Table 7-1-5. to each address.
(After setting the data, be sure to press the PAUSE button of the adjusting remote commander before changing the address.)
- 3) Set data: 00 to page: 6, address: 00.

Address	Data
00	00
01	0F
02	30
03	65
04	2B
05	00
06	00
07	00
08	C3
09	0C
0A	00
0B	7E
0C	65
0D	2E
0E	62
0F	EC
10	00

Table. 7-1-5.

6. 28 MHz Original Oscillation Adjustment (VC board)

Adjust the 28 MHz oscillation of the synchronization clock. If the oscillation is not 28 MHz, the period will be inaccurate or the image will not be in color.

Subject	Not required
Measurement Point	TP709 (CL)
Measuring Instrument	Frequency counter
Adjusting Element	CT701
Specified Value	14318181 \pm 71 Hz

Adjusting method:

- 1) Use CT701 to adjust the oscillation frequency to 14318181 \pm 71 Hz.

7. V SUB Adjustment

Set the CCD imager V SUB voltage to the voltage specified for the imager.

Subject	Not required
Adjustment Page	F
Adjustment Address	04

Adjusting Method:

- 1) Read the V SUB voltage code of the CCD imager.
Obtain the corresponding V SUB data from the following table.
- 2) Page: 6, address: 00, data: 01
- 3) Set the V SUB data to page: F, address: 04.
- 4) Press the PAUSE button of the adjusting remote commander.

V SUB			V SUB		
Voltage Code	Data	Voltagee (Vdc) *1	Voltage Code	Data	Voltagee (Vdc) *1
e	6F	9.0	g	AD	14.0
f	75	9.5	r	B3	14.5
g	7B	10.0	s	B9	15.0
h	82	10.5	t	C0	15.5
j	88	11.0	u	C6	16.0
k	8E	11.5	v	CC	16.5
l	94	12.0	w	D2	17.0
m	9A	12.5	x	D8	17.5
n	A1	13.0	y	DF	18.0
p	A7	13.5	z	E5	18.5

*1: The V SUB voltages (TP703) given are reference values.

4. **Page 0 Data Identification (PAGE/TYPE/STATUS)**
Change the data of page 0, address 00 according to the type of IC used for the circuit's size (C1000).

Changing Method

- 1) Page 0, address 00, data 00
- 2) Set data 00 to page 0, address 00.
- 3) Select page 0.
- 4) Read the data displayed on the adjusting remote commander (4 digits) and enter the second one hexa 00
- 5) When 0 is 0, set 00 to page 0, address 00. When 0 is 4, set 00.
- 6) Press the [PAUSE] button of the adjusting remote commander as

4. **Page 0 Data Write**
(PAGE/TYPE/STATUS/TYPE/STATUS)

Adjustment Page	00
Adjustment Address	00 to 00

Writing method

- 1) Page 0, address 00, data 00
- 2) Select page 0, and input the data shown in Table T-4-6 to each address
(Substituting the data, hexa to press the [PAUSE] button of the adjusting remote commander before changing the address.)
- 3) Set data 00 to page 0, address 00.

Address	Data
00	00
01	00
02	00
03	00
04	00
05	00
06	00
07	00
08	00
09	00
0A	00
0B	00
0C	00
0D	00
0E	00
0F	00
10	00
11	00
12	00
13	00
14	00
15	00
16	00
17	00
18	00
19	00
1A	00
1B	00
1C	00
1D	00
1E	00
1F	00

Table T-4-6.

5. **00 MHz Original Oscillator Adjustment**
(00 Input)

Adjust the 00 MHz oscillation of the synthesizer circuit.

If the oscillation is not 00 MHz, the period will be incorrect on the image will not be a color.

Subject	Not required
Adjustment Item	TP00 (C1.2)
Adjusting Instrument	Frequency meter
Adjusting Element	CT00
Expected Value	140MHz ± 70 Hz

Adjusting method

- 1) The CT00 is adjust the oscillation frequency to 140MHz ± 70Hz.

7. **V SUB Adjust**

Set the C102 output V SUB voltage to the voltage specified for the output.

Subject	Not required
Adjustment Page	0
Adjustment Address	00

Adjusting Method

- 1) Read the V SUB voltage value of the C102 output.
- 2) Obtain the corresponding V SUB data from the following table.
- 3) Page 0, address 00, data 00
- 4) Set the V SUB data to page 0, address 00.
- 5) Press the [PAUSE] button of the adjusting remote commander as

V SUB		V SUB		V SUB	
Voltage Grade	Data	Voltage (Vrms) **	Voltage Grade	Data	Voltage (Vrms) **
+	00	0.0	0	00	0.0
+	01	0.1	+	01	0.1
+	02	0.2	+	02	0.2
+	03	0.3	+	03	0.3
+	04	0.4	+	04	0.4
+	05	0.5	+	05	0.5
+	06	0.6	+	06	0.6
+	07	0.7	+	07	0.7
+	08	0.8	+	08	0.8
+	09	0.9	+	09	0.9
+	10	1.0	+	10	1.0
+	11	1.1	+	11	1.1

** The V SUB voltage (TP00) gives an reference value.

8. VRG Adjustment

Set the CCD imager V RG voltage to the voltage specified for the imager.


Subject	Not required
Adjustment Page	F
Adjustment Address	05 (V PGH)

Adjusting Method:

- 1) Read the VRG voltage code of the CCD imager.
Obtain the corresponding VRG data from the following table.
- 2) Page: 6, address: 00, data: 01
- 3) Set the VRG data to page: F, address: 05.
- 4) Press the PAUSE button of the adjusting remote commander.

VRG		
Voltage Code	Data	Voltage (Vdc) *2
1	33	1.0
2	4E	1.5
3	69	2.0
4	84	2.5
5	9F	3.0
6	BA	3.5
7	D5	4.0

*2: The VRG voltages (TP707) given are reference values.



(Example) When "6m" is displayed:
The V SUB voltage code is "m" and therefore the V SUB data will be "9A".
The VRG voltage code is "6" and therefore the VRG data will be "BA".

Fig. 7-1-7.

9. Flange Back Adjustment

The flange back adjustment for the inner focus lens is performed automatically.

Subject	Chart for flange back adjustment (2000 ± 5 mm from the front side of the lens Luminance: 300 ± 50 lux)
Measurement Point	Check the operations on the TV monitor
Measuring Instrument	TV monitor
Adjustment Page	F
Adjustment Address	16, 17, 18, 19, 1A, 1B

Adjusting method:

- 1) Check that the flange back adjustment chart center and the exposure display center coincide at both zoom lens TELE end and WIDE end.
- 2) Page: 6, address: 00, data: 01
- 3) Check that the data of page: 6, address: 21 is 00.
- 4) Check that the page: F, address: 16 to 1B data is at the initial value. (Refer to Table 7-1-4. "Page F address list")
- 5) Set data: 13 to page: 6, address: 01 and press the PAUSE button of the adjusting remote commander.
- 6) Set data: 15 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
(The adjustment data is automatically input to page: F, addresses: 16 to 1B.)
- 7) Check that the data of page: 6, address: 21 is 01.
(Display indicating flange back adjustment completion)

Processing after completing adjustments

- 1) Turn off the main power supply (6.3V).

4. VHS Adjustment

Set the CCD Image VBI settings to the settings specified for the image.

Subject	Set required
Adjustment Page	F
Adjustment Address	16, 17, 18, 19

Adjusting Method

- Read the VBI voltage output for the CCD images.
Obtain the corresponding VBI data from the following table.
- Page 6, address 16, item 11
- Set the VBI data to page 17, address 16.
- Press the FV200 button of the adjusting remote controller.

VBI		
Voltage Code	Data	Voltage (V)
1	10	1.0
2	40	1.4
3	45	1.5
4	54	1.6
5	59	1.7
6	66	1.8
7	70	1.9

*1: The VBI voltage (FV200) gives an automatic value.



(Example) When "10" is displayed:

The VBI voltage code is "10" and therefore the VBI data will be "10".
The VBI voltage code is "10" and therefore the VBI data will be "10".

Fig. 7-1-2

5. Shutter Speed Adjustment

The Shutter Speed adjustment for the user lens has a preferred automatically.

Subject	Check the Shutter Speed adjustment (1000 ÷ 1 sec from the front side of the lens maximum 100 ÷ 10 sec)
Measurement Point Measuring Component	Check the operation on the TV monitor
Adjustment Page	F
Adjustment Address	16, 17, 18, 19, 1A, 1B

Adjusting method

- Check that the Shutter Speed adjustment start menu and the exposure display menu (shutter is lock open lens VBI 6 and not VBI 6 and).
- Page 6, address 16, item 11
- Check that the data of page 6, address 11 is 10.
- Check that the page 17, address 16 or 18 data is the shutter value. (Refer to Table 7-1-4, "Page 17 address 16")
- Set the data 12 to page 6, address 11 and press the PALISE button of the adjusting remote transmission.
- Set the data 12 to page 6, address 11, and press the PALISE button of the adjusting remote transmission.
(The adjustment data is automatically input to page 17, address 16 to 18)
- Check the the data of page 6, address 11 is 11.
(Display indicating Shutter Speed adjustment complete)

Recovery after completing adjustment

- Turn off the main power supply (SLP).

10. Flange Back Check

Subject	Siemens star (2m from the front of the lens)
Measurement Point	DDS display of EVF or TV monitor
Measuring Instrument	
Specified Value	Focused at the TELE end and WIDE end.

Checking method:

- 1) Place the Siemens star 2m from the front of the lens.
- 2) To open the IRIS, decrease the luminous intensity to the Siemens star up to a point before noise appears on the image.
- 3) Shoot the siemens star with the zoom TELE end.
- 4) Turn ON the auto focus.
- 5) When the lens is focused, turn OFF the auto focus. (Note 2)
- 6) Shoot the siemens star with the zoom WIDE end.
- 7) Check that the lens is focused.

Note 1: Input the following data for CCD-TR82/TR400/TR550/TR750.

- 1) Set data: 02 to page: 6, address: 32.
- 2) Set data: 01 to page: 6, address: 33.

Note 2: When the auto focus is ON, the lens can be checked if it is focused or not by observing the data on page A of the adjusting remote commander.

- 1) Set data: 0C to page: 6, address: 02.
- 2) Page A shows the state of the focus.

A : 00 : XX

└─┬─┘
 └─┬─┘
 Odd: Focused
 Even: Unfocused

Processing after compleating adjustments

- 1) Set data: 00 to page: 6, address: 02.

For CCD-TR82/TR400/TR550/TR750

- 2) Set data: 00 to page: 6, address: 32.
- 3) Set data: 00 to page: 6, address: 33.

11. HALL Adjustment

To eliminate the differences in the outputs of the hall element attached to the iris for detecting the position of the lens iris, adjust the hall AMP gain and hall offset.

Subject	Not required
Measurement Point	DDS display of EVF or TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	06, 07
Specified Value	32 to 36 during IRIS OPEN B4 to B8 during IRIS CLOSE

Adjusting method:

- 1) Page: 6, address: 00, data: 01
- 2) Page: 1, address: 00, data: 01
- 3) Set data: 21 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
- 4) Set data: 03 to page: 6, address: 02.
- 5) Set data: 03 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 6) Set data: 80 to page: F, address: 07, and press the PAUSE button of the adjusting remote commander.
- 7) Set data: 40 to page: F, address: 06, and press the PAUSE button of the adjusting remote commander.
- 8) Read the DDS display data (the bottom two digits of the display data at the bottom right of the EVF or the monitor TV display), and set to W2.
- 9) Set data: 30 to page: F, address: 06, and press the PAUSE button of the adjusting remote commander.
- 10) Read the DDS display data, and set to W1.
- 11) Set data: 01 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 12) Read the DDS display data, and set to K1.
- 13) Set data: 40 to page: F, address: 06, and press the PAUSE button.
- 14) Read the DDS display data, and set to K2.
- 15) Convert W1, W2, K1, K2 to decimal notation, and obtain W1', W2', K1', K2'. (Refer to Table 7-1-5. "Hexadecimal notation-decimal notation conversion table".)
- 16) Calculate X1' using the following equations (decimal notation calculation).

$$A' = W2' + K1' - W1' - K2' \dots \dots \dots \text{Equation 1}$$

$$B' = W1' - K1' \dots \dots \dots \text{Equation 2}$$

$$X1' = \frac{2080 + (48 \times A') - (16 \times B')}{A'} \dots \dots \dots \text{Equation 3}$$

10. Change Beam Check

Subject	Measure rate (See Beam the front of the lens)
Measurement Point	CCD display of DVP or TV monitor
Measuring Instrument	
Specified Value	Presented in the TABLE and used "REF" and

Checking method

- Place the **Beam** rate See Beam the front of the lens.
- On open the **REF**, decrease the luminance intensity to the **Beam** rate up to a point before color appears on the image.
- Shoot the **Beam** rate with the screen **TRAC** end.
- Shoot **CR** the same theme.
- When the lens is focused, turn **CR** the auto-focus. (State 3)
- Shoot the **Beam** rate with the screen **WIDE** end.
- Check that the lens is focused.

Note 1: Input the following data for CCD-TRAC/Beam/TV/REF

- Set data 01 on page 4, address 32.
- Set data 01 on page 4, address 33.

Note 2: When the auto focus is ON, the lens was focused if it is focused or not by observing the data on page 4 of the adjusting remote commander.

- Set data 02 on page 4, address 01.
- Page 4 shows the state of the lens.



Processing after completing adjustments

- Set data 01 on page 4, address 01.

For CCD-TRAC/Beam/TV/REF

- Set data 01 on page 4, address 32.
- Set data 02 on page 4, address 33.

11. PAL/NTSC Adjustment

To eliminate the difference in the output of the full chroma obtained in the case the detecting the position of the test film, adjust the full **AAP** gain and full offset.

Subject	See required
Measurement Point	CCD display of DVP or TV monitor
Measuring Instrument	
Adjustment Page	1
Adjustment Address	01, 02
Specified Value	01 to 01 display 0100-0100 02 to 02 display 0100 0100

Adjusting method

- Page 4, address 01, data 01
- Page 1, address 01, data 01
- Set data 01 on page 01, address 01, and press the **PAUSE** button of the adjusting remote commander
- Set data 01 on page 4, address 01
- Set data 01 on page 4, address 01, and press the **PAUSE** button of the adjusting remote commander
- Set data 01 on page 01, address 01, and press the **PAUSE** button of the adjusting remote commander
- Set data 01 on page 01, address 01, and press the **PAUSE** button of the adjusting remote commander
- Reset the **005** display data (the bottom two digits of the display data at the bottom right of the DVP or the monitor TV display) and set to 00.
- Set data 01 on page 01, address 01, and press the **PAUSE** button of the adjusting remote commander
- Reset the **005** display data, and set to 00.
- Set data 01 on page 4, address 01, and press the **PAUSE** button of the adjusting remote commander
- Reset the **005** display data, and set to 00.
- Set data 01 on page 01, address 01, and press the **PAUSE** button.
- Reset the **005** display data, and set to 00.
- Correct **W**, **B**, **G**, **R** is detected position, and obtain **W**, **B**, **G**, **R** (State in Table 7-1-3 "Theoretical position-detecting position-correction value")
- Calculate **X** using the following equation (Theoretical position value obtained).

$$X = (W - B) \times (G - R) \times 100 \quad \text{Equation 1}$$

$$W - B = X \quad \text{Equation 2}$$

$$G - R = X \quad \text{Equation 3}$$

- 17) Convert $X1'$ to hexadecimal notation, and obtain $X1$.
(Round off to one decimal place)
- 18) Set data: $X1$ to page: F, address: 06, and press the PAUSE button of the adjusting remote commander.
- 19) Change the data of page: F, address: 07, and adjust the DDS display data to "34".
- 20) Press the PAUSE button of the adjusting remote commander.
- 21) Set data: 03 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 22) Read the DDS display data, and set to $W0$. If $W0$ lies within the "B4" to "B8" range, perform "Processing after completing adjustments". If it lies outside the range, perform the following adjustments.
- 23) Convert $W0$ to hexadecimal notation, and obtain $W0'$.
- 24) Calculate $X2'$ using the following equations (decimal notation calculation).

$$C' = W0' - B' - 52 \dots \dots \dots \text{Equation 4}$$

$$X2' = \frac{(130 - B') \times (X1' - 48) + 48 \times C'}{C'} \dots \dots \dots \text{Equation 5}$$

($X1'$ and B' are values obtained from equations 2 and 3)
- 25) Convert $X2'$ to hexadecimal notation and obtain $X2$.
(Round off to one decimal place)
- 26) Set data $X2$ to page: F, address: 06, and press the PAUSE button of the adjusting remote commander.
- 27) Change the data of page: F, address: 07, and adjust the DDS display data to "B6".
- 28) Press the PAUSE button of the adjusting remote commander.
- 29) Set data: 01 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 30) Check that the DDS display data lies within the "32" to "36" range.

Processing after Completing Adjustments

- 1) Set data: 00 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
- 2) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 3) Page D protect mode setting.
Page: 1, address: 00, data: 00

12. SYNC Level Check (VC board)

Subject	Not required
Measurement Point	TP607
Measuring Instrument	Oscilloscope
Specified Value	$A=140 \pm 10 \text{ mV}$

Adjusting method:

- 1) Page: 6, address: 00, data: 01
- 2) Set data: 03 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 3) Check that the SYNC level (A) satisfies the specified value.

Processing after completing adjustments

- 1) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.




Fig. 7-1-8.

13. BURST Level Check (VC board)

Subject	Not required
Measurement Point	TP609
Measuring Instrument	Oscilloscope
Specified Value	$A=140 \pm 15 \text{ mVp-p}$

Adjusting method:

- 1) Page: 6, address: 00, data: 01
- 2) Set data: 03 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 3) Check that the Burst level (A) satisfies the specified value.

Processing after completing adjustments

- 1) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.




Fig. 7-1-9.

- (7) Connect X_2 to terminal/point 1, and attach X_3 .
(Connect off to one terminal/point)
- (8) Set data X_1 to page 1, address 05, and press the FALLEN button of the adjusting-measure transmitter.
- (9) Change the data of page 1, address 01, and adjust the DCM display data to "54".
- (10) Press the FALLEN button of the adjusting-measure transmitter.
- (11) Set data 02 to page 1, address 04, and press the FALLEN button of the adjusting-measure transmitter.
- (12) Read the DCM display data, and set it to 96. If it lies outside the "54" to "96" range, perform "Resetting after completing adjustment". If it lies outside the range, perform the following adjustment.
- (13) Connect X_1 to terminal/point 1, and attach X_2 .
- (14) Calculate X_2 using the following equation (terminal voltage calculation):

$$C \times 0.01 \times 0.1 \times 0.1 = 25 \quad \text{Equation 4}$$

$$X_2 = \frac{0.01 \times 0.1 \times 0.1 \times 0.1}{C} \quad \text{Equation 5}$$
- (15) X_2 and 0.1 are values obtained from equation 4 and 5.
- (16) Connect X_2 to terminal/point 1, and attach X_3 .
(Connect off to one terminal/point)
- (17) Set data X_1 to page 1, address 05, and press the FALLEN button of the adjusting-measure transmitter.
- (18) Change the data of page 1, address 01, and adjust the DCM display data to "54".
- (19) Press the FALLEN button of the adjusting-measure transmitter.
- (20) Set data 02 to page 1, address 04, and press the FALLEN button of the adjusting-measure transmitter.
- (21) Check that the DCM display data lies within the "54" to "96" range.

Resetting after Completing Adjustment

- (1) Set data 02 to page 1, address 04, and press the FALLEN button of the adjusting-measure transmitter.
- (2) Set data 02 to page 1, address 01, and press the FALLEN button of the adjusting-measure transmitter.
- (3) Page 1, terminal/point setting.
Page 1, address 04, data 01

13. BENE Level Check (VC Invert)

Subject	Not applied
Measurement Point	TPW0
Measuring Instrument	Level Gauge
Specified Value	Area 1 = 10 m ²

Adjusting method

- (1) Page 1, address 04, data 01
- (2) Set data 02 to page 1, address 01, and press the FALLEN button of the adjusting-measure transmitter.
- (3) Check that the BENE level (VC) satisfies the specified value.

Resetting after completing adjustment

- (1) Set data 02 to page 1, address 01, and press the FALLEN button of the adjusting-measure transmitter.



Fig. 7-1-4

14. BURET Level Check (VC Invert)

Subject	Not applied
Measurement Point	TPW0
Measuring Instrument	Level Gauge
Specified Value	Area 1 = 10 m ² /sq

Adjusting method

- (1) Page 1, address 04, data 01
- (2) Set data 02 to page 1, address 01, and press the FALLEN button of the adjusting-measure transmitter.
- (3) Check that the BURET level (VC) satisfies the specified value.

Resetting after completing adjustment

- (1) Set data 02 to page 1, address 01, and press the FALLEN button of the adjusting-measure transmitter.



Fig. 7-1-5

14. Picture Frame Setting


Subject	Color bar chart standard picture frame
Measurement Point	Video output terminal
Measuring Instrument	Oscilloscope and TV monitor.
Specified Value	$A=B, C=D, t=0 \pm 0.1 \text{ msec}$

Setting method:

- 1) Turn the auto focus off.
- 2) Adjust the focus.
- 3) Adjust the zoom and the camera direction, and set to the specified position.
- 4) Mark the position of the picture frame on the monitor display, and adjust the picture frame to this position in following adjustments using "color bar chart standard picture frame".

Check on the oscilloscope

1. horizontal period



2. Vertical period




Fig. 7-1-10.

Check on the TV monitor




Fig. 7-1-11.

14. Picture Frame Setting

Subject	Color for short standard picture frame
Measurement Point	Video output terminal
Measuring Instrument	Oscilloscope and TV monitor
Specified Value	A=0, C=0, L=0 & B1=0mm

(Setting method)

- 1) Turn the main frame off.
- 2) Adjust the frame.
- 3) Adjust the zoom and the focus electrically, and set to the specified position.
- 4) Check the position of the picture frame on the monitor display, and adjust the picture frame to this position in following adjustment using "color bar short standard picture frame".

Check on the oscilloscope

1. Unadjusted period



2. Adjusted period



Fig. T4-10

Check on the TV monitor



Fig. T4-11

15. Color Reproduction Adjustment

Adjust the color separation matrix coefficient so that the proper color reproduction is produced.

Subject	Color bar chart standard picture frame
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	F
Adjustment Address	08 (RED MATRIX), 09 (BLUE MATRIX), 0A (B-Y HUE), 0B (R-Y HUE)
Specified Value	All color luminance points should settle within each color reproduction frame.

Adjusting method:

- 1) Page: 6, address: 00, data: 01
- 2) Set data: 00 to page: 6, address: 03.
- 3) Set data: F1 to page: F, address: 10, and press the PAUSE button of the adjusting remote commander.
- 4) Adjust the GAIN and PHASE of the vectorscope, and adjust the burst luminance point to the burst position of the color reproduction frame.
- 5) Change the data of addresses 08, 09, 0A and 0B of page: F, and settle each color luminance point in each color reproduction frame.

Note 1: Be sure to press the PAUSE button of the adjusting remote commander before changing the addresses.

If not, the new data will not be written to the memory.

- 6) Press the PAUSE button of the adjusting remote commander.

Processing after completing adjustments

- 1) Set data: E0 to page: F, address: 10 and press the PAUSE button of the adjusting remote commander.
- 2) Set data: 10 to page: 6, address: 03.

For CCD-TR42/TR70/TR72/TR80

Burst position




Fig. 7-1-12.

For CCD-TR82/TR550

Burst position




Fig. 7-1-13.

For CCD-TR400/TR750

Burst position




Fig. 7-1-14.




Fig. 7-1-15. Direction of the Movements of the Adjustment Address and Luminance Point

18 Color Reproduction Adjustment

Adjust the color separation matrix coefficients so that the paper color reproduction is perfect.

Subject	Color for each standard patch frame
Measurement Point	White paper (white)
Measuring Instrument	Colorimeter
Adjustment Page	7
Adjustment Address	04 (GREEN) 04 (RED) 04 (BLUE) 04 (RED) 04 (BLUE) 04 (BLUE)
Special Value	All color luminance points should satisfy within each color reproduction frame.

Adjusting method

- Page 6, address 04, data 04
- Set data 04 to page 6, address 04.
- Set data 04 to page 6, address 04, and press the F4/REI button of the adjusting remote commander.
- Adjust the GCM and PRACH of the colorimeter, and adjust the color luminance point to the lower position of the color reproduction frame.
- Change the data of address 04, 05, 06, and 07 of page 6, and make each color luminance point to each color reproduction frame.
 Note 1) Its use is given the F4/REI button of the adjusting remote commander before changing the address.
 If not, the use data will not be written to the memory.
- Press the F4/REI button of the adjusting remote commander.

Proceeding after completing adjustments

- Set data 04 to page 7, address 04 and press the F4/REI button of the adjusting remote commander.
- Set data 04 to page 4, address 04.

For CCD-TR400/TR60/TR80/TR80

Basic pattern



Fig. 7-4-13

For CCD-TR400/TR60

Basic pattern



Fig. 7-4-14

For CCD-TR400/TR80

Basic pattern



Fig. 7-4-15



Fig. 7-4-16: Direction of the movements of the Adjustment Address and Luminance Point

16. IRIS IN/OUT Adjustment (VC board)

For the unit to judge if the white balance is indoors or outdoors in auto white balance operations, measure the light level and write it in the EEPROM.

If the level is not correct, the white balance will not be accurate.

Subject	White pattern
Measurement Point	DDS display of EVF or TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	13, 14

Adjusting method:

- 1) Page: 6, address: 00, data: 01
- 2) Release the page D protect.
Page: 1, address: 00, data: 01
- 3) Set data: 21 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
- 4) Set data: 0E to page: 6, address: 02.
- 5) Set data: 0B to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 6) Read the DDS display data (Note 1), and take the upper two digits as D1 and the lower two as D2.
- 7) Convert D1 to a decimal number and obtain D1'. (Refer to Table 7-1-4. "Hexadecimal Notation-Decimal Notation Conversion Table".)
- 8) Calculate D3' using the following equations. (Equations 1 and 2 are for decimal notation calculation)
When $D2 \geq D0$
 $D3' = D1' - 21$ Equation 1
When $D2 < D0$
 $D3' = D1' - 22$ Equation 2
- 9) Convert D3' to a hexadecimal number and obtain D3.
- 10) Set D3 to page: F, address: 13, and press the PAUSE button of the adjusting remote commander.
- 11) Set data: 09 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
(IND0.5 SHUTTER mode setting)
- 12) Read the DDS display data (Note 1), and take the upper two digits as D4 and the lower two as D5.
- 13) Convert D4 to a decimal number and obtain D4'. (Refer to Table 7-1-4. "Hexadecimal Notation-Decimal Notation Conversion Table".)
- 14) Calculate D6' using the following equations. (Equations 3 and 4 are for decimal notation calculation)
When $D5 \geq F0$
 $D6' = D4' - 13$ Equation 3
When $D5 < F0$
 $D6' = D4' - 14$ Equation 4
- 15) Convert D6' to a hexadecimal number and obtain D6.
- 16) Set D6 to page: F, address: 14, and press the PAUSE button of the adjusting remote commander.

Note 1: The right four digits of the display data at the right bottom side of the EVF and monitor TV is the LIGHT LEVEL data. If the lower digits change severely and cannot be read, record it on a tape once, play it back by frame feeding, and obtain the average value.

Processing after Completing Adjustments

- 1) Set data: 00 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
- 2) Set data: 00 to page: 1, address: 00.
- 3) Set data: 00 to page: 6, address: 00, and press the PAUSE button of the adjusting remote commander.
- 4) Set data: 00 to page: 6, address: 02.

10. **DO NOT** Adjustment (DO NOT)

For the entire Judge if the white balance is adjusted in automatic in auto white balance operation, estimate the light level and reduce it in the D50F (20).

If the level is adjustment, the white balance will not be automatic.

Subject	White pattern
Measurement Point	100% display of D50F or D50F monitor
Measuring Equipment	
Adjustment Page	P
Adjustment address	13, 14

Adjusting method.

- 1) Page 6, address (0) data (0)
 - 2) Release the page (0) pattern.
 - 3) Page 1, address (0) data (0)
 - 4) Set data (0) to page 1, address (0), and press the F4/F5 button of the adjusting remote commander.
 - 5) Set data (0) to page 4, address (0).
 - 6) Set data (0) to page 4, address (0), and press the F4/F5 button of the adjusting remote commander.
 - 7) Read the D50F display data (Data 0) and enter the upper two digits as (0) and the lower as (0).
 - 8) Current (0) is a decimal number and enter (0). (Refer to Table 7-1-4, "Microcomputer Function-Function Function Operating Table")
 - 9) Calculate (0) using the following equations. (Equation 1 and 2 are for decimal number calculation)

When (0) > 0

$$D50F = (0) \times 10 \text{ ----- Equation 1}$$

When (0) < 0

$$D50F = (0) \times 10 \text{ ----- Equation 2}$$
 - 10) Current (0) is a hexadecimal number and enter (0).
 - 11) Set (0) to page 7, address 14, and press the F4/F5 button of the adjusting remote commander.
 - 12) Set data (0) to page 4, address (0), and press the F4/F5 button of the adjusting remote commander.
 - 13) Press the D50F display data (Data 0), and enter the upper two digits as (0) and the lower two as (0).
 - 14) Current (0) is a decimal number and enter (0). (Refer to Table 7-1-4, "Microcomputer Function-Function Function Operating Table")
 - 15) Calculate (0) using the following equations. (Equation 3 and 4 are for decimal number calculation)

When (0) > 0

$$D50F = (0) \times 10 \text{ ----- Equation 3}$$

When (0) < 0

$$D50F = (0) \times 10 \text{ ----- Equation 4}$$
 - 16) Current (0) is a hexadecimal number and enter (0).
 - 17) Set (0) to page 7, address 14, and press the F4/F5 button of the adjusting remote commander.
- Note 1) The right four digits of the display data, to the right of the left side of the D50F and monitor (0) is the D50F (20)F5. data. If the lower four digits change currently and cannot be read, repeat it as a step once, play it back by these buttons, and obtain the average value.

Proceeding after Completing Adjustment

- 1) Set data (0) to page 13, address (0), and press the F4/F5 button of the adjusting remote commander.
- 2) Set data (0) to page 1, address (0).
- 3) Set data (0) to page 4, address (0), and press the F4/F5 button of the adjusting remote commander.
- 4) Set data (0) to page 4, address (0).

17. MAX GAIN Adjustment (VC board)

Correct the differences in the minimum illuminance.

If the illuminance is not consistent, the image level required for taking subjects in low illuminance will not be produced (dark).

Subject	White pattern standard picture frame
Measurement Point	TP607 (CAM Y)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	15
Specified Value	CCD-TR42/TR70/TR72/TR80/TR430 $A=275 \pm 10 \text{ mV}$ CCD-TR82/TR550 $A=195 \pm 10 \text{ mV}$ CCD-TR400/TR750 $A=210 \pm 10 \text{ mV}$

Adjusting method:

- 1) Page: 6, address: 00, data: 01
- 2) Set data: 19 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 3) Change the data of page: F, address: 15, and adjust so that the Y OUT signal level (A) becomes the specified value.
Note: The data of address: 15 should be 70 to FF.
- 4) Press the PAUSE button of the adjusting remote commander.

Processing after completing adjustments

- 1) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.




Fig. 7-1-16.

18. Auto White Balance Standard Data Input

Subject	White pattern standard picture frame
Adjustment Page	F
Adjustment Address	0C, 0D, 0E, 0F

Adjusting method:

- 1) Turn the power of the unit OFF/ON.
- 2) Page: 6, address: 00, data: 01
- 3) Check that the data of page: 6, address: 11 is 00.
- 4) Wait for 2 seconds.
- 5) Set data: 11 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 6) Set data: 0D to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
 (When the standard data is taken in, the data will be automatically input to addresses 0C to 0F of page F.)
- 7) Check that the data of page: 6, address: 11 is 01.

Processing after completing adjustments

- 1) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.

17. IRIS GAIN Adjustment (PG 6000)

Correct the difference in the process fluctuations.

If the difference is not corrected, the range limit specified for setting outputs in the difference will not be achieved (not).

Subject	White pattern standard plane focus
Measurement Point	YPRN (C&M Y)
Measuring Instrument	Gas leakage
Adjustment Page	0
Adjustment Address	01
Specified Value	OCS-TRACETRYTRISQTRISQTRISQ ADD 1. 10mV OCS-TRISQTRISQ As PR 1. 10mV OCS-TRISQTRISQ ADD 1. 10mV

Adjusting method

- 1) Page 4, address 00, data 00
- 2) Set data 00 to page 4, address 01, and press the PAUSE button of the adjusting remote commander
- 3) Change the data of page 0, address 00, and adjust so that the Y (A) signal level (A) increases the specified value.
 Note: The data of address 01 should be 00 or PR.
- 4) Press the PAUSE button of the adjusting remote commander

Processing after completing adjustment

- 1) Set data 00 to page 4, address 00, and press the PAUSE button of the adjusting remote commander




Fig 2-8-18.

18. Auto White Balance Standard Data Input

Subject	White pattern standard plane focus
Adjustment Page	0
Adjustment Address	00, 00, 00, 00

Adjusting method

- 1) Press the power of the unit (POWER)
- 2) Page 4, address 00, data 00
- 3) Check that the data of page 4, address 01 is 00
- 4) Wait for 2 seconds
- 5) Set data 00 to page 4, address 00, and press the PAUSE button of the adjusting remote commander
- 6) Set data 00 to page 4, address 00, and press the PAUSE button of the adjusting remote commander
 (When the standard data is taken in, the data will be automatically input to addresses 00 to 03 of page 0.)
- 7) Check that the data of page 4, address 01 is 00

Processing after completing adjustment

- 1) Set data 00 to page 4, address 01 and press the PAUSE button of the adjusting remote commander

19. Auto White Balance Adjustment

Adjust to the proper auto white balance output data.

If it is not correct, auto white balance and color reproducibility will be poor.

Subject	White pattern standard picture frame
Filter	Filter C14 for color temperature correction
Measurement Point	Check with the DDS display on the EVF or TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	11 (NORM R) 12 (NORM B)
Specified Value	CCD-TR42/TR70/TR72/TR80/ TR400/TR530/TR750 R ratio: 2A40 to 2AC0 B ratio: 5E00 to 5F00 CCD-TR82/TR550 R ratio: 2B40 to 2BC0 B ratio: 5E00 to 5F00

Adjusting method:

- 1) Place the C14 filter for color temperature correction on the lens.
- 2) Page: 1, address: 00, data: 01
- 3) Set data: 21 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
- 4) Page: 6, address: 00, data: 01
- 5) Set data: D0 to page: F, address: 10, and press the PAUSE button of the adjusting remote commander.
- 6) Set data: 04 to page: 6, address: 02.
- 7) Change the data of page: F, address: 11, and adjust the average value of the DDS display data (the display data at the bottom right of the EVF or the TV monitor) to the R ratio specified value.
- 8) Press the PAUSE button of the adjusting remote commander.
- 9) Set data: 05 to page: 6, address: 02.
- 10) Change the data of page: F, address: 12, and adjust the average value of the DDS display data to the B ratio specified value.
- 11) Press the PAUSE button of the adjusting remote commander.

Processing after completing adjustments

- 1) Set data: 00 to page: F, address: 10, and press the PAUSE button of the adjusting remote commander.
- 2) Set data: 00 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
- 3) Set data: 00 to page: 6, address: 02.
- 4) Page D protect mode setting.
Page: 1, address: 00, data: 00

20. White Balance Check

Subject	White pattern standard picture frame
Filter	Filter C14 for color temperature correction ND filter 1.0 and 0.3
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Specified Value	Fig. 7-1-17. A to C

Checking method:

- 1) Check that the lens is not covered with either filter.
- 2) Page: 6, address: 00, data: 01
- 3) Set data: 0F to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 4) Check that the center of the white luminance point is within the circle shown in Fig. 7-1-17.A.
- 5) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 6) Set data: 23 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 7) Place the C14 filter on the lens.
- 8) Check that the center of the white luminance point settles in the circle shown in Fig. 7-1-17. B.
- 9) Remove the C14 filter, and place the ND filter 1.3 (1.0+0.3) on the lens.
- 10) Check that the center of the white luminance point settles in the circle shown in Fig. 7-1-17. C.

Processing after completing adjustments

- 1) Set data: 00 to page: 6, address: 01, and press the PAUSE button of the adjusting remote commander.
- 2) Set data: 00 to page: 6, address: 00, and press the PAUSE button.

18. Auto White Balance Adjustment

Adjust to the proper auto white balance output rate.

If it is not correct, auto white balance and color reproducibility will be poor.

Subject	White balance standard picture frame
Filter	Place CM for color temperature correction
Measurement Point	Check with the DDC display on the DVP or TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Values	11 (PROMOT) 12 (PROMOT)
Specified Value	CC1: 75.42/70.00/70.00/69.00 75.42/70.00/70.00/69.00 B ratio: 25.40 to 26.00 B ratio: 20.00 to 21.00 CC2: 75.42/70.00 B ratio: 25.40 to 26.00 B ratio: 20.00 to 21.00

Adjusting method

- Place the CM filter for color temperature correction on the lens.
- Page 1, address 00, data 01
- Set data 02 to page 0, address 00, and press the PAUSE button of the adjusting remote commander.
- Page 4 address 00, data 00
- Set data 00 to page F, address 00, and press the PAUSE button of the adjusting remote commander.
- Set data 00 to page 0, address 00.
- Change the data of page F, address 11, and adjust the average value of the DDC display data (the display data at the bottom right of the DVP or the TV monitor) to the B ratio specified value.
- Press the PAUSE button of the adjusting remote commander.
- Set data 00 to page 4, address 00.
- Change the data of page F, address 12, and adjust the average value of the DDC display data to the B ratio specified value.
- Press the PAUSE button of the adjusting remote commander.

Processing after completing adjustment

- Set data 00 to page F, address 00, and press the PAUSE button of the adjusting remote commander.
- Set data 00 to page 0, address 00, and press the PAUSE button of the adjusting remote commander.
- Set data 00 to page 4, address 00.
- Page 0 picture mode setting.
Page 1, address 00, data 00

19. White Balance Check

Subject	White picture standard picture frame
Filter	Place CM for color temperature correction MD filter 1.0 and 0.2
Measurement Point	White output amount
Measuring Instrument	Yellometer
Specified Value	Fig. 74-17 A to C

Checking method

- Check that the lens is set around with silver filter.
- Page 4, address 00, data 00.
- Set data 00 to page 0, address 00, and press the PAUSE button of the adjusting remote commander.
- Check that the center of the white frameless panel is white. (the white shown in Fig. 74-17 A.)
- Set data 00 to page 0, address 00, and press the PAUSE button of the adjusting remote commander.
- Set data 02 to page 4, address 00, and press the PAUSE button of the adjusting remote commander.
- Place the CM filter on the lens.
- Check that the center of the white frameless panel is white. (the white shown in Fig. 74-17 B.)
- Remove the CM filter, and place the MD filter 1.0 (1.0-0.2) on the lens.
- Check that the center of the white frameless panel is white. (the white shown in Fig. 74-17 C.)

Processing after completing adjustment

- Set data 00 to page 4, address 00, and press the PAUSE button of the adjusting remote commander.
- Set data 00 to page 0, address 00, and press the PAUSE button.




Fig. 7-1-17. A




Fig. 7-1-17. B




Fig. 7-1-17. C

21. VIDEO OUT Level Check

Subject	Color bar chart standard picture frame
Measurement Point	Video output terminal (Terminated at 75Ω)
Measuring Instrument	Oscilloscope
Specified Value	Y level= 660 ± 40 mV SYNC level= 285 ± 20 mV BURST level= 285 ± 20 mV

Checking method:

- 1) Check that the Y level, SYNC level and BURST level satisfy the specified values.




Fig. 7-1-18.



Fig. 3-4-12 A



Fig. 3-4-13 B



Fig. 3-4-14 B

35. W8000 (BUT Level Check)

Subject	Color for visualized picture (mm)
Measurement Point	Visual output terminal (Visualized at 10 G)
Measuring Instrument	Oscilloscope
Specified Value	Y level: 400 ± 40 mV SYNC level: 10 ± 20 mV BLURST level: 10 ± 20 mV

Checking method

- Check that the Y level, SYNC level and BLURST level satisfy the specified values.



Fig. 3-4-15


1-3. ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENTS (CCD-TR42/TR72/TR82/TR400/TR430/ TR550/TR750)

1-3-1. Horizontal Slant Adjustment

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Monoscope section
Specified Value	$\pm 1.5^\circ$

Adjusting method:

- 1) Adjust RV904 (BRIGHT) so that the CRT can be seen easily and clearly.
- 2) Loosen the DY (deflection yoke) tightening screw.
- 3) Rotate DY, and adjust the image so that it is horizontal.
- 4) Tighten the DY tightening nut.
(Do not tighten it too tightly.)



Specified value: The image should be within $\pm 1.5^\circ$ of the horizontal line.

Fig. 7-1-19.




Fig. 7-1-20.

1-3-2. Centering Adjustment

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Monoscope section
Specified Value	$\pm 4\%$

Adjusting method:

- 1) Use the centering adjustment ring and adjust so that the left, right, top, and bottom sides of the display are uniform.
(Refer to Fig. 7-1-20.)

Note: As the centering position changes due to earth magnetism, rotate it 360° in the horizontal direction, and adjust with the center section of the modifying position.




Fig. 7-1-21.

1-3-3. Focus Adjustment

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Monoscope section

Adjusting method:

- 1) Adjust the focus ring to obtain the optimum focus.
(Refer to Fig. 7-1-20.)

1-3-4. Aberration Adjustment

Model	E-E
Signal	Dot pattern
Specified Value	$T < 2 \cdot D$, $F < D$

Adjusting method:

- 1) Adjust the aberration adjustment ring so that the tracing of the dot becomes less than twice the diameter of the dot, or the fan aberration becomes less than the diameter of the dot.
- 2) If the centering becomes displaced here, perform the centering adjustment from the beginning again.



Fig. 7-1-22.

1-3-5. Horizontal Amplitude Adjustment (VF-65 board)

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Monoscope section
Adjusting Element	C909
Specified Value	$6 \pm 2\%$

Adjusting method:

- 1) Rotate RV903, and adjust the top and bottom sides of the monoscope image to the top and bottom edges of the display.
- 2) Rotate RV904 so that the brightness is the normal level.
- 3) Adjust the pattern (A) of the H size adjustment capacitor (C909) to "short" or "open", so that the horizontal direction over scan becomes $6 \pm 2\%$ (Left and right totals). (Refer to Fig. 7-1-24.)





Fig. 7-1-23.



VF-65 board (Component side)

Section A	Size H
Open	Small
Short	Big

Fig. 7-1-24.

1-3-4. Aberration Adjustment

Model	S.R.
Signal	Dot pattern
Specified Value	$T < 0.2 \times D$, $P < 0.2$

Adjusting method

- Adjust the aberration adjustment ring so that the focusing of the dot becomes less than twice the diameter of the dot, or the line aberration becomes less than six times the diameter of the dot.
- If the remaining focusing aberration here, perform the remaining adjustment from the beginning again.



Fig. 7-1-22.

1-3-5. Horizontal Aberration Adjustment (W-40 Series)

Model	Playback
Signal	Alignment tape For checking operation (W11-DSP) Microscope section
Adjusting Element	W40
Specified Value	$d \pm 2\%$

Adjusting method

- Rotate W40, and adjust the top and bottom sides of the microscope image in the top and bottom edges of the display.
- Rotate W40 so that the brightness is the correct level.
- Adjust the pattern (X) of the H axis adjustment capacitor (C40F) in "clock" or "open" so that the horizontal aberration over the frame is $\pm 2\%$ (left and right sides). (Refer to Fig. 7-1-24.)



Fig. 7-1-23.



W-40 series (Component map)

Position A	Size H
Open	Small
Clock	Big

Fig. 7-1-24.

1-3-6. Vertical Amplitude Adjustment (VF-65 board)

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Monoscope section
Adjusting Element	RV903
Specified Value	$5 \pm 2\%$

Adjusting method:

- 1) Adjust RV903 so that the vertical direction over scan becomes $5 \pm 2\%$ (Top and bottom totals).




Fig. 7-1-25.

1-3-7. Brightness Adjustments (VF-65 board)

Model	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Monoscope section
Adjusting Element	RV904

Adjusting method:

- 1) Rotate RV904, and adjust so that the bright/dark sections of the gray scale are displayed correctly. (The bright section should be unsatisfactory till the cross hatch appears vague in the monoscope circle. The dark section should be unsatisfactory till the darkest section and the second darkest section of the gray scale cannot be differentiated.)

1-3-8. Horizontal Amplitude, Vertical Amplitude, Focus Check

"1-3-5. Horizontal Amplitude Adjustment" and "1-3-6. Vertical Amplitude Adjustment" should both satisfy the specified values. If not, perform the adjustments from the beginning again. In this case, perform [1-3-7. Brightness, Contrast Adjustments] again. Moreover, check the focus, and if it found to be vague, perform "1-3-3. Focus Adjustment" and "1-3-4. Aberration Adjustment".

1-4. COLOR ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENTS (CCD-TR70/TR80)

Note 1: The backlight (fluorescent tube) is driven by a 800 Vp-p, 16 kHz AC power supply.

Therefore, be careful not to touch the backlight holder as you will receive an electric shock.

Note 2: When replacing the LCD unit, ensure there will be no damages by static electricity.

[Adjusting connector]

Some measuring points for adjusting the view-finder are concentrated at CN902 of the VF-67 board. Connect the measuring equipments via the measuring pin tool. The following table lists the pin numbers and signal names of CN902.

Pin No.	Signal Name	Pin No.	Signal Name
1	LC COM	2	EVF GND
3	G OUT	4	13.5V
5	NC	6	12V
7	R OUT	8	B OUT
9	NC	10	PCO

Table 7-1-6.

[Power Supply Voltage]

Adjust the power supply voltage for the battery pin so that Pin ⑦ (EVF UNREG) of CN851 of the VF-66 board becomes 6.0 ± 0.1 Vdc.

[Video Input Signal for Adjusting]

If the signal column specifies "Color bar signal whose chroma signal and burst signal are turned off", input a color bar signal whose chroma signal and burst signal have been turned off to the video input pin as the video input signal for adjusting. Check that the signal level of Pin ⑪ of CN851 of the VF-66 board is 1.0 ± 0.12 Vp-p before adjusting.




Fig. 7-1-26. Color bar signal whose chroma signal and burst signals are turned off

1-2-6. Vertical Amplitude Adjustment (VP-66 board)

Model	Playback
Signal	Alignment input For checking operation (PUSH-TEST) Maintenance position
Adjusting Element	VR601
Specified Value	2.0 ± 2%

Adjusting method

- Adjust VR601 so that the vertical direction scan area becomes 2.0 ± 2% (Top and bottom marks).



Fig. 7-1-25

1-2-7. Brightness Adjustment (VP-66 board)

Model	Playback
Signal	Alignment input For checking operation (PUSH-TEST) Maintenance position
Adjusting Element	VR701

Adjusting method

- Set VR701, and adjust so that the brightness portions of the gray scale are displayed correctly. (The bright portion should be satisfactory all the time with upper edge of the composite signal. The dark portion should be satisfactory all the time with lower edge of the composite signal.)

1-2-8. Horizontal Amplitude, Vertical Amplitude, Focus Check

"1-2-1. Horizontal Amplitude Adjustment" and "1-2-4. Vertical Amplitude Adjustment" should both satisfy the specified values. If not, perform the adjustments from the beginning again. In this case, perform [1-2-1. Brightness, Contrast Adjustment] again. Moreover, check the focus, and if it does not be right, perform "1-2-3. Focus Adjustment" and "1-2-4. Alignment Adjustment".

1-4. COLOR ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENTS (CCD-VIDEO-TRAC)

Note 1: The backlight (fluorescent tube) is driven by a 600 V type, 14 W type AC power supply. Therefore, be careful not to touch the backlight holder as you will receive an electric shock.

Note 2: When replacing the LCD unit, ensure there will be no damage by static electricity.

(Adjusting accessories)

Before measuring points for adjusting the view-finder, an oscilloscope or CRO of the VP-67 board. Connect the measuring equipment via the measuring test lead. (The following table lists the pin numbers and signal names of CROs).

Pin No.	Signal Name	Pin No.	Signal Name
1	LC-CDM	8	EXT-DR
2	2-OUT	9	14-Dr
3	3-Dr	10	1-Dr
4	4-OUT	11	5-OUT
5	5-Dr	12	POD

Table 7-1-4.

(Power Supply Voltage)

Adjust the power supply voltage for the testing pin as the Pin (2) (EXT-DR) or CRO1 of the VP-66 board becomes 1.0 ± 0.1 Vdc.

(Video Input Signal for Adjusting)

If the signal within specified "Color bar signal whose chroma signal and luminance signal are turned off", input a color bar signal whose chroma signal and luminance signal have been turned off to the video input pin or the video input signal for adjusting. Check that the signal level of Pin (2) or CRO1 of the VP-66 board is 1.0 ± 0.05 Vdc before adjusting.




Fig. 7-1-26. Color bar signal whose chroma signal and luminance signal are turned off

1. Current Consumption Adjustment (VF-66 board)

Adjust the luminance and color temperature of the back light. If these are not correct, the image will be brighter or darker than normal.


Mode	Stop
Signal	Color bar signal whose chroma signal and burst signal are turned off
Measurement Point	Remove L851 and measure + : Pin ⑦ of CN851 - : ⊕ pin of C861
Measuring Instrument	Ammeter
Adjustment Page	D
Adjustment Address	B7
Specified Value	55 ± 5 mA

Note 1: Wait for 30 secs. after the power supply has been turned on before this adjustment.

Note 2: After adjusting, connect L851.

Adjusting method:

- 1) Check that the voltage of Pin ⑦ of CN851 is 6.0 ± 0.1 Vdc.
- 2) Page: 1, address: 00, data: 01
- 3) Change the data of page: D, address: B7, and adjust the current consumption to 55 ± 5 mA.
- 4) Press the PAUSE button of the adjusting remote commander.



VF-66 BOARD Component side

Fig. 7-1-27.

2. Power Supply Voltage Check (VF-67 board)

Mode	Record
Measuring Instrument	Digital voltmeter
13.5V check	
Measurement Point	Pin ⑭ of CN901
Specified Value	13.5 ± 0.3 Vdc
12.0V check	
Measurement Point	Pin ⑬ of CN901
Specified Value	12.0 ± 0.3 Vdc

3. EVR Initial Data Input

Mode	STOP
Signal	Arbitrary
Adjustment Page	D

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Select page D, and input the data in the following table.

Note: To write in the nonvolatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time the data is set.

Address	Data
B0 (BRIGHT)	A0
B1 (COLOR)	AE
B2 (HUE)	95
B3 (SUB BRIGHT R)	7A
B4 (SUB BRIGHT B)	6A
B5 (CONTRAST)	70
B6 (VCO)	90
B7 (INVERTER CURRENT)	35
B8 (SUB CONTRAST R)	7A
B9 (SUB CONTRAST B)	7A
BA (GAMMA 1)	70
BB (GAMMA 2)	F0

1. Current Consumption Adjustment (VP-88 board)

Adjust the brightness and color temperature of the back light. If there are not screen, the image will be lighter or darker than normal.

Mode	Step
Signal	Color bar signal whose chroma signal and burst signal are turned off
Measurement Point	Resistor (R1) and resistor + Pin (2) of CN50 + Pin (3) of CN6
Measuring Instrument	Ammeter
Adjustment Page	0
Adjustment Address	0F
Specified Value	00 ± 1mA

Step 1: Wait for 30 sec. after the power supply has been turned on before this adjustment.

Step 2: After adjusting, connect LRS

adjusting method.

- Check that the voltage of Pin (2) of CN50 is 0.5~0.8 V.
- Page 0, address, 0F, data 0.
- Change the data of page 0, address 0F, and adjust the current consumption to 00 ± 2 mA.
- Press the FAC/ST button of the adjusting remote controller.



VP-88 (8848) Component side

Fig. P4-87.

2. Power Supply Voltage Check (VP-87 board)

Mode	Result
Measuring Instrument	Digital multimeter
12.5V mode	
Measurement Point	Pin (2) of CN50
Specified Value	12.5 ± 0.5 Vdc
12.0V mode	
Measurement Point	Pin (2) of CN50
Specified Value	12.0 ± 0.5 Vdc

3. EEPROM Initial Data Input

Mode	EEPROM
Signal	Address
Adjustment Page	0

Adjusting method.

- Page 0, address 00, data 00
- Enter page 0, and input the data in the following table.
Note: To write to the non-volatile memory (EEPROM), press the CHASE button of the adjusting remote controller each time the data is set.

Address	Data
00 (ADDRESS)	00
01 (COLOR)	00
02 (V.D)	00
03 (SUB BRIGHT 0)	7A
04 (SUB BRIGHT 1)	6A
05 (CONTRAST)	00
06 (V.D)	00
07 (OVERVIEW CONTRAST)	00
08 (SUB CONTRAST 0)	7A
09 (SUB CONTRAST 1)	7A
0A (P.DIMM 1)	00
0B (P.DIMM 2)	00

4. VCO Adjustment (VF-67 board)

Set the free running frequency of the VCO.

If it is not correct, the image will waver.

Mode	Record
Signal	Color bar
Measurement Point	Pin ⑩ of CN902 (PCO)
Measuring Instrument	Oscilloscope (DC range)
Adjustment Page	D
Adjustment Address	B6
Specified Value	$A=2.8 \pm 0.1V$

Adjusting method:

- 1) Check the GND level of the oscilloscope.
- 2) Page: 1, address: 00, data: 01
- 3) Change the data of page: D, address: B6, and adjust the PCO voltage (A) to the specified value.
- 4) Press the PAUSE button of the adjusting remote commander.




Fig. 7-1-28.

5. Bright Adjustment (VF-67 board)

Adjust to the proper LCD panel driving video signal level.

If it is not correct, the image will be saturated (whitish) or blackish.

Mode	Record
Signal	No signal
Measurement Point	Pin ③ of CN902 (G OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	B0 (BRIGHT)
Specified Value	$A=7.0 \pm 0.1V$

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: B0, and adjust the potential difference (A) between the reversed waveform pedestal and the non reversed waveform pedestal to the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.




Fig. 7-1-29.

4. VCO Adjustment (VP-67 board)

Set the free running frequency of the VCO.
If it is not correct, the image will wobble.

Mode	Reset
Signal	Color bar
Measurement Point	Pin (2) of CH02(PIC2)
Measuring Instrument	Oscilloscope (DC range)
Adjustment Page	00
Adjustment Address	00
Specified Value	Analog 2.5V

Adjusting method

- Check the CH02 level of the oscilloscope.
- Page 1, address 00, data, 00
- Change the data of page 01, address 00, and adjust the VCO voltage (V) to the specified value.
- Press the FOCUS button of the adjusting remote control.




Fig. 7-1-26

5. Brightness Adjustment (VP-67 board)

Adjust to the proper LUT1 point (white-black signal level).
If it is not correct, the image will be saturated (pinkish) or blackish.

Mode	Reset
Signal	No signal
Measurement Point	Pin (2) of CH02(PIC2)
Measuring Instrument	Oscilloscope
Adjustment Page	0
Adjustment Address	00 (PASCOT)
Specified Value	Analog 0.5V

Adjusting method

- Page 1, address 00, data, 00
- Change the data of page 01, address 00, and adjust the gamma difference (A) between the current waveform (white) and the set gamma waveform (black) to the specified value.
- Press the FOCUS button of the adjusting remote control.



Fig. 7-1-28

6. Contrast Adjustment (VF-67 board)

Set the contrast of the image.

If the contrast is not correct, the image will be blur (whitish) or saturated.

Mode	Record
Signal	Color bar signal whose chroma and burst signals are turned off
Measurement Point	Pin ③ of CN902 (G OUT)
Measuring Instrument	Oscilloscope External trigger: Pin ③ of IC902 (FRP)
Adjustment Page	D
Adjustment Address	B5 (CONTRAST)
Specified Value	$A=2.0 \pm 0.1V$

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: B5, and adjust the voltage (A) between the white (100%) and pedestal to the specified value.
- 3) Press the PAUSE button of the adjusting remote command.




Fig. 7-1-30.

7. SUB BRIGHT R Preset Adjustment (1) (VF-67 board)

White balance rough adjustment (1)

Mode	Record
Signal	No signal
Measurement Point	Pin ⑦ of CN902 (R OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	B3 (SUB BRIGHT R)
Specified Value	$A=7.0 \pm 0.1V$

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: B3 and adjust the potential difference (A) between the reversed waveform pedestal and the non reversed waveform pedestal to the specified value.
- 3) Press the PAUSE button of the adjusting remote command.




Fig. 7-1-31.

6. Oscilloscope Adjustment (CP-407 board)

On the output of the lamp.

If the waveform is not correct, the range will be 50mV (vertical) or automatic.

Mode	Remark
Signal	Color bar signal whose channel and level signal are turned off
Measurement Value	Pin (2) of CP-407 (pin 40-42)
Measuring Instrument	Oscilloscope General trigger Pin (2) of CP-407 (pin 42)
Adjustment Page	0
Adjustment Address	00 00 00 00 00 00
Specified Value	±0.1V ±1.0V

Adjusting method.

- 1) Page 1, address 00, data 00
- 2) Change the data of page 0, address 00, and adjust the voltage (V) between the white (VCR) and ground to the specified value.
- 3) Press the F4/F5E button of the adjusting master connector.



Fig. 7-1-46

7. SLM 40000 (7) Pin Power Adjustment (7) (CP-407 board)

White balance range adjustment (7)

Mode	Remark
Signal	No signal
Measurement Item	Pin (2) of CP-407 (pin 40-42)
Measuring Instrument	Oscilloscope
Adjustment Page	0
Adjustment Address	00 00 00 00 00 00
Specified Value	±0.1V ±1.0V

Adjusting method.

- 1) Page 1, address 00, data 00
- 2) Change the data of page 0, address 00, and adjust the potential difference (V) between the vertical waveform ground and the two vertical waveforms pattern to the specified value.
- 3) Press the F4/F5E button of the adjusting master connector.



Fig. 7-1-47

8. SUB BRIGHT B Preset Adjustment (2) (VF-67 board)

White balance rough adjustment (2)

Mode	Record
Signal	No signal
Measurement Point	Pin ⑧ of CN902 (B OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	B4 (SUB BRIGHT B)
Specified Value	$A=7.1 \pm 0.1V$

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: B4 and adjust the potential difference (A) between the reversed waveform pedestal and the non reversed waveform pedestal to the specified value.
- 3) Press the PAUSE button of the adjusting remote command-er.




Fig. 7-1-32.

9. White Balance Adjustment

Adjust to the proper white balance level.

If it is not correct, the color reproducibility of the LCD panel will be poor.

Mode	Record
Signal	Color bar signal whose chroma and burst signals are turned off
Measurement Point	Check on the LCD display
Measuring Instrument	
Adjustment Page	D
Adjustment Address	B3 (SUB BRIGHT R), B4 (SUB BRIGHT B)
Specified Value	The display should not be colored

Note: Wait for more than 1 minute after the power supply has been turned on before this adjustment.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Check that the LCD display is not colored. If it is, change the data of address: B3 and address: B4 of page: D, and adjustment the display is not colored.
- 3) Press the PAUSE button of the adjusting remote command-er.

5. SUB-RECENT R Present Adjustment (R)
(20-87 board)
 White balance rough adjustment (R)

Mode	Remark
Signal	No signal
Measurement Point	Pin 82 of U5000-25 (OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	5
Adjustment Address	54 (SUB RECENT R)
Specified Value	Analog 4-5.1V

Adjusting method

- 1) Page 1, address 02, data 00
- 2) Change the data of page 5, address 54 and adjust the potential difference (A) between the external resistance potential and the non-terminal resistance potential to the specified value.
- 3) Push the **PAUSE** button of the adjusting source equipment.



Fig. 3-1-22

6. White Balance Adjustment

Adjust to the proper white balance level.

If this is not correct, the color reproducibility of the LCD panel will be poor.

Mode	Remark
Signal	Color bar signal whose chroma and tinted signals are turned off
Measurement Point	Check on the LCD display
Measuring Instrument	
Adjustment Page	5
Adjustment Address	52 (SUB RECENT R) 54 (SUB RECENT R)
Specified Value	The display should not be adjusted

Notes: Wait for more than 1 minute after the power supply has been opened on before this adjustment.


Adjusting method

- 1) Page 1, address 02, data 00
- 2) Check that the LCD display is not adjusted. If it is, change the data of address 02 and address 54 of page 5, and adjustment to display is not adjusted.
- 3) Push the **PAUSE** button of the adjusting source equipment.

1-5. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS


DD BOARD (CONDUCTOR SIDE)

DD BOARD (COMPONENT SIDE)




CCD-TR42/TR72/TR82/TR400/TR430/TR550/TR750

VF-65 BOARD (COMPONENT SIDE) VF-65 BOARD (CONDUCTOR SIDE)



CCD-TR70/TR80

VF-66 BOARD (COMPONENT SIDE)



1-6. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS

EO BOARD (CONDUCTOR SIDE)



EO BOARD (COMPONENT SIDE)



EO-TRM/TRM/TRM/TRM/TRM/TRM

VF-60 BOARD (COMPONENT SIDE) VF-60 BOARD (CONDUCTOR SIDE)




EO-TRM/TRM


VF-60 BOARD (COMPONENT SIDE)




VC BOARD (COMPONENT SIDE)




VC BOARD (COMPONENT SIDE)




**VF-66 BOARD
(CONDUCTOR SIDE)**



FP-89 BOARD




VC BOARD (COMPONENT SIDE)



VC BOARD (COMPONENT SIDE)



VP-22 BOARD
(CONNECTION SIDE)



VP-22 BOARD



7-2. MECHANICAL SECTION ADJUSTMENTS

Mechanism Parts Adjustments

For details on the adjustments and checks of mechanical section and replacements of mechanism parts, refer to the separate volume-"8 mm Video Mechanism Adjustment Manual IV A Mechanism".

2-1. OPERATING WITHOUT A CASSETTE

- 1) Refer to "2. DISASSEMBLY" and supply the power with the cabinet removed. (So that the mechanical deck can be operated.)
- 2) Connect the adjusting remote commander to the remote terminal.
- 3) Turn on the HOLD switch of the adjusting remote commander.
- 4) Close the cassette compartment without loading a cassette and complete loading.
- 5) Set data: 01 to page: 1, address: 00.
(Release of the protect)
- 6) Set data: 01 to page: D, address: 02, and press the PAUSE button of the adjusting remote commander.
(Emergency prohibition mode setting)
- 7) Set data: 04 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
(Sensor ineffective mode setting)

By carrying out the above procedure, the unit can be operated without loading a cassette.

Be sure to carry out "Processing after Operations" after checking the operations.

Set the data of page: D, address: 03 to the following if the sensor ineffective mode, forced VTR power supply ON mode or forced camera power supply ON mode are to be used together.

Forced VTR power supply ON mode 06

Forced camera power supply ON mode 05

[Processing after Operations]

- 1) Set data: 01 to page: 1, address: 00.
(Release of protect)
- 2) Set data: 00 to page D, address: 02, and press the PAUSE button of the adjusting remote commander.
(Release of the emergency prohibition mode)
- 3) Set data: 00 to page: D, address: 03, and press the PAUSE button of the adjusting remote commander.
(Release of the sensor ineffective mode)
- 4) Set data: 00 to page: 1, address: 00.
(Protect setting)
- 5) Disconnect the power supply of the unit.

7-2. MECHANICAL SECTION ADJUSTMENTS

Mechanism Parts Adjustments

For details on the adjustments and checks of mechanical section and replacement of mechanism parts, refer to the separate volume "3.000 Value Mechanism Adjustment Manual" of 3.000 Series.

3-1. OPERATING WITHOUT A CASSETTE

- 1) Refer to "3.000 CASSETTE" and supply the power with the volume required. (So that the mechanism itself can be operated.)
- 2) Connect the adjusting screw connector to the screw terminal.
- 3) Turn on the HOLD switch of the adjusting screw connector.
- 4) Close the cassette compartment without loading a cassette until complete loading.
- 5) Set data 01 to page 1, address 01.
(Release of tape/print)
- 6) Set data 01 to page 2, address 01, and press the PAUSE button of the adjusting screw connector.
(Emergency protection mode setting)
- 7) Set data 04 to page 2, address 01, and press the PAUSE button of the adjusting screw connector.
(Power lock/release mode setting)

By carrying out the above procedure, the unit can be operated without loading a cassette.

Please to carry out "Processing after Operation" after finishing the operation.

Set the data of page 2, address 01 to the following if the master lock/release mode, forced VTR power supply ON mode or forced cassette power supply ON mode are to be used together.

Forced VTR power supply ON mode -----01

Forced cassette power supply ON mode -----01

(Processing after Operation)

- 1) Set data 01 to page 1, address 01.
(Release of power)
- 2) Set data 02 to page 2, address 01, and press the PAUSE button of the adjusting screw connector.
(Release of the emergency protection mode)
- 3) Set data 02 to page 2, address 01, and press the PAUSE button of the adjusting screw connector.
(Release of the master lock/release mode)
- 4) Set data 01 to page 1, address 01.
(Power setting)
- 5) Disconnect the power supply of the unit.

2-2. TAPE PATH ADJUSTMENT

1. Preparations for adjustments

- 1) Clean the tape path face (tape guide, drum, capstan shaft, pinch roller).
- 2) Connect the adjusting remote commander to the remote terminal.
- 3) Turn on the HOLD switch of the adjusting remote commander.
- 4) Select page: 1, address: 00, and set data: 01.
(Release of the protect)
- 5) Select page: D, address: 01, and set data: 03.
(Set the track shift mode. The adjusting remote commander can be disconnected if its PAUSE button of remote commander is pressed. In this case, be sure to perform "Processing after operations" after completing adjustments.)
- 6) Connect the oscilloscope.
Channel 1-Pin ③ of CN102 of VS board
External trigger-Pin ④ of CN102 of VS board
(Connect the oscilloscope via the measuring pin tool for the video section (J-6082-140-A).)
- 7) Playback the alignment tape (WR5-1NP) for tracking.
- 8) Check that the RF waveform of the oscilloscope is flat at both the entrance and the exit.
If not flat, perform necessary adjustment according to the separate 8 mm Video Mechanical Adjustment Manual IV (A Mechanism).
- 9) Perform "Processing after operations", after completing adjustments.

CN102 of VS board

1	PB 'CH RF
2	PB PCM RF
3	PB RF
4	RF SWP
5	RP GND
6	REC 2

[Processing after operations]

- 1) Connect the adjusting remote commander, and turn on the HOLD switch.
- 2) Select page: 1, address: 00, and set data: 01.
- 3) Select page: D, address: 02, and set data: 00.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Remove the power supply from the unit.




Fig. 7-2-1.

2-2. TAPE PATH ADJUSTMENT

1. Preparations for adjustments

- 1) Check the tape path flow (tape guide, drum, capstan shaft, pinch roller).
- 2) Connect the adjusting remote commander to the remote terminal.
- 3) Turn on the POWER switch of the adjusting remote commander.
- 4) Select page 1, address 00, and set data 00.
(Return to the point)
- 5) Select page 12, address 00, and set data 00.

(For the auto shift mode. The adjusting remote commander can be demonstrated if the FAULT status of remote commander is cleared. In this case, be sure to perform "Processing after operation" after completing adjustments.

2) Connect the multimeter.

Channel 1: Pin ② of CDS01 of VU board
Reference: Page Pin ② of CDS01 of VU board

(Compare the multimeter 0V to the measuring pin test 0V)
(The value within 0.000-0.40-0.0)

- 7) Play back the alignment tape (WFL-00P) for tracking.
- 8) Check that the RF waveform of the multimeter is flat in both the outside and the end.
If not flat, perform necessary adjustment according to the operation 1 and VUba (Mechanical Adjustment Manual 2) (4. Installation).
- 9) Perform "Processing after operation", after completing adjustments.

CDS01 of VU board

1	Pin ② CDS RF
2	Pin ② CDS RF
3	Pin ② RF
4	RF 000P
5	RF 000P
6	RF ②

(Processing after operation)

- 1) Connect the adjusting remote commander and turn on the POWER switch.
- 2) Select page 1, address 00, and set data 00.
- 3) Select page 12, address 00, and set data 00.
- 4) Press the FAULT button of the adjusting remote commander.
- 5) Remove the power supply from the unit.



Fig. 2-2-1

7-3. VIDEO SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 7-92.

3-1. PREPARATIONS BEFORE ADJUSTMENT

The following adjusting instruments are used for adjusting the video section.

3-1-1. Equipments to be Used

- 1) TV monitor
- 2) Oscilloscope: 2 phenomena, band 30 MHz or wider, with delay mode. (Use a 10:1 probe unless specified otherwise.)
- 3) Frequency counter
- 4) Pattern generator with video output terminal
- 5) Digital voltmeter
- 6) Audio generator
- 7) Audio level meter
- 8) Audio distortion meter
- 9) Audio attenuator
- 10) Regulated power supply
- 11) Alignment tape
 - For tracking adjustment (WR5-1NP)
Part Code: 8-967-995-02
 - For Hi8 mode video frequency characteristics adjustment (WR5-7NE)
Part Code: 8-967-995-13
 - For checking normal mode operations
For SP (WR5-5NSP)
Part Code: 8-967-995-42
Or (WR5-4NSP)
Part Code: 8-967-995-41
For LP (WR5-4NL)
Part Code: 8-967-995-51
For checking AFM stereo operations (WR5-9NS)
Part Code: 8-967-995-23
 - For checking Hi8 mode operations (ME tape)
For SP (WR5-8NSE)
Part Code: 8-967-995-43
For LP (WR5-8NLE)
Part Code: 8-967-995-52
- 12) remote commander for adjustment (J-6082-053-A)
- 13) VC board extension cord (42P, 0.8 mm)
Part Code: J-6082-285-A
- 14) Control switch block (FK board)
extension cord (9P, 0.8 mm)
Part Code: J-6082-288-A
- 15) Control switch block (CK board)
extension cord (18P, 0.8 mm)
Part Code: J-6082-289-A
- 16) AU-165 board extension cord (34P, 0.8 mm)
(CCD-TR72/TR80/TR400/TR430/TR750)
Part Code: J-6082-286-A

3-1-2. Adjusting Precautions

- 1) The adjustment for this unit is performed using the VIDEO input (VIDEO terminal input), or the camera input. The camera input can be used for video adjustments only. Use the VIDEO input for the other adjustments.

When using the VIDEO input, set the power supply switch to "PLAYER" or set the "forcible VTR power supply ON mode" using the adjusting remote commander. (Note 1).

When using the camera input, set the power supply switch to "CAMERA" or set the "Forcible camera+VTR power supply ON mode" using the adjusting remote commander (Note 2).

After completing adjustments, be sure to exit the "forcible VTR power supply ON mode" or "forcible camera+VTR power supply ON mode" (Note 3).

- 2) The F panel block (MA board) is not used for video adjustments. Disconnect the following connectors in these adjustments.
 1. CN1301 of the AU board
- 3) The view finder (VF board) is not used for video adjustments. Disconnect the following connector in these adjustments.
 1. CN206 of the VS board (4P, 0.5 mm)
- 4) The cabinet (R) (CK board: Power supply switch, camera function switch) need not be connected if the "forcible VTR power supply ON mode" or "forcible camera+VTR power supply ON mode" is set. In this case, disconnect the following connectors.
 1. CN503 of the VS board (18P, 0.8 mm)
 2. CN101 of the ZB board (4P, 0.8 mm)
 3. CN501 of the VS board (24P, 0.8 mm)
(CCD-TR400/TR750)

However, as disconnecting these connectors means disconnecting the 3V lithium power supply, data set by the user such as the date, time, and menu will be lost. After completing the adjustments, set these data again, and be sure to exit the "forcible VTR power supply ON mode" or "forcible camera+VTR power supply ON mode". (Note 3)
When connecting the cabinet (R) using the extension cord, use the following type.

1. J-6080-289-A (18P, 0.8 mm)

7-3. VIDEO SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 7-52.

7-3-1. PREPARATIONS BEFORE ADJUSTMENT

The following adjusting instruments are used for adjusting the video section.

7-3-1-1. Equipments to be Used

- 1) TV receiver
- 2) Oscilloscope: 2 channels, band 30 MHz or wider, with delay mode (Time) (It is preferable to use specified waveform.)
- 3) Frequency counter
- 4) Pattern generator with video output terminal
- 5) Digital voltmeter
- 6) Audio generator
- 7) Audio level meter
- 8) Audio frequency meter
- 9) Audio attenuator
- 10) Regulated power supply
- 11) Alignment tape

- The tracking adjustment (VCO-VIF)
Ref. Code: 4-997-995-03
- The VCR audio video frequency characteristic adjustment (VRS-VIS)
Ref. Code: 4-997-995-01
- The tracking period audio operation (Re-IF) (VRS-VIS)
Ref. Code: 4-997-995-02
- Or (VRS-VIS)
Ref. Code: 4-997-995-01
- The tracking IF/IF audio operation (VRS-VIS)
Ref. Code: 4-997-995-03
- The tracking IF/IF audio operation (S-IF type)
Ref. IF (VRS-VIS)
Ref. Code: 4-997-995-01
- Or (S-IF type)
Ref. Code: 4-997-995-03

- 12) Rotate extension for adjustment (2-993-995-03)
- 13) VC/level extension cord (20710-01) cord
Ref. Code: 1-6003-389-A
- 14) Control voltage block (VIF board)
extension cord (207, 0.5 mm)
Ref. Code: 1-6003-389-A
- 15) Control voltage block (VCR board)
extension cord (207, 0.5 mm)
Ref. Code: 1-6003-389-A
- 16) A/V/IF/level extension cord (207-0.5 mm)
(CCTV-TV/CCTV/IF-AV/IF/level)
Ref. Code: 1-6003-389-A

7-3-1-2. Adjusting Procedures

- 1) The adjustment for this will be performed using the VIDEO input (VIDEO terminal input), or the remote input. The remote input can be used for video adjustments only. Use the VIDEO input for the color adjustments.

When using the VIDEO input, set the power supply switch to "PLAY/STOP" or set the "Variable VCR power supply ON mode" using the adjusting remote commander (Ref. 5).

When using the remote input, set the power supply switch to "CAMERA" or set the "Variable VCR power supply ON mode" using the adjusting remote commander (Ref. 5).

After completing adjustments, be sure to set the "Variable VCR power supply ON mode" at "Variable camera/VCR power supply ON mode" (Ref. 5).

- 2) The F point block (S-IF board) is not used for video adjustments. Disconnect the following connector in these adjustments.
 1. CONNECT of the A/IF board
- 3) The video filter (VIF board) is not used for video adjustments. Disconnect the following connector in these adjustments.
 1. CONNECT of the VIF board (207-0.5 mm)
- 4) The initial (S) (SIF board) power supply switch, output function switch and set are connected if the "Variable VCR power supply ON mode" or "Variable camera/VCR power supply ON mode" is set. In this case, disconnect the following connectors.
 1. CONNECT of the VIF board (207, 0.5 mm)
 2. CONNECT of the SIF board (207-0.5 mm)
 3. CONNECT of the VIF board (207, 0.5 mm)
(CCTV-TV/CCTV/IF-AV/IF/level)

However, in disconnecting these extension cords, disconnecting the VIF board power supply cable and by the user work on the line, then, set power will be lost. After completing the adjustments, set these data again, and be sure to set the "Variable VCR power supply ON mode" or "Variable camera/VCR power supply ON mode" (Ref. 5).

When connecting the initial (S) using the extension cord use the following type.

1. 1-6003-389-A (207, 0.5 mm)

- 5) The lens block and VC board are not used for video adjustments. Disconnect the following connectors in these adjustments.

1. CN203 of the VS board (42P, 0.8 mm)
2. CN775 of the VC board (8P, 0.8 mm)
(CCD-TR82/TR400/TR550/TR750)

Connect the following when removing the VC board.

1. Connect Pin ② (REG H) and Pin ⑦ (D3.6V) of CN203 of the VS board with a jumper wire.

When connecting the VC board using the extension cord, use the following type.

1. J-6080-285-A (42P, 0.8 mm)

- 6) The audio board (AU board) is required only for audio adjustments. When not using it, disconnect the following connector.

1. CN202 of the VS board

When connecting the AU-165 board (CCD-TR72/TR80/TR400/TR430/TR750) using the extension cord, use the following type.

1. J-6080-286-A (34P, 0.8 mm)

- 7) When opening the VS board, disconnect the following connectors.

1. CN502 of the VS board (9P, 0.8 mm)

The VTR function keys will not work. Use the remote commander to perform operations other than EJECT.

When connecting the FK board and CN502 of VS board using the extension cord, use the following type.

1. J-6080-288-A (9P, 0.8 mm)

Note 1: Setting the “forcible VTR power supply ON mode (VIDEO input mode)”

- 1) Set data: 01 to page: 1, address: 00.
(Releasing the page D protect)
- 2) Set data: 02 to page: D, address: 03 and press the PAUSE button of the adjusting remote commander.
(Setting the forcible VTR power supply ON mode)

By performing the above, the VTR can be operated with the cabinet (R) removed. After completing adjustments, be sure to exit the “forcible power supply ON mode”.

Note 2: Setting the “forcible camera+VTR power supply ON mode (camera input mode)”

- 1) Set data: 01 to page: 1, address: 00.
(Releasing the page D protect)
- 2) Set data: 03 to page: D, address: 03 and press the PAUSE button of the adjusting remote commander.
(Setting the forcible camera+VTR power supply ON mode)

By performing the above, the VTR can be operated with the cabinet (R) removed. After completing adjustments, be sure to exit the “forcible power supply ON mode”.

Note 3: Exiting the “forcible power supply ON mode”

- 1) Set data: 01 to page: 1, address: 00.
(Releasing the page D protect)
- 2) Set data: 00 to page: D, address: 03 and press the PAUSE button of the adjusting remote commander.
(Setting the forcible power supply ON mode)
- 3) Set data: 00 to page: 1, address: 00.
(Setting the page D protect)

3-1-3. Connecting the Equipments

Connect the measuring instruments as shown in Fig. 7-3-1. according to the input terminal specifications (VIDEO input or CAMERA input), and perform the adjustments.

The input terminal is specified in the () in the signal column. Either input terminal can be used when there are no specifications.

Note 1: If the VIDEO input is used for the adjustments which specify for the CAMERA input to be used, the product specifications of the unit may not be satisfied in some cases. Be sure to perform according to the specifications.

Note 2: When adjustments are performed with the S video output terminal VTR as the signal source, the efficiencies of the unit may be affected by VTR. It is recommended that a pattern generator with a Y/C separation output terminal be used as much as possible.

- f) The fan speed and VC board are not used for other adjustments. Document the following operation in these adjustments:

1. CH000 of the VC board (P00, 0.0 mm)
2. CH005 of the VC board (P0, 0.0 mm)
- CH000-TH000-TH000-TH000-TH000

Connect the following wires connecting the VC board.

1. Connect Pin (4) (SMD 15) and Pin (2) (SMD 15) of CH000 of the VC board with a jumper wire.

When connecting the VC board using the extension cord, use the following type.

1. J-0000-000-A (P0, 0.0 mm)

- g) The scale board (S0 board) is required only for scale adjustments. When not using it, document the following operation:

1. CH000 of the VC board
- When connecting the S0-000 board (CH0-000-TH000-TH000-TH000-TH000) using the extension cord, use the following type.

1. J-0000-000-A (P0, 0.0 mm)

- h) When opening the VC board, document the following operation:

1. CH000 of the VC board (P0, 0.0 mm)

The VTR focusing lens will not work. Use the remote commander to perform operations other than DIRECT.

When connecting the VC board and CH000 of VC board using the extension cord, use the following type.

1. J-0000-000-A (P0, 0.0 mm)

Note 1: Setting the "Invisible VTR power supply ON mode (VTR000 input mode)"

- 1) Set data 04 in page 1, address 00.

(Following the page 2 content)

- 2) Set data 00 in page 0, address 00 and press the F4/000 button of the adjusting remote commander.
(Setting the Invisible VTR power supply ON mode)

By performing the above, the VTR can be operated with the infrared (IR) command. After completing adjustments, be sure to set the "Invisible power supply ON mode".

Note 2: Setting the "Invisible remote/VTR power supply ON mode (input mode)"

- 1) Set data 01 in page 1, address 00.

(Following the page 2 content)

- 2) Set data 00 in page 0, address 00 and press the F4/000 button of the adjusting remote commander.
(Setting the Invisible remote/VTR power supply ON mode)

By performing the above, the VTR can be operated with the infrared (IR) command. After completing adjustments, be sure to set the "Invisible power supply ON mode".

Note 3: Setting the "Invisible power supply ON mode"

- 1) Set data 01 in page 1, address 00.

(Following the page 2 content)

- 2) Set data 00 in page 0, address 00 and press the F4/000 button of the adjusting remote commander.
(Setting the Invisible power supply ON mode)

- 3) Set data 00 in page 1, address 00.

(Following the page 2 content)

5-4-5. Connecting the Equipment


Connect the measuring instruments as shown in Fig. 5-54, according to the type critical specifications (VTR000 input or CH000A input), and perform the adjustments.

The input terminal is specified in the [] in the signal column. Other input terminal can be used when there are no specifications.

Note 1: If the VTR000 input is used for the adjustments which specify for the CH000A input to be used, the product specifications of the test may not be satisfied in some cases. Be sure to perform according to the specifications.

Note 2: When adjustments are performed with the 2 video output terminal VTR as the signal source, the synchronization of the test may be affected by VTR. It is recommended that a pattern generator with a VC separate output terminal be used as much as possible.


Connecting the TV monitor and regulated power supply



Connecting the pattern generator

[VIDEO Input]

Set the power supply switch to "PLAYER" or set the "forcible VTR power supply ON mode" using the adjusting remote commander.




Note: The TV monitor cannot be connected. Use the view finder to monitor.


[CAMERA Input]

Set the power supply switch to "CAMERA" or set the "forcible camera+VTR power supply ON mode" using the adjusting remote commander.

- When the pattern generator has a Y/C separation output terminal



- When the pattern generator has no Y/C separation output terminal



Note 1: Remove the VC board.

Note 2: Connect Pins ⑦ and ② of CN203 with the jumper wire.

Note 3: The chroma signal input is not required for some adjustments.

3-1-4. How to Set the REC Mode in the Model with out REC switch

- REC key forbidden accept mode cancel
 1. Connect the adjusting remote commander to the remote terminal.
 2. Turn on the power.
 3. Turn on the HOLD switch of the adjusting remote commander.
 4. Select the page: 1 address: 00, and set the data to 01. (Protect mode cancel)
 5. Select the page: D address: 17, and set the data to 12 [13].^{Note 1} (REC key forbidden accept mode cancel)
 6. Press PAUSE button on the adjusting remote commander. (Write to the non-volatile memory)

The REC key is accepted through the above procedure.

- REC mode setting
 1. Turn off the HOLD switch of the adjusting remote commander.
 2. Press REC buttons of the adjusting remote commander.
 3. Perform "3. Procedure after completed the adjustment", after completing adjustment.
- Procedure after completed the adjustment

Be sure to return the mode to REC key forbidden accept mode after adjustment.

 1. Connect the adjusting remoter controller.
 2. Turn on the power.
 3. Turn on HOLD switch of the adjusting remote commander.
 4. Select the page: 1 address: 00, and set the data to 01. (Protect mode cancel)
 5. Select the page: D address: 17, and set the data to 02 [03].^{Note 1} (Setting of the REC key forbidden accept mode)
 6. Press PAUSE button on the adjusting remote commander. (Write to the non-volatile memory)
 7. Turn off the power.

Note 1: No mark : CCD-TR42/TR70/TR72/TR80/TR82
[] : CCD-TR430/TR550

Fig. 7-3-1.

3-1-5. Checking the Input Signals

Because the video signal obtained from the pattern generator is used as the adjustment signal for adjusting the VTR section, the video output signal must satisfy the given specifications.

1. CAMERA Input

Connect the oscilloscope to Pin ⑬ of CN203 on VS board, and check that the sync signal of the Y signal is approximately 0.143 Vp-p and that the amplitude of the video section is approximately 0.357 Vp-p. (When a VTR with the S VIDEO output terminal is used, also check that the chroma signal and burst signal have not remained.) Connect the oscilloscope to Pin ⑰ of CN203 on VS board, and check that the burst signal amplitude of the chroma signal is approximately 0.143 Vp-p and flat, and that the amplitude ratio of the burst signal to the chroma signal is 0.30:0.66. The Y and chroma signals used in the adjustment are shown in Fig. 7-3-2.




Fig. 7-3-2. Color bar signal of pattern generator

2. VIDEO Input

Connect the oscilloscope to the video input/output terminal, and check that the sync signal amplitude of the video signal is approximately 0.286V, the amplitude of the video section is approximately 0.714V, the amplitude of the burst signal is approximately 0.286V and flat, and that the level ratio of the burst signal to the "red" signal is 0.30:0.66.

The video signal (color bar) used for adjusting the VTR section is shown in Fig. 7-3-3.




Fig. 7-3-3. Color Bar Signal of Pattern Generator

3rd-8. Checking the Input Signals

Between the video signal obtained from the pattern generator is used as the reference signal for adjusting the VTR section, the color input signal must satisfy the given specifications.

1. CAMERA Input

Connect the oscilloscope to Pin (2) of C3000 on V5 board, and check that the sync signal of the Y signal is approximately 0.24V. Very carefully the amplitude of the video section is approximately 0.20V Vpp. (When a VTR with the S-VHS input signal is used, also check that the chroma signal and burst signal level are correct.) Connect the oscilloscope to Pin (3) of C3000 on V5 board, and check that the burst signal amplitude of the chroma signal is approximately 0.14V Vpp and that the amplitude ratio of the burst signal to the chroma signal is 0.0014. The Y and chroma signals used in the adjustment are shown in Fig. 7-5-2.




Fig. 7-5-2. Color bar signal of pattern generator

2. VHS/Hi Input

Connect the oscilloscope to the video input/output terminal, and check that the sync signal amplitude of the video signal is approximately 0.28V, the amplitude of the video section is approximately 0.21V, the amplitude of the burst signal is approximately 0.08V and that the burst ratio of the burst signal to the "red" signal is 0.0008.

The video signal (center left) used for adjusting the VTR section is shown in Fig. 7-5-3.




Fig. 7-5-3. Color bar signal of Pattern Generator

3-1-6. Alignment Tape

The following table lists alignment tapes which are available.
Use the tape specified in the signal column for each adjustment.

If the type of tape to be used for checking operations is not specified, use whichever type.

Name	Record-ing mode	Tape type	Tape speed	Recording contents		Usage
				Video area	PCM area	
Tracking WR5-1NP	L	MP	SP	CH2: Signal for 1 MHz tape path adjustment		Tape path adjustment Switching position adjustment
Video frequency characteristics WR5-7NE	E	ME	SP	RF sweep 0 to 15 MHz Marker 2, 4.5, 7, 8.5, 10 MHz		Frequency characteristics adjustment
Video frequency characteristics WR5-2N	L	MP	SP	RF sweep Marker 1, 3.58, 5.5, 7 MHz		
Operation check (SP mode) WR5-5NSP	L	MP	SP	<ul style="list-style-type: none"> Video signal Color bar 4 minutes Monoscope 4 minutes Audio signal (AFM) 400 Hz 60% modulation 	<ul style="list-style-type: none"> Audio signal (PCM) Monoscope section 20 Hz 20 sec. 400 Hz 20 sec. 14 kHz 20 sec. } Repeated 4 times Color bar section 1 kHz 4 minutes 	Checking operations
Operation check WR5-8NSE	E	ME	SP		<ul style="list-style-type: none"> Audio signal (PCM) 400 Hz 	
Operation check WR5-4NL	L	MP	LP	<ul style="list-style-type: none"> Video signal Color bar 4 minutes Monoscope 4 minutes Audio signal (AFM) 400 Hz 60% modulation 		
Operation check WR5-8NLE	E	ME	LP		<ul style="list-style-type: none"> Audio signal (PCM) 400 Hz 	
AFM stereo Operation check WR5-9NS	L	MP	SP	<ul style="list-style-type: none"> Video signal Color bar 4 minutes Monoscope 4 minutes Audio signal (AFM) Stereo section (color bar) Lch: 400 Hz, Rch: 1 kHz $\left(\begin{array}{l} L+R: \\ 1.5 \text{ MHz} \pm 60 \text{ kHz DEV} \\ L-R: \\ 1.7 \text{ MHz} \pm 30 \text{ kHz DEV} \end{array} \right)$ Bilingual section (Monoscope) MAIN: 400 Hz (1.5 MHz \pm 60 kHz DEV) SUB: 1 kHz (1.7 MHz \pm 30 kHz DEV) 	<ul style="list-style-type: none"> Audio signal (PCM) 400 Hz 8 minutes 	AFM stereo Checking operations

Note: Recording mode

L Normal (Original) mode
E hi8 (hi band) mode

Tape type

MP Particle type metal tape
ME Evaporated type metal type

Table 7-3-1.

9-1-4. Alignment Types

The following table lists alignment types which are available.
Use the type specified in the signal column for each adjustment.

If the type of type to be used for identifying systems is not specified, any equivalent type.

Name	Mounting type method	Type type	Type signal	Recording standards		Usage
				Video area	PCM area	
Tuning WB3-070	L	10P	10P	GCR signal for 1 Mbit type (only adjustment)		Type path adjustment Following position adjustment
Video frequency characteristics WB3-070	B	10B	10P	RF video line (100MHz) Monitor 2.4-5, 7, 8.5, 10 MHz		Frequency characteristics adjustment
Video frequency characteristics WB3-070	L	10P	10P	RF video Monitor 1.5-5.5, 8.5, 10 MHz		
Operation check GPI mode WB3-070P	L	10P	10P	<ul style="list-style-type: none"> Video signal Color bar waveform Monochrome waveform Audio signal (APM) 400 Hz-5 kHz modulation 	<ul style="list-style-type: none"> Audio signal (PCM) Monochrome waveform 40 Hz-5 kHz Color bar waveform 40 Hz-5 kHz 	Checking operations
Operation check WB3-070B	B	10B	10P		<ul style="list-style-type: none"> Audio signal (PCM) 400 Hz 	
Operation check WB3-070L	L	10P	10P	<ul style="list-style-type: none"> Video signal Color bar waveform Monochrome waveform Audio signal (APM) 400 Hz-5 kHz modulation 	<ul style="list-style-type: none"> Audio signal (PCM) 400 Hz 	
Operation check WB3-070L1	B	10B	10P		<ul style="list-style-type: none"> Audio signal (PCM) 400 Hz 	
APM mode Operation check WB3-070	L	10P	10P	<ul style="list-style-type: none"> Video signal Color bar waveform Monochrome waveform Audio signal (APM) Binaural (stereo) Left: 400 Hz, Right: 1 kHz (Left) (Left: 1 kHz & 400 Hz APM) (Right) (Right: 1 kHz & 400 Hz APM) Binaural waveform (Monochrome) 400 Hz-5 kHz (1.5 MHz & 400 Hz CPM) (500-1 kHz) (1.5 MHz & 20 kHz CPM) 	<ul style="list-style-type: none"> Audio signal (PCM) 400 Hz-5 kHz 	APM mode Checking operations

Note: Recording mode

- L: Monochrome (Luminance) mode
B: Binaural (stereo) mode

Type type

- 10P: Parallel type (normal type)
10B: Binaural type (normal type)

Table 9-1-1.

Fig. 7-3-4. shows the 75% color bar signals recorded on the alignment tape.

Note: Measure using the video output terminal (Terminated at 75 Ω)




Fig. 7-3-4. Color Bar Signals of the Alignment Tape

3-1-7. Input/Output Level and Impedance

1. CCD-TR42/TR70/TR72/TR80/TR82/TR430/TR550

Video output Phono jack, 1 Vp-p, 75 Ω ,
unbalanced, sync negative

Audio output Phono jack, -7.5 dBs,
(at load impedance 47 k Ω)
impedance less than 2.2 k Ω

2. CCD-TR400/TR750

S video input/output 4-pin mini DIN,
Luminance signal:
1 Vp-p, 75 ohms,
unbalanced, sync negative

Chrominance signal:
0.286 Vp-p, 75 ohms, unbalanced

Video input/output Phono jack, 1 Vp-p, 75 ohms, unbalanced,
sync negative

Audio input/output Phono jack,
Input: -7.5 dBs, input impedance more
than 47 kilohms
Output: -7.5 dBs, (at load impedance
47 kilohms), impedance less than
2.2 kilohms

Fig. 7-3-4 shows the YTS color bar signals recorded on the alignment tape.

Monitor Monitor using the video output recorded (Demonstrated at 75-2)




Fig. 7-3-4. Color Bar Signals of the Alignment Tape

2-1-1. Input/Output Level and Impedance

1. OSD-TRM/TS-TRM/TS-TRM/TS-TRM/TS-TRM

Video output: Phase (all), 1 Vp-p, 75 Ω , balanced, sync negative

Audio output: Phase (all), -1.0 dB, balanced, sync negative
(all level impedance 75 Ω)
Impedance: 100 Ω (all 1.2 k Ω)

2. OSD-TRM/TS-TRM

Video input/output: 1 Vp-p, 75 Ω , balanced, sync negative
Impedance: 100 Ω (all 1.2 k Ω)
Audio input/output: Phase (all), 1 Vp-p, 75 Ω , balanced, sync negative
Impedance: 100 Ω (all 1.2 k Ω)
Input: -1.0 dB, 100 Ω (all 1.2 k Ω)
Output: -1.0 dB, 100 Ω (all 1.2 k Ω)
Impedance: 100 Ω (all 1.2 k Ω)

3-1-8. Service Mode

1. Setting the service mode


The service mode consists of the adjustment mode which adjusts the EVR and the test mode which shows the condition of the unit.

The unit can be set into the test mode and adjustment mode by connecting the adjusting remote commander (Set the HOLD switch to "HOLD").

LCD Display of the Adjusting Remote Controller


0:00:00
 Page Data Address

(1) Service LANC memory map



Page	Page Layout
0	
1	D page write protect setting/release
2	Mode controller RAM, I/O
3	Mechanism controller RAM, I/O
4	
5	
6	Shared by camera section
7	Camera controller RAM, I/O
8	
9	
A	2 bytes data display
B	
C	
D	VTR EEPROM (Note 1)
E	
F	Camera EEPROM (Note 2)

Adjusting remote commander RM-95 (J-6082-053-A)



Note 1: The data of this page is written in the EEPROM (IC501 of VS board).

Note 2: The data of this page is written in the EEPROM (IC601 of VC board).

(2) Category codes

This unit uses category codes for pages 2 and 3.

(Example)

Specification of	Page 2	Category 01	Address 47
------------------	--------	-------------	------------


Page 2 is the mode controller

Page 3 is the mechanism controller

The actual category and address are specified by the adjusting remote commander as follows.

Order	Page	Address	Data	Procedure
1	2	00	01	Select category 01 using the data of page 2, address 00. From here onwards, category 01 will be selected at page 2 until the data of page 2, address 01 is rewritten.
2	2	47		As the data of page 2, address 00 is 01, select page 2, address 47 to select page 2, category 01, address 47. (The data of this address is the battery voltage A/D conversion value of the mode controller input.)

[Shifting to the service mode using the adjusting remote commander]



Command Name	Command Function	Normal LANC Command
Page Up	Page+1	Edit Search+
Page Down	Page-1	Edit Search -
Direct Page Set	Sets to the specified page	Event Clear
Address Up	Address+1	Fast Forward
Address Down	Address-1	Rewind
Data Up	Data+1	Play Back
Data Down	Data-1	Stop
Store	Writes data in the EEPROM, RAM	Pause

(3) Additional note on adjustment


After the completion of the all adjustments, cancell the adjustment mode by either of the following ways.

- 1) Unplug the main power supply and remove the lithium battery. (In this case, date and time and menu setting have been set by users are canceled. Perform resetting.)
- 2) Return data of the address: 00 on page: 1 to 00. And when data on page: 2 is changed, return the data to the original condition.

(2) Category code

The next two category codes for pages 1 and 2.


(Example)



The target category and address are specified by the following remote commands as follows.

Order	Page	Address	Date	Procedure
1	1	00	01	Select category(01) using the date of page 1, address 00. From here onwards, category 01 will be selected in page 2 with the date of page 1, address(0) is modified
2	2	01		At the date of page 1, address 00 to 01, select page 2, address 01 to select page 2, category 01, address 01 (The date of this address is the factory voltage A/D representing value of the mode controller system)

(Referring to the remote mode using the following remote commands)



Remote Mode	Command Function	Normal/ABN Command
Page 1/2	Page 1	Left Arrow
Page 0/100	Page 1	Left Arrow
Direct/Range for	Mode for the specification page	Power/Stop
Address 0/1	Address 0	Power/Forward
Address 0/1	Address 1	Power/Forward
Slide Up	Slide 1	Power/Slide
Slide Down	Slide 2	Power/Slide
Slide	Write data to the A/D register, hold	Power/Slide

(3) Additional note on adjustment

After the completion of the all adjustments, reset the adjustment mode by either of the following steps.

- Display the main power supply and restore the slides, battery (In this case, data not store and system setting have been set by users are restored. No data is restored.)
- Select date of the address 00 on page 1 to 00, and adjust date on page 2 is changed, return the date to the original condition

2. Page D write protect

Release/set the page D write protect.

Page 1	Address 00
--------	------------

Data	Function
00	Normal (Write protect condition)
01	Release the write protect

3. Test mode setting

Set/release each test mode. Release the protect (Page: 1, Address: 00, Data: 01) before setting the data.

Page D	Address 02
--------	------------

Data	Function
00	Normal
01	Test mode 1 Various emergency prohibitions and releases Drum, capstan, loading motor, reel, tape top and end, DEW SP/LP automatic discrimination prohibition, manual switching, 5 minutes pause release prohibition Power off prohibition/release by battery end
02	Test mode 2 Not used
03	Test mode 3 Track shift Performs the track shift playback Rear lock distinction prohibition during PB SP/LP automatic discrimination prohibition, manual switching
04	Test mode 4 Rear lock mode Performs rear lock playback SP/LP automatic discrimination prohibition, manual switching

- ※ For page D, the data set will be recorded in the nonvolatile memory by pressing the PAUSE button on the adjusting remote commander. Take note that, in this case, the test mode will not be released even if the main power has been turned off (6.3 Vdc).
- ※ Be sure to return this address data to 00 after completing adjustments/repairs and press the PAUSE button of the adjusting remote commander.

4. Emergency code

Fault (error) symptoms can be checked.

Page D	Address E4
--------	------------

Last emergency code

.....Last error code generated (This data will be renewed each time an error occurs.)

Page D	Address E8
--------	------------

2nd emergency code

.....2nd error code generated

Page D	Address EC
--------	------------

First emergency code

.....First error code generated

- ※ Be sure to rewrite the data of addresses E4, E8 and EC to 00 after repairs/adjustments.
- ※ When rewriting the data, be sure to press the PAUSE button of the remote commander after setting the data.

Code	Error Condition
00	No error
01	Loading motor error
02	Reel error during unloading
03	Reel errors at other times
04	Capstan error
05	FG error during drum start up
06	PG error during drum start up
07	FG error during normal drum conditions
08	PG error during normal drum conditions
09	Phase error during normal drum conditions

8. Page 3 write protect

Subsequent the page 3 write protect.

Page 3	Address 00
00	Normal (data/content protection)
01	Release the write protect

9. Test mode switching

Enter/leave mode test mode. Activate the pattern (Page 1, Address 00, Data 00) before writing the data.

Page 02	Address 00
---------	------------

State	Function
00	Normal
01	Test mode 1 Various emergency protection and activate Error response, loading error, test response and etc. (With SPOLP automatic discrimination, protection, manual switching, it controls power response protection) Power off protection/release by history and
02	Test mode 2 Not used
03	Test mode 3 Input and Response for test and playback Playback data also protection during PG (Prior automatic discrimination protection, manual switching)
04	Test mode 4 Power test mode Response test and playback SPOLP automatic discrimination protection, manual switching

- For page 03, the data set will be processed in the microtable memory by pressing the PG/DIR button on the adjusting remote commander. Take care that, in this case, the test mode will not be released even if the main power has been closed off (p.133)
- Be sure to return the address data to 00 after completing adjustment/operation and press the PG/DIR button of the adjusting remote commander

4. Emergency code

Test (error) response can be checked

Page 0	Address 00
--------	------------

Last emergency code

---Last error code generated (This data will be returned each time an error occurs.)

Page 0	Address 00
--------	------------

Last emergency code

---Last error code generated

Page 01	Address 00
---------	------------

Last emergency code

---Last error code generated

- Be sure to return the data of addresses 04, 05 and 06 to 00 after operation/adjustment.
- When entering the data, be sure to press the PG/DIR button of the remote commander after setting the data.

State	Error Condition
00	No error
01	Loading error state
02	Power error during switching
03	Power error at other time
04	Capacitor error
05	PG error during other start up
06	PG error during other start up
07	PG error during operation protection
08	PG error during normal start procedure
09	Power error during normal start procedure

5. Emergency mode

The operation mode can be checked during faults.

Page D	Address E5
--------	------------

Last emergency mode

.....The operation mode when the last error is generated
(This data will be renewed each time an error occurs.)

Page D	Address E9
--------	------------

2nd emergency mode

.....The operation mode when the 2nd error is generated

Page D	Address ED
--------	------------

First emergency mode

.....The operation mode when the first error is generated

※ Be sure to rewrite the data of addresses E5, E9 and ED to 00 after repairs/adjustments.


※ When rewriting the data, be sure to press the PAUSE button of the adjusting remote commander after setting the data.

Code	Error Conditions
00	BEFOR INITIALIZE
01	EJECTED
02	NORMAL STOP
03	FF
04	NORMAL REC
06	NORMAL PB
07	PB PAUSE
12	LOADING
14	REC PAUSE
26	X1
27	1/5 SLOW
31	UNLOADING
46	CUE
56	REVIEW
62	STOP TAPE END
66	X2
67	FRAME
72	STOP TAPE TOP
83	REWIND
85	REC REVIEW (+)
95	REC REVIEW (-)
97	-PB PAUSE
A2	EMERGENCY LOADING
A5	EDIT SEARCH (+)
B1	EMERGENCY UNLOADING
B2	STOP EMERGENCY 1
B5	EDIT SEARCH (-)
C2	STOP EMERGENCY 2
E2	STOP NO CASSETTE
F5	EDIT PAUSE

6. Bit value discrimination

Bit values must be discriminated using the display data of the adjusting remote commander for the following items. Use the table below to discriminate if the bit value is "1" or "0".

Adjusting remote commander display



Remote controller display	Bit value			
	bit 3 or bit 7	bit 2 or bit 6	bit 1 or bit 5	bit 0 or bit 4
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
Ⓐ→ 8	1	0	0	0
9	1	0	0	1
A(A)	1	0	1	0
B(B)	1	0	1	1
C(C)	1	1	0	0
D(D)	1	1	0	1
Ⓑ→ E(E)	1	1	1	0
F(F)	1	1	1	1

(Example) If the remote commander display data is "8E", bit values from bit7 to bit4 can be discriminated from column Ⓐ, and those from bit3 to bit0 from column Ⓑ.

4. Emergency mode

The operation mode can be changed during tests.

Page 0	Address 00
--------	------------

End emergency mode

→ The operation mode when the test error is generated.
(This can be set to normal mode or emergency mode.)

Page 0	Address 00
--------	------------

End emergency mode

→ The operation mode when the test error is generated.

Page 0	Address 00
--------	------------

Test emergency mode

→ The operation mode when the test error is generated.

5. Be sure to verify the data of addresses 00, 01 and 02 in 00 after operation/operation.

6. When verifying the data, be sure to press the [PAUSE] button of the adjusting remote commander when setting the data.

Code	Error Description
00	START INITIAL
01	START
02	INITIAL STOP
03	PP
04	INITIAL/REC
05	INITIAL /P
06	PP PAUSE
07	PP PAUSE
08	PP
09	PP
10	PP
11	PP
12	PP
13	PP
14	PP
15	PP
16	PP
17	PP
18	PP
19	PP
20	PP
21	PP
22	PP
23	PP
24	PP
25	PP
26	PP
27	PP
28	PP
29	PP
30	PP
31	PP
32	PP
33	PP
34	PP
35	PP
36	PP
37	PP
38	PP
39	PP
40	PP
41	PP
42	PP
43	PP
44	PP
45	PP
46	PP
47	PP
48	PP
49	PP
50	PP
51	PP
52	PP
53	PP
54	PP
55	PP
56	PP
57	PP
58	PP
59	PP
60	PP
61	PP
62	PP
63	PP
64	PP
65	PP
66	PP
67	PP
68	PP
69	PP
70	PP

4. Bit value identification

The bit value can be determined using the display data of the adjusting remote commander for the following items. Use the table below to determine if the bit value is "1" or "0".

Adjusting remote commander display



Remote commander display	Bit value			
	bit 0 or bit 1	bit 4 or bit 5	bit 8 or bit 9	bit 12 or bit 13
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
A(10)	1	0	1	0
B(11)	1	0	1	1
C(12)	1	1	0	0
D(13)	1	1	0	1
E(14)	1	1	1	0
F(15)	1	1	1	1

(Example) If the remote commander display data is "00", bit values from bit 0 to bit 15 are the characteristics from column 0, and from bit 0 to bit 15 from column 0.

7. Battery voltage check

Page 2	Category 01	Address 47
--------	-------------	------------

Display Data	Battery Voltage
F0	Approx. 10.6 Vdc
E0	Approx. 9.9 Vdc
D0	Approx. 9.2 Vdc
C0	Approx. 8.5 Vdc
B0	Approx. 7.8 Vdc
A0	Approx. 7.1 Vdc
90	Approx. 6.4 Vdc
80	Approx. 5.7 Vdc
70	Approx. 5.0 Vdc

Using method:

Order	Page	Address	Data	Procedure
1	2	00	01	Specification of category 01
2	2	47		The battery voltage can be discriminated by the display data.

※ Voltage measurement accuracy is approx. $\pm 10\%$.

7. Battery voltage sheet

Page: 2	Category: 01	Address: 07
Display Data	Battery Voltage	
FD	Approx. 13.6 Vdc	
ED	Approx. 8.8 Vdc	
DD	Approx. 8.8 Vdc	
CD	Approx. 8.8 Vdc	
BD	Approx. 7.8 Vdc	
AD	Approx. 6.8 Vdc	
BD	Approx. 6.8 Vdc	
BD	Approx. 6.7 Vdc	
FD	Approx. 8.8 Vdc	

Using method:

Order	Page	Address	Data	Procedure
1	2	02	00	Specification of category 01
2	2	07		The battery voltage can be illustrated by the display data.

■ Voltage measurement accuracy is approx. ± 0.05%.

8. Mechanism controller Input/output check

Page 2	Category 00	Address 83
--------	-------------	------------

Bit	Input Signal	Input Signal Level
0		
1	E/L DET	"1"=Hi8, "0"=Normal
2	SP/LP DET	"1"=SP, "0"=LP
3	CLOG DET	"1"=Clog detected, "0"=Others
4	REC PROOF	"1"=Recording prohibited, "0"=Recording possible
5	TAPE PREEND	"1"=Tape preend, "0"=Others
6	DEW DET	"0"=Condensation occurred, "1"=Others
7	CASSETTE IN	"0"=No cassette

Using method:

Order	Page	Address	Data	Procedure
1	2	00	00	Specification of category 00
2	2	83		The condition of each input signal can be discriminated by differentiating the bit value of the display data.

Page 2	Category 00	Address 84
--------	-------------	------------

Bit	Input Signal	Input Signal Level
0	VA PB MODE	"1"=PB, "0"=REC
1	RP PB MODE	"1"=PB, "0"=REC
2	JOG	"1"=Variable speed playback, "0"=Others
3	ME/MP SW	"1"=ME tape, "0"=Other tape
4	Hi8 MP SW	"1"=Hi8 MP tape, "0"=Other tape
5	SERVO OPERATION	"1"=SP mode, "0"=LP mode
6	VIDEO MUTE	"1"=Mute, "0"=Video output
7	AUDIO MUTE	"1"=Mute, "0"=Audio output

Using method:

Order	Page	Address	Data	Procedure
1	2	00	00	Specification of category 00
2	2	84		The condition of each signal can be discriminated by differentiating the bit value of the display data.

5. Mechanism controller Input/output sheet

Page 2	Category 00	Address 00
---------------	--------------------	-------------------

Bit	Input Signal	Input Signal Level
0		
1	SL DET	"True, "False
2	SPIN DET	"SP, "NAP
3	CLAM DET	"Clamp closed, "Clamped
4	REC-PROOF	"Recovery pending, "Recovery possible
5	TAPE-PROOF	"Tape present, "Others
6	DEM DET	"Demagnetism sensed, "Others
7	CASSETTE IN	"Yes cassette

Using method

Order	Page	Address	Size	Precondition
1	2	00	00	Specification of category 00
2	2	01		The condition of each input signal can be identified/checked by differentiating the bit values of the display data.

Page 2	Category 00	Address 04
---------------	--------------------	-------------------

Bit	Input Signal	Input Signal Level
0	UL-PE IN/OUT	"UL-PE, "N-PEOC
1	RP-PE IN/OUT	"True, "False
2	JOG	"Variable speed playback, "Others
3	WIND-UP	"Full tape, "Other tape
4	REW-UP	"Full RT tape, "Other tape
5	REWIND OPERATIONS	"Full mode, "W-UP mode
6	VIDEO MUTE	"Video, "Audio output
7	AUDIO MUTE	"Video, "Audio output

Using method

Order	Page	Address	Size	Precondition
1	2	04	04	Specification of category 00
2	2	04		The condition of each signal can be identified/checked by differentiating the bit values of the display data.

9. Mode switch and CC DOWN switch check


The mode switch position (mechanical section condition) can be checked.

Page 3	Category 00	Address E9
--------	-------------	------------

Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
MSW 2	MSW 1	MSW 0	CC DOWN				

				DATA	POSITION	FUNCTION
0	0	0	0/1	E*/F*	BL	Interval of each position
0	1	1	1	7*	END	FULL END processing (T side lock removal)
0	0	1	1	3*	EJECT	Cassette compartment ejection
1	0	1	1	B*	USE	EJECTED (Unskate end)
0	0	1	0	2*	LOAD	LOADING (Skate in)
1	0	0	0	8*	READY	NORMAL STOP position
1	1	0	0	C*	TURN	OFF of pinch roller only with STOP↔FF/REW (oscillating position)
0	1	0	0	4*	RP	PB, REC, RVS, REV, CUE
0	0	0	0	0*	FF	FF/REW

*: Don't care



Using method:

Order	Page	Address	Data	Procedure
1	3	00	00	Specification of category 00
2	3	E9		The mode switch position and CC DOWN switch condition can be discriminated by the display data.

2. Mode switch and CE (CCM) status check

The mode switch pattern (mechanical action condition) can be checked.

Page ID	Category ID	Address ID
---------	-------------	------------

act	loc	loc	dir	act	act	dir	act
act01	act01	act01	CCM000				

act	loc	loc	dir	data	position	Function
0	0	0	00	0100	00	Initial of act position
0	0	0	0	10	000	FEEL SW? (sensing, 7 bits (only correct))
0	0	0	0	01	0000	Closest (sensing) position
0	0	0	0	00	000	FEEL SW? (sensing)
0	0	0	0	01	0000	Minimum (force)
0	0	0	0	01	0000	Minimum STOP position
0	0	0	0	01	0000	Off of work after only with STOP + FEEL SW? (sensing position)
0	0	0	0	01	00	FE, SW, SWL, SWP, CLW
0	0	0	0	01	00	FEEL SW

*, Don't use

LOADING ← Loading mode status → LOAD




(Log output)

Order	Page	Address	Dir	Procedure
1	0	00	00	Special function of category 00
2	0	01		The mode switch condition and CE (CCM) switch condition can be discriminated by the display data.

10. Tape top/end sensor check

Page 3	Category 02	Address 0A
--------	-------------	------------

Display Data	Tape Top/End Sensor Condition
00	Tape present (Middle of tape)
01	Tape end
10	Tape top
11	No tape



Using method:

Order	Page	Address	Data	Procedure
1	3	00	02	Specification of category 02
2	3	0E	10	Request for tape top/end sampling operations
3	3	0A		The condition of the tape top/end sensor can be discriminated by the display data.

11. Version of mechanical control microprocessor

Page 3	Category 02	Address 0B
--------	-------------	------------

Display Data	Microprocessor version
01	Version 1


Using method:

Order	Page	Address	Data	Procedure
1	3	00	02	Specification of category 02
2	3	0B		The microprocessor version can be discriminated by the display data.

F6. Tape input/output sensor checks

Page ID	Category ID	Address ID
---------	-------------	------------

Display Date	Tape Input/output Sensor Specifications
00	Tape present (detected at input)
01	Tape read
00	Tape input
01	No tape



Using protocol

Order	Page	Address	Date	Procedure
1	3	00	00	Specifications of category 00
2	3	00	01	Adjust the tape input/output sampling operations
3	3	00		The condition of the tape input/output can be determined by the display date.

F1. Version of microprocessor control microprocessor

Page ID	Category ID	Address ID
---------	-------------	------------

Display Date	Microprocessor version
01	Version 1

Using protocol

Order	Page	Address	Date	Procedure
1	3	00	01	Specifications of category 01
2	3	00		The microprocessor version can be determined by the display date.

**12. Page D address list for standard 8 mm model
(CCD-TR42/TR70/TR72/TR80/TR82/TR430/TR550)**

Note 1: The adjustment data initial value is the data input before performing video section adjustments (Page D) if the Page D data has been erased due to some reason.

Note 2: The data written in the adjustment data memo column are fixed.

After adjusting, check that these data have not been rewritten by mistake.

Note 3: In some case, data have been input to the page D address 91 to AF, BC to D3 and F0 to FF. This has no relation to the adjustment.

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
00		Not used		
01		Not used		
02	TEST MODE (MECHA-CON)	Mecha-con (IC505) test mode	00	00
03	TEST MODE (MODE-CON)	Mode-con (IC503) test mode	00	00
04	SW POSITION (L)	Switching position adjustment (Low)	80	
05	SW POSITION (H)	Switching position adjustment (High)	0B	
06	BATTERY END	Battery end adjustment	66	
07	BATTERY PRE-END	Battery end adjustment	7F	
08	BATTERY LOW	Battery end adjustment	84	
09	BATTERY MIDDLE	Battery end adjustment	8A	
0A	BATTERY HIGH	Battery end adjustment	8E	
0B			00	00
0C		Not used		
0D		Not used		
0E		Not used		
0F		Not used		
10		Design data	00	00
11		Design data	00	00
12		Design data	00	00
13		Design data	00	00
14		Design data	95	95
15		Design data	77	77
16		Design data	01	01
17	VARIATION	CCD-TR42/TR70/TR72/TR80/TR82	02	02
		CCD-TR430/TR550	03	03
18	FEATURE	CCD-TR42/TR70/TR72/TR80/TR430	04	04
		CCD-TR82/TR550	64	64
19	FEATURE		80	80
1A	FEATURE	CCD-TR42/TR70/TR82/TR550	58	58
		CCD-TR72/TR80/TR430	DC	DC
1B	FEATURE	CCD-TR42/TR70/TR72/TR80/TR82/TR430	20	20
		CCD-TR550	60	60
1C	FEATURE		00	00
1D	FEATURE		00	00
1E		Not used		
1F		Not used		

Table 7-3-2. (1)

**12. Page D addresses that for standard 10 wire model
(CCD-TRAY/TRAFFIC/TRAFFIC/TRAFFIC/TRAFFIC/TRAFFIC)**

Note 1: The adjustment data reset value at the date input before performing factory address adjustment (Page 10) of the Page D data has been moved into a new column.

Note 2: The data written in the adjustment data screen column are fixed.

After adjusting, check that these data have not been modified by mistake.

Reference: In some cases, data have been input in the page D address N in 00, 0C in 03 and 00 in 00. This has no relation to the adjustment.

Address	Items	Function () contains the adjustment settings output (reset)	Adjustment data	
			Initial value	Write address
00		Not used		
01		Not used		
02	TRAY MOTOR (TRAY/TRAFFIC)	Motor run (0-99) set mode	00	00
03	TRAY MOTOR (TRAY/TRAFFIC)	Motor run (0-99) set mode	00	00
04	(W/ FLOW/TRAFFIC)	Defining position adjustment (Low)	00	
05	(W/ FLOW/TRAFFIC)	Defining position adjustment (High)	00	
06	BATTERY BIAS	Setting and adjustment	00	
07	BATTERY PRE-BIAS	Setting and adjustment	00	
08	BATTERY LOW	Setting and adjustment	00	
09	W/ FLOW/TRAFFIC	Setting and adjustment	00	
0A	W/ FLOW/TRAFFIC	Setting and adjustment	00	
0B			00	00
0C		Not used		
0D		Not used		
0E		Not used		
0F		Not used		
10		Charge data	00	00
11		Charge data	00	00
12		Charge data	00	00
13		Charge data	00	00
14		Charge data	00	00
15		Charge data	00	00
16		Charge data	00	00
17	FEATURE	CCD-TRAY/TRAFFIC/TRAFFIC/TRAFFIC/TRAFFIC	00	00
		CCD-TRAY/TRAFFIC	00	00
18	FEATURE	CCD-TRAY/TRAFFIC/TRAFFIC/TRAFFIC	04	04
		CCD-TRAY/TRAFFIC	04	04
19	FEATURE		00	00
1A	FEATURE	CCD-TRAY/TRAFFIC/TRAFFIC/TRAFFIC/TRAFFIC	04	04
		CCD-TRAY/TRAFFIC	00	00
1B	FEATURE	CCD-TRAY/TRAFFIC/TRAFFIC/TRAFFIC/TRAFFIC	00	00
		CCD-TRAY	00	00
1C	FEATURE		00	00
1D	FEATURE		00	00
1E		Not used		
1F		Not used		

Table 7-4-8 (2)

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
20		Not used		
21		Not used		
22		Not used		
23			00	00
24		Design data	00	00
25		Design data	00	00
26		Design data	14	14
27		Design data	14	14
28		Design data	64	64
29		Design data	64	64
2A		Design data	6E	6E
2B		Design data	6E	6E
2C		Design data	64	64
2D		Design data	64	64
2E		Design data	6E	6E
2F		Design data	6E	6E
30		Design data	DC	DC
31		Design data	DC	DC
32	EVR REC C (SP L ME)	SP Normal ME REC C adjustment [IC951 ⑩]	DC	
33	EVR REC C (SP L MP)	SP Normal MP REC C adjustment [IC951 ⑩]	DC	
34			DC	DC
35			DC	DC
36		Design data	DC	DC
37		Design data	DC	DC
38	EVR REC LOW 1 (ME)	1ch ME REC L adjustment [IC951 ⑳]	E4	
39	EVR REC LOW 1 (MP)	1ch MP REC L adjustment [IC951 ㉑]	EB	
3A	EVR REC LOW 2 (ME)	2ch ME REC L adjustment [IC951 ㉒]	E4	
3B	EVR REC LOW 2 (MP)	2ch MP REC L adjustment [IC951 ㉓]	EB	
3C		Not used		
3D		Not used		
3E		Not used		
3F		Not used		
40		Not used		
41		Not used		
42	EVR REC Y 1CH (L ME)	1ch Normal ME REC Y level adjustment [IC951 ㉔]	A9	
43	EVR REC Y 1CH (L MP)	1ch Normal MP REC Y level adjustment [IC951 ㉕]	A9	
44		Not used		
45		Not used		
46	EVR REC Y 2CH (L ME)	2ch Normal ME REC Y level adjustment [IC951 ㉖]	A9	
47	EVR REC Y 2CH (L MP)	2ch Normal MP REC Y level adjustment [IC951 ㉗]	A9	
48		Not used		
49		Not used		

Table 7-3-2. (2)

Address	Name	Function () contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Max. value
00		Not used		
01		Not used		
02		Not used		
03			00	00
04		Design data	00	00
05		Design data	00	00
06		Design data	1A	14
07		Design data	1A	14
08		Design data	04	04
09		Design data	04	04
0A		Design data	00	00
0B		Design data	00	00
0C		Design data	00	00
0D		Design data	00	00
0E		Design data	00	00
0F		Design data	00	00
10		Design data	0C	0C
11		Design data	0C	0C
12	INT. REF. C (MP1, MP2)	MP internal MP1/MP2 adjustment (COM1, 0)	0A	
13	INT. REF. C (MP1, MP3)	MP internal MP1/MP3 adjustment (COM1, 0)	0C	
14			0C	0C
15			0C	0C
16		Design data	0C	0C
17		Design data	0C	0C
18	INT. REF. C (MP1, MP4)	Int. MP1/MP4 adjustment (COM1, 0)	0A	
19	INT. REF. C (MP1, MP5)	Int. MP1/MP5 adjustment (COM1, 0)	00	
1A	INT. REF. C (MP1, MP6)	Int. MP1/MP6 adjustment (COM1, 0)	0A	
1B	INT. REF. C (MP1, MP7)	Int. MP1/MP7 adjustment (COM1, 0)	00	
1C		Not used		
1D		Not used		
1E		Not used		
1F		Not used		
20		Not used		
21		Not used		
22	INT. REF. C (MP2, MP8)	Int. MP2/MP8 adjustment (COM1, 0)	0A	
23	INT. REF. C (MP2, MP9)	Int. MP2/MP9 adjustment (COM1, 0)	0A	
24		Not used		
25		Not used		
26	INT. REF. C (MP2, MP10)	Int. MP2/MP10 adjustment (COM1, 0)	0A	
27	INT. REF. C (MP2, MP11)	Int. MP2/MP11 adjustment (COM1, 0)	0A	
28		Not used		
29		Not used		

Table 1-64 (5)

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
4A		Not used		
4B		Not used		
4C		Not used		
4D		Not used		
4E		Not used		
4F		Not used		
50		Design data	A2	A2
51		Design data	A1	A1
52		Not used		
53		Not used		
54			00	00
55			00	00
56			90	90
57			00	00
58			00	00
59			75	75
5A			E6	E6
5B			E6	E6
5C			E6	E6
5D			E6	E6
5E	EVR MT 1CH (L)	1ch Normal frequency characteristic adjustment [IC951 ⑱]	E6	
5F			E2	E2
60			E2	E2
61			E2	E2
62			E2	E2
63	EVR MT 2CH (L)	2ch Normal frequency characteristic adjustment [IC951 ⑳]	E2	
64		Not used		
65		Not used		
66		Not used		
67		Not used		
68		Not used		
69			E6	E6
6A			E6	E6
6B			E6	E6
6C			E6	E6
6D			E6	E6
6E		Not used		
6F		Not used		
70	EVR SYNC AGC	SYNC AGC adjustment [IC951 ㉔]	8E	
71	EVR COMB ADJ	Chroma comb filter adjustment [IC951 ㉕]	95	
72			B0	B0
73			B0	B0

Table 7-3-2. (3)

Address	Name	Function [] specifying the adjustment settings output format	Adjustment data	
			Initial value	Min/max value
4A		Not used		
4B		Not used		
4C		Not used		
4D		Not used		
4E		Not used		
4F		Not used		
50		Output data	A1	A1
51		Output data	A1	A1
52		Not used		
53		Not used		
54			00	00
55			00	00
56			00	00
57			00	00
58			00	00
59			7F	7F
5A			00	00
5B			00	00
5C			00	00
5D			00	00
5E	ENV MT (3) (A)	1st Normal frequency characteristic adjustment (ENV) (A)	00	00
5F			00	00
60			00	00
61			00	00
62			00	00
63	ENV MT (3) (A)	2nd Normal frequency characteristic adjustment (ENV) (A)	00	00
64		Not used		
65		Not used		
66		Not used		
67		Not used		
68		Not used		
69			00	00
6A			00	00
6B			00	00
6C			00	00
6D			00	00
6E		Not used		
6F		Not used		
70	ENV TRNG-A0C	TRNG-A0C adjustment (ENV) (A)	00	
71	ENV TRNG-A1A	Channel mode filter adjustment (ENV) (A)	00	
72			00	00
73			00	00

Table 7-6-6 (2)

14. Grounds Rayheads Adjustment 2 (V8 board)

Rayheads center frequency setting. If desired, the center measured value.

Mode	Playback
Signal	Adjustment signal For checking operation (V8C-0100) Color bar section
Measurement Point	Video output terminal
Measuring Instrument	Video scope
Adjustment Page	B
Adjustment Address	B1 (C-0100) (V8C) B1 (C-0100) (V8C)
Specified Value	The path from the blue luminance point to the red luminance point should be a straight line.

Adjusting method

- 1) Page 1, address B1, data B1
- 2) Change the data of page D, address B1, and adjust so that the path from the blue luminance point to the red luminance point becomes a straight line.
- 3) Press the FOCUS button of the adjusting remote command.
- 4) Set the focus line in address B1 of page D to address B1 of page D.
- 5) Press FOCUS button of the adjusting remote command.



Fig. 7-10-25

15. Grounds Filter Flow Adjustment (V8 board)

Set the level and phase of the 1st stage signal for the color flow. If desired, the center measured correction of tone is played back.

Mode	Playback
Signal	Adjustment signal For checking operation (V8C-0100) Color bar section
Measurement Point	Video output terminal
Measuring Instrument	Video scope
Adjustment Method	V8C-0100 (V8C)
Adjustment Page	B
Adjustment Address	B1 (C-0100) (V8C)
Specified Value	Minimum color luminance point correction when the "flow" control is turned on/off

Set the 1st stage signal ON/OFF at the same center.

Adjusting method

- 1) Page 1, address B1, data B1
- 2) Minimize the correction of the color luminance point when the color is turned on/off with FOCUS.
- 3) Change the data of page D, address B1, and minimize the correction of the color luminance point when the color is on/off.
- 4) Press the FOCUS button of the adjusting remote command.
- 5) Repeat steps 2) to 4).



Fig. 7-10-26

Address	Name	Function () contains the adjustment; voltage output terminal	Adjustment data	
			Initial value	Range
74		Not used		
75	ENV CARBON (L)	Reset T-VM carbon/temperature adjustment (CCH1) (8)	00	
76		Not used		
77	ENV THERM (ENV) (L)	Reset T-VM thermal adjustment (CCH2) (8)	07	
78			00	00
79			00	00
7A			00	00
7B			00	00
7C			00	00
7D			00	00
7E			00	00
7F			00	00
80	ENV C-TEMP (ENV)	EE sensor output adjustment (CCH1) (8)	00	
81	ENV C-TEMP (FB)	FE sensor output adjustment (CCH1) (8)	00	
82	ENV BATH (ENV)	EE BATH input level adjustment (CCH1) (8)	A2	
83	ENV BATH (FB)	FE BATH input level adjustment (CCH1) (8)	A2	
84		Not used		
85			00	00
86			00	00
87	ENV DE-TEMP (FB) (L)	Reset FE DE-TEMP input adjustment (CCH1) (8)	00	
88			00	00
89			00	00
8A			00	00
8B			00	00
8C	ENV AERO MATHS (ENV)	EE auto adjustment (CCH1) (8) CCH2-TEMP/TEMP	A2	
8D	ENV AERO MATHS (FB)	FE auto adjustment (CCH1) (8) CCH2-TEMP/TEMP	A2	
8E	ENV 1 FMS (ENV)	1.7 MHz divider adjustment (CCH1) (8) CCH2-TEMP/TEMP	A2	
8F	ENV 1 FMS (FB)	1.7 MHz divider adjustment (CCH1) (8)	A2	
90			00	00
91 to 9F				
9E	BRIGHT	Bright adjustment (CCH1) (8) CCH2-TEMP/TEMP	A2	
9F	COLOUR	Color setting (CCH1) (8) CCH2-TEMP/TEMP	A2	A2
9C	HUE	Hue setting (CCH1) (8) CCH2-TEMP/TEMP	00	00
9D	SUB BRIGHT B	Sub-bright B adjustment (CCH1) (8) CCH2-TEMP/TEMP	7A	
9E	SUB BRIGHT R	Sub-bright R adjustment (CCH1) (8) CCH2-TEMP/TEMP	7A	
9F	CONTRAST	Gamma adjustment (CCH1) (8) CCH2-TEMP/TEMP	70	
9A	VCO	VCO adjustment (CCH1) (8) CCH2-TEMP/TEMP	70	
9B	INVERTED CURSOR	Cursor inversion adjustment (CCH1) (8) CCH2-TEMP/TEMP	70	
9C	SUB CONTRAST B	Sub-contrast B setting (CCH1) (8) CCH2-TEMP/TEMP	7A	7A
9D	SUB CONTRAST R	Sub-contrast R setting (CCH1) (8) CCH2-TEMP/TEMP	7A	7A
9E	CORONA 1	Gamma 1 setting (CCH1) (8) CCH2-TEMP/TEMP	70	70

Table 7-9-1 (9)

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
BB	GAMMA 2	Gamma 2 setting [IC903 ⑫] CCD-TR70/TR80	F0	F0
BC to D3				
D4	CCD FLAW DATA	CCDimager correction data (for backup) ※ Refer "CCD Imager Correction Data Writing" of Camera Section Adjustments		
D5	CCD FLAW DATA			
D6	CCD FLAW DATA			
D7	CCD FLAW DATA			
D8	CCD FLAW DATA			
D9	CCD FLAW DATA			
DA	CCD FLAW DATA			
DB	CCD FLAW DATA			
DC	CCD FLAW DATA			
DD	CCD FLAW DATA			
DE	CCD FLAW DATA			
DF	CCD FLAW DATA			
E0	CCD FLAW DATA			
E1	CCD FLAW DATA			
E2	CCD FLAW DATA			
E3	CCD FLAW DATA			
E4	EMERGENCY LAST CODE	Last emergency code	00	
E5	EMERGENCY LAST MODE	Last emergency mode	00	
E6		N.C.	00	
E7		N.C.	00	
E8	EMERGENCY 2ND CODE	2nd emergency code	00	
E9	EMERGENCY 2ND MODE	2nd emergency mode	00	
EA		N.C.	00	
EB		N.C.	00	
EC	EMERGENCY 1ST CODE	1st emergency code	00	
ED	EMERGENCY 1ST MODE	1st emergency mode	00	
EE		N.C.	00	
EF		N.C.	00	

Table 7-3-2. (5)

Address	Name	Function 1 (includes the adjustment voltage output terminal)	Adj. adjustment data	
			Initial value	Memory operation
00	COMPASS	Compass Function (COMP-0) (CCS-Tx 0x7000)	00	00
0C to 0D				
04	CCS FLAW DATA	CCS (Charge Controller) data (for testing) ■ Refer "CCS (Charge Controller) Data Writing" at Charge Controller Adjustment		
05	CCS FLAW DATA			
06	CCS FLAW DATA			
07	CCS FLAW DATA			
08	CCS FLAW DATA			
09	CCS FLAW DATA			
0A	CCS FLAW DATA			
0B	CCS FLAW DATA			
0C	CCS FLAW DATA			
0D	CCS FLAW DATA			
0E	CCS FLAW DATA			
0F	CCS FLAW DATA			
10	CCS FLAW DATA			
11	CCS FLAW DATA			
12	CCS FLAW DATA			
13	CCS FLAW DATA			
14	EMERGENCY LIFT CODE	Set emergency code	00	
15	EMERGENCY LIFT CODE	Set emergency code	00	
16		N/C	00	
17		N/C	00	
18	EMERGENCY INT. CODE	Set emergency code	00	
19	EMERGENCY INT. CODE	Set emergency code	00	
1A		N/C	00	
1B		N/C	00	
1C	EMERGENCY INT. CODE	Set emergency code	00	
1D	EMERGENCY INT. CODE	Set emergency code	00	
1E		N/C	00	
1F		N/C	00	

Table 7-4-6 (b)

**13. Page D address list for HI8 model
(CCD-TR400/TR750)**

Note 1: The adjustment data initial value is the data input before performing video section adjustments (Page D) if the Page D data has been erased due to some reason.

Note 2: The data written in the adjustment data memo column are fixed.

After adjusting, check that these data have not been rewritten by mistake.

Note 3: In some case, data have been input to the page D address 91 to D3 and F0 to FF. This has no relation to the adjustment.

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
00		Not used		
01		Not used		
02	TEST MODE (MECHA-CON)	Mecha-con (IC505) test mode	00	00
03	TEST MODE (MODE-CON)	Mode-con (IC503) test mode	00	00
04	SW POSITION (L)	Switching position adjustment (Low)	80	
05	SW POSITION (H)	Switching position adjustment (High)	0B	
06	BATTERY END	Battery end adjustment	66	
07	BATTERY PRE-END	Battery end adjustment	7F	
08	BATTERY LOW	Battery end adjustment	84	
09	BATTERY MIDDLE	Battery end adjustment	8A	
0A	BATTERY HIGH	Battery end adjustment	8E	
0B			00	00
0C		Not used		
0D		Not used		
0E		Not used		
0F		Not used		
10			00	00
11			00	00
12			00	00
13			00	00
14			95	95
15			77	77
16			01	01
17	VARIATION	CCD-TR400	12	12
		CCD-TR750	13	13
18	FEATURE		E8	E8
19	FEATURE		80	80
1A	FEATURE		DC	DC
1B	FEATURE	CCD-TR400	20	20
		CCD-TR750	60	60
1C	FEATURE		00	00
1D	FEATURE		00	00
1E		Not used		
1F		Not used		

Table 7-3-3. (1)

**12. Page D address list for 886 model
(20/25/30/35/40)**

Note 1: The adjustment data initial value is the data here before performing value setting adjustments (Page 16) of the Page D data has been reset due to power failure.

Note 2: The data written in the adjustment data screen values are fixed.

After adjusting, check that these data have not been accidentally modified.

Note 3: In some cases, data have been copied to the page D address (6) to (15) and (16) to (17). This has no relation to the adjustments.

Address	Items	Functions [] indicates the adjustment settings output terminal	Adjustment data	
			Initial value	Screen resolution
00		No read		
01		No read		
02	TEST MODE (MODE COMP)	Mode use (MODE) not mode	00	00
03	TEST MODE (MODE COMP)	Mode use (MODE) not mode	00	00
04	SPRINGER COMP	Swinging position adjustment (F. adj)	00	
05	SP POWER FREQ	Swinging position adjustment (High)	00	
06	BATTERY FREQ	Energy use adjustment	00	
07	BATTERY FREQ	Energy use adjustment	77	
08	BATTERY LOW	Energy use adjustment	00	
09	BATTERY DETAIL	Energy use adjustment	15	
0A	BATTERY TECH	Energy use adjustment	00	
0B			00	00
0C		No read		
0D		No read		
0E		No read		
0F		No read		
10			00	00
11			00	00
12			00	00
13			00	00
14			00	00
15			00	00
16			77	77
17			00	00
18	NOBATION	CCD TRAIL CCD DETAIL	11	11
19	FEATURE		00	00
1A	FEATURE		00	00
1B	FEATURE		00	00
1C	FEATURE	CCD TRAIL CCD DETAIL	00	00
1D	FEATURE		00	00
1E	FEATURE		00	00
1F		No read		
20		No read		

Table P-09- (7)

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
20		Not used		
21		Not used		
22		Not used		
23			03	03
24		Design data	00	00
25		Design data	00	00
26		Design data	1C	1C
27		Design data	25	25
28		Design data	D8	D8
29		Design data	E5	E5
2A		Design data	DC	DC
2B		Design data	EF	EF
2C		Design data	D8	D8
2D		Design data	E5	E5
2E		Design data	DC	DC
2F		Design data	EF	EF
30	EVR REC C (SP E ME)	SP Hi8 ME REC C adjustment [IC951 ⑩]	E6	
31	EVR REC C (SP E MP)	SP Hi8 MP REC C adjustment [IC951 ⑩]	E6	
32	EVR REC C (SP L ME)	SP Normal ME REC C adjustment [IC951 ⑩]	E6	
33	EVR REC C (SP L MP)	SP Normal MP REC C adjustment [IC951 ⑩]	E6	
34	EVR REC C (LP E ME)	LP Hi8 ME REC C adjustment [IC951 ⑩]	E6	E6
35	EVR REC C (LP E MP)	LP Hi8 MP REC C adjustment [IC951 ⑩]	E6	E6
36	EVR REC C (LP L ME)	LP Normal ME REC C adjustment [IC951 ⑩]	E6	E6
37	EVR REC C (LP L MP)	LP Normal MP REC C adjustment [IC951 ⑩]	E6	E6
38	EVR REC LOW 1 (ME)	1ch ME REC L adjustment [IC951 ⑳]	D6	
39	EVR REC LOW 1 (MP)	1ch MP REC L adjustment [IC951 ⑳]	E0	
3A	EVR REC LOW 2 (ME)	2ch ME REC L adjustment [IC951 ⑳]	D6	
3B	EVR REC LOW 2 (MP)	2ch MP REC L adjustment [IC951 ⑳]	E0	
3C		Not used		
3D		Not used		
3E		Not used		
3F		Not used		
40	EVR REC Y 1CH (E ME)	1ch Hi8 ME REC Y level adjustment [IC951 ㉔]	D8	
41	EVR REC Y 1CH (E MP)	1ch Hi8 MP REC Y level adjustment [IC951 ㉔]	DD	
42	EVR REC Y 1CH (L ME)	1ch Normal ME REC Y level adjustment [IC951 ㉔]	DC	
43	EVR REC Y 1CH (L MP)	1ch Normal MP REC Y level adjustment [IC951 ㉔]	D5	
44	EVR REC Y 2CH (E ME)	2ch Hi8 ME REC Y level adjustment [IC951 ㉔]	D8	
45	EVR REC Y 2CH (E MP)	2ch Hi8 MP REC Y level adjustment [IC951 ㉔]	DD	
46	EVR REC Y 2CH (L ME)	2ch Normal ME REC Y level adjustment [IC951 ㉔]	DC	
47	EVR REC Y 2CH (L MP)	2ch Normal MP REC Y level adjustment [IC951 ㉔]	D5	
48		Not used		
49		Not used		

Table 7-3-3. (2)

Address	Name	Function [] indicates the adjustment settings output inverted	Adjustment data	
			Initial value	Range
00		Not used		
01		Not used		
02		Not used		
03			00	00
04		Design data	00	00
05		Design data	00	00
06		Design data	00	00
07		Design data	00	00
08		Design data	00	00
09		Design data	00	00
0A		Design data	00	00
0B		Design data	00	00
0C		Design data	00	00
0D		Design data	00	00
0E		Design data	00	00
0F		Design data	00	00
10	ENV_BRC_C (D/F) MD	MF MD MF/BRC adjustment (COM) [0]	00	
11	ENV_BRC_C (D/F) MP	MF MP MF/BRC adjustment (COM) [0]	00	
12	ENV_BRC_C (D/F) LM	MF LM MF/BRC adjustment (COM) [0]	00	
13	ENV_BRC_C (D/F) LP	MF LP MF/BRC adjustment (COM) [0]	00	
14	ENV_BRC_C (D/F) MD	LP MD MF/BRC adjustment (COM) [0]	00	00
15	ENV_BRC_C (D/F) MP	LP MP MF/BRC adjustment (COM) [0]	00	00
16	ENV_BRC_C (D/F) LM	LP LM MF/BRC adjustment (COM) [0]	00	00
17	ENV_BRC_C (D/F) LP	LP LP MF/BRC adjustment (COM) [0]	00	00
18	ENV_BRC_L (H) 1 (MD)	MD MD BRC L adjustment (COM) [0]	00	
19	ENV_BRC_L (H) 1 (MP)	MD MP BRC L adjustment (COM) [0]	00	
1A	ENV_BRC_L (H) 1 (LM)	MD LM BRC L adjustment (COM) [0]	00	
1B	ENV_BRC_L (H) 1 (LP)	MD LP BRC L adjustment (COM) [0]	00	
1C		Not used		
1D		Not used		
1E		Not used		
1F		Not used		
20	ENV_BRC_Y (H) 2 (MD)	MD MD BRC Y 2 level adjustment (COM) [0]	00	
21	ENV_BRC_Y (H) 2 (MP)	MD MP BRC Y 2 level adjustment (COM) [0]	00	
22	ENV_BRC_Y (H) 2 (LM)	MD LM BRC Y 2 level adjustment (COM) [0]	00	
23	ENV_BRC_Y (H) 2 (LP)	MD LP BRC Y 2 level adjustment (COM) [0]	00	
24	ENV_BRC_Y (H) 3 (MD)	MD MD BRC Y 3 level adjustment (COM) [0]	00	
25	ENV_BRC_Y (H) 3 (MP)	MD MP BRC Y 3 level adjustment (COM) [0]	00	
26	ENV_BRC_Y (H) 3 (LM)	MD LM BRC Y 3 level adjustment (COM) [0]	00	
27	ENV_BRC_Y (H) 3 (LP)	MD LP BRC Y 3 level adjustment (COM) [0]	00	
28		Not used		
29		Not used		

Table 2-3-4-10

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
4A		Not used		
4B		Not used		
4C		Not used		
4D		Not used		
4E		Not used		
4F		Not used		
50			D3	D3
51			CE	CE
52		Not used		
53		Not used		
54			C2	C2
55			C2	C2
56			97	97
57			70	70
58			70	70
59			85	85
5A	EVR MT 1CH (SP E ME)	1ch SP Hi8 ME frequency characteristic adjustment [IC951 ⑩]	DC	
5B	EVR MT 1CH (SP E MP)	1ch SP Hi8 MP frequency characteristic adjustment [IC951 ⑩]	DC	
5C	EVR MT 1CH (LP E ME)	1ch LP Hi8 ME frequency characteristic adjustment [IC951 ⑩]	DC	
5D	EVR MT 1CH (LP E MP)	1ch LP Hi8 MP frequency characteristic adjustment [IC951 ⑩]	DC	
5E	EVR MT 1CH (L)	1ch Normal frequency characteristic adjustment [IC951 ⑩]	DC	
5F	EVR MT 2CH (SP E ME)	2ch SP Hi8 ME frequency characteristic adjustment [IC951 ⑳]	CD	
60	EVR MT 2CH (SP E MP)	2ch SP Hi8 MP frequency characteristic adjustment [IC951 ⑳]	CD	
61	EVR MT 2CH (LP E ME)	2ch LP Hi8 ME frequency characteristic adjustment [IC951 ⑳]	CD	
62	EVR MT 2CH (LP E MP)	2ch LP Hi8 MP frequency characteristic adjustment [IC951 ⑳]	CD	
63	EVR MT 2CH (L)	2ch Normal frequency characteristic adjustment [IC951 ⑳]	CD	
64		Not used		
65		Not used		
66		Not used		
67		Not used		
68		Not used		
69			DC	DC
6A			DC	DC
6B			DC	DC
6C			DC	DC
6D			DC	DC
6E		Not used		
6F		Not used		
70	EVR SYNC AGC	SYNC AGC adjustment [IC951 ㉔]	8E	
71	EVR COMB ADJ	Chroma comb filter adjustment [IC951 ㉔]	95	
72			B0	B0
73			B0	B0

Table 7-3-3. (3)

Address	Name	Position () indicates the adjustment settings output terminal	Adjustment data	
			Initial value	Output value
4A		No read		
4B		No read		
4C		No read		
4D		No read		
4E		No read		
4F		No read		
50			00	00
51			00	00
52		No read		
53		No read		
54			00	00
55			00	00
56			00	00
57			00	00
58			00	00
59			00	00
5A	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
5B	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
5C	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
5D	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
5E	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
5F	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
60	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
61	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
62	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
63	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
64	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
65	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
66	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
67	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
68	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
69	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
6A	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
6B	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
6C	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
6D	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
6E	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
6F	ENV MT 12K (P 1.4K)	Set 2P 140 MHz frequency characteristic adjustment (ENV 0)	00	
70	ENV 170K (A4)	ENV ACC adjustment (ENV 0)	00	
71	ENV 170K (A4)	ENV ACC adjustment (ENV 0)	00	
72			00	00
73			00	00

Table F-4-4 (9)

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
74	EVR CARRIER (E)	Hi8 Y-FM carrier frequency adjustment [IC951 ④③]	C3	
75	EVR CARRIER (L)	Normal Y-FM carrier frequency adjustment [IC951 ④③]	BB	
76	EVR DEVIATION (E)	Hi8 Y-FM deviation adjustment [IC951 ④④]	A6	
77	EVR DEVIATION (L)	Normal Y-FM deviation adjustment [IC951 ④④]	97	
78			59	59
79			53	53
7A			7B	7B
7B			7B	7B
7C			00	00
7D			00	00
7E			00	00
7F			00	00
80	EVR C EMPH (EE)	EE chroma emphasis adjustment [IC951 ④②]	99	
81	EVR C EMPH (PB)	PB chroma emphasis adjustment [IC951 ④②]	99	
82	EVR EMPH (EE)	EE EMPH input level adjustment [IC951 ④⑧]	A5	
83	EVR EMPH (PB)	PB EMPH input level adjustment [IC951 ④⑧]	90	
84		Not used		
85			AA	AA
86	EVR DE-EMPH (PB E)	Hi8 PB DE-EMPH level adjustment [IC951 ④⑦]	B0	
87	EVR DE-EMPH (PB L)	Normal PB DE-EMPH level adjustment [IC951 ④⑦]	A2	
88			00	00
89			00	00
8A			00	00
8B			48	48
8C	EVR AUDIO MATRIX (EE)	EE matrix adjustment [IC951 ②③]	AF	
8D	EVR AUDIO MATRIX (PB)	PB matrix adjustment [IC951 ②③]	AF	
8E	EVR 1.7 MHz DEV	1.7 MHz deviation adjustment [IC951 ②⑥]	AF	
8F	EVR 1.5 MHz DEV	1.5 MHz deviation adjustment [IC951 ②⑦]	AF	
90			60	60
91 to D3				
D4	CCD FLAW PATTERN	CCDimager correction data (for backup) ※ Refer "CCD Imager Correction Data Writing" of Camera Section Adjustments		
D5	CCD FLAW DATA			
D6	CCD FLAW DATA			
D7	CCD FLAW DATA			
D8	CCD FLAW DATA			
D9	CCD FLAW DATA			
DA	CCD FLAW DATA			
DB	CCD FLAW DATA			
DC	CCD FLAW DATA			
DD	CCD FLAW DATA			
DE	CCD FLAW DATA			
DF	CCD FLAW DATA			

Table 7-3-3. (4)

Address	Name	Function [] denotes the adjustment voltage output terminal	Adjustment data	
			Initial value	Store contents
74	DVS GAIN(0) (0)	0th DVS gain frequency adjustment (DVS) (0)	00	
75	DVS GAIN(0) (1)	1st DVS gain frequency adjustment (DVS) (0)	00	
76	DVS GAIN(0) (2)	2nd DVS gain frequency adjustment (DVS) (0)	00	
77	DVS GAIN(0) (3)	3rd DVS gain frequency adjustment (DVS) (0)	00	
78			00	00
79			00	00
7A			00	00
7B			00	00
7C			00	00
7D			00	00
7E			00	00
7F			00	00
80	DVS G GAIN(0) (0)	0th DVS G gain frequency adjustment (DVS G) (0)	00	
81	DVS G GAIN(0) (1)	1st DVS G gain frequency adjustment (DVS G) (0)	00	
82	DVS G GAIN(0) (2)	2nd DVS G gain frequency adjustment (DVS G) (0)	00	
83	DVS G GAIN(0) (3)	3rd DVS G gain frequency adjustment (DVS G) (0)	00	
84		No read		
85			AA	AA
86	DVS DS-GAIN(0) (0)	0th DS-DVS gain level adjustment (DVS) (0)	00	
87	DVS DS-GAIN(0) (1)	1st DS-DVS gain level adjustment (DVS) (0)	00	
88			00	00
89			00	00
8A			00	00
8B			00	00
8C	DVS AUTO MATCH(0) (0)	0th auto adjustment (DVS) (0)	00	
8D	DVS AUTO MATCH(0) (1)	1st auto adjustment (DVS) (0)	00	
8E	DVS L 1 MIN LEV	0th L1 min deviation adjustment (DVS) (0)	00	
8F	DVS L 2 MIN LEV	1st L2 min deviation adjustment (DVS) (0)	00	
90			00	00
91 to 9F				
9A	CCD FLAW PARTITION	(1) Storage correction data (for backup) (2) Refer "CCD Image Correction Data Writing" of Camera Module Adjustment		
9B	CCD FLAW DATA			
9C	CCD FLAW DATA			
9D	CCD FLAW DATA			
9E	CCD FLAW DATA			
9F	CCD FLAW DATA			
9A	CCD FLAW DATA			
9B	CCD FLAW DATA			
9C	CCD FLAW DATA			
9D	CCD FLAW DATA			
9E	CCD FLAW DATA			
9F	CCD FLAW DATA			
9A	CCD FLAW DATA			
9B	CCD FLAW DATA			
9C	CCD FLAW DATA			
9D	CCD FLAW DATA			

Table 7-84 (9)

Address	Name	Function [] contains the adjustment voltage output terminal	Adjustment data	
			Initial value	Memo column
E0	CCD FLAW DATA	CCDimager correction data (for backup) ※ Refer “CCD Imager Correction Data Writing” of Camera Section Adjustments		
E1	CCD FLAW DATA			
E2	CCD FLAW DATA			
E3	CCD FLAW DATA			
E4	EMERGENCY LAST CODE	Last emergency code	00	
E5	EMERGENCY LAST MODE	Last emergency mode	00	
E6		N.C.	00	
E7		N.C.	00	
E8	EMERGENCY 2ND CODE	2nd emergency code	00	
E9	EMERGENCY 2ND MODE	2nd emergency mode	00	
EA		N.C.	00	
EB		N.C.	00	
EC	EMERGENCY 1ST CODE	1st emergency code	00	
ED	EMERGENCY 1ST MODE	1st emergency mode	00	
EE		N.C.	00	
EF		N.C.	00	

Table 7-3-3. (5)

Address	Name	Function [] indicates the adjusted voltage output terminal	Adjustment data	
			Initial value	Setting options
00	CCD PLAN DATA	(1) Storage correction data (for backup) (2) Refer "CCD Storage Correction Data Writing" of Camera Section Adjustments		
01	CCD PLAN DATA			
02	CCD PLAN DATA			
03	CCD PLAN DATA			
04	EMERGENCY LAST CODE	Last emergency code	00	
05	EMERGENCY LAST ADDR	Last emergency code	00	
06		INC.	00	
07		INC.	00	
08	EMERGENCY 2ND CODE	2nd emergency code	00	
09	EMERGENCY 2ND ADDR	2nd emergency code	00	
0A		INC.	00	
0B		INC.	00	
0C	EMERGENCY 3RD CODE	3rd emergency code	00	
0D	EMERGENCY 3RD ADDR	3rd emergency code	00	
0E		INC.	00	
0F		INC.	00	

Table 7-0-3 (2)

3-2. POWER SYSTEM ADJUSTMENTS

1. Oscillator Frequency Check (DD board)

Mode	Camera record
Subject	Arbitrary
Measurement Point	Q905 collector
Measuring Instrument	Frequency counter
Specified Value	500 ± 50 kHz

Adjusting method:

- 1) Check that the oscillator frequency satisfies the specified value.

2. Power Voltage Check (DD board)

Mode	Camera record
Subject	Arbitrary
Measuring Instrument	Digital voltmeter
D5V check	
Measurement Point	Pin ② of CN901
Specified Value	4.9 ± 0.1 Vdc
EVF5V check	
Measurement Point	Pin ③ of CN901
Specified Value	4.9 ± 0.1 Vdc
VID 5V check	
Measurement Point	Pins ② and ④ of CN901
Specified Value	4.9 ± 0.1 Vdc
AU 5V check	
Measurement Point	Pin ⑤ of CN901
Specified Value	4.9 ± 0.1 Vdc
RP 5V check	
Measurement Point	Pin ⑥ of CN901
Specified Value	4.9 ± 0.1 Vdc
CAM5V check	
Measurement Point	Pins ⑤ and ⑥ of CN901
Specified Value	4.85 ± 0.1 Vdc
SS 3.6V check	
Measurement Point	Pin ③ of CN901
Specified Value	3.6 ± 0.1 Vdc
D3.6V check	
Measurement Point	Pins ① and ② of CN901
Specified Value	3.6 ± 0.1 Vdc
CAM 15V check	
Measurement Point	Pin ⑦ of CN901
Specified Value	15 ± 0.3 Vdc
CAM -8.5V check	
Measurement Point	Pin ⑧ of CN901
Specified Value	-8.5 ^{+0.25} _{-0.4} Vdc
MT 5V check	
Measurement Point	Pins ⑨, ⑩ and ⑪ of CN901
Specified Value	5.0 ± 0.1 Vdc

3-3. SYSTEM CONTROL SYSTEM ADJUSTMENTS

1. Page D Initial Value Input

If the page D data has been erased due to some cause, input the page D initial value before performing adjustments. For details on the initial value, refer to "Page D address list" in "3-1-8. Service Mode".

Mode	E-E
Signal	Arbitrary
Adjustment Page	D
Adjustment Address	00 to 90, [B0 to BB], (D4 to EF)

[] : CCD-TR70/TR80

Input method:

- 1) Page: 1, address: 00, data: 01
- 2) Select page D, and input the initial value to each address.
(After setting the data (initial value), be sure to press the PAUSE button of the adjusting remote commander before changing the address.)

3-8. POWER SYSTEM ADJUSTMENTS

1. Oscillator Frequency Check (RF board)

Mode	Current panel
Subject	Antenna
Measurement Point	Oscillator
Measuring Instrument	Frequency counter
Specified Value	327.435 kHz

Following method

- Check that the oscillator frequency satisfies the specified value.

2. Power Voltage Check (RF board)

Mode	Current panel
Subject	Antenna
Measuring Instrument	Signal voltmeter
RFV check	
Measurement Point	Pc (B) and Pda
Specified Value	0.2 ± 0.1 Vdc
20V RFV check	
Measurement Point	Pc (B) of CPM0
Specified Value	4.0 ± 0.1 Vdc
100 VV check	
Measurement Point	Pda (B) and Pda (B) of CPM0
Specified Value	4.0 ± 0.1 Vdc
50 VV check	
Measurement Point	Pda (B) of CPM0
Specified Value	4.0 ± 0.1 Vdc
30 VV check	
Measurement Point	Pda (B) of CPM0
Specified Value	4.0 ± 0.1 Vdc
100V VV check	
Measurement Point	Pda (B) and Pda (B) of CPM0
Specified Value	4.0 ± 0.1 Vdc
50 VV check	
Measurement Point	Pda (B) of CPM0
Specified Value	4.0 ± 0.1 Vdc
100V VV check	
Measurement Point	Pda (B) of CPM0
Specified Value	11.0 ± 0.1 Vdc
100V ± 0 VV check	
Measurement Point	Pda (B) of CPM0
Specified Value	±0.03 Vdc ±0.4
100 VV check	
Measurement Point	Pda (B) and Pda (B) of CPM0
Specified Value	0.0 ± 0.1 Vdc

3-9. SYSTEM CONTROL SYSTEM ADJUSTMENTS

1. Page 0 Initial Value Input

If the page 0 data has been entered after a power reset, input the page 0 initial value before performing adjustments. For details on the initial value, refer to "Page 0 address list" in "3-1-0 Service Manual".

Mode	S.E.
Subject	Antenna
Adjustment Page	0
Adjustment Address	7070-00, 7070-00, 7070-00

[] : 000-000000

Input method

- Page 1, address (B) data (C)
- Select page (C), and input the initial value to each address.
(After setting the data (initial value), be sure to press the Pwr/Off button of the adjusting remote commander before changing the address.)

2. Battery End Adjustment

Set the battery end voltage.

If the voltage is incorrect, the life of the battery will shorten.

The image at the battery end will also be rough.

Mode	Camera record
Signal	Arbitrary
Measurement Point	LCD display of the adjusting remote control unit
Measuring Instrument	
Adjustment Page	D
Specified Value	06 (BATT END) 07 (BATT PRE-END) 08 (BATT LOW) 09 (BATT MIDDLE) 0A (BATT HIGH)

Connection:

- 1) Connect the regulated power supply and the digital voltmeter as shown in Fig. 7-3-5.




Fig. 7-3-5.

Adjusting method:

- 1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display is 6.3 ± 0.1 Vdc.
- 2) Page: 1, address: 00, data: 01
- 3) Decrease the output voltage of the regulated power supply so that the digital voltmeter display is 5.50 ± 0.01 Vdc.
- 4) Set data: 01 to page: 2, address: 00.
(Specification of category 01)
- 5) Select page: 2, address: 47, read the adjusting remote commander display data, and set to D6.
- 6) Set data D6 to page: D, address: 06, and press the PAUSE button of the adjusting remote commander.
- 7) Convert D47 to decimal notation, and obtain D47'. (Refer to Table 7-1-4. "Hexadecimal notation-decimal notation conversion table")
- 8) Calculate D7', D8', D9' and DA' using following equations (decimal notation calculation).

$$D7' = D47' + 3$$

$$D8' = D47' + 8$$

$$D9' = D47' + 14$$

$$DA' = D47' + 18$$
- 9) Convert D7', D8', D9' and DA' to hexadecimal notation, and obtain D7, D8, D9 and DA.
- 10) Set data: D7' to page: D, address: 07, and press the PAUSE button of the adjusting remote commander.
- 11) Set data: D8' to page: D, address: 08, and press the PAUSE button.
- 12) Set data: D9' to page: D, address: 09, and press the PAUSE button.
- 13) Set data: DA to page: D, address: 0A, and press the PAUSE button.
- 14) Perform "Battery Down Check".

8. Battery Level Adjustment

Set the battery end voltage.

If the voltage is measured, the life of the battery will shorten.

The longer the battery end will also be rough.

Mode	Current screen
Signal	Battery
Measurement Point	LED display of the adjusting screen
Measuring instrument	internal unit
Adjustment Page	0
Specified Value	02 (BATT END) 03 (BATT PRE-END) 04 (BATT L-VAL) 05 (BATT MID-VAL) 06 (BATT H-VAL)

Caution:

- Connect the regulated power supply and the digital voltmeter as shown in Fig. 7-4-5.



Fig. 7-4-5

Adjusting method

- Adjust the output voltage of the regulated power supply so that the digital voltmeter display is 4.2 ± 0.1 Vdc.
- Press 1, address 02, data 02.
- Decrease the output voltage of the regulated power supply so that the digital voltmeter display is 4.05 ± 0.01 Vdc.
- Set data 02 to page 0, address 02.
- Return page 0, address 02, read the adjusting screen continuously (display data, and set to 0).
- Set data 04 to page 0, address 04, and press the F4/04 function of the adjusting screen commander.
- Connect D0 to channel 1, and obtain D0' (Data in Table 7-3-4, "Functional position-channel relation screen table").
- Obtain D1', D2', D3' and D4' using following equation (channel screen calculation):

$$D1' = D0 \times 10$$

$$D2' = D0 \times 40$$

$$D3' = D0 \times 100$$

$$D4' = D0 \times 160$$
- Connect D1', D2', D3' and D4' to functional screen, and obtain D1, D2, D3 and D4.
- Set data D1' to page 0, address 01, and press the F4/01 function of the adjusting screen commander.
- Set data D2' to page 0, address 02, and press the F4/02 function.
- Set data D3' to page 0, address 03, and press the F4/03 function.
- Set data D4' to page 0, address 04, and press the F4/04 function.
- Return "Battery Level Check".

3. Battery Down Check

Mode	Camera record
Subject	Arbitrary

Connection

- 1) Connect the regulated power supply and the digital voltmeter as shown in Fig. 7-3-5.

Checking method:

Remove the adjusting remote commander, and perform the following check. If the check is not satisfied, perform from the beginning again.

- 1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display becomes 6.3 ± 0.1 Vdc.
- 2) Set to the camera recording mode.
- 3) Check that the \square mark on the EVF (viewfinder) display is not lighted up. (TALLY lamp lights up).
- 4) Decrease the the output voltage of the regulated power supply so that the digital voltmeter display becomes 5.54 ± 0.01 Vdc.
- 5) Check that the \square mark on the EVF display and the TALLY lamp blinks every second.
- 6) Decrease the the output voltage of the regulated power supply so that the digital voltmeter display becomes 5.42 ± 0.01 Vdc.
- 7) Check that the \square mark on the EVF display and the TALLY lamp are blinking faster, the VTR stops and the power supply turns off.

3-4. SERVO SYSTEM ADJUSTMENTS

1. Switching Position Adjustment (VS board)

Switching timing of video head setting. If deviated in this case causes switching noise or jitter on the played back screen.

Mode	Playback
Signal	Alignment tape: For tracking adjustment (WR5-1NP)
Measurement Point	CH1: Pin ④ of CN101 (RF SWP) CH2: Pin ③ of CN101 (PB RF)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	04 (SW POSITION) (LOW) 05 (SW POSITION) (HIGH)
Specified Value	$t_1 = 0 \pm 10 \mu\text{sec}$

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Set data: 0B to page: D, address: 05.
- 3) Change the data of page: D, address: 05 and minimize "t1". (Coarse adjustment)
- 4) Change the data of page: D, address: 04, and adjust so that the switching position (t1) becomes the specified value. (Fine adjustment)
- 5) Press the PAUSE button of the adjusting remote commander.




Fig. 7-3-6.

3. Battery Level Check

Mode	Charge reset
Adjust	Arbitrary

Comments

- Connect the regulated power supply and the digital voltmeter as shown in Fig. 7-3-3.

Checking method

Execute the adjusting screen commands, and perform the adjusting check. If the check is not satisfied, perform from the beginning again.

- Adjust the output voltage of the regulated power supply so that the digital voltmeter display increases 0.5V to 0.5V Vdc.
- Set the screen measuring mode.
- Check that the 0V mark on the P/P (identified) display is highlighted up. (TALLY lamp lights up).
- Decrease the the output voltage of the regulated power supply so that the digital voltmeter display increases 0.5V to 0.5V Vdc.
- Check that the 0V mark on the DFF display and the TALLY lamp lights every second.
- Decrease the the output voltage of the regulated power supply so that the digital voltmeter display increases 0.5V to 0.5V Vdc.
- Check that the 0V mark on the DFF display and the TALLY lamp are lighting from the VDR stop and the power supply goes off.

3-4. ERWD SYSTEM ADJUSTMENTS

1. Switching Position Adjustment (PH Invert)

Switching timing of valve level setting. If deviated as the main station switching mode at first in the signal test series.

Mode	Playback
Signal	Adjustment input The tracking adjustment (PHS-DFF)
Measurement Point	CH1 (PH-0) of CHDS (DFF-DFF) CH2 (PH-0) of CHDS (PH-DFF)
Measuring instrument	Oscilloscope
Adjustment Page	21
Adjustment address	16 (DFF POSITION) (LOW) 16 (DFF POSITION) (HIGH)
Specified Value	Low to 10 pulse

Adjusting method

- Page 1, address 00, data 01
- Set time 00 to page 0, address 00.
- Change the data of page 0, address 00 and address "0"
- (Change address)
- Change the data of page 0, address 0A, and adjust so that the switching position (P) becomes the specified value. (Phase adjustment)
- From the (TALLY) screen of the adjusting screen command.



Fig. 7-3-6

3-5. Standard 8 mm VIDEO SYSTEM ADJUSTMENTS (CCD-TR42/TR70/TR72/TR80/TR82/TR430/TR550)

The adjustments of the video system must be performed according to the following adjustment procedure.

The color video signal supplied from the pattern generator is used as the video input signal for adjusting the video system in recording mode. Check that the sync signal and the color burst signal satisfy the specification specified during the adjustment set-up shown in Figs. 7-3-2. and 7-3-3.

[Adjusting procedure]

- 1) Playback frequency characteristics adjustment
- 2) Flying erase check
- 3) VXO oscillation frequency check
- 4) SYNC AGC level adjustment
- 5) Comb filter adjustment
- 6) Emphasis input level adjustment
- 7) WHITE CLIP check
- 8) DARK CLIP check
- 9) DE EMPH level adjustment
- 10) PB Y out level adjustment
- 11) Y FM carrier frequency adjustment
- 12) Y FM deviation adjustment
- 13) Chroma emphasis adjustment 1
- 14) Chroma emphasis adjustment 2
- 15) Comb filter fine adjustment
- 16) REC Y level adjustment
- 17) REC L adjustment
- 18) REC CHROMA level adjustment
- 19) REC ATF level check

1. Playback Frequency Characteristic Adjustment (VS board)

Eliminate the differences in the head characteristics of each channel. If there are differences, flickers and over modulation noises will be produced.

Note 1: The adjusting element for CH2 is shown in parentheses [].

Mode	Playback
Signal	Alignment tape: For frequency characteristic adjustment (WR5-6N)
Measurement Point	CH1: Pin ③ of CN102 (PB RF) EXT TRIG: Pin ④ of CN102 (RF SWP)
Measuring Instrument	Oscilloscope TRIG SLOPE: +, [-]
Adjustment Page	D
Adjustment Address	5E (MT 1CH (L)), [63 (MT 2CH (L))]
Specified Value	3.58 MHz level: 5.5 MHz level= 4: (3 ± 0.3)

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) After memorizing the data of page: D, address: 05, set data: 1A.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Change the data of address: 5E [63] of page D, and adjust the level ratio of 3.58 MHz and 5.5 MHz of PB RF output waveform to the specified value.

Note 2: After each address adjustment, be sure to press the PAUSE button of the adjusting remote commander and memorize the data.

- 5) Set the data memorized at step 2) to page: D, address: 05, and press the PAUSE button of the adjusting remote commander.




Fig. 7-3-7.

3-4 Standard 4-pin VIDEO SYSTEM ADJUSTMENTS (CCIR/SECAM/NTSC/NTSC/NTSC/NTSC)

The adjustments of the video system must be performed according to the following adjustment procedure.

The video color signal supplied from the picture generator is used as the video color signal for adjusting the video system in recording mode. Check that the test signal and the color burst signal satisfy the specifications specified during the adjustment set-up shown in Figs. 3-4-1 and 3-4-2.

(Adjusting procedure)

- 1) Playback frequency characteristic adjustment
- 2) Flying area check
- 3) VHS machine frequency check
- 4) SYNC ASC level adjustment
- 5) Color filter adjustment
- 6) Composite input level adjustment
- 7) WHITE CLIP check
- 8) COLOR CLIP check
- 9) GUN BIAS (V) level adjustment
- 10) RB Y red level adjustment
- 11) Y FM carrier frequency adjustment
- 12) Y FM carrier adjustment
- 13) Chroma amplitude adjustment 1
- 14) Chroma amplitude adjustment 2
- 15) Color filter bias adjustment
- 16) SEC Y level adjustment
- 17) SEC L adjustment
- 18) SEC COLORIA level adjustment
- 19) SEC A/T level check

1. Playback Frequency Characteristic Adjustment (PB FREQ)

Minimize the difference in the level characteristic of each channel. If there are differences, adjust and over compensation before 60 Hz position.

Note 1: The adjusting circuit for CTR is shown in parentheses ().

Mode	Playback
Signal	Alignment tape No. frequency characteristic adjustment (400-600)
Measurement Point	CH1 Pb (B) + CTR (PB BP) EXT TRIG Pb (B) + CTR (B) (IF 600)
Following waveform	Waveform (100 BOLD + 1.5)
Adjustment Page	10
Adjustment Address	00 (EXT CTR 0.0), 03 (EXT CTR 1.0)
Specified Value	1.00 MHz level 0.5 (100 level) 0.5 (0.5 + 0.5)

Adjusting method

- 1) Page 1 address (0), data (0)
- 2) After searching the data of page 0, address (0), set data 1.0.
- 3) Press the FFL/SL button of the adjusting remote commander.
- 4) Change the data of address 00 (00) of page 0, and adjust the level ratio of 1.00 MHz and 0.5 MHz of PB BP output waveform to the specified value.
Note 2: After each address adjustment, be sure to press the FFL/SL button of the adjusting remote commander and monitor the data.
5) Set the data measured in step 3) to page 0, address 03, and press the FFL/SL button of the adjusting remote commander.



Fig. 3-4-2

2. Flying Erase Check (VS board)

Mode	Record
Signal	Arbitrary
Measurement Point	Pin ⑫ of CN101 (FE (X))
Measuring Instrument	Oscilloscope and frequency counter
Specified Value	Frequency: 8.0 ± 0.5 MHz Voltage: 6.0 ± 1 Vp-p (ME tape) Above 7.0 Vp-p (MP tape)

Checking method:

- 1) Check that the oscillation frequency and the oscillation voltage satisfies the specified value.




Fig. 7-3-8.

3. VXO Oscillation Frequency Check (VS board)

Mode	Record
Signal	Color bar
Measurement Point	Pin ⑥ of IC201
Measuring Instrument	Frequency counter
Specified Value	3579545 ± 50 Hz

Note: Connect the frequency counter via a high impedance (approximately 10 MΩ) and low capacity (below 10 pF) buffer.

Adjusting method:

- 1) Check that the oscillation frequency of pin ⑥ of IC201 is 3579545 ± 50 Hz.




Fig. 7-3-9.

4. SYNC AGC Level Adjustment (VS board)

Adjust so that the Y signal level to be recorded becomes consistent. If it is not consistent, the camera EE image and OA image will be brighter or darker than normal.

Mode	Camera record
Signal	Color bar (Camera input) Note 1
Measurement Point	Pin ⑥ of CN201 (VIDEO I/O) Note 2
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	70 (SYNC AGC)
Specified Value	$A=1.00 \pm 0.025V$

Note 1: The chroma signal input is not required.

Note 2: Terminate the video out terminal at 75Ω .
75Ω resistor (Part code: 1-247-804-11)

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 70, and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote command.




Fig. 7-3-10.

g. Flying Edge Check (V6 board)

Mode	Signal
Signal	Arbitrary
Measurement Point	Pin ② of IC204C (IC203)
Measuring Instrument	Oscilloscope and frequency counter
Specified Value	Frequency: 0.8 ± 0.2 MHz Voltage: 0.8 V ± 0.2 V _{pp} (V _{OH} type) Above 1.0 MHz (V _{OH} type)

Checking method:

- Check that the oscillation frequency and the oscillation voltage satisfy the specified value.



Fig. 7-6-6

h. V60 Oscillation Frequency Check (V6 board)

Mode	Signal
Signal	Arbitrary
Measurement Point	Pin ② of IC201
Measuring Instrument	Frequency counter
Specified Value	0.075MHz ± 50 kHz

Note: Connect the frequency counter via a high impedance (approximately 10 kΩ) and low capacity (below 10 pF) buffer.

Adjusting method:

- Check that the oscillation frequency of pin ② of IC201 is 0.075MHz ± 50 kHz.



Fig. 7-6-7

i. 0750 ADC Level Adjustment (V6 board)

Adjust so that the "Y" signal level is the specified level on the oscilloscope. If it is not measured, the voltage 0V range and 0.5V range will be higher or lower than actual.

Mode	Current mode
Signal	Color bar (Current Input) Item 1
Measurement Point	Pin ② of IC201 (0750) (X) (Item 1)
Measuring Instrument	Oscilloscope
Adjustment Page	5
Adjustment Address	0750Y0C.ADC
Specified Value	0 ~ 1.00 ± 0.02V

Note 1: The current signal input is not required.

Note 2: Terminate the video and composite T240-T242 outputs (Port code: 1-041-604-02)

Adjusting method:

- Page 1, address (X) data (X)
- Change the data of page 0, address 70, and adjust so that the "Y" signal level (X) becomes the specified value.
- Press the F4/F50 button of the adjusting remote command.



Fig. 7-6-8

5. Comb Filter Adjustment (VS board)

Set the level and phase of the 1H delayed signal for the comb filter.

Mode	Camera record
Signal	Color bar (Note 1)
Measurement Point	Pin ⑭ of IC201 (Y COMB OUT)
Measuring Instrument	Oscilloscope
Adjusting Element	RV202 (PHASE)
Adjustment Page	D
Adjustment Address	71 (COMB ADJ)
Specified Value	Residual chroma component (A) is minimum.

Note 1: Connect the pattern generator as shown in the following figure.





Fig. 7-3-11.

Adjusting method:

- 1) Set to the VIDEO input mode.
- 2) Set to the record mode.
- 3) Page: 1, address: 00, data: 01
- 4) Set data: 00 to page: 2, address: 00.
(Specification of category 00)
- 5) Set data: 04 to page: 2, address: B0.
- 6) After memorizing the data of address: 9A of page: 2, set data: 10 to the address. (TEST A mode setting)
- 7) After memorizing the data of address: 9D of page: 2, set data: 30 to the address. (TEST B mode setting)
- 8) Change the data of page: D, address: 71, and adjust the residual chroma component (A) to minimum.
- 9) Adjust RV202 so that the residual chroma component becomes minimum.
- 10) Repeat 8) and 9).
- 11) Press the PAUSE button of the adjusting remote commander.

Processing after completing adjustments

- 1) Set the data memorized at step 7) to address: 9D of page: 2.
- 2) Set the data memorized at step 6) to address: 9A of page: 2.
- 3) Set data: 00 to page: 2, address: B0.
(Release of TEST A, B mode)

3. Control Filter Adjustment (VR board)

Set the level and phase of the full-adjusted signal for the main filter.

Mode	Control method
Signal	Color bar (Photo. 7)
Measurement Point	Pin ② of IC201 (74V04B01-007)
Measuring Instrument	Oscilloscope
Adjusting Parameter	RV201 (VR board)
Adjustment Page	5
Adjustment Address	71 (CCTB01-003)
Specified Value	Optimal chroma component (C) in waveform.

Note 1. Connect the pattern generator to chroma as in the following figure.



Adjusting method

- Set to the V-VIDEO input mode.
- Set to the normal mode.
- Page 1, address 02, data 00.
- Set data 00 to page 1, address 03.
(Specification of category 00)
- Set data 00 to page 1, address 04.
- After transmitting the data of address 04 of page 1, set data 00 to the address (TEXT A mode setting).
- After transmitting the data of address 02 of page 1, set data 00 to the address (TEXT B mode setting).
- Change the data of page 1, address 71, and adjust the optimal chroma component (C) in waveform.
- Adjust RV201 so that the optimal chroma component becomes minimum.
- Repeat 8) and 9).
- Press the PICTURE button of the adjusting remote control.

Processing after completing adjustment

- Set the data transmitted in step 7) to address 03 of page 1.
- Set the data transmitted in step 7) to address 04 of page 1.
- Set data 00 to page 1, address 03.
(Release of TEXT A, B mode)



Fig. 7-6-11.

6. Emphasis Input Level Adjustment (VS board)

Y level of emphasis circuit setting. If deviated, this causes too bright or too dark image during play back after recording.

Mode	Camera record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ⑤ of IC201 (EMPH IN) or Pin ⑤ of IC205
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	82 (EMPH (EE))
Specified Value	A=0.50 ± 0.01V

Note 1: The chroma signal input is not required.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 82, and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.




Fig. 7-3-12.

7. WHITE CLIP check (VS board)

Mode	Camera record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ③ of IC201 (Y RF OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	MP tape: 7B (W CLIP (SP L MP)) ME tape: 7A (W CLIP (SP L ME))
Specified Value	A=220 ± 10%

Note 1: The data of address 7B and 7A are fixed value.

(The data of address 7B and 7A are "86".)

Note 2: The chroma signal input is not required.

Checking method:

- 1) Set to the record mode.
- 2) Set data: 00 to page: 2, address: 00.
(Specification of category 00)
- 3) Set data: 04 to page: 2, address: B0.
- 4) After memorizing the data of address: 9A of page: 2, set data: 01 to the address. (TEST 2 mode setting)
- 5) Check that the white clip level (A) satisfies the specified value.

Processing after completing adjustments

- 1) Set the data memorized at step 4) to address: 9A of page: 2.
- 2) Set data: 00 to page: 2, address: B0.
(Release of TEST 2 mode)




Fig. 7-3-13.

6. Synthesizer Input Level Adjustment (VR board)

Y level of synthesizer output setting. If disturbed, the screen can bright or too dull image during play back after recording.

Menu	Custom reset
Signal	Color bar (CAMERA input)
Measurement Point	Pin 16 of IC201 (CONP16IN) or Pin 16 of IC202
Measuring Instrument	Oscilloscope
Adjustment Page	03
Adjustment Address	13 (250V1-250V)
Specified Value	4-6.00 ± 0.05V

Note 1: The chroma signal input is not required.

Adjusting method:

- 1) Page 1, address 00, data 00
- 2) Change the data of page 01, address 13, and adjust so that the Y signal level (V) becomes the specified value.
- 3) Press the (PAUSE) button of the adjusting remote controller.



Fig. 7-10-10

7. WHITE CLIP output (VR board)

Menu	Custom reset
Signal	Color bar (CAMERA input)
Measurement Point	Pin 16 of IC201 (CONP16IN)
Measuring Instrument	Oscilloscope
Adjustment Page	03
Adjustment Address	MP input 10-10 (CLIP (250V1, MP) L10input 10 (70-CLIP (250V1, MP))
Specified Value	4-2.00 ± 0.05

Note 1: The data of address 10 and 14 are fixed value.
(The data of address 10 and 14 are "00")

Note 2: The chroma signal input is not required.

Checking method:

- 1) Set to the record mode.
- 2) Set data 00 on page 1, address 00.
(Specification of sampling "0")
- 3) Set data 10 on page 1, address 00.
- 4) After recording, the data of address 04 of page 2, set data 00 in the address (TEST 1 mode setting).
- 5) Check that the white clip level (A) satisfies the specified value.

Processing after sampling adjustment:

- 1) Set the data indicated on step 2 to address 04 of page 2
- 2) Set data 00 on page 1, address 00.
(Release of TEST 1 mode)



Fig. 7-10-11

8. DARK CLIP check (VS board)

Mode	Camera record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ③⑨ of IC201 (Y RF OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	24 (D CLIP 1) 25 (D CLIP 2)
Specified Value	$A=100 \pm 10\%$

Note 1: The data of address 24 and 25 are fixed value.
(The data of address 24 and 25 are "00".)

Note 2: The chroma signal input is not required.

Note 3: The chroma signal input is not required.

Checking method:

- 1) Set to the record mode.
- 2) Set data: 00 to page: 2, address: 00.
(Specification of category 00)
- 3) Set data: 04 to page: 2, address: B0.
- 4) After memorizing the data of address: 9A of page: 2, set data: 01 to the address. (TEST 2 mode setting)
- 5) Check that the dark clip level (A) satisfies the specified value.

Processing after completing adjustments

- 1) Set the data memorized at step 4) to address: 9A of page: 2.
- 2) Set data: 00 to page: 2, address: B0.
(Release of TEST 2 mode)




Fig. 7-3-14.

9. DE EMPH Level Adjustment (VS board)

De-emphasis input level setting. If deviated, this causes excessive brightness or darkness.

Mode	Playback
Signal	Alignment tape: For checking operations Color bar section (WR5-5NSP)
Measurement Point	Pin ②② of IC201 (DL IN 1)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	87 (DE-EMPH (PB L))
Specified Value	$A=0.54 \pm 0.01V$

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 87, and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Perform "PB Y OUT Level Adjustment".




Fig. 7-3-15.

3. CMYK CLUT sheet (PS level)

Items	Comments
Signal	Color bar (CMYK256, 4x20)
Measurement Point	Pin #1 of 15-pin (7.5V) DVI
Measuring Instrument	Densitometer
Adjustment Page	D
Adjustment Address	2400-CLUT (3) 25-0-CLUT (5)
Specified Value	A=000.0, 100%

Note 1: The dots of address 24 and 25 are fixed values.

(The dots of address 24 and 25 are "00")

Note 2: The density adjustment must be completed.

Note 3: The density signal input must be required.

Checking method

- 1) Turn the repeat mode.
- 2) Set data 100% (page 1, address 35, Signification of category (0)).
- 3) Set data 30% (page 1, address 36).
- 4) After connecting the dots of address 34 of page 2, set data 0) to the address (TEST 3 mode setting).
- 5) Check that the data clip level (A) satisfies the specified value.

Processing after completing adjustment

- 1) Set the data recorded at step 4) to address 34 of page 2.
- 2) Set data 30 to page 1, address 36.
(Status of TEST 3 mode)



Fig. 7-8-16

5. CMYK Level Adjustment (PS level)

The grayscale input level setting. If disabled, this screen returns brightness to default.

Items	Methods
Signal	Alignment target For checking operations Color bar screen (Y80-0000)
Measurement Point	Pin #1 of 15-pin (7.5V) DVI
Measuring Instrument	Densitometer
Adjustment Page	D
Adjustment Address	80-Y80-0000 (PS 1.5)
Specified Value	A=0.04 ± 0.01

Adjusting method

- 1) Page 1, address 35, data 00
- 2) Change the data of page 1, address 37, and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the F4 (EXIT) button of the adjusting remote command set.
- 4) Perform "PS Y-DUT Level adjustment"



Fig. 7-8-15

10. PB Y OUT Level Adjustment

PB LINE OUT Y level setting. If deviated, this causes too bright or too dark picture.

Mode	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Color bar section
Measurement Point	Pin ⑥ of CN201 (VIDEO I/O)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	83 (EMPH (PB))
Specified Value	$A=1.0 \pm 0.05V$

Note 1: Terminate the video output/output terminal at 75Ω .
 75Ω resistor (Part code: 1-247-804-11)

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 83, and adjust so that the video signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.




Fig. 7-3-16.

11. Y FM Carrier Frequency Adjustment (VS board)

FM carrier frequency of REC Y setting. If deviated, this caused blurred played back picture or deteriorated resolution.

Mode	Record
Signal	No signal (CAMERA input)
Measurement Point	Pin ③ of IC201 (Y RF OUT) (JL209)
Measuring Instrument	Frequency counter
Adjustment Page	D
Adjustment Address	75 (CARRIER (L))
Specified Value	$4.385 \pm 0.01 \text{ MHz}$

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 75, and adjust so that the Y FM carrier frequency becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.



Fig. 7-3-17.

18. PM F OUT Level Adjustment

PM F OUT Y level setting. If disturbed, the screen too high or too low picture.

Mode	Playback
Signal	Alignment tape For checking horizontal (VHS-VHS) Color bar signal
Measurement Point	Pin 1 of CH1IN (CH1IN 5V)
Measuring instrument	Oscilloscope
Adjustment Page	03
Adjustment Address	83 (0x05F) (YH)
Specified Value	Adj. 0 is 0.00V

Note 1) The center of the video output signal located at YH
TDA register (Data code: 1-307-854-11)

Adjusting method:

- 1) Page 1, address 03, item 01
- 2) Change the data of page 03, address 83, and adjust so that the video signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting source connected.



Fig. 7-4-16

19. Y PM Carrier Frequency Adjustment (YH Item)

PM carrier frequency of EEC. Y setting. If disturbed, the screen shows vertical black planes or distorted waveform.

Mode	Source
Signal	No signal (VCR/PSA input)
Measurement Point	Pin 1 of CH1IN (Y 1F OUT) (0.00V)
Measuring instrument	Frequency counter
Adjustment Page	03
Adjustment Address	70 (0x03E) (L)
Specified Value	4.580 ± 0.01 MHz

Adjusting method:

- 1) Page 1, address 03, item 01
- 2) Change the data of page 03, address 70, and adjust so that the Y PM carrier frequency becomes the specified value.
- 3) Press the PAUSE button of the adjusting source connected.



Fig. 7-4-17

12. Y FM Deviation Adjustment (VS board)

FM deviation of REC Y setting. If deviated, this causes too bright/dark image, or marked occurrence of black picture or deteriorated resolution.

Mode	Record and playback
Signal	Color bar (CAMERA input)
Measurement Point	Pin ② of IC201 (DL IN 1)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	77 (DEVIATION (L))
Specified Value	$A=0.54 \pm 0.01V$

Note 1: Check that "Emphasis Input Level Adjustment", have been completed.

Note 2: The chroma signal input is not required.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Record the color bar signal.
- 3) Playback the recorded signal.
- 4) Check the playback signal level (A).
Specification: $A=0.54 \pm 0.01V$
- 5) If the specification is not satisfied, change the data of page: D, address: 77, and repeat steps 2) to 4).

Playback signal level	Changing the data
When smaller than the specified value	Increase
When bigger than the specified value	Decrease

- 6) Press the PAUSE button of the adjusting remote command.
- 7) Perform "Y FM Carrier Frequency Adjustment".




Fig. 7-3-18.

13. Chroma Emphasis Adjustment 1 (VS board)

Emphasis center frequency setting. If deviated, this causes unnatural color.

Mode	Record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ⑧ of IC201 (REC C OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	80 (C EMPH (EE)) 81 (C EMPH (PB))
Specified Value	Minimum fo component

Adjusting method:

- 1) Set to the record mode.
- 2) Page: 1, address: 00, data: 01
- 3) Set data: 00 to page: 2, address: 00.
(Specification of category 00)
- 4) Set data: 04 to page: 2, address: B0.
- 5) After memorizing the data of address: 9A of page: 2, set data: 02 to the address. (TEST 1 mode setting)
- 6) Change the data of page: D, address: 80, and adjust so that the amplitude of the latter section of the chroma signal (yellow section) becomes minimum.
- 7) Press the PAUSE button of the adjusting remote command.
- 8) Set the same data as address: 80 of page: D to address: 81 of page D.
- 9) Press the PAUSE button of the adjusting remote command.

Processing after completing adjustments

- 1) Set the data memorized at step 5) to address: 9A of page: 2.
- 2) Set data: 00 to page: 2, address: B0.
(Release of TEST 1 mode)




Fig. 7-3-19.

18. Y FM Deviation Adjustment (VR board)

(The deviation of 150% Y setting. If increased, the noise on high/low range, or needed maximum of black picture is calculated correctly.)

Menu	Source and playback
Signal	Color bar (PAL/NTSC input)
Measurement Pole	Pin 10 of IC201 (PAL/NTSC)
Measuring Instrument	Oscilloscope
Adjusted Page	D
Adjustment Address	70 (DEVIATION/2)
Specified Value	$4 \pm 0.54 \pm 0.05 \text{ V}$

Note 1: Check that "Threshold Input Level Adjustment", have been completed.

Note 2: The chroma signal input is not required.

Adjusting method

- 1) Page 1, address 02, data 00
- 2) Record the value (average).
- 3) Playback the recorded signal.
- 4) Check the playback signal waveform.
(Specification: $4 \pm 0.54 \pm 0.05 \text{ V}$)
- 5) If the specification is not satisfied, change the data of page 0, address 70, and repeat steps 2) to 4).

Playback signal level	Changing the data
When smaller than the specified value	Increase
When larger than the specified value	Decrease

- 6) Press the PAUSE button of the adjusting remote command.
- 7) Perform "Y FM Center Frequency Adjustment".



Fig. 7-3-18

19. Chroma Amplitude Adjustment (VR board)

Amplitude center frequency setting. If divided, the noise standard value.

Menu	Source
Signal	Color bar (PAL/NTSC input)
Measurement Pole	Pin 10 of IC201 (PAL/NTSC)
Measuring Instrument	Oscilloscope
Adjusted Page	D
Adjustment Address	60 (C-CHAMP/CH) 61 (C-CHAMP/PH)
Specified Value	Maximum 4 components

Adjusting method

- 1) Set in the measurement.
- 2) Page 1, address 02, data 00
- 3) Set data 00 on page 1, address 02.
(Specification of category 00)
- 4) Set data 00 on page 1, address 02.
- 5) After measuring the data of address 0A of page 1, set data 00 in the address 70001 (1 unit setting).
- 6) Change the data of page 0, address 60, and adjust so that the amplitude of the latter output of the chroma signal (center output) becomes minimum.
- 7) Press the PAUSE button of the adjusting remote command.
- 8) Set the same data as address 0A of page 1 to address 01 of page 0.
- 9) Press the PAUSE button of the adjusting remote command.

Processing after completing adjustments

- 1) Set the data mentioned in step 8) in address 0A of page 1.
- 2) Set data 00 in page 0, address 00.
(Please set 70001 to mode)

Minimize the amplitude of the later section of the waveform.



Fig. 7-3-19

14. Chroma Emphasis Adjustment 2 (VS board)

Emphasis center frequency setting. If deviated, this causes unnatural color.

Mode	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Color bar section
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	D
Adjustment Address	81 (C EMPH (PB)) 80 (C EMPH (EE))
Specified Value	The path from the blue luminance point to black luminance point should be a straight line.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 81, and adjust so that the path from the blue luminance point to black luminance point becomes a straight line.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set the same data as address: 81 of page: D to address: 80 of page: D.
- 5) Press PAUSE button of the adjusting remote commander.




Fig. 7-3-20.

15. Comb Filter Fine Adjustment (VS board)

Set the level and phase of the 1H delayed signal for the comb filter. If deviated, this causes marked occurrence of beets in played back picture.

Mode	Playback
Signal	Alignment tape: For checking operations (WR5-5NSP) Color bar section
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjusting Element	RV202 (PHASE)
Adjustment Page	D
Adjustment Address	71 (COMB ADJ)
Specified Value	Minimum color luminance point movement when the "Edit" switch is turned on/off

Note 1: Turn the edit ON/OFF at the menu screen.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Minimize the movements of the color luminance point when the edit is on/off with RV202.
- 3) Change the data of page: D, address: 71 and minimize the movements of the color luminance point when the edit is on/off
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Repeat steps 2) to 4).




Fig. 7-3-21.

14. Grounds Rhythmic Adjustment 2 (VR Screen)

Rhythmic center frequency setting. If desired, the center measured value.

Mode	Playback
Signal	Adjustment signal For checking operation (NR-01-000) Color bar section
Measurement Field	Video output terminal
Measuring Instrument	Video scope
Adjustment Page	B
Adjustment Address	B1 (C-0000) (VR) B1 (C-0000) (VR)
Specified Value	The path from the blue luminance point to the red luminance point should be a straight line.

Adjusting method

- 1) Page 1, address B1, data 00
- 2) Change the data of page D, address B1, and adjust so that the path from the blue luminance point to the red luminance point becomes a straight line.
- 3) Press the FOCUS button of the adjusting screen command.
- 4) Set the focus line in address B1 of page D to address B1 of page D.
- 5) Press FOCUS button of the adjusting screen command.



Fig. 7-10-25

15. Grounds Filter Phase Adjustment (VR Screen)

Set the level and phase of the filter delay signal for the center line. If desired, the center measured correction of tone is played back.

Mode	Playback
Signal	Adjustment signal For checking operation (NR-01-000) Color bar section
Measurement Field	Video output terminal
Measuring Instrument	Video scope
Adjustment Address	C-0000 (VR-0000)
Adjustment Page	B
Adjustment Address	T1 (C-0000) (VR)
Specified Value	Minimum value luminance point correction when the "blue" level is equal to 0.01

Set to 0. Then the all ON/OFF at the same screen.

Adjusting method

- 1) Page 1, address B1, data 00
- 2) Minimize the correction of the color luminance point when the all is equal to 0.01 with FOCUS.
- 3) Change the data of page D, address T1, and minimize the correction of the color luminance point when the all is equal.
- 4) Press the FOCUS button of the adjusting screen command.
- 5) Repeat steps 2) to 4).



Fig. 7-10-26

16. REC Y Level Adjustment (VS board)

Recording level of luminance signal setting. If deviated, this causes black stretch over modulation noise or color shade.

Mode	Record
Signal	No signal
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope Board width limit: 20 MHz
Adjustment Page	D
Adjustment Address	47 (REC Y 2CH (L MP)) 43 (REC Y 1CH (L MP)) 46 (REC Y 2CH (L ME)) 42 (REC Y 1CH (L ME))
Specified Value	$A=145 \pm 5 \text{ mVp-p}$

Note 1: Use a normal MP type tape.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) After memorizing the data of address: 3B of page: D, set data: FF to the address.
- 3) Set data: FF to address: 43 of page: D, and press the PAUSE button of the adjusting remote commander.
- 4) Change the data of page: D, address: 47, and adjust so that REC Y level (A) becomes the specified value.
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Set data to address: 42, 43, 46 of page: D as shown in following table.

(Be sure to press the PAUSE button of the adjusting remote control unit after setting each data.)

Address	Data
42	Same data as address: 47
43	Same data as address: 47
46	Same data as address: 47

- 7) Set the data memorized at step 2) to address: 3B of page: D and press the PAUSE button of the adjusting remote commander.




Fig. 7-3-22.

17. REC L Adjustment (VS board)

Set the recording levels of the REC AFM signal and REC ATF signal. If the level is too low, the audio S/N will deteriorate, tracking will not be stable, or SP/LP will not be discriminated properly. If too high, color beats will be produced on the self-recording/playback image.

Mode	Record
Signal	No signal (VIDEO input)
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	3B (REC LOW 2 (MP)) 39 (REC LOW 1 (MP)) 3A (REC LOW 2 (ME)) 38 (REC LOW 1 (ME))
Specified Value	$A=6.7 \pm 1.0 \text{ mVp-p}$

Note 1: Use a MP type tape.

Note 2: AU board is required for this adjustment.

Note 3: For CCD-TR72/TR80/TR430, do not insert any plug into the right audio input terminal.

Connection:

- 1) Connect Emitter of Q113 and GND with a jumper wire.
- 2) Connect Pin ⑤ of IC508 and GND with a $0.01 \mu\text{F}$ capacitor. (Parts cord: 1-101-004-00)

Adjusting method:

- 1) Page: 1, address: 00, data: 01
 - 2) Change the data of page: D, address: 3B, and adjust so that the REC AFM signal level (A) becomes the specified value.
 - 3) Press the PAUSE button of the adjusting remote commander.
 - 4) Read the data of page: D, address: 3B, and set to D3B.
 - 5) Set data: D3B to address: 39 of page D.
 - 6) Press the PAUSE button of the adjusting remote commander.
 - 7) Convert D3B to decimal notation, and obtain D3B'.
- (Refer to Table 7-1-3. "Hexadecimal notation-decimal notation conversion table")
- 8) Calculate D3A' using following equation (decimal notation calculation).
- $$D3A' = D3B' - 7$$
- 9) Convert D3A' to hexadecimal notation, and obtain D3A.
 - 10) Set data: D3A to address: 3A of page D.
 - 11) Press the PAUSE button of the adjusting remote commander.
 - 12) Set data: D3A to address: 38 of page D.
 - 13) Press the PAUSE button of the adjusting remote commander.
 - 14) Perform "REC CHROMA Level Adjustment".

16. HSC Y Level Adjustment (YR Input)

Setting level of luminance signal using YR channel. The menu that controls color calibration is also shown.

Mode	Normal
Signal	YR signal
Measurement Point	No. 8 of CHASE/HSR 2
Measuring Instrument	Challenger
Adjustment Page	01
Adjustment Address	49 (HSC Y RCR 0.540V) 43 (HSC Y LCR 0.540V) 44 (HSC Y RCR 0.540V) 43 (HSC Y LCR 0.540V)
Specified Value	$4 \times 0.01 + 1.00 \text{Vpp}$

Note 1: Use a normal JFP type lens.

Adjusting method:

- 1) Page 1, address 00, data 00
- 2) After completing the data of address 00 of page 0, set data 00 to the address
- 3) Set data 00 to address 43 of page 0 and press the FOCUS button of the adjusting remote commander
- 4) Change the data of page 0, address 43, and adjust so that HSC Y error (+) becomes the specified value
- 5) Press the FOCUS button of the adjusting remote commander
- 6) Set data to address 43, 44, 43 of page 0 as above in following order.
(Be sure to press the FOCUS button of the adjusting remote commander only after setting each data.)

Address	Data
43	Lower data to address 40
44	Lower data to address 40
43	Lower data to address 40

- 7) Set the data mentioned in step 6 to address 00 of page 0 and press the FOCUS button of the adjusting remote commander




Fig. F-4-02

17. HSC L Adjustment (YR Input)

Setting the level of the HSC L signal and HSC L/F signal. If the level is too low, the color L/F will deteriorate, leading will not be stable, or BFLP will not be discriminated properly. If too high, color tone will be produced on the self-screening display image.

Mode	Normal
Signal	YR signal / YL/F signal
Measurement Point	No. 8 of CHASE/HSR 2
Measuring Instrument	Challenger
Adjustment Page	01
Adjustment Address	50 (HSC L/FW 0.540V) 54 (HSC L/FW 0.540V) 54 (HSC L/FW 0.540V) 50 (HSC L/FW 0.540V)
Specified Value	$4 \times 0.01 + 1.00 \text{Vpp}$

Note 1: Use a JFP type lens.

Note 2: All level is optional for this adjustment.

Note 3: Step 000 > 0000 (00000000), do not insert any plug into the right color input terminal.

Condition:

- 1) Connect Section of 01 01 and CHASE with a jumper wire.
- 2) Connect Pin 8 of CHASE and BFL with a JFP all together. (Part code: 1-01-004-00)

Adjusting method:

- 1) Page 1, address 00, data 00
- 2) Change the data of page 0, address 00, and adjust so that the HSC L/FW signal level (+) becomes the specified value
- 3) Press the FOCUS button of the adjusting remote commander
- 4) Read the data of page 0, address 00, and set to 00
- 5) Set data 00 to address 00 of page 0
- 6) Press the FOCUS button of the adjusting remote commander
- 7) Connect Data to desired position, and adjust Data.
(Refer to Table F-1-1 "Functional attribute-related address connection table")
- 8) Calculate "Data" using following equation (functional attribute calculation).
Data = Data / F
- 9) Connect Data to functional position, and adjust Data.
- 10) Set data Data to address 04 of page 0.
- 11) Press the FOCUS button of the adjusting remote commander
- 12) Set data Data to address 04 of page 0
- 13) Press the FOCUS button of the adjusting remote commander
- 14) Perform "HSC CHROMA Level Adjustment".




Fig. 7-3-23.

18. REC CHROMA Level Adjustment (VS board)

Set REC CHROMA signal level. If it is lower than its normal level, chroma signal noise in played back picture will increase. If it is set higher, Y signal noises will increase and white modulation noises will be produced.

Mode	Record
Signal	Color bar (VIDEO input)
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	33 (REC C (SP L MP)) 32 (REC C (SP L ME)) 37 (REC C.(LP L MP)) 36 (REC C (LP L ME))
Specified Value	$A=29 \pm 3$ mVp-p

Note 1: Use a MP type tape.

Connection:

- 1) Connect Emitter of Q113 and GND with a jumper wire.
- 2) Connect Pin ⑤ of IC508 and GND with a 0.01 μ F capacitor. (1-101-004-00)
- 3) Disconnect AU board.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 33, and adjust so that the REC CHROMA signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote command-er.
- 4) Read the data of page: D, address: 33, and set to D33.
- 5) Set data: D33 to address: 32 of page D.
- 6) Press the PAUSE button of the adjusting remote command-er.
- 7) Set data: D33 to address: 36 of page D.
- 8) Press the PAUSE button of the adjusting remote command-er.
- 9) Set data: D33 to address: 37 of page D.
- 10) Press the PAUSE button of the adjusting remote command-er.




Fig. 7-3-24.



Fig. 7-4-25

16. RISC CHROMA Level Adjustment (HIS board)

Use RISC CHROMA signal level. If it is lower than the normal level, chroma signal wave is played back picture will become. If it is not higher, Y signal, color will become and white modulation wave will be produced.

Mode	Reset
Type	Color bar (VIDEO input)
Measurement Point	Pin 24 of CHROMA (RISC 3)
Measuring instrument	Oscilloscope
Adjustment Page	0
Adjusted Address	3A (RISC 0:0P 1.40V) 3B (RISC 0:0P 1.40V) 3F (RISC 0:0P 1.40V) 3A (RISC 0:0P 1.40V)
Specified value	$Amplitude = 3 mVpp$

Note 1: Use a 600-type tape

Operation

- 1) Connect the tape of CHROMA and CHROMA with a tape machine.
- 2) Connect the 24 of CHROMA and CHROMA with a 600-type tape.
- 3) Disconnect the board.

Adjusting method

- 1) Page 1, address 3A, level 0.
- 2) Change the data of page 0, address 3B, and adjust so that the RISC CHROMA signal level (3A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting device connected.
- 4) Read the data of page 0, address 3B, and set to 0.
- 5) Set data, CHROMA address, 3C of page 0.
- 6) Press the PAUSE button of the adjusting device connected.
- 7) Set data, CHROMA address, 3D of page 0.
- 8) Press the PAUSE button of the adjusting device connected.
- 9) Set data, CHROMA address, 3E of page 0.
- 10) Press the PAUSE button of the adjusting device connected.



Fig. 7-4-26

19. REC ATF Level Check (VS board)

Mode	Record
Signal	No signal
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope
Specified Value	$A=6.4 \pm 1.5 \text{ mVp-p}$

Note 1: Use a MP type tape.

Connection:

- 1) Connect Emitter of Q113 and GND with a jumper wire.
- 2) Disconnect AU board.

Adjusting method:

- 1) Check that the REC ATF signal level (A) satisfies the specified value.




Fig. 7-3-25.

3-6. Hi8 VIDEO SYSTEM ADJUSTMENTS (CCD-TR400/TR750)

The adjustments of the video system must be performed according to the following adjustment procedure.

The color video signal supplied from the pattern generator is used as the video input signal for adjusting the video system in recording mode. Check that the sync signal and the color burst signal satisfy the specification specified during the adjustment set-up shown in Figs. 7-3-2. and 7-3-3.

[Adjusting procedure]

- 1) Playback frequency characteristics adjustment
- 2) Flying erase check
- 3) VXO oscillation frequency check
- 4) SYNC AGC level adjustment
- 5) Comb filter adjustment
- 6) Emphasis input level adjustment
- 7) WHITE CLIP check
- 8) DARK CLIP check
- 9) DE EMPH level adjustment
- 10) PB Y out level adjustment
- 11) Normal mode Y FM carrier frequency adjustment
- 12) Normal mode Y FM deviation adjustment
- 13) Hi8 mode Y FM carrier frequency adjustment
- 14) Hi8 mode Y FM deviation adjustment
- 15) Chroma emphasis adjustment 1
- 16) Chroma emphasis adjustment 2
- 17) Comb filter fine adjustment
- 18) REC Y level adjustment
- 19) REC L adjustment
- 20) REC CHROMA level adjustment
- 21) REC ATF level check

18. SEC XTP Level Check (VR board)

Mode	Result
Signal	No signal
Measurement Point	Pin ② of C5401 (VR) ②
Measuring Instrument	Oscilloscope
Specified Value	Level is ± 1.5 Vpp

Note 1 Check MP type type

Caution

- 1) Connect function of G1 H and GND with a jumper wire.
- 2) Disconnect AG board.

Adjusting method

- 1) Check that the SEC XTP signal level (Vp) satisfies the specified value.



Fig. 7-4-45

14-6. RGB VIDEO SYSTEM ADJUSTMENTS (CDD-TRADITION)

The adjustments of the video system area be performed according to the following adjustment procedure.

The color video signal supplied from the pattern generator is used as the video input signal for adjusting the video system in assembly mode. Check that the sync signal and the video level signal satisfy the specifications specified during the adjustment using streamer as (Figs. 7-4-52 and 7-4-53).

Adjusting procedure

- 1) Playback frequency discrimination adjustment
- 2) Shrug error check
- 3) YCC saturation frequency check
- 4) DENC-ACC level adjustment
- 5) Color filter adjustment
- 6) Magnetics input level adjustment
- 7) W-ITTS CLP check
- 8) GARR CLP check
- 9) CG-164PH level adjustment
- 10) PB Y-co level adjustment
- 11) Normal mode YTM center frequency adjustment
- 12) Normal mode YTM deviation adjustment
- 13) AG mode Y FM center frequency adjustment
- 14) AG mode Y FM deviation adjustment
- 15) Chroma magnetic adjustment 1
- 16) Chroma magnetic adjustment 2
- 17) Color filter line adjustment
- 18) SEC Y level adjustment
- 19) SEC L adjustment
- 20) SEC C-ORAMA level adjustment
- 21) SEC XTP level check

1. Playback Frequency Characteristic Adjustment (VS board)

Eliminate the differences in the head characteristics of each channel. If there are differences, flickers and over modulation noises will be produced.

Note 1: The adjusting element for CH2 is shown in parentheses [].

Mode	Playback
Signal	Alignment tape: For frequency characteristic adjustment (WR5-7NE)
Measurement Point	CH1: Pin ③ of CN102 (PB RF) EXT TRIG: Pin ④ of CN102 (RF SWP)
Measuring Instrument	Oscilloscope TRIG SLOPE: +, [-]
Adjustment Page	D
Adjustment Address	5A (MT 1CH (SP E ME)) 5B (MT 1CH (SP E MP)) 5C (MT 1CH (LP E ME)) 5D (MT 1CH (LP E MP)) 5E (MT 1CH (L)) [5F (MT 2CH (SP E ME))] 60 (MT 2CH (SP E MP)) 61 (MT 2CH (LP E ME)) 62 (MT 2CH (LP E MP)) [63 (MT 2CH (L))]
Specified Value	4.5 MHz level: 8.5 MHz level= 3: (2 ± 0.2)

Address	Data
5B	D5A
5C	D5A
5D	D5A
5E	D5A+8
60	D5F
61	D5F
62	D5F
63	D5F+8




Fig. 7-3-26.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Press the PAUSE button of the adjusting remote commander.
- 3) Change the data of address: 5A [5F] of page D, and adjust the level ratio of 4.5 MHz and 8.5 MHz of PB RF output waveform to the specified value.

Note 2: After each address adjustment, be sure to press the PAUSE button of the adjusting remote commander and memorize the data.

- 4) Read the data of page: D, address: 5A, and set to D5A.
- 5) Read the data of page: D, address: 5F, and set to D5F.
- 6) Set data to address: 5B to 5E and 60 to 63 of page: D as shown in following table.
(Be sure to press the PAUSE button of the adjusting remote commander after setting each data.)

3. Payday's Frequency (Weekly/Biweekly Adjustment)

Elaborate the difference in the bond characteristics of each element. If there are differences, discuss and your modulation within 20% be correct.

Lemma 7. The adjoint element \bar{a} (2.1) is dense in \mathfrak{g} .

[illegible]

Addresse	Status
JB	Go
JC	Go
JD	Go
JE	Cancel
JF	Go
JG	Go
JH	Go
JI	Cancel



Abstract

Figure 1

- 1) Page 1, address (B), date (B)
 - 2) From the FACSIMI button of the adjoining window command:
 - a) Press the **OK** button
 - 3) Change the date of address (A), 10% of page (C), and adjust the level value of 0.5 (left) and 0.5 (right) of PG (B) using the arrow for the specified value.
- NOTE 2:** After each address adjustment, be sure to press the FACSIMI button of the adjoining window command and to maintain the data.
- 4) Read the date of page (C), address (A), and set to **END**.
 - 5) Read the date of page (C), address (B), and return (C).
 - 6) Set the date to address (B) to 20 and 20 to 20 of page (C) in the data in following table.
- (Be sure to press the FACSIMI button of the adjoining window command after setting each data.)

2. Flying Erase Check (VS board)

Mode	Record
Signal	Arbitrary
Measurement Point	Pin ⑫ of CN101 (FE (X))
Measuring Instrument	Oscilloscope and frequency counter
Specified Value	Frequency: 8.0 ± 0.5 MHz Voltage: 6.0 ± 1 Vp-p (ME tape) Above 7.0 Vp-p (MP tape)

Checking method:

- 1) Check that the oscillation frequency and the oscillation voltage satisfies the specified value.




Fig. 7-3-27.

3. VXO Oscillation Frequency Check (VS board)

Mode	Record
Signal	Color bar
Measurement Point	Pin ⑥ of IC201
Measuring Instrument	Frequency counter
Specified Value	3579545 ± 50 Hz

Note: Connect the frequency counter via a high impedance (approximately $10\text{ M}\Omega$) and low capacity (below 10 pF) buffer.

Adjusting method:

- 1) Check that the oscillation frequency of pin ⑥ of IC201 is 3579545 ± 50 Hz.




Fig. 7-3-28.

4. SYNC AGC Level Adjustment (VS board)

Adjust so that the Y signal level to be recorded becomes consistent. If it is not consistent, the camera EE image and OA image will be brighter or darker than normal.

Mode	Record
Signal	Color bar (Camera input) Note 1
Measurement Point	Pin ② of CN201 (Y IN/OUT) Note 2
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	70 (SYNC AGC)
Specified Value	$A=1.00 \pm 0.025\text{V}$

Note 1: The chroma signal input is not required.

Note 2: Connect Pin ② of CN201 and Pin ③ of CN201 (S-Y GND) with a 75Ω resistor.
 75Ω resistor (Part code: 1-247-804-11)

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 70, and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.




Fig. 7-3-29.

3. Flying Stress Check (YR board)

Mode	Reset
Signal	Address
Measurement Pole	Pin ② of C0001 (YR YR)
Measuring Instrument	Oscilloscope and frequency counter
Specified Value	Frequency: 8.0 ± 0.2 MHz Voltage: 0.8 ± 0.1 Vpp (400Vpp) After 100 Vpp is set (1V)

Checking method

- Check that the oscillation frequency and the oscillation voltage satisfy the specified value.



Fig. 7-5-27

4. Y02 Oscillation Frequency Check (YR board)

Mode	Reset
Signal	Output pin
Measurement Pole	Pin ② of C0001
Measuring Instrument	Frequency counter
Specified Value	800kHz ± 20 Hz

Note: Connect the frequency counter via a high impedance (approximately 10 kΩ) and low capacity (below 10 pF) buffer.

Adjusting method

- Check that the oscillation frequency of pin ② of C0001 is 800kHz ± 20 Hz.



Fig. 7-5-28

5. STV92 AGC Level Adjustment (YR board)

Adjust so that the Y signal level is the specified increase amount. If it is not constant, the current AG image and CG image will be lighter or darker than normal.

Mode	Reset
Signal	Output pin (Output pin) from 1
Measurement Pole	Pin ② of C0001 (Y (AGC/Y) from 2)
Measuring Instrument	Oscilloscope
Adjustment Page	01
Adjustment Address	70 (STV92 AGC)
Specified Value	Aut. AGC is 0.000V

Note 1: The external signal input is not required.

Note 2: Connect Pin ② of C0001 and Pin ② of C0001 (Y-Y) with a 75Ω resistor.

75Ω resistor (Part no.: 0-307-600-11)

Adjusting method

- Page 01, address 70, data 01.
- Change the data of page 01, address 70, and adjust so that the Y signal level (AGC) increases the specified value.
- Press the PAL/NTSC button of the adjusting remote controller.




Fig. 7-5-29

5. Comb Filter Adjustment (VS board)

Mode	Record
Signal	Color bar (Note 1)
Measurement Point	Pin ⑭ of IC201 (Y COMB OUT)
Measuring Instrument	Oscilloscope
Adjusting Element	RV202 (PHASE)
Adjustment Page	D
Adjustment Address	71 (COMB ADJ)
Specified Value	Residual chroma component (A) is minimum.

Note 1: Connect the pattern generator as shown in the following figure.

Note 2: Connect Pin ⑭ of IC251 (INPUT SEL.) and Pin ⑨ of IC251 (Vcc) with a jumper wire.



Note: The TV monitor cannot be connected.
Use the view finder to monitor.

Adjusting method:

- 1) Set to the VIDEO input mode.
- 2) Set to the record mode.
- 3) Page: 1, address: 00, data: 01
- 4) Change the data of page: D, address: 71, and adjust the residual chroma component (A) to minimum.
- 5) Adjust RV202 so that the residual chroma component becomes minimum.
- 6) Repeat 4) and 5).
- 7) Press the PAUSE button of the adjusting remote commander.




Fig. 7-3-30.

B. Control Filter Adjustment (P/N ignored)

Mode	Setting
Signal	Center bar (Note 1)
Measurement Point	Pin 46 of IC201 (Y1 COARSE-TUNE)
Measuring Instrument	Oscilloscope
Adjusting Element	VR104 (pin46AD)
Adjustment Page	04
Adjustment Address	T1 (IC201 AD3)
Specified Value	Residual channel component (A) is minimum

Note 1: Observe the picture generator waveforms in the following figure.

Note 2: Connect Pin 46 of IC201 (Y1/NT TUNE) and Pin 46 of IC201 (Y1/4) to the oscilloscope.



Note: The TV number cannot be corrected.
Use the channel number.

Adjusting method

- 1) Set to the Y1/4/NT input mode.
- 2) Set to the channel mode.
- 3) Page 1, address 04, step 01.
- 4) Change the data of page 01, address T1, and adjust the residual channel component (A) to minimum.
- 5) Adjust YV104 so that the residual channel component becomes minimum.
- 6) Repeat 4) and 5).
- 7) Press the F4/ADR button of the adjusting remote command.



Fig. 7-4-20.

6. Emphasis Input Level Adjustment (VS board)

Y level of emphasis circuit setting. If deviated, this causes too bright or too dark image during play back after recording.

Mode	Record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ⑤ of IC201 (EMPH IN) or Pin ⑤ of IC205
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	82 (EMPH (EE))
Specified Value	$A=0.50 \pm 0.01V$

Note 1: The chroma signal input is not required.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 82, and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.




Fig. 7-3-31.

7. WHITE CLIP check (VS board)

Mode	Record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ③ of IC201 (Y RF OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	Hi8 mode ME tape: 78 (W CLIP (SP E ME)) Hi8 mode Hi8 MP tape: 79 (W CLIP (SP E MP)) Normal mode MP tape: 7B (W CLIP (SP L MP))
Specified Value	Hi8 mode ME tape: $A=195 \pm 10\%$ Hi8 mode Hi8 MP tape: $A=190 \pm 10\%$ Normal mode MP tape: $A=220 \pm 10\%$

Note 1: The data of address 78 to 7B are fixed value.

Address	Data
78	59
79	53
7A	7B
7B	7B

Note 2: The chroma signal input is not required.

Checking method:

- 1) Set to the record mode.
- 2) Set data: 00 to page: 2, address: 00.
(Specification of category 00)
- 3) Set data: 04 to page: 2, address: B0.
- 4) After memorizing the data of address: 9A of page: 2, set data: 01 to the address. (TEST 2 mode setting)
- 5) Check that the white clip level (A) satisfies the specified value.

Processing after completing adjustments

- 1) Set the data memorized at step 4) to address: 9A of page: 2.
- 2) Set data: 00 to page: 2, address: B0.
(Release of TEST 2 mode)




Fig. 7-3-32.

6. Synthesizer Input Level Adjustment (YB board)

Y level of composite video signal. If detected, the screen too bright or too dark image during playback after recording.

Mode	Normal
Signal	Color bar (CAMERA input)
Measurement Point	Pin (3) of YOUT (CAMERA IN) or Pin (3) of YCCIN
Measuring Instrument	Oscilloscope
Adjustment Page	0
Adjustment Address	00-07-001 (20%)
Specified Value	Auto (0.1 ± 0.01V)

Note 1: The screen signal input is not required.

Adjusting method:

- 1) Page 1, address (0) data (0)
- 2) Change the data of page (0), address (0), and adjust so that the Y signal level (A) becomes the specified value.
- 3) Press the [F4.00] button of the adjusting screen (screen-00).



Fig. 7-4-01

7. WHITE-CLIP about (YB board)

Mode	Normal
Signal	Color bar (CAMERA input)
Measurement Point	Pin (3) of YOUT (Y B-CLIP)
Measuring Instrument	Oscilloscope
Adjustment Page	0
Adjustment Address	YB mode (YB input) 70 (Y-CLIP (0.75 VAC)) YB mode (YB MP input) 70 (Y-CLIP (0.75 VAC)) Normal mode (MP input) 70 (Y-CLIP (0.75 VAC))
Specified Value	YB mode (YB input) 0 ± 0.01 ± 0.06 YB mode (YB MP input) 0 ± 0.01 ± 0.06 Normal mode (MP input) Auto (0.1 ± 0.01V)

Note 1: The data of address (0) is "0" (fixed value).

Address	Data
70	00
70	00
70	70
70	70

Note 2: The screen signal input is not required.

Checking method:

- 1) Set to the normal mode.
- 2) Set data (0) to page 1, address (0).
- 3) (Specification of category (0))
- 4) Set data (0) to page 1, address (0).
- 5) After terminating the data of address (0) of page 1, set data (1) to the address. (YBUT 2 mode setting)
- 6) Check that the white clip level (A) matches the specified value.

Processing after completing adjustments:

- 1) Set the data (screened at step 6) to address (0) of page 1.
- 2) Set data (0) to page 1, address (0).
- 3) (Release of YBUT 2 mode)



Fig. 7-4-02

8. DARK CLIP check (VS board)

Mode	Record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ③ of IC201 (Y RF OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	24 (D CLIP 1) 25 (D CLIP 2)
Specified Value	Hi8 mode ME tape: A=85 ± 10% Hi8 mode Hi8 MP tape: A=80 ± 10% Normal mode MP tape: A=100 ± 10%

Note 1: The data of address 24 and 25 are fixed value.
(The data of address 24 and 25 are "00".)

Note 2: The chroma signal input is not required.

Checking method:

- 1) Set to the record mode.
- 2) Set data: 00 to page: 2, address: 00.
(Specification of category 00)
- 3) Set data: 04 to page: 2, address: B0.
- 4) After memorizing the data of address: 9A of page: 2, set data: 01 to the address. (TEST 2 mode setting)
- 5) Check that the dark clip level (A) satisfies the specified value.

Processing after completing adjustments

- 1) Set the data memorized at step 4) to address: 9A of page: 2.
- 2) Set data: 00 to page: 2, address: B0.
(Release of TEST 2 mode)




Fig. 7-3-33.

9. DE EMPH Level Adjustment (VS board)

De-emphasis input level setting. If deviated, this causes excessive brightness or darkness.

Mode	Playback
Signal	Alignment tape: For checking operations Color bar section Normal mode : WR5-5NSP Hi8 mode : WR5-8NSE
Measurement Point	Pin ⑰ of IC201 (DL IN 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	86 (DE-EMPH (PB E)) 87 (DE-EMPH (PB L))
Specified Value	A=0.54 ± 0.01V

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Playback the color bar section of the normal mode alignment tape (WR5-5NSP).
- 3) Change the data of page: D, address: 87, and adjust so that the Y signal level (A) becomes the specified value.
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Playback the color bar section of the Hi8 mode alignment tape (WR5-8NSE).
- 6) Change the data of page: D, address: 86 and adjust so that the Y signal level (A) becomes specified value.
- 7) Press the PAUSE button of the adjusting remote commander.
- 8) Perform "PB Y OUT Level adjustment".




Fig. 7-3-34.

8. DMM YOUT Level (YB Input)

Mode	Signal
Signal	Color bar (ColorBGA input)
Measurement Point	Pin 16 of IC20 (YOUT OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	1d (D) CLP 1) 1d (D) CLP 2)
Specified Value	100 mode MP type AutoH is 10%
	100 mode SSB MP type AutoH is 10%
	Normal mode MP type AutoH is 10%

Note 1: The data of address 1d and 1e are fixed value.
(The data of address 1d and 1e are "00")

Note 2: The channel signal input is not required.

Checking method

- Set to the normal mode
- Set data 00 to page 1, address 00.
(display position of category 00)
- Set data 0d to page 1, address 00.
- After completing the data of address 1d, of page 1, set data 00 to the address 100012 mode setting.
- Check that the data, only level (A) satisfies the specified value.

Proceeding after completing adjustment

- Set the data mentioned in step 4) to address 1d, of page 1.
- Set data 00 to page 1, address 00.
(Return of 10012 mode)



Fig. 7-4-26

9. DMM YOUT Level Adjustment (YB Input)

The maximum level setting. If correct, the status returns to factory or factory.

Mode	Signal
Signal	Adjustment type For checking operation Color bar output Normal mode: YB1-YB2 100 mode: YB1-YB2
Measurement Point	Pin 16 of IC20 (YOUT IN)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	1d (YB1-YB2) (YB 1) 1d (YB1-YB2) (YB 2)
Specified Value	AutoH is 100%

Adjusting method

- Page 1, address 00, data 00
- Perform the color bar output of the normal mode alignment type (YB1-YB2).
- Change the data of page 1, address 00, and adjust so that the Y signal level (A) becomes the specified value.
- Press the F4/000 button of the adjusting remote command.
- Perform the color bar output of the 100 mode alignment type (YB1-YB2).
- Change the data of page 1, address 00 and adjust so that the Y signal level (A) becomes specified value.
- Press the F4/000 button of the adjusting remote command.
- Perform the YOUT Level adjustment.



Fig. 7-4-27

10. PB Y OUT Level Adjustment (VS board)

PB LINE OUT Y level setting. If deviated, this causes too bright or too dark picture.

Mode	Playback
Signal	Alignment tape: For checking operations (WR5-8NSE) Color bar section
Measurement Point	Pin ② of CN201 (Y IN/OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	83 (EMPH (PB))
Specified Value	$A=1.0 \pm 0.05V$

Note 1: Connect Pin ② of CN201 and Pin ③ of CN201 (S-Y GND) with a 75Ω resistor.
(Part code: 1-247-804-11)

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 83, and adjust so that the video signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote command-er.




Fig. 7-3-35.

11. Normal Mode Y FM Carrier Frequency Adjustment (VS board)

Normal mode FM carrier frequency of REC Y setting. If deviated, this caused blurred played back picture or deteriorated resolution.

Mode	Record
Signal	No signal (CAMERA input)
Measurement Point	Pin ③ of IC201 (Y RF OUT)
Measuring Instrument	Frequency counter
Adjustment Page	D
Adjustment Address	75 (CARRIER (L))
Specified Value	$4.385 \pm 0.01 \text{ MHz}$

Adjusting method:

- 1) Insert a normal MP type tape.
- 2) Page: 1, address: 00, data: 01
- 3) Change the data of page: D, address: 75, and adjust so that the Y FM carrier frequency becomes the specified value.
- 4) Press the PAUSE button of the adjusting remote command-er.




Fig. 7-3-36.

18. **Y IF GAT Level Adjustment (YIF Level)**
 PB-LINE GAT Y level setting. If adjusted, this causes too bright or too dark picture.

Mode	Function
Signal	Alignment tape: For checking operation (VCR-4000H). Color bar output
Measurement Point	Pin ② of CH01 (Y INQUT)
Measuring Instrument	Oscilloscope
Adjustment Page	0
Adjustment Address	45 (0400H) (YIF)
Specified Value	ca. 1.2 V (RMS)

Make 1: Connect Pin ② of CH01 and Pin ② of CH01 (B-Y GAT) with a 75Ω resistor.
 (Part code: 1-997-804-11)

Adjusting method:

- 1) Page 1, address: 00, data: 00
- 2) Change the data of page 0, address 00, and adjust so that the video signal level (V) becomes the specified value.
- 3) Press the FINEST button of the adjusting remote command.



Fig. 7-9-25

19. **Normal Mode Y FM Carrier Frequency Adjustment (YIF Level)**

Normal mode (H) carrier frequency of 59C Y setting. If adjusted, this causes altered played back picture or distorted resolution.

Mode	Function
Signal	No signal (CAMERA input)
Measurement Point	Pin ② of IC201 (Y IF OUT)
Measuring Instrument	Frequency counter
Adjustment Page	0
Adjustment Address	73 (040000H) (YIF)
Specified Value	4,800 ± 0.05 MHz

Adjusting method:

- 1) Insert a normal MP type tape.
- 2) Page 1, address 00, data: 00
- 3) Change the data of page 0, address 73, and adjust so that the Y FM carrier frequency becomes the specified value.
- 4) Press the FINEST button of the adjusting remote command.



Fig. 7-9-26

12. Normal Mode Y FM Deviation Adjustment (VS board)

Normal mode FM deviation of REC Y setting. If deviated, this causes too bright/dark image, or marked occurrence of black picture or deteriorated resolution.

Mode	Record and playback
Signal	Color bar (CAMERA input)
Measurement Point	Pin ⑩ of IC201 (DL IN 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	77 (DEVIATION (L))
Specified Value	$A=0.54 \pm 0.01V$

Note 1: Check that "Emphasis Input Level Adjustment", have been completed.

Note 2: The chroma signal input is not required.

Adjusting method:

- 1) Insert a normal MP type tape.
- 2) Page: 1, address: 00, data: 01
- 3) Record the color bar signal.
- 4) Playback the recorded signal.
- 5) Check the playback signal level (A).
Specification: $A=0.54 \pm 0.01V$
- 6) If the specification is not satisfied, change the data of page: D, address: 77, and repeat steps 3) to 5).

Playback signal level	Changing the data
When smaller than the specified value	Increase
When bigger than the specified value	Decrease

- 7) Press the PAUSE button of the adjusting remote command-er.
- 8) Perform "Normal Mode Y FM Carrier Frequency Adjustment".




Fig. 7-3-37.

13. Hi8 Mode Y FM Carrier Frequency Adjustment (VS board)

Hi8 mode FM carrier frequency of REC Y setting. If deviated, this caused blurred played back picture or deteriorated resolution.

Mode	Record
Signal	No signal (CAMERA input)
Measurement Point	Pin ③ of IC201 (Y RF OUT)
Measuring Instrument	Frequency counter
Adjustment Page	D
Adjustment Address	74 (CARRIER (E))
Specified Value	$6.000 \pm 0.01 \text{ MHz}$

Adjusting method:

- 1) Insert a ME type tape.
- 2) Page: 1, address: 00, data: 01
- 3) Change the data of page: D, address: 74, and adjust so that the Y FM carrier frequency becomes the specified value.
- 4) Press the PAUSE button of the adjusting remote command-er.




Fig. 7-3-38.

13. Normal Mode Y FM Deviation Adjustment (YR Input)

Normal mode FM deviation of RSC Y writing. If desired, this mode can highlight image, or marked occurrence of black plane in horizontal position.

Mode	Normal mode playback
Signal	Color bar (Y-AMBER input)
Measurement Point	Fig. 8 of Y-AM (A, B, C, D)
Measuring Instrument	Oscilloscope
Adjustment Page	10
Adjustment Address	71 (0015A702H 0.0)
Specified Value	4-624 2.000V

Note 1: Check that "Playback Input Level adjustment", has been completed.

Note 2: The above signal input level is required.

Adjusting method

- 1) Insert a normal YFM-type tape.
- 2) Page 1, address 00, data 00.
- 3) Record the color bar input.
- 4) Playback the recorded signal.
- 5) Check the playback signal level (A).
Specification: 2.00V
- 6) If the specification is not satisfied, change the data of page 0, address 71, and repeat step 3 to 5.

Playback signal level	Changing the data
When smaller than the specified value	Increase
When bigger than the specified value	Decrease

- 7) Press the PAUSE button of the adjusting screen (normal).
- 8) Perform "Normal Mode Y FM Center Frequency adjustment".



Fig. 7-4-27.

14. NR Mode Y FM Center Frequency Adjustment (YR Input)

NR mode FM center frequency of RSC Y writing. If desired, the normal lateral played back picture is horizontal position.

Mode	Normal
Signal	The signal (Y-AMBER input)
Measurement Point	The 8 of Y-AM (Y-AM 0.0)
Measuring Instrument	Frequency analyzer
Adjustment Page	0
Adjustment Address	74 (0015A000 0.0)
Specified Value	4020 0.021 MHz

Adjusting method

- 1) Insert a NR-type tape.
- 2) Page 1, address 00, data 00.
- 3) Change the data of page 0, address 74, and adjust so that the Y FM center frequency becomes the specified value.
- 4) Press the PAUSE button of the adjusting screen (normal).



Fig. 7-4-28.

14. Hi8 Mode Y FM Deviation Adjustment (VS board)

Hi8 mode FM deviation of REC Y setting. If deviated, this causes too bright/dark image, or marked occurrence of black picture or deteriorated resolution.

Mode	Record and playback
Signal	Color bar (CAMERA input)
Measurement Point	Pin ①⑦ of IC201 (DL IN 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	76 (DEVIATION (E))
Specified Value	$A=0.54 \pm 0.01V$

Note 1: Check that "Emphasis Input Level Adjustment", have been completed.

Note 2: The chroma signal input is not required.

Adjusting method:

- 1) Insert a ME type tape.
- 2) Page: 1, address: 00, data: 01
- 3) Record the color bar signal.
- 4) Playback the recorded signal.
- 5) Check the playback signal level (A).
Specification: $A=0.54 \pm 0.01V$
- 6) If the specification is not satisfied, change the data of page: D, address: 76, and repeat steps 3) to 5).

Playback signal level	Changing the data
When smaller than the specified value	Increase
When bigger than the specified value	Decrease

- 7) Press the PAUSE button of the adjusting remote command.
- 8) Perform "Hi8 Mode Y FM Carrier Frequency Adjustment".




Fig. 7-3-39.

15. Chroma Emphasis Adjustment 1 (VS board)

Emphasis center frequency setting. If deviated, this causes unnatural color.

Mode	Record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ⑧ of IC201 (REC C OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	80 (C EMPH (EE)) 81 (C EMPH (PB))
Specified Value	Minimum fo component

Adjusting method:

- 1) Set to the record mode.
- 2) Page: 1, address: 00, data: 01
- 3) Set data: 00 to page: 2, address: 00.
(Specification of category 00)
- 4) Set data: 04 to page: 2, address: B0.
- 5) After memorizing the data of address: 9A of page: 2, set data: 02 to the address. (TEST 1 mode setting)
- 6) Change the data of page: D, address: 80, and adjust so that the amplitude of the latter section of the chroma signal (yellow section) becomes minimum.
- 7) Press the PAUSE button of the adjusting remote command.
- 8) Set the same data as address: 80 of page: D to address: 81 of page D.
- 9) Press the PAUSE button of the adjusting remote command.

Processing after completing adjustments

- 1) Set the data memorized at step 5) to address: 9A of page: 2.
- 2) Set data: 00 to page: 2, address: B0.
(Release of TEST 1 mode)




Fig. 7-3-40.

14. RGB Mode Y PB Bandwidth Adjustment (YB Source)

Set mode (YB) source of RGB Y setting. If desired, the source has highlight range, or muted extension of black points as determined methods.

Mode	Source and playback
Signal	Color bar (COLORBAR signal)
Measurement Point	Fig. 7-3-39 of RGB (RGB PB 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Action	IN (DEVIATION/ST)
Specified Value	40.50 ± 0.05V

Note 1: Check the "Playback Input Level Adjustment", item (see completed).

Note 2: The chroma signal input is not required.

Adjusting method

- Insert a RGB type tape.
- Page 1, address 00, data 00.
- Reset the color bar signal.
- Playback the recorded signal.
- Check the playback signal level (40).
- Specification is not satisfied, change the data of page 1, address 10, and repeat step 4 to 5.

Playback signal level	Changing the data
When smaller than the specified value	Increase
When larger than the specified value	Decrease

- Press the PAUSE button of the adjusting remote command.
- Push the "YB Mode Y PB Chroma Frequency Adjustment".



Fig. 7-3-39

15. Chroma Frequency Adjustment 1 (YB Source)

Display color frequency setting. If desired, the source constant value.

Mode	Source
Signal	Color bar (COLORBAR signal)
Measurement Point	Fig. 7-3-40 (RGB COLOR)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Action	IN (CHROMA ST) IN (CHROMA FREQ)
Specified Value	Ultrasonic Measurement

Adjusting method

- Set to the measurement.
- Page 1, address 00, data 00.
- Set data 00 to page 1, address 00.
(Specification of category 00)
- Set data 00 to page 1, address 00.
- After measuring the data of address 0A of page 1, set data 00 to the source. (TBS 1 mode setting)
- Change the data of page 1, address 00, and adjust so that the amplitude of the latter section of the chroma signal (yellow section) becomes maximum.
- Press the PAUSE button of the adjusting remote command.
- Set the data data to address 00 of page 0 to address 01 of page 0A.
- Press the PAUSE button of the adjusting remote command.

Processing when completing adjustments

- Set the data constant of step 15 to address 0A of page 0.
- Set data 00 to page 1, address 00.
(Release of TBS 1 mode)



Fig. 7-3-40

16. Chroma Emphasis Adjustment 2 (VS board)

Emphasis center frequency setting. If deviated, this causes unnatural color.

Mode	Playback
Signal	Alignment tape: For checking operations Color bar section
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	D
Adjustment Address	81 (C EMPH (PB)) 80 (C EMPH (EE))
Specified Value	The path from the blue luminance point to black luminance point should be a straight line.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 81, and adjust so that the path from the blue luminance point to black luminance point becomes a straight line.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set the same data as address: 81 of page: D to address: 80 of page: D.
- 5) Press PAUSE button of the adjusting remote commander.




Fig. 7-3-41.

17. Comb Filter Fine Adjustment (VS board)

Set the level and phase of the 1H delayed signal for the comb filter. If deviated, this causes marked occurrence of beets in played back picture.

Mode	Playback
Signal	Alignment tape: For checking operations Color bar section
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjusting Element	RV202 (PHASE)
Adjustment Page	D
Adjustment Address	71 (COMB ADJ)
Specified Value	Minimum color luminance point movement when the "Edit" switch is turned on/off

Note 1: Turn the edit ON/OFF at the menu screen.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Minimize the movements of the color luminance point when the edit is on/off with RV202.
- 3) Change the data of page: D, address: 71 and minimize the movements of the color luminance point when the edit is on/off
- 4) Press the PAUSE button of the adjusting remote commander.
- 5) Repeat steps 2) to 4).




Fig. 7-3-42.

14. Channel Impedance Adjustment 2 (20 turns)

Outside water frequency setting. If disabled, this means constant value

Mode	Playback
Signal	Alignment type For channel operations Color for noise
Measurement Mode	Value output (normal)
Measuring Instrument	Voltmeters
Adjusted Page	0
Adjusted Address	00: 00000 (V) 01: 00000 (V)
Specified Value	The path from the water impedance point to Mark impedance point should be straight line.

Adjusting method

- 1) Page 1, address 00, data 00
- 2) Change the data of page 0, address 00, and adjust so that the path from the Mark impedance point to Mark impedance point becomes a straight line.
- 3) Press the FWD/REV button of the adjusting remote controller.
- 4) Set the data table in address 01 of page 0 to address 01 of page 0.
- 5) Press FWD/REV button of the adjusting remote controller.



Fig. 7-4-4-1

15. Space Filter Fine Adjustment (20 turns)

Set the level and phase of the (3) delayed signal for the next filter. If disabled, this means default occurrence of level is played back pattern.

Mode	Playback
Signal	Alignment type For channel operations Color for noise
Measurement Mode	Value output (normal)
Measuring Instrument	Voltmeters
Adjusted Channel	00: 0000 (V)
Adjusted Page	0
Adjusted Address	01: 00000 (V)
Specified Value	Indicates water impedance point movement when the "00" value is output signal

Note 1) Turn the OFF/ONOFF to the same state.

Adjusting method

- 1) Page 1, address 00, data 00
- 2) Indicate the occurrence of the water impedance point when the unit is output with 0V/0V.
- 3) Change the data of page 0, address 01, and indicate the occurrence of the water impedance point when the unit is on/off.
- 4) Press the FWD/REV button of the adjusting remote controller.
- 5) Repeat steps 3) to 4).



Fig. 7-4-4-2

18. REC Y Level Adjustment (VS board)

Recording level of luminance signal setting. If deviated, this causes black stretch over modulation noise or color shade.

Mode	Record
Signal	No signal
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope Board width limit: 20 MHz
Adjustment Page	D
Adjustment Address	44 (REC Y 2CH (E MP)) 40 (REC Y 1CH (E MP)) 45 (REC Y 2CH (E ME)) 41 (REC Y 1CH (E ME)) 47 (REC Y 2CH (L MP)) 43 (REC Y 1CH (L MP)) 46 (REC Y 2CH (L ME)) 42 (REC Y 1CH (L ME))
Specified Value	A=125 ± 5 mVp-p

Note: Use a ME type tape.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) After memorizing the data of address: 3A of page: D, set data: FF to the address.
- 3) Set data: FF to page: D, address: 40 and press the PAUSE button of the adjusting remote commander.
- 4) Change the data of page: D, address: 44, and adjust so that REC Y level (A) becomes the specified value.
- 5) Press the PAUSE button of the adjusting remote commander.
- 6) Read the data of page: D, address: 44 and set to D44.
- 7) Convert D44 to decimal notation, and obtain D44'.
(Refer to Table 7-1-4. "Hexadecimal notation – decimal notation conversion table")
- 8) Calculate D45', D46' and D47' using following equations (decimal notation calculation).

$$D45' = D44' + 5$$

$$D46' = D44' + 4$$

$$D47' = D44' - 3$$
- 9) Convert D45', D46' and D47' to hexadecimal notation and obtain D45, D46 and D47.
- 10) Set data to address: 40, 41, 42, 43, 45, 46 and 47 of page: D as shown in following table.
(Be sure to press the PAUSE button of the adjusting remote control unit after setting each data.)
- 11) Set the data memorized at step 2) to address: 3A of page: D and press the PAUSE button of the adjusting remote commander.




Fig. 7-3-43.

Address	Data
40	D44
41	D45
42	D46
43	D47
45	D45
46	D46
47	D47

16. RISC Y-Level Adjustment (RIS Level)

Operating level of Riscsource signal setting. If defined, this means that a shift will occur when the value is set to 0.

Mode	Normal
Signal	No signal
Measurement Point	Pin 8 of CH00 (RISC)
Measuring Instrument	Oscilloscope Bandwidth limit 20 MHz
Adjustment Page	0
Adjustment Address	40 (RISC Y-CH00-0-MP) 41 (RISC Y-CH00-1-MP) 42 (RISC Y-CH00-2-MP) 43 (RISC Y-CH00-3-MP) 44 (RISC Y-CH00-4-MP) 45 (RISC Y-CH00-5-MP) 46 (RISC Y-CH00-6-MP) 47 (RISC Y-CH00-7-MP) 48 (RISC Y-CH00-8-MP) 49 (RISC Y-CH00-9-MP)
Specification Value	Ac 0.0 ± 0.0V

Note: Use a 100-ohm probe.

Adjusting method

- 1) Page 1, address: 00, data: 00.
- 2) After recognizing the value of address 0A of page 0, set data 00 to the address.
- 3) Set data 00 to page 0, address: 40 and press the F4(SET) button of the adjusting remote controller.
- 4) Change the data of page 0, address: 40, and adjust so that RISC Y level (+) becomes the specified value.
- 5) Press the F4(SET) button of the adjusting remote controller.
- 6) Set the data of page 0, address: 40 and set to 00.
- 7) Current Dcr is default value, and write Dcr*.
(Dcr* = Table 1-1-4, "Transmitted number = default number remote controller")
- 8) Calculate Dcr*, Dcr' and Dcr'' using following equation (default number transmitted).

$$\begin{aligned} Dcr' &= Dcr \times 3 \\ Dcr'' &= Dcr' \times 4 \\ Dcr''' &= Dcr' \times 5 \end{aligned}$$
- 9) Current Dcr*, Dcr' and Dcr'' is transmitted number and write Dcr, Default Dcr.
- 10) Set data to address: 40, 41, 42, 43, 44, 45, 46 and 47 of page 0 numbers to following table.
 (The user is press the F4(SET) button of the adjusting remote controller after setting each data.)
- 11) Set the data transmitted at step 2) to address 0A of page 0 and press the F4(SET) button of the adjusting remote controller.



Fig. 1-6-15

Address	Data
40	Dcr
41	Dcr
42	Dcr
43	Dcr
44	Dcr
45	Dcr
46	Dcr
47	Dcr

19. REC L Adjustment (VS board)

Set the recording levels of the REC AFM signal and REC ATF signal. If the level is too low, the audio S/N will deteriorate, tracking will not be stable, or SP/LP will not be discriminated properly. If too high, color beats will be produced on the self-recording/playback image.

Mode	Record
Signal	No signal (VIDEO input)
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	3A (REC LOW 2 (ME)) 38 (REC LOW 1 (ME)) 3B (REC LOW 2 (MP)) 39 (REC LOW 1 (MP))
Specified Value	$A = 6.8 \pm 1.0 \text{ mVp-p}$

Note 1: Use a ME type tape.

Note 2: AU board is required for this adjustment.

Note 3: Do not insert any plug into the right audio input terminal.

Connection:

- 1) Disconnect HE-14 board.
- 2) Connect Pin ⑤ of IC508 and GND with a $0.01 \mu\text{F}$ capacitor.
(Parts code: 1-101-004-00)

Adjusting method:

- 1) Page: 1, address: 00, data: 01
 - 2) Change the data of page: D, address: 3A, and adjust so that the REC AFM signal level (A) becomes the specified value.
 - 3) Press the PAUSE button of the adjusting remote command-er.
 - 4) Read the data of page: D, address: 3A, and set to D3A.
 - 5) Set data: D3A to address: 38 of page D.
 - 6) Press the PAUSE button of the adjusting remote command-er.
 - 7) Convert D3A to decimal notation, and obtain D3A'.
- (Refer to Table 7-1-4. "Hexadecimal notation-decimal notation conversion table")
- 8) Calculate D3B' using following equation (decimal notation calculation).
$$D3B' = D3A' + 10$$
 - 9) Convert D3B' to hexadecimal notation, and obtain D3B.
 - 10) Set data: D3B to address: 3B of page D.
 - 11) Press the PAUSE button of the adjusting remote command-er.
 - 12) Set data: D3B to address: 39 of page D.
 - 13) Press the PAUSE button of the adjusting remote command-er.
 - 14) Perform "REC CHROMA Level Adjustment".




Fig. 7-3-44.

Fig. 7-6-43. Adjustment (VR board)

For the recording levels of the RDC AFM signal and RDC ACF signal. If the level is too low, the audio AFM will deteriorate, resulting will not be reliable, or RFLP will not be discriminated properly. If too high, noise level will be produced on the self-recording/playback image.

Mode	Reset
Signal	No signal (RFLP) input
Measurement Value	70.0% of 100.0mV (RDC)
Measuring Instrument	Galvanometer
Adjustment Page	02
Adjustment Address	5A (RDC LOW quality) 5B (RDC LOW quantity) 5C (RDC LOW quality) 5D (RDC LOW quantity)
Specified Value	multiplier 1.000Vpp

Note (1): Use a 500-type type.

Note (2): ALL boards is required for this adjustment.

Note (3): Do not insert any plug into the right audio input terminal.

Connections

- Connect RDC-14 board.
- Connect Pin(5) of RDC and RFLP with a 100 μ F capacitor.
(Pins only 1-10-400-00)

Adjusting method

- Page 1, address 02, data 02.
- Change the data of page 02, address 5A, and adjust so that the RDC AFM signal level (A) increases the specified value.
- Press the F4/F5 key of the adjusting remote command set.
- Read the data of page 02, address 5B, and set to 00.
- Set data. Data to address 5B of page 02.
- Press the F4/F5 key of the adjusting remote command set.
- Connect DCS to external variation, and check DCS.
(Refer to "Table 7-3-4, "Standardized variation-checking remote command table").
- Calculate DCS" using following equation (Measured variation calculation).
$$DCS = DCS \times 1.8$$
- Connect DCS to horizontal variation, and check DCS.
- Set data. Data to address 5C of page 02.
- Press the F4/F5 key of the adjusting remote command set.
- Set data. Data to address 5D of page 02.
- Press the F4/F5 key of the adjusting remote command set.
- Perform "RDC CHANNEL Level Adjustment".



Fig. 7-6-44.

20. REC CHROMA Level Adjustment (VS board)

Set REC CHROMA signal level. If it is lower than its normal level, chroma signal noise in played back picture will increase. If it is set higher, Y signal noises will increase and white modulation noises will be produced.

Mode	Record
Signal	Color bar (CAMERA input)
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	30 (REC C (SP E ME)) 31 (REC C (SP E MP)) 32 (REC C (SP L ME)) 33 (REC C (SP L MP)) 34 (REC C (LP E ME)) 35 (REC C (LP E MP)) 36 (REC C (LP L ME)) 37 (REC C (LP L MP))
Specified Value	$A=28 \pm 3 \text{ mVp-p}$

Note 1: Use a ME type tape.

Connection:

- 1) Disconnect HE-14 board.
- 2) Connect Pin ⑥ of IC508 and GND with a $0.01 \mu\text{F}$ capacitor.
(Parts code: 1-101-004-00)
- 3) Disconnect AU board.

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 30, and adjust so that the REC CHROMA signal level (A) becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Read the data of page: D, address: 30, and set to D30.
- 5) Set data to address: 31 to 37 of page: D as shown in following table.

(Be sure to press the PAUSE button of the adjusting remote commander after setting each data.)

Address	Data
31	D30
32	D30
33	D30
34	D30
35	D30
36	D30
37	D30




Fig. 7-3-45.

36. RSC CHANNEL Level Adjustment (PS board)

See RSC CHANNEL signal level. If it is below the specified level, decrease signal level to signal level picture will increase. If it is not higher, Y signal picture will increase and white colorless picture will be produced.

Menu	Screen
Page1	Color bar (CHANNEL input)
Measurement Point	Pin 5 of CHIN (RSC-2)
Measuring Instrument	Oscilloscope
Adjustment Page	0
Adjustment Action	00 RSC-C-SP-1-LoVp 01 RSC-C-SP-1-LoVp 02 RSC-C-SP-1-LoVp 03 RSC-C-SP-1-LoVp 04 RSC-C-SP-1-LoVp 05 RSC-C-SP-1-LoVp 06 RSC-C-SP-1-LoVp 07 RSC-C-SP-1-LoVp
Specified Value	Amplitude 1.5Vp

Note 1: Use a 40 type tap.

Correction

- 1) Disconnect PS-04 board.
- 2) Connect Pin(5) of SCOR and CHIN with white pH amplifier (Pin mode 1 001-004-00).
- 3) Disconnect AG board.

Adjusting method

- 1) Page 1, address 00, data 00
- 2) Change the data of page 0, address 00, and adjust so that the RSC CHANNEL signal level (u) becomes the specified value.
- 3) Press the FVCRS button of the adjusting remote-commander.
- 4) Read the data of page 0, address 00 and write it in.
- 5) See data in address 00, in 07 of page 0 as shown in following table.

(Be sure to press the FVCRS button of the adjusting remote commander after setting each data.)

Address	Data
00	000
01	000
02	000
03	000
04	000
05	000
06	000
07	000



Fig. 7-3-65.

21. REC ATF Level Check (VS board)

Mode	Record
Signal	No signal
Measurement Point	Pin ⑥ of CN102 (REC 2)
Measuring Instrument	Oscilloscope
Specified Value	$A=6.6 \pm 1.5 \text{ mVp-p}$

Note 1: Use a ME type tape.

Connection:

- 1) Disconnect HE-14 board.
- 2) Disconnect AU board.

Adjusting method:

- 1) Check that the REC ATF signal level (A) satisfies the specified value.




Fig. 7-3-46.


3-7. MONAURAL AUDIO SYSTEM ADJUSTMENT (CCD-TR42/TR70/TR82/TR550)

- Perform the adjustment using the color bar signal as a video signal input for VIDEO terminal

[Connecting the measuring instruments for the audio]

Connect the audio system measuring instruments besides the video system measuring instruments as shown in Fig. 7-3-47, and perform adjustments with the power switch [player] position.

- Connection of Audio generator and attenuator .



- Connection of Audio level meter or distortion meter




Fig. 7-3-47.

[Adjustment Procedure]

- 1) E-E output level check
- 2) Deviation adjustment
- 3) Overall level characteristics, distortion check
- 4) Overall noise level check

23. RSC APT Level Check (YR Screen)

Mode	Result
Signal	No signal
Measurement Point	Pin 8 of J2002 (RSC R)
Measuring instrument	Oscilloscope
Specified value	$A_{VCR} = 1.5 \text{ mVpp}$

Note 1: Use a 50 Ω type cable.

Connection

- 1) Connect RSC left board.
- 2) Connect RSC board.

Adjusting method

- 1) Check that the RSC APT signal level (V_{CR}) satisfies the specified value.



Fig. 7-3-46

24. MONITORIAL AUDIO SYSTEM ADJUSTMENT (CCC-TRM2/CCC-TRM2/THRM2)

- 1) Perform the adjustment using the value for signal as a video signal input for VIDEO terminal.

(Connecting the measuring instruments for the audio)

Connect the audio system measuring instruments (meter for video system measuring instruments as shown in Fig. 7-3-47), and perform adjustment only for preset matrix (played) position.

- 1) Connection of Audio generator and oscilloscope



- 2) Connection of Audio level meter or deviation meter



Fig. 7-3-47

(Adjustment Procedure)

- 1) 3.5 output level check
- 2) Deviation adjustment
- 3) Overall level discrimination, deviation check
- 4) Overall video level check

1. E-E Output Level Check (AU-169 board)

Mode	Record
Signal	400 Hz, -7.5 dBs, Audio input terminal
Measurement Point	Pin ④ of IC1301
Measuring Instrument	Audio level meter (Oscilloscope)
Specified Value	-7.5 ± 2 dBs $\left(925 \begin{smallmatrix} +240 \\ -190 \end{smallmatrix} \text{ mVp-p} \right)$

Checking method:

- 1) Check that the 400 Hz signal level satisfies the specified value.

2. Deviation Adjustment

Adjust to the optimum audio FM signal deviation.

If the adjustment is not correct, its playback level will differ from that of other units.

Mode	Playback
Signal	Alignment tape: For checking the operation (WR5-5NSP)
Measurement Point	Audio output terminal
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	8F (1.5 MHz DEV)
Specified Value	-7.5 ± 0.5 dBs

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 8F, and adjust so that the 400 Hz signal level becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.

3. Overall Level Characteristic, Distortion Check

Mode	Self recording/playback
Signal	400 Hz, -7.5 dBs, Audio input terminal
Measurement Point	Audio output terminal
Measuring Instrument	Audio level meter and distortion meter
Specified Value	Level: -7.5 ± 2 dBs Distortion rate: Below 0.5% (Note 1)

Note: 1) Value when the following filter is used




Fig. 7-3-48.

Checking method:

- 1) Input the 400 Hz, -7.5 dBs signal to the audio input terminal.
- 2) Record the signal.
- 3) Remove the input signal.
- 4) Playback the recorded section.
- 5) Check that the 400 Hz signal level of the audio output terminal is -7.5 ± 2 dBs, and that the distortion rate is below 0.5% (Note 1).

4. Overall Noise Level Check

Mode	Self recording
Signal	No signal: Audio input terminal
Measurement Point	Audio output terminal
Measuring Instrument	Audio level meter (Use an IHF-A curve auditory correction filter)
Specified Value	Below -65.0 dBs

Checking method:

- 1) Insert the shorting plug to the audio input terminal.
- 2) Record.
- 3) Remove the shorting plug.
- 4) Playback the recorded section.
- 5) Check that the noise level of the audio output terminal is below -65.0 dBs.

1. I/O Output Level Check (400-400 (source))

Mode	Reset
Signal	400 Hz, -12 dBm, Audio input terminated
Measurement Point	Pin 4 of IC ₁ /IC ₂
Measuring Instrument	Audio level meter (flat/average)
Specified Value	-12.5 ± 3 dBm $\left\{ \begin{array}{l} 100 \sim 200 \\ -100 \sim 0 \end{array} \right.$ dBμV _{rms}

Checking method:

- 1) Check that the 400-Hz signal level satisfies the specified value.

2. Distortion Adjustment

Adjusts the optimum audio (flat) input distortion.
If the adjustment is not correct, the playback level will differ from that of other units.

Mode	Playback
Signal	Adjustment signal For checking the operation (400-Hz/100%)
Measurement Point	Audio output terminal
Measuring Instrument	Oscilloscope
Adjustment Range	0
Adjustment Address	BF11.3 (400-Hz/100%)
Specified Value	-1.5 ± 1.5 dB

Adjusting method:

- 1) Page 1, address 00, data 00
- 2) Change the data of page 10, address 0F, and adjust so that the 400-Hz signal level becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote controller on.

3. Overall Level Characteristic, Distortion Check

Mode	Self monitoring/playback
Signal	400 Hz, -12 dBm, Audio input terminated
Measurement Point	Audio output terminal
Measuring Instrument	Audio level meter and distortion meter
Specified Value	Level: -12.5 ± 3 dBm Distortion rate: Below 0.1% (100 Hz)

Notes: 1) Values when the following filter is used



Fig. 7-4-45

Checking method:

- 1) Input the 400-Hz, -12 dBm signal to the audio input terminal.
- 2) Reset the signal.
- 3) Restore the input signal.
- 4) Playback the recorded section.
- 5) Check that the 400-Hz signal level of the audio output terminal is -12.5 ± 3 dBm, and that the distortion rate is below 0.1% (100 Hz).

4. Overall Volume Level Check

Mode	Self monitoring
Signal	No signal: Audio input terminal
Measurement Point	Audio output terminal
Measuring Instrument	Audio level meter (Filter is OFF: A more accurate measurement time)
Specified Value	Below -10.5 dBm

Checking method:

- 1) Insert the checking plug to the audio input terminal.
- 2) Reset.
- 3) Restore the checking plug.
- 4) Playback the recorded section.
- 5) Check that the audio level of the audio output terminal is below -10.5 dBm.

3-8. STEREO AUDIO SYSTEM ADJUSTMENT (CCD-TR72/TR80/TR400/TR430/TR750)

- Perform the adjustment using the color bar signal as a video signal input for VIDEO terminal.

[Connecting the measuring instruments for the audio]

Connect the audio system measuring instruments in addition to the video system measuring instruments as shown in Fig. 7-3-49, and perform adjustments at the power switch [player] or [video] position.

Set the Hi-Fi SOUND switch in the menu display to the following position unless specified otherwise.

- Stereo position

- Note:**
- 1) When inputting the audio signal, input the same signal to both L, and R channels, unless specified otherwise.
 - 2) Be sure to insert the plug (shorting plug or dummy plug, etc.) into the audio terminal (right). If the plug is not inserted, the unit will be set into the monaural mode, and correct adjustments cannot be carried out. (Monaural mode)
During recording .. REC AFM RF1.7 MHz carrier will not be output.
During playback .. The L+R signal will be output from the audio terminal (left).
 - 3) The items to be adjusted for the R channel will be indicated within the [], in regard to the adjusting items to be adjusted for both L and R channels.




Fig. 7-3-49.

[Adjustment Procedure]

- 1) E-E output level check
- 2) REC matrix L-R adjustment
- 3) REC matrix L+R check
- 4) 1.5 MHz deviation adjustment
- 5) 1.7 MHz deviation adjustment
- 6) Overall level characteristics, distortion check
- 7) Separation check
- 8) Overall noise level check

1. E-E Output Level Check (AU-165 board)

Mode	Record
Signal	400 Hz, -7.5 dBs audio input terminal right [left]
Measurement Point	Pin ④ of IC1301 [Pin ⑤ of IC1301]
Measuring Instrument	Oscilloscope
Specified Value	925^{+240}_{-190} mVp-p (-7.5 ± 2 dBs)

Checking method:

- 1) Check that the 400 Hz signal level satisfies the specified value.

2. Matrix L-R Adjustment (AU-165 board)

Adjust the audio matrix. If improper, this causes deteriorated separation (with stereo signal).

Mode	Record
Signal	400 Hz, -7.5 dBs Input to both left and right terminals of the audio input terminal
Measurement Point	Pin ⑤ of IC1301
Measuring Instrument	Oscilloscope (Use 1:1 probe)
Adjustment Page	D
Adjustment Address	8C (AUDIO MATRIX (EE)) 8D (AUDIO MATRIX (PB))
Specified Value	0 ± 20 mVp-p

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 8C, and minimize the 400 Hz signal level.
- 3) Press the PAUSE button of the adjusting remote commander.
- 4) Set the same data as address: 8C of page: D to address: 8D of page: D.
- 5) Press the PAUSE button of the adjusting remote commander.

2-6. STEREO-AUDIO SYSTEM ADJUSTMENT (DSD-TR01/TR02/TR03/TR04/TR05)

- Perform the adjustments using the audio test signal as a video signal input the VCR(s) monitor.

(Concerning the measuring instruments for the device)
Connect the audio system measuring instruments in addition to the video system measuring instruments as shown in Fig. 2-4-49, and perform adjustments at the power source (play) or (pause) position.

See the 10-4) DCR(s) value in the same display in the following position when specified otherwise.

- Stereo position

- Method:**
- When outputting the audio signal, input the video signal to both L and R channels, adjust specified reference.
 - Be sure to insert the plug (starting plug or dummy plug etc.) into the stereo connector (right). If the plug is not inserted, the test will be not done for measured audio, and automatic adjustment cannot be carried out. (Automatic mode)
During recording – SBC, APO, LTP, F-Matrix mode will not be output.
During playback – The Left signal will be output from the audio terminal (left).
③ The item to be adjusted for the R channel will be indicated within the () 1, in regard to the following item to be adjusted for both L and R channels.



Fig. 2-4-49

Adjustment Procedures

- 5-4) page level check
- SBC matrix L-R adjustment
- SBC matrix L-R check
- 1.5 MHz deviation adjustment
- 1.7 MHz deviation adjustment
- Overall level characteristics, distortion check
- Separation check
- Overall noise level check

3. 10-4) Output Level Check (All-100 board)

Mode	Setting
Signal	400 Hz, -7.0 dBs audio input terminal input (left)
Measurement Point	Pin ② of VCR(s) (Pin ② of VCR(s))
Measuring Instrument	GainScope
Specified Value	100 \pm 10% (dB) or (-7.0 \pm 1.0 dB)

Checking method

- Check that the 400 Hz signal level satisfies the specified value.

3. Matrix L-R Adjustment (All-100 board)

Adjust the audio matrix (if necessary) for stereo interference separation (with stereo signal).

Mode	Setting
Signal	400 Hz, -7.0 dBs input to both left and right terminals of the audio input terminal
Measurement Point	Pin ② of VCR(s)
Measuring Instrument	GainScope (Pin ② of VCR(s))
Adjustment Type	D
Adjustment Address	BC (AUDIO MATRIX) (DSD) BD (AUDIO MATRIX) (PS)
Specified Value	0.0 (dB) (dB)

Adjusting method

- Page 1 address (0, data, 0)
- Change the item of page D, address BC, and calculate the 400 Hz signal level
- Press the (HOLD) button of the adjusting remote command.
- Set the cursor bar at address BC of page D or address BD of page D.
- Press the (HOLD) button of the adjusting remote command.

3. REC Matrix L+R Check (AU-165 board)

Mode	Record
Signal	1. 400 Hz, -7.5 dBs: Audio input terminal left No signal: Audio input terminal right 2. No signal: Audio input terminal left 400 Hz, -7.5 dBs: Audio input terminal right
Measurement Point	Pin ④ of IC1301
Measuring Instrument	Oscilloscope
Specified Value	The level difference is 0 ± 10 mVp-p when only the left terminal is input and when only the right terminal is input.

Note: When measuring the signal level of pin ④ of IC1301, wait for more than 1 minute after signal input before measuring. (To stabilize the AGC)

Adjusting method:

- 1) Input the 400 Hz, -7.5 dBs signal only to the audio input terminal (left). (Insert the shorting plug to the audio input terminal (right).)
- 2) Read the 400 Hz signal level of pin ④ of IC1301, and take it down. (Approximately 250 mVp-p)
- 3) Input the 400 Hz, -7.5 dBs signal only to the audio input terminal (right). (Insert the shorting plug to the audio input terminal (left).)
- 4) Check that the 400 Hz signal level of pin ④ of IC1301 is (the value that was taken down at step 2) ± 10 mVp-p.

4. 1.5 MHz Deviation Adjustment

Adjusts the 1.5 MHz AFM signal deviation. If improper, this causes deteriorated separation with Alignment tape (with stereo signal) and the playback level will differ from that of other unit.

Mode	Playback
Signal	Alignment tape: For checking the operation (WR5-5NSP)
Measurement Point	Audio output terminal left or right
Measuring Instrument	Oscilloscope, Level meter
Adjustment Page	D
Adjustment Address	8F (1.5 MHz DEV)
Specified Value	-7.5 ± 0.5 dBs

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 8F, and adjust so that the 400 Hz signal level becomes the specified value.
- 3) Press the PAUSE button of the adjusting remote commander.

5. 1.7 MHz Deviation Adjustment

Adjust the 1.7 MHz AFM deviation. If improper, this causes deteriorated separation (with stereo signal).

Mode	Playback
Signal	Alignment tape: AFM stereo for checking operation (WR5-9NS) Stereo (color bar) section
Measurement Point	Audio output terminal right
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	8E (1.7 MHz DEV)
Specified Value	Cross talk component is below 30 mVp-p

Adjusting method:

- 1) Page: 1, address: 00, data: 01
- 2) Change the data of page: D, address: 8D, and minimize the cross talk component (400 Hz).
- 3) Press the PAUSE button of the adjusting remote commander.

2. 400 MHz Left Channel (400-400 kHz)

Mode	Feature
Signal	1. 400 Hz, -120 dBm Audio input terminated left Stereo Audio input terminated right
	2. 10 signals Audio input terminated left 400 Hz, +12 dBm Audio input terminated right
Measurement Point	Pc @ of IC101
Measuring Instrument	Quillscope
Specified Value	The level difference is 0.3 dB when when only the left channel is input and when only the right channel is input.

Note: When measuring the signal level of pin @ of IC101, wait for more than 1 minute after signal input before measuring. (To maintain the AGC)

Adjusting method

- Input the 400 Hz, -120 dBm signal only to the audio input terminal (left). (Insert the stereo plug to the audio input terminal (right).)
- Read the 400 Hz signal level of pin @ of IC101, and wait 1 minute. (Approximately 120 mVpp)
- Input the 400 Hz, -120 dBm signal only to the audio input terminal (right). (Insert the stereo plug to the audio input terminal (left).)
- Check that the 400 Hz signal level of pin @ of IC101 is (the value that was shown when using 2) ± 0.3 mVpp.

3. 1.2 MHz Stereoscopic Adjustment

Adjust the 1.2 MHz stereo signal deviation. If improper, this causes stereoscopic separation with alignment error (with stereo signal) and the playback level will differ from that of other sets.

Mode	Playback
Signal	Alignment tape For checking the separation (FM-0-000)
Measurement Point	Audio output terminal left or right
Measuring Instrument	Quillscope, Level meter
Adjustment Page	01
Adjustment Address	9F(1.2 MHz, 100%)
Specified Value	-1.5 ± 0.2 dB

Adjusting method

- Page 1, address: 00, data: 00
- Change the data of page 01, address: 0F, and measure the the AGC changed level (increase the specified value).
- Press the PAUSE button of the adjusting remote command.

21

4. 1.2 MHz Stereoscopic Adjustment

Adjust the 1.2 MHz stereo deviation. If improper, this causes stereoscopic separation (with stereo signal)

Mode	Playback
Signal	Alignment tape AGC status for checking separation (FM-0-000) Stereo (center test) section
Measurement Point	Audio output terminal right
Measuring Instrument	Quillscope
Adjustment Page	01
Adjustment Address	9F(1.2 MHz, 100%)
Specified Value	Center test component is below 0 mVpp

Adjusting method

- Page 1, address: 00, data: 00
- Change the data of page 01, address: 0F, and measure the center test component (400 Hz).
- Press the PAUSE button of the adjusting remote command.

6. Overall Level Characteristics, Distortion Check

Mode	Self recording/playback
Signal	400 Hz, -7.5 dBs: Audio input terminal (left) [right] No signal: Audio input terminal (right) [left]
Measurement Point	Audio output terminal (left) [right]
Measuring Instrument	Audio level meter and distortion meter
Specified Value	Level: -7.5 ± 2 dBs Distortion rate: Below 0.8% (Note 2)

- Note:** 1) The [] indicates the measuring point during the right channel check.
2) Value when the 200 kHz to 6 kHz band-path filter is used




Fig. 7-3-50.

Checking method:

- 1) Input the 400 Hz, -7.5 dBs signal only to the audio input terminal (left) [right].
Note: Be sure to insert the shorting plug to the terminal that was not signal input.
- 2) Record the signal.
- 3) Remove the input signal.
- 4) Playback the recorded section.
- 5) Check that the 400 Hz signal level of the audio output terminal (left) [right] is -7.5 ± 2 dBs, and that the distortion rate is below 0.8% (Note 2).

7. Separation Check

Mode	Self recording /playback
Signal	No signal: Audio input terminal (left) [right] 400 Hz, -7.5 dBs: Audio input terminal (right) [left]
Measurement Point	Audio output terminal (left) [right]
Measuring Instrument	Audio level meter (Use an IHF-A curve auditory correction filter)
Specified Value	Below -27.5 dBs

- Note:** The [] indicates the measuring point during the right channel check.

Checking method:

- 1) Insert a shorting plug into the audio input terminal (left) [right], and input a 1kHz, -7.5 dBs signal only to the audio input terminal (right) [left].
- 2) Record the signal.
- 3) Remove the input signal.
- 4) Playback the recorded section.
- 5) Check that the cross talk level (1 kHz) of the audio output terminal (left) [right] is below -27.5 dBs.

8. Overall Noise Level Check

Mode	Self recording/playback
Signal	No signal: Audio input terminal left and right
Measurement Point	Audio output terminal (left) [right]
Measuring Instrument	Audio level meter (Use an IHF-A curve auditory correction filter)
Specified Value	Below -62.5 dBs

- Note:** The [] indicates the measuring point during the right channel check.

Checking method:

- 1) Insert the shorting plug to both left and right of the audio input terminals.
- 2) Record.
- 3) Remove the shorting plug.
- 4) Playback the recorded section.
- 5) Check that the noise level of the audio output terminal (left) [right] is below -62.5 dBs.

6. General Level Characteristics, Repetitive Check

Mode	Self monitoring/playback
Signal	All Fx, ± 0.5 dBs Audio input nominal (left) (right) No signal, Audio input nominal (left) (right)
Measurement Point	Audio output nominal (left) (right)
Measuring Instrument	Audio level meter and distortion meter
Specified Value	Level: -1.5 ± 0.5 dBs Distortion rate below 0.05% (Note 2)

Note 1) The [] indicates the measuring point during the right channel check.

2) Value when the 200 Hz to 8 kHz bandwidth filter is used



Fig. 7-6-16.

Checking method

- 1) Input the 200 Hz, ± 0.5 dBs signal only to the audio input nominal (left) (right).

Note: Use start to insert the checking plug to the nominal test area on signal input.

- 2) Remove the signal.
- 3) Remove the input signal.
- 4) Playback the recorded content.
- 5) Check that the 200 Hz signal level of the audio output nominal (left) (right) is -1.5 ± 0.5 dBs, and that the distortion rate is below 0.05% (Note 2).

7. Repetitive Check

Mode	Self monitoring/playback
Signal	No signal, Audio input nominal (left) (right) All Fx, ± 0.5 dBs Audio input nominal (left) (right)
Measurement Point	Audio output nominal (left) (right)
Measuring Instrument	Audio level meter (Use an IEC A-weighted frequency filter)
Specified Value	Below -17.5 dBs

Note: The [] indicates the measuring point during the right channel check.

Checking method

- 1) Insert a checking plug into the audio input nominal (left) (right), and input a 100Hz, ± 0.5 dBs signal only to the audio input nominal (right) (left).
- 2) Remove the signal.
- 3) Remove the input signal.
- 4) Playback the recorded content.
- 5) Check that the noise rate (at 0 dB) of the audio output nominal (left) (right) is below -17.5 dBs.

8. General Noise Level Check

Mode	Self monitoring/playback
Signal	No signal, Audio input nominal left and right
Measurement Point	Audio output nominal (left) (right)
Measuring Instrument	Audio level meter (Use an IEC A-weighted frequency filter)
Specified Value	Below -10 ± 1 dBs


Note: The [] indicates the measuring point during the right channel check.

Checking method


- 1) Insert the checking plug to both left and right of the audio input nominal.
- 2) Remove.
- 3) Remove the checking plug.
- 4) Playback the recorded content.
- 5) Check that the noise level of the audio output nominal (left) (right) is below -10 ± 1 dBs.

3-9. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS


DD BOARD (CONDUCTOR SIDE)




DD BOARD (COMPONENT SIDE)



AU-169 BOARD (COMPONENT SIDE)
(CCD-TR42/TR70/TR82/TR550)



AU-165 BOARD (COMPONENT SIDE)
(CCD-TR72/TR80/TR400/TR430/TR750)



3.4. APPENDMENT DIAGRAM FOR ALIGNMENT PRINTS

DD BOARD (CONDUCTOR SIDE)




DD BOARD (COMPONENT SIDE)




AD-148 BOARD (COMPONENT SIDE)
(DD-174/175/176/178/179/180)




AD-148 BOARD (COMPONENT SIDE)
(DD-174/175/176/178/179/180)




VS BOARD (COMPONENT SIDE)




VS BOARD (CONDUCTOR SIDE)



VE BOARD (COMPONENT SIDE)




VE BOARD (CONDUCTOR SIDE)



Warning Indicators


If indicators flash in the viewfinder, or a caution lamp on the camcorder flashes, check the following:

- ♪: You can hear the beep sound when the BEEP is set to ON.




If indicators flash in the viewfinder, or a caution lamp on the camcorder flashes, check the following:

- ♪: You can hear the beep sound when the BEEP is set to ON.



Identifying the Parts


Identify the parts of the circuit shown in the diagram below.



1. The battery (1.5V)
2. The switch (1.5V)
3. The light bulb (1.5V)
4. The light bulb (1.5V)
5. The light bulb (1.5V)
6. The light bulb (1.5V)
7. The light bulb (1.5V)
8. The light bulb (1.5V)
9. The light bulb (1.5V)
10. The light bulb (1.5V)

Identifying Indicators


Identify the indicators in the circuit diagram below. Label the indicators with numbers 1 through 10.




1. The battery (1.5V)
2. The switch (1.5V)
3. The light bulb (1.5V)
4. The light bulb (1.5V)
5. The light bulb (1.5V)
6. The light bulb (1.5V)
7. The light bulb (1.5V)
8. The light bulb (1.5V)
9. The light bulb (1.5V)
10. The light bulb (1.5V)

4-3. SEMICONDUCTORS


DTA123JK
MSA1586
MSC4116
RN1302
UN511D
UN5113
UN5213
2SA1162
2SA1163
2SA1576
2SA1838
2SB1218
2SB1295
2SB1462
2SC1623
2SC4116
2SC4154
2SC4178
2SC4400
2SC4555
2SC4909




FP101
FP102




MTD6N154




UN094
2SB1121
2SB1122
2SB798
2SD1615




UN5111
UN5211




XN4113
XN4213
XN4501



XN4312
XN4601




XN4401




2SK1875




MA110
MA111
MA365
1SS352




MA142WA
MA152WA




MA142WK




MA4Z082WA




MA6S121



MA728




MA796




02Z13




1SS226




1SS250



LN1251C



LN1371G



Ref.No.	Part No.	Description	Remark
M003	1-542-162-11	MICROHONE UNIT	
M901	A-7048-564-A	DRUM ASSY (DGH-78A-R) (TR42/TR70/TR72/TR80/TR82/TR430/TR550)	
M901	A-7048-633-A	DRUM ASSY (DGH-92A-R) (TR400/TR750)	
M905	1-698-364-01	MOTOR ASSY, FOCUS (TYPE I)	
M906	1-698-363-01	MOTOR ASSY, ZOOM (TYPE I)	
M907	3-708-888-01	METER, IG (TYPE II)	
M908	3-708-889-01	MOTOR ASSY, FOCUS (TYPE II)	
M909	3-708-887-01	MOTOR ASSY, ZOOM (TYPE II)	

ACCESSORIES & PACKING MATERIALS

	1-467-574-21	REMOTE COMMANDER (RMT-708)	
	1-575-334-11	CORD, CONNECTION (A/V connecting cable) (TR72/TR80/TR400/TR430/TR750)	
	1-575-335-21	CORD, CONNECTION (S VIDEO connecting cable) (TR400/TR750)	
	3-738-517-01	BELT (S), SHOULDER	
	3-758-475-21	MANUAL, INSTRUCTION (ENGLISH) (TR42/TR70/TR72/TR80/TR82)	
	3-758-475-31	MANUAL, INSTRUCTION (FRENCH) (TR42/TR70:Canadian/TR80:Canadian/TR82:Canadian)	
	3-758-742-21	MANUAL, INSTRUCTION (ENGLISH) (TR400)	
	3-758-742-31	MANUAL, INSTRUCTION (FRENCH) (TR400:Canadian)	
	3-758-782-11	MANUAL, INSTRUCTION (ENGLISH, SPANISH) (TR430/TR550)	
	3-758-782-41	MANUAL, INSTRUCTION (CHINESE) (TR430/TR550:E)	
	3-758-783-11	MANUAL, INSTRUCTION (ENGLISH, SPANISH) (TR750)	
	3-758-783-41	MANUAL, INSTRUCTION (CHINESE) (TR750:E)	
	3-758-964-11	MANUAL, INSTRUCTION (KOREAN) (TR550:Tourist/TR750:Tourist)	
*	3-795-581-21	SAFEGUARD (SONY), IMPORTANT (TR400:US/TR70:US/TR80:US/TR82:US)	
*	3-795-581-21	SAFEGUARD (SONY), IMPORTANT (TR72)	
*	3-958-198-11	INDIVIDUAL CARTON (TR400)	
*	3-958-198-31	INDIVIDUAL CARTON (TR750)	
*	3-958-663-01	INDIVIDUAL CARTON (TR82)	
*	3-958-663-11	INDIVIDUAL CARTON (TR72)	
*	3-958-663-21	INDIVIDUAL CARTON (TR42)	
*	3-958-663-31	INDIVIDUAL CARTON (TR70)	
*	3-958-663-41	INDIVIDUAL CARTON (TR80)	
*	3-958-663-71	INDIVIDUAL CARTON (TR550)	
*	3-958-663-81	INDIVIDUAL CARTON (TR430)	
*	3-958-664-01	CUSHION, (LOWER)	
*	3-958-665-01	CUSHION, ACC	
	A-6768-253-A	RFU ADAPTOR (RFU-90UC) (Except Tourist)	


Ref.No.	Part No.	Description	Remark
**	AC-V25/V25A	AC POWER ADAPTOR	
***	NP-55	BATTERY PACK	
Note.			
**		MARK PARTS IS AVAILABLE FOR REPAIR SERVICE.	
***		MARK PARTS IS AVAILABLE AS AN OPTIONAL ACCESSORY.	

HARDWARE LIST

#1	7-627-553-47	PRECISION SCREW +P 2X4 TYPE 3	
----	--------------	-------------------------------	--


[illegible]

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT




CCD-TR42/TR70/TR72/TR80/TR430

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT




CCD-TR400/TR750

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT




CCD-TR82/TR550

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT




CCD-TRAP/TRETT/TRETT/TRETT

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT



CCD-TRAP/TRETT

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT



CCD-TRAP/TRETT